



CHCNAV i83Pro GNSS User Guide



Make your work more efficient

Table of Content

Table of Content	2
Preface	5
Copyright 2024	5
Trademarks	5
Safety Warnings	5
FCC Interference Statement	5
CE Interference Statement	5
1. Introduction	6
1.1 Safety Information	6
1.2 Regulations and Safety	6
1.3 Technical Support	6
1.4 Disclaimer	7
1.5 Your Comments	7
2. Getting Started with i83Pro	8
2.1 About the Receiver	8
2.2 Parts of the Receiver	8
2.2.1 Front Panel	8
2.2.2 Lower Housing	9
2.2.3 Receiver Ports	10
2.3 Batteries and Power	10
2.3.1 Batteries	10
2.3.2 The Internal Battery	10
2.3.3 Battery Safe	11
2.4 Inserting SIM Card	11
2.5 Product Basic Supply Accessories	12
2.5.1 Base Kit Basic Supply	12
2.5.2 Rover Kit Basic Supply	13
2.6 Connecting to an Office Computer	13
2.7 Connecting to a Controller	14
2.7.1 Connecting via Wi-Fi with Landstar Software	14
2.7.2 Connecting via Bluetooth with Landstar Software	15
2.8 Downloading Logged Data	16
2.8.1 FTP Download	16
2.8.2 Web Server Download	17
2.8.3 USB Download	18
3. Equipment Setup and Operation	20
3.1 Post-processing Base Station Setup	20
3.2 Real-Time Base Station Setup	21
3.2.1 Internal Cellular or UHF	21
3.2.2 External UHF	22
3.3 Real-Time Rover Station Setup	23

3.4 Working with the Tilt Compensation	24
3.4.1 Operation Steps for first IMU initialization	24
3.4.2 Notes of using tilt measurement	26
4. Configuring Through a Web Browser	27
4.1 Status Menu	28
4.1.1 Position Submenu	28
4.1.2 Activity Submenu	29
4.1.3 Google Map Submenu	29
4.2 Satellites Menu	30
4.2.1 Tracking Table Submenu	30
4.2.2 Tracking Info. Table Submenu	31
4.2.3 Tracking Skyplot Submenu	31
4.2.4 Satellite Activation Submenu	32
4.3 Receiver Configuration Menu	32
4.3.1 Description	33
4.3.2 Antenna Configuration Submenu	33
4.3.3 Reference Station Settings Submenu	33
4.3.4 Receiver Reset Submenu	35
4.3.5 Languages Submenu	35
4.3.6 User Management Submenu	35
4.3.7 HCPPT Settings	36
4.4 Data Recording Menu	36
4.4.1 Log Settings Submenu	36
4.4.2 FTP Push Settings Submenu	38
4.4.3 FTP Push Log Submenu	39
4.4.4 Data Download Submenu	39
4.5 IO Settings Menu	40
4.6 Network Setting Menu	45
4.6.1 Description Submenu	45
4.6.2 Mobile Network Setting Submenu	46
4.6.3 Email Alarm Submenu	46
4.6.4 HTTP Submenu	47
4.6.5 HTTPS Submenu	47
4.6.7 FTP Service Submenu	48
4.7 Module Setting Menu	48
4.7.1 Description Submenu	48
4.7.2 WiFi Submenu	49
4.7.3 Bluetooth Settings Submenu	49
4.7.4 Radio Settings Submenu	49
4.7.5 IMU Setting	49
4.8 Firmware Menu	50
4.8.1 Firmware Info Submenu	50

4.8.2 Hardware Version Submenu	50
4.8.3 Config File Submenu	51
4.8.4 System Log Download Submenu	51
4.8.5 User Log Submenu	51
4.8.6 Firmware Update Submenu	52
4.8.7 GNSS Board Upgrade Submenu	52
4.8.8 GNSS Registration Submenu	53

Preface

Copyright 2024

CHC | Shanghai Huace Navigation Technology Ltd. All rights reserved. The CHC are trademark of Shanghai Huace Navigation Technology Limited. All other trademarks are the property of their respective owners.

Trademarks

All product and brand names mentioned in this publication are trademarks of their respective holders.

Safety Warnings

The Global Positioning System (GPS) is operated by the U.S. Government, which is solely responsible for the accuracy and maintenance of the GPS network. Accuracy can also be affected by poor satellite geometry and obstructions, like buildings and heavy canopy.

FCC Interference Statement

This equipment has been designed to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules in the Portable Mode. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Interference Statement

Declaration of Conformity: Hereby, Shanghai Huace Navigation Technology Ltd. declares that this i83Pro is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the Declaration of conformity can be found at Shanghai Huace Navigation Technology Ltd.



1. Introduction

The i83Pro GNSS Receiver User Guide describes how to set up and use the CHC i83Pro GNSS receiver. In this manual, “the receiver” refers to the i83Pro GNSS receiver unless otherwise stated. Even if you have used other Global Navigation Satellite Systems (GNSS) products before, CHC recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to www.chcnave.com for an interactive look at CHC and GNSS.

1.1 Safety Information

An absence of specific alerts does not mean that there are no safety risks involved.

A Warning or Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.



WARNING - A Warning alerts you to a potential misused or wrong setting of the equipment.



CAUTION - A Caution alerts you to a possible risk of serious injury to your person and/or damage to the equipment.

1.2 Regulations and Safety

The receivers contain a built-in wireless modem for signal communication through Bluetooth® wireless technology or through external communication datalink. Regulations regarding the use of the wireless modem vary greatly from country to country. In some countries, the unit can be used without obtaining an end-user license. However, in some countries, the administrative permissions are required. For license information, consult your local dealer. Bluetooth® operates in license-free bands.

Before operating a i83Pro GNSS receiver, determine if authorization or a license to operate the unit is required in your country. It is the responsibility of the end-user to obtain an operator's permit or license for the receiver for the location or country of use.

This receiver is designed to withstand the rough environment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



CAUTION - Operating or storing the receiver outside the specified temperature range will cause irreversible damage.

1.3 Technical Support

If you have a problem and cannot find the information you need in this manual or CHC website (www.chcnave.com), contact your local CHC dealer from which you purchased the receiver(s).

If you need to contact CHC technical support, please contact us by email (support@chcnave.com) or Skype ([chc_support](https://www.skype.com)) or Knowledge Base (<https://support.chcnave.com/portal/en/kb>).

1.4 Disclaimer

Before using the receiver, please make sure that you have read and understood this User Guide, as well as the safety information. CHC holds no responsibility for the wrong operation by users and for the losses incurred by the wrong understanding about this User Guide. However, CHC reserves the rights to update and optimize the contents in this guide regularly. Please contact your local CHC dealer for new information.

1.5 Your Comments

Your feedback about this user guide will help us to improve it in future revision. Please email your comments to support@chcnav.com.

2. Getting Started with i83Pro

2.1 About the Receiver

The new CHCNAV i83Pro GNSS receiver offers integrated IMU-RTK technology to provide a robust and accurate GNSS positioning in any circumstances. Unlike the standard MEMS based GNSS receivers, the i83Pro GNSS IMU-RTK combines state-of-the-art GNSS RTK engine, calibration-free professional IMU sensor and advanced GNSS tracking capabilities. Survey projects are achieved with high productivity and reliability pushing the boundaries of conventional GNSS RTK survey.

The LCD panel enables user to check satellite-tracking status, internal battery status, Wi-Fi status, working mode, data logging status and basic receiver information. Bluetooth and Wi-Fi technology provides cable-free communication between the receiver and controller.

The receiver can be used as the part of an RTK GNSS system with CHC LansStar software. Moreover, user can download the GNSS data that recorded in the internal memory of receiver to a computer.

To configure the receiver for performing a wide variety of functions, you can use the web interface by connecting the receiver with PC or smartphone through Wi-Fi.

2.2 Parts of the Receiver

The operating controls are all located on the front panel. SIM card slot is on the backside. Serial ports and connectors are located on the bottom of the unit.

2.2.1 Front Panel

The following figure shows a front view of the receiver.



Name	Description
Correction LED (Yellow/Green)	•Indicates whether the receiver is transmitting/receiving differential data. •As a Base station: successfully transmitting differential data, flash yellow light. •As a Rover station: successfully receiving differential data from Base station will flash yellow light when it is single or float, flash green light when it is fixed.
Satellite LED (Blue)	•Shows the number of satellites that the receiver has tracked. •When the receiver is searching satellites, the blue LED flashes once every 5 seconds. •When the receiver has tracked N satellites, the blue LED will flash N times every 5 seconds.
Fn button (White)	•Move to next line of the menus or options. •Move to next character of the value that you want to make change. •Cancel the change you make on a function.
Power button (White)	•Works as a Power button: •Press and hold this button for 3 seconds to turn on or turn off the receiver. •Works as a Confirm button •Hold Fn button and press this button for 5 times continuously to reset the mainboard.

2.2.2 Lower Housing

The lower housing contains one SIM card slot, one TNC radio antenna connector, one communication and power port and one USB type C communication and power port.

IO serial communication
and power port

USB communication and
power port



TNC radio antenna
connector

SIM card slot

2.2.3 Receiver Ports

Port	Name	Description
	IO port	•This port is a 7-pin LEMO connector that supports RS-232 communications and external power input. •Users can use a 7-pin cable to transmit differential data to an external radio.
	USB port	•This port is a type-C USB connector that supports USB communications. •Users can use USB Cable supplied with the system to download the logged data to a computer.
	Radio antenna connector	•Connect a radio antenna to internal radio of the receiver. And this connector is not used if you are using an external radio.

2.3 Batteries and Power

2.3.1 Batteries

The receiver has an built-in non-removable Lithium-ion battery.

2.3.2 The Internal Battery

The rechargeable Lithium-ion battery is supplied partially charged.



WARNING – Charge and use the rechargeable Lithium-ion battery only in strict accordance with the instructions. Charging or using the battery in unauthorized equipment can cause an explosion or fire and can result in personal injury and/or equipment damage.

To prevent injury or damage:

- Do not charge or use the battery if it appears to be damaged or leaking.

- Charge the Lithium-ion battery only in a CHC product that is specified to charge it. Be sure to follow all instructions that are provided with the battery charger.
- Discontinue charging a battery that gives off extreme heat or a burning odor.
- Use the battery only in CHC equipment that is specified to use it.
- Use the battery only for its intended use and according to the instructions in the product documentation.

2.3.3 Battery Safe



WARNING – Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire and can result in personal injury and/or property damage.

To prevent injury or damage:

- Do not use or charge the battery if it appears to be damaged. Signs of damage include, but are not limited to discoloration, warping, and leaking battery fluid.
- Do not expose the battery to fire, high temperature, or direct sunlight.
- Do not immerse the battery in water.
- Do not use or store the battery inside a vehicle under hot weather condition.
- Do not drop or puncture the battery.
- Do not open the battery or short-circuit its contacts.



WARNING – Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. Battery fluid is corrosive and contact with it can result in personal injury and/or property damage.

To prevent injury or damage:

- If the battery leaks, avoid with the battery fluid.
- If battery fluid gets into your eyes, immediately rinses your eyes with clean water and seek medical attention. Please do not rub your eyes!
- If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.

2.4 Inserting SIM Card

Open the SIM card slot cover.

Insert the SIM card with the contacts facing upward, as indicated by the SIM card icon next to the SIM card slot.

Close the cover to prevent water immersion.

To eject the SIM card, slightly push it in to trigger the spring-loaded release mechanism.

Insert the SIM card with the contacts facing upward, as indicated by the SIM card icon next to the SIM card slot.

To eject the SIM card, slightly push it in to trigger the spring-loaded release mechanism.

Tip – The SIM card is provided by your cellular network service provider.

2.5 Product Basic Supply Accessories

2.5.1 Base Kit Basic Supply

Item	Picture
i83Pro GNSS Receiver	
UHF Bar Antenna (410-470 MHz)	
Power Adapter	
USB Type-C Cable	
H.I. Tape	
Extension pole	
Tribrach with optical plummet	
Auxiliary H.I. Tool	
Transport Hard Case	


2.5.2 Rover Kit Basic Supply

Item	Picture
i83Pro GNSS Receiver	
UHF Bar Antenna (410-470 MHz)	
Power Adapter	
USB Type-C Cable	
2M Range Polew/bag	
Auxiliary H.I. Tool	
Transport Hard Case	

2.6 Connecting to an Office Computer

The receiver can be connected to an office computer for serial data transfer or settings via a USB Type-C Cable. Before you connect to the office computer, ensure that the receiver is powered on by internal battery or external power.

The following figure shows how to connect to the computer for serial data transfer or settings:




2.7 Connecting to a Controller

2.7.1 Connecting via Wi-Fi with Landstar Software

Turn on the controller → run Landstar → go to **Config** main menu → tap **Connect**.

In the Connect screen, select CHC for the Manufacture field, i83Pro for Device Type field, **WIFI** for Connection Type field.




Tap the Wireless Lan icon on the right side to select the hot spot → Switch on the WiFi module by the top switch → select the target device in the list.



Tap **Connect** to link to the hot spot.


Tap the **Connect** button to build the connection.



2.7.2 Connecting via Bluetooth with Landstar Software


Turn on the controller → run Landstar → go to **Config** main menu → tap **Connect**.

In the Connect screen, select **CHC** for the Manufacture field, **i83Pro** for Device Type field, **Bluetooth** for Connection Type field.



Tap the **Bluetooth Manager** and turn on the **Bluetooth** function to search Bluetooth device around → select the target device in the list → Tap back button → select the target device in the Bluetooth manager list.

Tap the **Connect** button to build the connection.




2.8 Downloading Logged Data

Data logging involves the collection of GNSS measurement data over a period at a static point or points, and subsequent post-processing of the information to accurately compute baseline information. Data logging using receivers requires access to suitable GNSS post-processing software such as the CHC Geomatics Office (CGO) Software.


2.8.1 FTP Download

The procedures of downloading logged data through FTP are as follows:


- (1) Switch on the receiver, search its Wi-Fi in the computer and connect.
- (2) After the successful connection, open the file manager in the computer and input "ftp:\\192.168.1.1" in the address box.



- (3) Input user name and password, the default user name and password are "ftp".




(4) Double click the folder “repo_receiver SN” (take 3411955 as example), you will see 9 folders. The “push_log” folder is used to save the log files, and the other 8 folders represent different logging sessions and are used for store static data.




(5) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i83Pro system automatically and named by the date which is decided by GPS time when you start to log data.



(6) Select the destination folder and double click it, two folders named as different data format (hcn and rinex) will be displayed.



(7) Select the data format that you configured to save the static data, you will find the static raw data.



Notes: For hcn files, the name of the file is represented as XX XXXXDD D NN, where XXXXX X is

the SN of the receiver, D DD is day of year, and NN is the recording session.



WARNING – The static data will be saved in the first logging session, the “record_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

2.8.2 Web Server Download

The procedures of downloading logged data through web server refer to 5.4.4 Data Download Submenu.

2.8.3 USB Download

The procedures of downloading logged data in the receiver are as follows:


(1) Switch on the receiver and connect it with a computer by Type-C Cable. After the successful connection, a removable disk named as the Serial Number (SN) of the receiver will appear on the computer.



(2) Double click the removable disk and you will see the folder named as “repo”.




(3) Double click this folder, you will see 9 folders. The “push_log” folder is used to save the log files, and the other 8 folders represent different logging session and are used for store static data.




(4) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i83Pro system automatically and named by the date which is decide by GPS time when you start to log data.



(5) Select the destination folder and double click it, and then two folders named as different data format (hcn and rinex) will be displayed.



(6) Select the data format that you have configured to save the static data, you will find the static raw data.



Tip – For hcn files, the name of the file is represented as XXX XXXD DD NN, where XXX XXX is the SN of the receiver, D DD is day of year, and NN is the recording session.




WARNING – The static data will be saved in the first logging session, the “record_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

3. Equipment Setup and Operation

3.1 Post-processing Base Station Setup

For good performance, the following base station setup guidelines are recommended:

Components:



No.	Name
a	i83Pro GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	Aluminum tripod

Steps:

- 1)Put tripod in the target position, center and level it roughly.
- 2)Place and lock the tribrach in the tripod.
- 3)Screw the receiver onto the tribrach.
- 4)Center and level the receiver more precisely.
- 5)Connect the receiver to external battery by using external power cable if necessary.
- 6)Connect the receiver to external storage disk by using USB cable if necessary.
- 7)Turn on the receiver by pressing the power button for 3 s.
- 8)Measure the antenna height by using H.I. tape and auxiliary H.I. tool.

9) Press the function button to select Data to start recording static raw.

If work with a data controller:

1) Switch on the data controller and connect it to the receiver.


2) Use software to configure the receiver as static mode.

3.2 Real-Time Base Station Setup

3.2.1 Internal Cellular or UHF

For good rover operation, the following base station setup guidelines are recommended:

Components:



No.	Name
a	i83Pro GNSS receiver
b	UHF whip antenna
c	Extension pole (30 cm)
d	Tribrach adaptor
e	Tribrach w/ Opti
f	Aluminum tripod
g	Micro SIM card (12 mm x 15 mm)

Steps:

1) Put tripod in the target position, center and level it roughly.

2) Place and lock the tribrach in the tripod.

If work as a **celluar base station**, the SIM card need to be inserted

1) Screw the receiver onto the tribrach.

2) Center and level the receiver more precisely.

If work as a **UHF base station**, the UHF whip antenna need to be connected to the receiver.

- 1) Connect the receiver to external battery by using external power cable if necessary.
- 2) Connect the receiver to external storage disk by using USB cable if necessary.
- 3) Turn on the receiver by pressing the power button for 3 s.
- 4) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- 5) Switch on the data controller and connect it to the receiver.
- 6) Use software to configure the receiver as cellular base or UHF base mode.

3.2.2 External UHF

For good performance, the following base station setup guidelines are recommended:

Components:



No.	Name
a	i83Pro GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	GPS to datalink cable (power cable)
f	Aluminum tripod
h	Whip antenna
i	3 m cable for datalink antenna 3m

j	Pole mounting
k	External 410-470 datalink

Steps:


- 1) Put tripod in the target position, center and level it roughly.
- 2) Place and lock the tribrach in the tripod.
- 3) Screw the receiver onto the tribrach.
- 4) Center and level the receiver more precisely.
- 5) Connect the receiver to external datalink by using GPS to datalink cable.
- 6) Hang the external datalink on the tripod leg.
- 7) Connect the receiver to external battery by using external power cable if necessary.
- 8) Connect the receiver to external storage disk by using USB cable if necessary.
- 9) Turn on the receiver by pressing the power button for 3 s.
- 10) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- 11) Turn on the external datalink and configure it as need.

If work with a data controller:

- 1) Switch on the data controller and connect it to the receiver.
- 2) Use software to configure the receiver as cellular base or UHF base mode.

3.3 Real-Time Rover Station Setup

For good performance, the following rover station setup guidelines are recommended:

Components:

Name	
a	i83Pro GNSS receiver
b	whip antenna
c	2M range pole w/bag
d	Micro SIM card (12 mm x 15 mm)

Steps:

Keep the receiver fully charged.

If work as a **cellular rover station**, the SIM card need to be inserted.

Screw the receiver onto the pole.

If work as a **UHF rover station**, the UHF whip antenna need to be connected to the receiver.

- 1) Turn on the receiver by pressing the power button for 3 s.
- 2) Switch on the data controller and connect it to the receiver.
- 3) Use software to configure the receiver as cellular rover or UHF rover mode.
- 4) Center and level the receiver more precisely.
- 5) Use software to start survey.



3.4 Working with the Tilt Compensation

3.4.1 Operation Steps for first IMU initialization

1. Open Landstar8-> Tap Survey-> Tap  to activate tilt measurement.



2. Hold the pole vertical for a while and shake according to the procedures in the interface to do initialization.



3. This icon  will appear when the initialization is successful.



4. Enter the Name and Antenna, then tap , point will be collected and store to Points automatically.

5. When this icon  appears, the text will show "Tilt is not available, please measure in alignment" at the bottom of interface.



6. Tap to close tilt compensation.

3.4.2 Notes of using tilt measurement

1. At the beginning of initialization, the pole height of the instrument should be the same as that antenna height in the software.

2. In the process of tilt measurement, if the controller shows that “Tilt is not available, please measure in alignment” (red), please shake RTK slightly from left to right or back to front until the reminder disappears.

3. The controller will prompt “Tilt is not available, please measure in alignment” when the receiver is stationary over 30 seconds or the pole hit the ground toughly.

4. The pole cannot be shaken when point is collected.

5. Initialization is required:

- when the RTK is turned on every time;
- when IMU module is turned on every time;
- when receiver drops at working;
- when the pole is tilted more than 65 degree;
- when the receiver is stationary more than 10 minutes;
- when the RTK rotates too fast on the matching pole (2 rounds per second);
- when the pole hit the ground toughly.

4. Configuring Through a Web Browser

Supported browsers:


➤ Google Chrome

➤ Microsoft Internet Explorer version 10, or higher To connect to the receiver through a web browser:

1. Turn on the Wi-Fi of the receiver.

2. Search the wireless network named as GNSS-XXXXXXX (the SN of your receiver) on your computer, and then establish the connection.

3. After the successful connection between your computer and the receiver, enter the IP address (192.168.1.1) of the receiver into the address bar of the web browser on your computer:



4. The web browser prompts you to enter a login account and password:



The default login account for the receiver is:

➤ Login Account: admin

➤ Password: password

Note – Tick remember me option, and then the browser will remember the Login Account and Password you entered.

5. Once you log in, the web page appears as follows:




This web page shows the configuration menus on the left of the browser window, and the setting on the right. Each configuration menu contains the related submenus to configure the receiver and monitor receiver performance.

This chapter describes each configuration menu.

To view the web page in another language, select the corresponding language name from the drop down list on the upper right corner of the web page.

Currently, seven languages are available:



4.1 Status Menu

This menu provides a quick link to review the receiver's position information, satellites tracked, runtime, current data log status, current outputs, available memory, and more.

4.1.1 Position Submenu

This page shows the relevant position information about the receiver's position solution which including the position, DOP values, satellites used and tracked, and the receiver clock information.

Position
Latitude: 31°9'57.36875055"(North)
Longitude: 121°17'16.97717278"(East)
Height: 35.999
Type: Single

DOP
PDOP: 1.172767
HDOP: 0.616858
VDOP: 0.997431
TDOP: 0.744274

Satellite Used: 30Total
GPS(7): 1,7,8,9,21,27,30
GLONASS(5): 9,15,18,19,20
BDS(10): 1,3,7,9,10,26,35,40,44,59
GALILEO(6): 1,12,24,26,31,33
SBAS(0):
QZSS(2): 194,195

Satellites Tracked: 45Total
GPS(8): 1,7,8,9,16,21,27,30
GLONASS(5): 9,15,18,19,20
BDS(23): 1,2,3,4,5,6,7,8,9,10,12,16,24,26,29,35,38,39,40,44,45,59,60
GALILEO(7): 1,9,12,24,26,31,33
SBAS(0):
QZSS(2): 194,195

Receiver Clock
GPS Week: 2194
GPS Seconds: 379271

4.1.2 Activity Submenu

Lists several important items to help you understand how the receiver is being used and its current operating condition. Items include the identities of currently tracked satellites, internal and external storage usage rate, how long the receiver has been operational, state of the internal battery, power source state, files being logged, and data streams being output. With this information, it is easy to tell exactly what functions the receiver is performing.

Status

- Position
- Activity**
- Google Map

Activity


Satellites Track: 46Total
GPS(8): 1,7,8,9,16,21,27,30
GLONASS(5): 9,15,18,19,20
BDS(23): 1,2,3,4,5,6,7,8,9,10,12,16,24,26,29,35,38,39,40,44,45,59,60
GALILEO(7): 1,9,12,24,26,31,33
SBAS(0):
QZSS(3): 193,194,195

Activity Status
Current Time: 2022-01-27 09:21:39 (UTC)
Operation Duration: 00-00-00 01:20:50
Internal Storage: 368MB/7595MB
External Storage: Disconnected
External Power: Disconnected
Battery:

	Type	Description	Output
1	RTK Client	211.144.118.5 2192	---
2	TCP/UDP_Client1/NTRIP Server1	192.168.3.18.9900	---
3	TCP/UDP_Client2/NTRIP Server2	192.168.3.18.9901	---
4	TCP/UDP_Client3/NTRIP Server3	192.168.3.18.9902	---
5	TCP/UDP_Client4/NTRIP Server4	192.168.3.18.9903	---
6	TCP/UDP_Client5/NTRIP Server5	192.168.3.18.9904	---
7	TCP/UDP_Client6/NTRIP Server6	192.168.3.18.9905	---
8	TCP Server/NTRIP Caster1	9901	---
9	TCP Server/NTRIP Caster2	9902	---
10	TCP Server/NTRIP Caster3	9903	---
11	TCP Server/NTRIP Caster4	9904	---
12	Serial Port	9600	---
13	Bluetooth	ONS9-3200193	---
14	Radio	460.0500MHz	---

4.1.3 Google Map Submenu

Tap this submenu to show the location of the receiver on Google map.



4.2 Satellites Menu

Use the Satellites menu to view satellite tracking details and enable/disable GPS, GLONASS, BDS and Galileo constellations. These menus include tabular and graphical displays to provide all required information on satellite tracking status.



4.2.1 Tracking Table Submenu

Provides the status of satellites tracked in general, such as the satellite ID, satellite type, attitude angle, azimuth angle, L1 SNR, L2 SNR, L5 SNR and enable/disable status of each one.

Tracking Table									
All ☒ GPS ☐ GLONASS ☐ BDS ☐ GALILEO ☐ SBAS ☐ QZSS ☐									
SV	Type	Elevation Angle	Azimuth Angle	L1 SNR	L2 SNR	L5 SNR	B1C SNR	B2A SNR	Enabled
3	GPS	21	282	40.000	40.850	30.880	0.000	0.000	Yes
4	GPS	15	318	40.030	36.800	27.800	0.000	0.000	Yes
16	GPS	45	242	44.820	39.450	0.000	0.000	0.000	Yes
26	GPS	74	318	48.720	43.430	36.160	0.000	0.000	Yes
27	GPS	12	188	34.690	35.890	26.250	0.000	0.000	Yes
29	GPS	23	50	41.370	36.580	0.000	0.000	0.000	Yes
31	GPS	55	44	45.450	41.970	0.000	0.000	0.000	Yes
32	GPS	35	149	42.840	38.490	30.140	0.000	0.000	Yes
1	GLONASS	52	211	41.760	46.170	0.000	0.000	0.000	Yes
2	GLONASS	40	313	47.100	46.320	0.000	0.000	0.000	Yes
8	GLONASS	14	174	36.530	43.730	0.000	0.000	0.000	Yes
12	GLONASS	41	300	45.760	49.200	0.000	0.000	0.000	Yes
21	GLONASS	22	94	37.800	44.160	0.000	0.000	0.000	Yes
1	BDS	45	140	39.830	42.710	44.970	0.000	0.000	No
2	BDS	35	235	35.420	43.410	42.250	0.000	0.000	No
3	BDS	50	199	40.270	44.410	43.470	0.000	0.000	Yes


4.2.2 Tracking Info. Table Submenu

The following figure is an example of satellite track diagram page. Users can determine the satellite types and the corresponding SNR of L-band carriers to be displayed in any combination.



4.2.3 Tracking Skyplot Submenu

The following figure is an example of Skyplot page.




4.2.4 Satellite Activation Submenu

Use this menu to enable or disable satellites.

Satellite Activation			
GPS GLONASS BDS GALILEO QZSS SBAS			
Enable All Disable All			
Satellite Id	Enable	Satellite Id	Enable
1	☒	2	☒
3	☒	4	☒
5	☒	6	☒
7	☒	8	☒
9	☒	10	☒
11	☒	12	☒
13	☒	14	☒
15	☒	16	☒
17	☒	18	☒
19	☒	20	☒
21	☒	22	☒
23	☒	24	☒
25	☒	26	☒
27	☒	28	☒

4.3 Receiver Configuration Menu

Use this menu to configure settings such as the antenna type and height, elevation mask and PDOP setting, the reference station coordinates, receiver resetting and web interface language:



4.3.1 Description

Receiver Info

- Antenna Type: CHCI83Pro
- Antenna SN: 3704054
- Measure Way: Antenna Phase Center
- Antenna Height: 2.0000(Meter)
- Elevation Mask: 10
- PDOP Mask: 6

Reference Station Info

- Reference Station Mode: Auto Rover
- Reference Latitude: 0°0'0.00000000°(South)
- Reference Longitude: 0°0'0.00000000°(West)
- Reference Height: 0.0000

This submenu shows the receiver information and reference station information, including antenna related information, elevation mask angle, reference station work mode and position, etc.

4.3.2 Antenna Configuration Submenu

Use this screen to configure all the items related to the GNSS antenna. You must enter the correct values for all antenna-related fields, because the choices you make affect the accuracy for logged data and broadcast correction data significantly:

Antenna Configuration

- Measure Way: Antenna Phase Center
- Antenna manufacturer: CHCNav
- Antenna Type: CHCI83Pro
- Antenna SN: 3704054
- Antenna Height: 2.0000 (Meter)
- Elevation Mask: 10
- PDOP Mask: 6

Save

4.3.3 Reference Station Settings Submenu

Reference Station Settings

Reference Station Mode: Auto Rover

Save

Sample for Average

Positioning Constraint: ☒ Single Solution Coordinates ☐ Fixed Solution Coordinates

Sampling Amount: 300 9.3%

Start Stop

Use this screen to configure settings such as the station coordinates and the broadcast station identifiers. You must enter accurate information in these fields, as this data affects the accuracy of logged data files and broadcast correction data significantly:

For Reference Station Mode, there are three modes available:

1.Auto Rover: The receiver will serve as a rover after this mode is enabled, and then receive correction data through the working mode set last time.

2.Auto Base: The receiver will serve as a base after this mode is enabled, and then broadcast correction data based on coordinate inputted by user or obtained through autonomous positioning automatically.

3.Manual Base: The receiver will serve neither as a base nor a rover after this mode is enabled. Users need to configure the receiver manually.

For Reference Latitude and Reference Longitude:

There are mainly three methods to enter the reference coordinates and shown as follows:

1.Acquire Current Position: Click this button to acquire current position obtained through autonomous positioning automatically.

2.Manual Input: Manually input the coordinate of a control point.

3.From CORS: After the receiver logging in CORS, the software can record the coordinate of current position based on fix solution.

For **Sample for Average**:

Users can determine the positioning limit and sampling amount. The positioning limit falls

into two types:

1.Single Solution Coordinates: Collect the coordinates of receiver obtained through autonomous positioning.


2.Fixed Solution Coordinates: Only collect coordinates of receiver with a fixed solution.

After the configuration of positioning limit and sampling amount, click  to carry out sampling and averaging → the progress bar will show the progress → the result will be served as the coordinate of current position.

If users need to save the changes, please tap  button.

4.3.4 Receiver Reset Submenu

Use this screen to completely or partially reset the receiver:



The screenshot shows the 'Receiver Reset' submenu with four options, each with a 'Confirm' button:

- Reboot Receiver: 
- Return to Factory Defaults: 
- Clear Satellite Data: 
- Turn Off Receiver: 

4.3.5 Languages Submenu


Use this screen to select the web interface language:



The screenshot shows the 'Language' submenu with a dropdown menu and a 'Confirm' button. The dropdown menu is open, showing the following options:

- English (selected)
- 中文
- Русский
- Español
- Português
- Français
- 日本語

4.3.6 User Management Submenu



The screenshot shows the 'User Management' submenu with a table of users and a toolbar with icons for Add, Save, Delete, and Modify Anti-theft password.

ID	User Name	Password
1	admin	*****
2	admin1	*****
3	admin2	*****

4.3.7 HCPPP Settings


HCPPP Settings ×

HCPPP Range: 5min

 Save

4.4 Data Recording Menu

Use the Data Logging menu to set up the receiver to log static GNSS data and to view the logging settings. You can configure settings such as observable rate, recording rate, continuous logging limit, and whether to auto delete old files when memory is low. This menu also provides the controls for the FTP push feature:



4.4.1 Log Settings Submenu

Here shows the data logging status, including internal and external storage usage and data logging status of each session. Also, users can configure the data logging settings for each session, including recording name, store location, storage limit, store formats, start time, etc.

Log Settings ×

Store Info

	Position	Total Storage	Storage Available
1	Internal Storage	28786MB	27904MB
2	External Storage	0MB	0MB

Attention: Total assigned storage size of 8 threads should be less than 27GB. It will stop recording when the storage is full.

Record Info

								 Clear All
Recording Numbe	File Name	Activated	Log Status	Setting Parameter		Switch		Clear Data
1	record1	No	Not Recording	Modify	Detail	ON	OFF	Clear
2	record2	No	Not Recording	Modify	Detail	ON	OFF	Clear
3	record3	No	Not Recording	Modify	Detail	ON	OFF	Clear
4	record4	No	Not Recording	Modify	Detail	ON	OFF	Clear
5	record5	No	Not Recording	Modify	Detail	ON	OFF	Clear
6	record6	No	Not Recording	Modify	Detail	ON	OFF	Clear
7	record7	No	Not Recording	Modify	Detail	ON	OFF	Clear
8	record8	No	Not Recording	Modify	Detail	ON	OFF	Clear

To edit the settings of each session, click the **Modify** button to the right of the required session, and then the Recording Edit screen appears:

The 'Recording Edit' window displays the following configuration options:

- Auto Record: ☐ Yes ☒ No
- Sample Interval: 1Hz (dropdown)
- Elevation Mask: 10 (°) (text input)
- Duration Time: 1440 (Minute) (text input)
- Site Name: 9999690 (text input)
- Antenna Height: 0.0000 (text input)
- Measure Way: Antenna Phase Ce (dropdown)
- Storage Format: HCN (dropdown)
- RINEX Version: OFF (dropdown)
- Advanced (button)
- Save (green button)
- Back (red button)

Click advanced to see more settings.

The 'Recording Edit' window displays the following advanced configuration options:

- Start Date: ☐ Yes ☒ No
- Apply Time: ☐ Yes ☒ No
- Integral Point Store: ☐ Yes ☒ No
- Circulating Memory: ☒ Yes ☐ No
the data overwritten first file after storage space is full
- Single Observations: ☒ Yes ☐ No
Turn on to record a single observation. Turn off to record repeated observations.
- Store Location: Internal Storage (dropdown)
- Assigned Storage: 6000 (MB) (text input)
- Observer: CHC (text input)
- Observe Agency: CHC (text input)
- FTP Push: ☒ Close
☐ 1:ftp server 1
☐ 2:ftp server 2
☐ 3:ftp server 3
- Save (green button)
- Back (red button)

In this screen, you can configure all the data logging parameters, and determine whether the recording files will be affected by the FTP Push. The parameters are mainly as follows:

- **Auto Record:** on or off.
- **Sample Interval:** Select the observable rate from the dropdown list.
- **Elevation Mask:** Enter the elevation mask.
- **Duration Time:** Set the duration of data logging.
- **Site Name:** Enter the name of the site.
- **Antenna Height:** the measured height value.
- **Measure way:** Antenna Phase Center, Vertical Height, Slant Height
- **Storage Format:** Select the format of the data store.
- **RINEX Version:** OFF, 3.02, 2.11
- **Start Date:** Select **Yes** or **No** option to determine whether to auto record start date.
- **Apply Time:** Select **Yes** or **No** option to determine whether to auto record apply time.

- **Integral Point Store:** Select **Yes** or **No** option to determine whether to allow receiver to save data every hour.
- **Circulating Memory:** Select **Yes** or **No** option to determine whether to auto delete old files if the storage space is full.
- **Repeat Observations:** Select **Yes** or **No** option to determine whether to turn on to record a single observation.
- **Store Location:** Internal Storage, External Storage.
- **Assigned Storage:** The assigned memory size of current thread(for example, Record 1) is 10000MB
- **Observer:** Enter the name of observer.
- **Observer Agency:** Enter the name of observer agency.
- **FTP Push:** Decide whether to push the stored files to the FTP server of your choice.

Tap  button to save the settings and back to the Log Settings screen. Also, users can click  to abandon the changed settings and back to Log Settings screen.

Note – To modify data logging parameters, make sure the data logging session is switched off.

To switch **on** or **off ANY** data logging session, tap the **ON** or **OFF** button on the right of the required session.

To delete the recorded files of **ANY** data logging session, tap the Clear button on the right of the required session.

To delete the recorded files of **ALL** data logging sessions, tap the Clear **ALL Accounts** button.

4.4.2 FTP Push Settings Submenu

Use this screen to configure the receiver to push stored files to the FTP server of your choice. Only files that are configured to use FTP push are transmitted.

Record Info				
Server ID	Server IP	Remote Directory	Server Description	Modify
1	192.168.3.72	/repo/first	ftp server 1	
2	192.168.3.72	/repo/second	ftp server 2	
3	192.168.3.72	/repo/third	ftp server 3	

Tap **Modify** button on the right of the required FTP server and the FTP Push Settings screen appears:

FTP Push Settings

Server IP: 192.168.3.72

Port: 21

Remote Directory: /repo/first

Local directory: /mnt/repo_3225804

Server Description: ftp server 1

User Name: ftpuser1

Password:

4.4.3 FTP Push Log Submenu

Shows the related information about the recorded files that be pushed. And users can tap **Clear Ftp Send Log button** in the upper right corner to clear the log of FTP Push operations.

FTP Push Log

Record Info

Server ID	Push File	File Size	Push Time	Push Successful Or Not
Page 1 of 1				

Displaying 0 to 0 of 0 items

4.4.4 Data Download Submenu

In this submenu, users can download the data files that recorded in the internal storage through the internal FTP site. Please note that Chrome, EDGE and Firefox version higher than year 2020 version remove the FTP support through the browser.

1. Click this submenu, and then the log on dialogue box will prompt you to enter a user name and password:

Sign in

ftp://192.168.1.1

Your connection to this site is not private

Username:

Password:

The default logon account for the internal FTP site is:

- User name: ftp
- Password: ftp

2. Click the directory named as “repo” to view and download the files currently stored on the

receiver:

Index of /		
Name	Size	Date Modified
 System Volume Information/		8/9/19, 10:28:00 PM
 repo_3225804/		7/16/19, 1:17:00 PM

3.To find the file need to be downloaded, click the name of data logging session → the date of file that be recorded → the format of the file → the name of the target file.

Index of /repo_3225804/		
 [parent directory]		
Name	Size	Date Modified
 push_log/		7/16/19, 1:17:00 PM
 record_1/		8/15/19, 10:22:00 AM
 record_2/		7/16/19, 1:17:00 PM
 record_3/		7/16/19, 1:17:00 PM
 record_4/		7/16/19, 1:17:00 PM
 record_5/		7/16/19, 1:17:00 PM
 record_6/		7/16/19, 1:17:00 PM
 record_7/		7/16/19, 1:17:00 PM
 record_8/		7/16/19, 1:17:00 PM

4.To download a file, left click the name of the target file → download the file according to the prompts.

4.5 IO Settings Menu



Use the IO Settings menu to set up all receiver outputs and inputs. The receiver can output CMR, RTCM, Raw data, Ephemeris data, GPGLGA, GPGLSV, on TCP/IP, UDP, serial port, or Bluetooth ports.

The following figure shows an example of the screen that appears when you select this submenu.


I/O Settings x						
	Type	Description	Output	Connection Status	Modify	
1	RTK Client	211.144.118.5:2102	---	Unconnected	Connect	Disconnecting
2	TCP/UDP_Client1/NTRIP Serv	192.168.3.18:9900	---	Unconnected	Connect	Disconnecting
3	TCP/UDP_Client2/NTRIP Serv	192.168.3.18:9901	---	Unconnected	Connect	Disconnecting
4	TCP/UDP_Client3/NTRIP Serv	192.168.3.18:9902	---	Unconnected	Connect	Disconnecting
5	TCP/UDP_Client4/NTRIP Serv	192.168.3.18:9903	---	Unconnected	Connect	Disconnecting
6	TCP/UDP_Client5/NTRIP Serv	192.168.3.18:9904	---	Unconnected	Connect	Disconnecting
7	TCP/UDP_Client6/NTRIP Serv	192.168.3.18:9905	---	Unconnected	Connect	Disconnecting
8	TCP Server/NTRIP Caster1	9901	---	Closed	Connect	Disconnecting
9	TCP Server/NTRIP Caster2	9902	---	Closed	Connect	Disconnecting
10	TCP Server/NTRIP Caster3	9903	---	Closed	Connect	Disconnecting
11	TCP Server/NTRIP Caster4	9904	---	Closed	Connect	Disconnecting
12	Serial Port	115200	---	---	Settings	
13	Bluetooth	GNSS-3411955	GPBGA:5s,	---	Settings	
14	Radio	462.5500MHz	---	---	Settings	

In this submenu, users can configure 6 types of input and output settings.

1. RTK Client

After configuring the settings of RTK client, users can log on CORS or APIS. Tap the Connect button to the right → the IO Settings screen will appear → choose one of the connection protocols among the NTRIP, APIS_BASE and APIS_ROVER → configure the related parameters → click  to log on CORS or APIS.

- Connection Protocol: NTRIP



RTK Client

Connection Protocol: NTRIP

Server IP: 211.144.118.5

Port: 2102


Mount Point: asd 

User Name: zc

Password: zc

- Connection Protocol: APIS_BASE



RTK Client

Connection Protocol: APIS_BASE

Server IP: 111.111.111.1

Port: 9901

Differential Data: OFF

- Connection Protocol: APIS_ROVER

RTK Client

Connection Protocol: APIS_ROVER

Server IP: 210.14.66.58

Port: 9902

Base ID: 1019923

Confirm Back

- Connection Protocol: TCP

RTK Client

Connection Protocol: TCP

Server IP: 201.255.122.215

Port: 9902

Confirm Back

2.TCP/UDP_Client/NTRIP Server

Tap the Connect button on the right of required TCP/UDP Client → the IO Settings screen will appear → select the connection protocol from TCP, UDP, NTRIP1.0 and NTRIP2.0 → enter the IP and Port of the target server → configure messages that you want to output to the target server → click **Confirm** to save and complete the connection.

- Connection Protocol: TCP

TCP/UDP Client

Auto connect: ☐

Server IP: 192.168.3.18

Port: 9902

Connection Protocol: TCP

Differential Data: OFF

Raw Data: OFF

HRC Data: OFF

GPGLA: OFF

GPGLC: OFF

GPGLT: OFF

GPGLA: OFF

Retransmit: RTK OFF

HCPPP Data: OFF

GPBSV: OFF

GPZDA: OFF

GPVTG: OFF

Confirm Back

- Connection Protocol: UDP

TCP/UDP Client

Auto connect: ☐

Server IP: 192.168.3.18

Port: 9902

Connection Protocol: UDP

Differential Data: OFF

Raw Data: OFF

HRC Data: OFF

GPGLA: OFF

GPGLC: OFF

GPGLT: OFF

GPGLA: OFF

Retransmit: RTK OFF

HCPPP Data: OFF

GPBSV: OFF

GPZDA: OFF

GPVTG: OFF

Confirm Back

- Connection Protocol: NTRIP1.0

TCP/UDP Client

Auto connect: ☐ Connection Protocol: NTRIP1.0

Server IP: 192.168.3.18 Port: 9900

Password: ***** Differential Data: OFF

Mount Point: HCPPP Data: OFF

Raw Data: OFF

HRC Data: OFF

GPSSA: OFF

GPSSV: OFF

GPBMC: OFF

GPZDA: OFF

GPST: OFF

GPVTG: OFF

GPSSA: OFF

Retransmit: RTK OFF

➤ Connection Protocol: NTRIP2.0

TCP/UDP Client

Auto connect: ☐ Connection Protocol: NTRIP2.0

Server IP: 192.168.3.18 User Name: link_a

Password: ***** Port: 9900

Mount Point: Differential Data: OFF

Raw Data: OFF HCPPP Data: OFF

HRC Data: OFF

GPSSA: OFF

GPSSV: OFF

GPBMC: OFF

GPZDA: OFF

GPST: OFF

GPVTG: OFF

GPSSA: OFF

Retransmit: RTK OFF

3.TCP Server/NTRIP Caster

Tap the Connect button to the right of required TCP Server/NTRIP Caster→ the IO Settings screen will appear → select one of the connection protocols between NTRIP and TCP → configure the other related parameters → click  to save the settings and open the server.

➤ Connection Protocol: TCP

TCP Server/NTRIP Caster

Auto connect: ☐ Connection Protocol: TCP

Port: 9901

Differential Data: OFF

HCPPP Data: OFF

GPSSA: OFF

GPSSV: OFF

GPBMC: OFF

GPZDA: OFF


GPST: OFF

GPVTG: OFF

GPSSA: OFF


Retransmit: RTK OFF

➤ Connection Protocol: NTRIP




4. Serial Port

Tap the Settings button on the right of Serial Port → the Serial Port Setup screen will appear → select Baud Rate used to transmit data → configure the messages that you want to output through the serial port → click  Confirm to save the settings and start to transmit.



5. Bluetooth


Tap the Settings button to the right of Bluetooth → the Bluetooth Set screen will appear → configure the messages that you want to transmit through Bluetooth → click  Confirm to save the settings and start to transmit.



6. Radio


Tap the Settings button to the right of Radio → the Radio Settings screen will appear →

select the format of differential data that you want to transmit through radio from the dropdown list → click  Confirm to save the settings and start to transmit.



4.6 Network Setting Menu

Use this menu to view network information, configure the receiver's mobile network, set email alert for specific situation, configure HTTP or HTTPS port, and the username and password of internal FTP site:



4.6.1 Description Submenu

Use this submenu to check the information of network setting.

Description x

Network Info

Power Status: ON

Network Mode: 2G/3G/4G Auto

Connection Protocol: CHINA MOBILE

Signal Strength: -71(dBm)

SIM Status: SIM Card Ok

Dialing Status: Offline

IMEI: 861529049455435

PhoneNumber: 1440033974571

4.6.2 Mobile Network Setting Submenu

Use this submenu to configure GPRS model, network module and modify dialing status.

Mobile Network Setting x

Network Settings

GPRS Model Status: ON ON OFF

Auto Start: ☒ Yes ☐ No

2G Only

3G Only

Network Mode: ☐ 2G/3G Auto

4G Only

☒ 2G/3G/4G Auto

SIM Type: E-SIM Switch

Dialing Status: Offline Dial Break

Auto Connect: ☐ Yes ☒ No

APN: 3gnet

Dialing String: *99#

User Name: card

Password: ****

Save

4.6.3 Email Alarm Submenu

Use this submenu to choose which situation of receiver will be alerted and input the email address.

Email Alarm x

TO

Email Address 1:

Email Address 2:

Email Address 3:

 Save

From

Account:

Password:

Server Address:

 Save

Email Alert

- ☐ Receiver is powered on
- ☐ External power is off
- ☐ Battery level is low
- ☐ Ftp push is failed
- ☐ Reciever(license) will be expired in 7 days.

 Save

4.6.4 HTTP Submenu

Use this submenu to configure HTTP port.

HTTP x

HTTP Port:

 Save

4.6.5 HTTPS Submenu

Use this submenu to configure HTTPS port.

HTTPS x

HTTPS

Enable HTTPS: ☒ Yes ☐ No

HTTPS Port:

 Save


4.6.7 FTP Service Submenu

Use this submenu to configure the user name and password of internal FTP site.

The screenshot shows the 'FTP Service' configuration window. It has a title bar 'FTP Service x'. Inside, there's a teal header 'FTP Service'. Below it, there are two input fields: 'User Name:' with the value 'ftp' and 'Password:' with three dots. At the bottom right is a teal 'Save' button with a floppy disk icon.

4.7 Module Setting Menu

Use this menu to check module information, configure WiFi, bluetooth, radio related settings, turn on/off static voice of buzzer, and setting IMU:



4.7.1 Description Submenu

Use this submenu to check the information of WiFi module, bluetooth module and radio module.

The screenshot shows the 'Description' submenu. It has a title bar 'Description x'. Below it, there are two panels. The left panel is titled 'Wi-Fi Information' and contains the following details: Power Status: ON, Wifi Mode: Access Point, MAC: 82:5b:10:07:ec:2b, Access Point Details, and SSID: GNSS-9999690. The right panel is titled 'Radio Information' and contains the following details: Radio Type: Integ, Radio Power: 1W, OTA Baud Rate: 9600, Radio Frequency: 443.000000MHz, Radio Protocol: Transparent, Radio Frequency Channel: Full Range, and Frequency Range: 410MHz---470MHz.

4.7.2 WiFi Submenu

Use this submenu to turn on/off WiFi function and modify password.

WiFi x

WiFi

Power Status: ON

SSID:

Encryption Type:

Network frequency bands:

4.7.3 Bluetooth Settings Submenu

Use this submenu to turn on/off bluetooth function and modify PIN number.

Bluetooth Settings x

Bluetooth Settings

Local Name: GNSS-9999690

MAC Address: 81:5B:10:07:EC:2B

PIN:

4.7.4 Radio Settings Submenu

Use this submenu to turn on/off radio function and configure radio parameters.

Radio Settings x

Radio Settings

Radio Status: OFF

Auto Start: ☐ Yes ☒ No

Radio Protocol:

Channel Bandwidth: (kHz)

OTA Baud Rate:

Radio Frequency: (410MHz---470MHz)

4.7.5 IMU Setting

Use this submenu to turn on/off IMU function and set antenna height.

4.8 Firmware Menu

Use this menu to check the current firmware information, download the system log, update the receiver firmware, download or update the configuration file and register the receiver, and more:


4.8.1 Firmware Info Submenu

Use this submenu to check the current firmware information. The following figure shows an example of the firmware information.

4.8.2 Hardware Version Submenu

Use this submenu to check the hardware information, including main board version and core

board version:




The screenshot shows a web browser interface with a tab labeled "Hardware Version x". The content area displays the following information:

Main Board:	1.1.0
Core Board:	1.1.0
PN:	A19305290907070002
Board Firmware Version Number:	5.53

4.8.3 Config File Submenu

Use this submenu to update Configuration File.




The screenshot shows a web browser interface with a tab labeled "Config File x". The content area contains the following options:

- Download Configuration File : [Download](#)
- Update Configuration File: [Browse](#)
- [Confirm](#)

4.8.4 System Log Download Submenu

Use this submenu to download the system log of the receiver.




The screenshot shows a web browser interface with a tab labeled "System Log x". The content area contains the following options:

- System Log Type: [Firmware Log](#)
- [Download](#)


4.8.5 User Log Submenu

Use this submenu to download the user log. Tap Download to download current user log; Tick items that you want to see on the user log and tap confirm button to confirm selected user log.



4.8.6 Firmware Update Submenu

Use this submenu to load new firmware to the receiver across the network. Tap the Browse button to locate the upgrade file → tap Confirm button to confirm the selected upgrading file and start upgrading.




Notes

It may take about 3 or 4 minutes to complete the firmware upgrading. Do not touch the power button or unplug the power until the upgrading process finishes, or damage will be caused to the receiver.

The receiver will restart after the firmware upgrading is done, so users need to reconnect the receiver with your computer via Wi-Fi, and then log-in the receiver through a web browser to continue the configuration.

4.8.7 GNSS Board Upgrade Submenu

Use this submenu to upgrade GNSS Board. Use this submenu to load new board to the receiver across the network. Tap the Browse button to locate the upgrade file → tap Confirm button to confirm the selected upgrading file and start upgrading.




GNSS Board Upgrade x

Upgrade File: 



4.8.8 GNSS Registration Submenu

Use this submenu to register the receiver. Paste or enter the registration code to the Registration Code field → tap Registration button to complete the registration.



GNSS Registration x

Serial Number:

Registration Limit:

Registration Code:

Registration deadline for external account access:

 Registration



CHC Navigation

Shanghai Huace Navigation Technology Ltd.

CHCNAV | Smart Navigation & Geo-Spatial Technology Park,
577 Songying Road, 201703, Shanghai, China

Email: sales@chcnave.com | support@chcnave.com


Skype: chc_support

Website: www.chcnave.com

This document is intended for general information purposes only. It does not consider the reader's specific circumstances and environmental constraints of use of GNSS.

Make your work more efficient

Detailed external antenna info		
Manufacturer	:	Shanghai Huace Navigation Technology Ltd.
Antenna type	:	Portable omnidirectional antenna
Model	:	QT450GSB-T
Antenna gain	:	UHF, max gain 2 dBi



FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 30cm between the radiator & your body.