

BEACONBUOY/GLOWBUOY

REMOTE CONTROL ON/OFF
KEY FOB TRANSMITTER

USER MANUAL:

Congratulations, your purchase of the KL Industries Remote Control On/Off Key Fob Transmitter for the BeaconBuoy and/or GlowBuoy will add tremendous functionality and convenience to your light for years to come.

Instructions:

- 1) Remove the three Screws located on the back of the device and put aside in a safe place.
- 2) Remove the Key Fob Transmitter Back Plate and Gasket.
- 3) Insert battery provided, making sure that the polarity is correct.
- 4) Test the Key Fob Transmitter by turning the switch on your GlowBuoy or BeaconBuoy to the 'On' position and activating the 'Off' switch on the Key Fob to make sure that the battery has been properly inserted and that the light then turns off.
- 5) With proper operation confirmed, replace the Gasket, Back Plate and three Screws making sure that the Screws are snug, but not over tightened.

Troubleshooting and Repair:

- 1) Key Fob does not work.
 - Check to make sure that the GlowBuoy or BeaconBuoy is charged and that the switch is in the 'On' position.
 - Check to make sure that the Key Fob battery is charged.
 - Check to make sure that the Gasket seal is secure and that there is no water inside the unit. (Salt water poses the greatest risk).

RESIDENTIAL EQUIPMENT CLASS B DIGITAL DEVICE INFORMATION TO USER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Manufactured for and Imported by KL Industries, Inc., 1790 Sun Dolphin Drive • Muskegon, MI 49444 USA
phone 231-733-2725 • fax 231-739-4502 • email klsales@klindustries.com • website www.glowbuoy.com www.beaconbuoy.com

BEACONBUOY/GLOWBUOY

REMOTE CONTROL ON/OFF
KEY FOB TRANSMITTER

USER MANUAL:

Congratulations, your purchase of the KL Industries Remote Control On/Off Key Fob Transmitter for the BeaconBuoy and/or GlowBuoy will add tremendous functionality and convenience to your light for years to come.

Instructions:

- 1) Remove the three Screws located on the back of the device and put aside in a safe place.
- 2) Remove the Key Fob Transmitter Back Plate and Gasket.
- 3) Insert battery provided, making sure that the polarity is correct.
- 4) Test the Key Fob Transmitter by turning the switch on your GlowBuoy or BeaconBuoy to the 'On' position and activating the 'Off' switch on the Key Fob to make sure that the battery has been properly inserted and that the light then turns off.
- 5) With proper operation confirmed, replace the Gasket, Back Plate and three Screws making sure that the Screws are snug, but not over tightened.

Troubleshooting and Repair:

- 1) Key Fob does not work.
 - Check to make sure that the GlowBuoy or BeaconBuoy is charged and that the switch is in the 'On' position.
 - Check to make sure that the Key Fob battery is charged.
 - Check to make sure that the Gasket seal is secure and that there is no water inside the unit. (Salt water poses the greatest risk).

RESIDENTIAL EQUIPMENT CLASS B DIGITAL DEVICE INFORMATION TO USER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Manufactured for and Imported by KL Industries, Inc., 1790 Sun Dolphin Drive • Muskegon, MI 49444 USA
phone 231-733-2725 • fax 231-739-4502 • email klsales@klindustries.com • website www.glowbuoy.com www.beaconbuoy.com

**BEACONBUOY/
GLOWBUOY**

REMOTE CONTROL ON/OFF
KEY FOB TRANSMITTER

**BEACONBUOY/
GLOWBUOY**

REMOTE CONTROL ON/OFF
KEY FOB TRANSMITTER