

# **CAR MULTIMEDIA SYSTEM**

## USER'S MANUAL



The Power to Surprise

## Read the following safety precautions for your safety

**Before using the product, read the contents of this user's manual carefully and use this product safely.**

※ The design and specifications of this product may change without prior notification for product and service improvement.

The actual features in the vehicle may differ from the illustrations.

For more accurate information about the vehicle, please refer to the catalogue.

※ This Audio system contains open source software, including without limitation, software distributed and/or modified under the GNU General Public license, Version 2, June 1991, and the GNU lesser General Public License, Version 2.1, February 1999.

For additional information and to obtain related materials including without limitation, the previous referred to licenses and software, please contact us at MOBIS\_OSSrequest@mobis.co.kr

## Notations used within this User's Manual

### **WARNING**

---

- Failure to observe the instructions within this category could result in death or serious injury or damage to the vehicle.
- 

### **CAUTION**

---

- Information on matters that could potentially lead to injury or vehicle damage/malfunction Information that could lead to higher user safety
- 

### **Information**

---

- Information and tips that provide additional user convenience in using the product
- 

### **NOTICE**

---

- Information on specific features that facilitate proper product use and functional understanding
  - Information on terminology used within this manual
-

---

## iPod®

---

iPod® is a registered trademark of Apple Inc.

---

## ***Bluetooth®* Wireless Technology**

---

A compatible *Bluetooth®* Wireless Technology-enabled cell phone is required to use *Bluetooth®* Wireless Technology.

The *Bluetooth®* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license.

Other trademarks and trade names are those of their respective owners.

A Bluetooth® enabled cell phone is required to use *Bluetooth®* Wireless Technology.

*Bluetooth®* Wireless Technology phone compatibility can be checked by visiting <http://www.kia.com>.





# part. 1 Basic

Warnings and Cautions

Key Product Features

Component Names and Functions

Starting the System for the First Time

## Safety Warnings

- Do not stare at the screen while driving. Staring at the screen for prolonged periods of time could lead to traffic accidents.
- Do not disassemble, assemble, or modify the Multimedia system. Such acts could result in accidents, fire, or electric shock.
- Heed caution not to spill water or introduce foreign objects into the device. Such acts could lead to smoke, fire, or product malfunction.
- If you use phone related functions while driving, you will find it difficult to concentrate on operating the vehicle and the current traffic conditions, so the possibility of an accident may increase. Please use phone related functions only when parked.
- Please refrain from use if the screen is blank or no sound can be heard as these signs may indicate product malfunction. Continued use in such conditions could lead to accidents (fires, electric shock) or product malfunctions.
- Do not touch the antenna during thunder or lightening as such acts may lead to lightning induced electric shock.
- Do not stop or park in parking-restricted areas to operate the product. Such acts could lead to traffic accidents.
- For most Audio and multimedia modes, the display will not operate when the vehicle is in motion. For your safety, first park the vehicle to watch or view the screen. (The screen will only operate when the parking brake is ON for manual transmission vehicles and when the parking brake is ON or the gearshift is in the P (PARK) position for automatic.)
- Some functions other than the one mentioned above cannot be used while driving. These functions operate only when the vehicle is parked.

## Safety Cautions

Pay attention to traffic conditions while driving.

- Operating the device while driving could lead to accidents due to a lack of attention to external surroundings. First park the vehicle before operating the device. In addition, the touch screen may not work for some functions when the vehicle is in motion. The touch screen feature will be supported once the vehicle has stopped.
- Adjust the volume to levels that allow the driver to hear sounds from outside of the vehicle. Driving in a state where external sounds cannot be heard may lead to accidents.
- Pay attention to the volume setting when turning the device on. A sudden output of extreme volume upon turning the device on could lead to hearing impairment. (Adjust the volume to a suitable levels before turning off the device.)
- If you want to change the position of device installation, please inquire with your place of purchase or service maintenance center. Technical expertise is required to install or disassemble the device.
- Turn on the car ignition before using this device. Do not operate the Multimedia system for long periods of time with the ignition turned off as such operations may lead to battery discharge.
- Upon using the Multimedia system for more than 10 minutes with the car engine turned off, the following warning will be displayed. After 10 minutes, the warning will be displayed for 5 seconds every 1 minute.
- Do not subject the device to severe shock or impact. Direct pressure onto the front side of the monitor may cause damage to the LCD or touch screen.
- When cleaning the device, make sure to turn off the device and use a dry and smooth cloth. Never use tough materials, chemical cloths, or solvents(alcohol, benzene, thinners, etc.) as such materials may damage the device panel or cause color/quality deterioration. When experiencing product concerns, inquire with your place of purchase or service maintenance center.
- Prevent caustic solutions such as perfume and cosmetic oil from contacting the dashboard because they may cause damage or discoloration.

# Key Product Features

This device is a Multimedia system equipped with a multifunctional player that supports Radio (FM, AM), SiriusXM™, USB, iPod, AUX, Bluetooth Audio and My Music features. The WIDE VGA LCD provides a high quality resolution while the powerful and rich sound system adds to the driving enjoyment.

|                   |                                                                                                                                                                                                                                                                                                                                             |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Display           | Wide TFT-LCD Display <ul style="list-style-type: none"><li>Provides high quality video through a Wide TFT-LCD Display using an LED Back Light.</li><li>Touch screen for maximum user convenience.</li></ul>                                                                                                                                 |
| Radio             | Digital Tuner Feature <ul style="list-style-type: none"><li>Digital Tuner using PLL method that supports memory of 40 broadcast stations.</li></ul> Radio broadcast station name <ul style="list-style-type: none"><li>Displays broadcast station names.</li></ul>                                                                          |
| Multimedia Player | Support for various Media Formats <ul style="list-style-type: none"><li>Support for various media formats, including Radio, USB, iPod, AUX and Bluetooth® Audio Streaming modes</li></ul> My Music <ul style="list-style-type: none"><li>Supports copying of music stored within USB devices into My Music (internal memory) mode</li></ul> |

|               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Miscellaneous | Bluetooth® Wireless Technology <ul style="list-style-type: none"><li>Convenient use of Bluetooth® Handsfree by using buttons within the steering wheel control</li></ul> Digital Screen Control Features <ul style="list-style-type: none"><li>Easy control of features through touch screen options</li></ul> Steering Wheel Control <ul style="list-style-type: none"><li>Control over audio features, voice recognition and Bluetooth® through the steering wheel control for maximum convenience</li></ul> |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

# Component Names and Functions

| Head Unit |                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Name      |                                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 1         |  | Selects FM/AM/SiriusXM™ mode <ul style="list-style-type: none"><li>Each time this is pressed, the mode is changed in the following order: FM → AM → SiriusXM™ → FM.</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2         |  | Selects MEDIA mode. <ul style="list-style-type: none"><li>If the media is not connected MEDIA mode will not be activated.</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 3         |  | <p>When pressed quickly (less than 0.8 seconds),</p> <ul style="list-style-type: none"><li>FM/AM mode: Plays the previous/next frequency.</li><li>SiriusXM™ mode: Changes the channel.</li><li>MEDIA (USB/iPod/My Music) mode: Changes the track, file or title (except for USB Image and AUX).</li></ul> <p>When pressed and held down (more than 0.8 seconds),</p> <ul style="list-style-type: none"><li>FM/AM mode: Continuously changes the frequency until the key is released.</li><li>MEDIA (USB/iPod/My Music) mode: Rewinds or fast forwards the track or file (except for USB Image, Bluetooth Audio, and AUX).</li></ul> |
| 4         |  | <ul style="list-style-type: none"><li>When power is off, press to turn power on.</li><li>When power is on, press and hold (more than 0.8 seconds) to turn the power off.</li><li>When power is on, press quickly (less than 0.8 seconds) to turn Audio off.</li><li>Turn left/right to adjust the volume.</li></ul>                                                                                                                                                                                                                                                                                                                 |

| Name |                                                                                    | Description                                                                                                                                                                                                                                            |
|------|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5    |  | Displays the Bluetooth phone mode.                                                                                                                                                                                                                     |
| 6    |  | Moves to the Apps/Info screen.                                                                                                                                                                                                                         |
| 7    |  | Moves to the UVO mode                                                                                                                                                                                                                                  |
| 8    |  | Moves to the Setup screen.                                                                                                                                                                                                                             |
| 9    |  | <ul style="list-style-type: none"><li>FM/AM mode: Changes the frequency.</li><li>SiriusXM™ mode: Changes the channel.</li><li>MEDIA (USB/iPod/My Music) mode: Changes the track, file or title (except USB Image, Bluetooth Audio, and AUX).</li></ul> |
| 10   |  | Resets the system settings. (Preset radio channels and other data will not be deleted)                                                                                                                                                                 |

※ The actual feature in the vehicle may differ from the illustration.

## Steering Wheel Controls

| Name                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | <p>When pressed quickly (less than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• Activates voice recognition.</li> </ul> <p>When pressed and held (more than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• Ends voice recognition.</li> <li>• If iOS device is connected through Bluetooth, activates or ends Siri Eyes Free.</li> </ul>                                                                                                                                                                                                                                                                                                                                               |
| 2  | <ul style="list-style-type: none"> <li>• Each time this is pressed, the mode is changed in the following order: FM → AM → SiriusXM → USB or iPod → AUX → Bluetooth Audio → My Music → → FM</li> <li>• If the media is not connected, the corresponding modes will be disabled</li> <li>• Press and hold (more than 0.8 seconds) to turn the Audio system on/off</li> <li>• When power is off, press button to turn power back on</li> </ul>                                                                                                                                                                                                                                                                      |
| 3  | Controls the volume                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4  | <p>When pressed quickly (less than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• FM/AM mode: searches broadcast frequencies saved to Presets</li> <li>• SiriusXM™ mode: searches broadcast channels saved to Presets</li> <li>• MEDIA (USB/iPod/My Music) mode: changes the track, file or title (except USB Image, AUX)</li> </ul> <p>When pressed and held (more than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• FM/AM mode: automatically searches broadcast frequencies</li> <li>• SiriusXM™ mode: automatically searches broadcast channels</li> <li>• MEDIA (USB/iPod/My Music) mode: quickly looks up songs (excluding USB images, AUX and Bluetooth audio files)</li> </ul> |

| Name                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5  | <p>When pressed quickly (less than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• When pressed in the dial screen, makes a call</li> <li>• When pressed in the incoming call screen, answers the call</li> <li>• When pressed during call waiting, switches to waiting call (Call Waiting)</li> </ul> <p>When pressed and held (more than 0.8 seconds),</p> <ul style="list-style-type: none"> <li>• When pressed in Bluetooth® Hands-free, redials the last dialed call</li> <li>• When pressed during a Bluetooth® Hands-free call, switches call back to mobile phone (Private)</li> <li>• When pressed while calling on the mobile phone, switches call back to Bluetooth® Hands-free (operates only when Bluetooth® Hands-free is connected)</li> </ul> |
| 6  | <ul style="list-style-type: none"> <li>• When pressed during a call, ends the phone call</li> <li>• When pressed in the incoming call screen, rejects the call</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

※ The actual feature in the vehicle may differ from the illustration.

# Starting the System for the First Time

## Turning the System On/Off

Press the engine start button or set the ignition key to On or ACC. Each time you turn on the system, a boot logo and safety warning will appear.



Pressing the power key on the head unit will display the safety guide. To change the system language between English, French, Spanish and Korean, select the **Language** button.

## NOTICE

- You cannot operate the system while it is booting up. It may take some time for all of features of the system, particularly the voice recognition system, to be ready for use.

Pressing and holding the power key on the head unit will turn off the system.

You can change Screen Saver Settings in Setup to display a clock on the Screen Saver.

## i Information

- If you turn off the system during a phone call using the Hands-free feature, then the call will automatically switch to your mobile phone.

## NOTICE

- Check the volume when turning on the system. Before turning on the system, adjust the volume to a reasonable level.

## System Reset


The System Reset function restores the system when it is not operating correctly. Press and hold the RESET key for a second or longer. (It is recommended that you press the RESET key using a tool, such as a pin or a clip.)

---

## Battery Warning Message

---

Always use the system while the car engine is running. If you turn on the system while the engine is off, a battery warning message will appear. When the engine starts, the message will disappear.



---

## NOTICE

---

- If you use the system for a long time with the engine off, the battery may become completely discharged.
- 

---

## Restrictions on Features for Safety Measures

---

Several features are limited while driving. The restriction screen will disappear when shifting gears into P or putting the parking brake on.

---

### WARNING

---

#### - Blank Screen

- Refrain from use if the screen is blank or no sound can be heard as these signs may indicate product malfunction. Continued use in such conditions could lead to accidents (fires, electric shock).
- 

---

### WARNING

---

#### - Touching the Antenna During A Thunder Storm

- Do not touch the antenna during thunder or lightning as such acts may lead to lightning induced electric shock.
-

## Home Screen

### Controls Menu Configuration for the Home Screen

Tap the  icon on any screen to display the Home Screen below.



| Features                        | Description                                                                                                                                                                            |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Radio/<br>Media Widget | <ul style="list-style-type: none"><li>Shows brief information on the radio or media that is now playing.</li><li>Tap the area to move to the mode that you are listening to.</li></ul> |
| <b>2</b> Connectivity<br>Widget | Shows any connected devices such as iPod, and Bluetooth.                                                                                                                               |
| <b>3</b> All Menus              | Shows all of the items in the system menu.                                                                                                                                             |
| <b>4</b> My Menu                | <ul style="list-style-type: none"><li>You can add up to eight menus here.</li><li>Add your favorite menus to have quick and easy access to them.</li></ul>                             |
| <b>5</b> Apps/Info              | Moves to the Apps/Info screen.                                                                                                                                                         |
| <b>6</b> Setup                  | Moves to the Setup screen.                                                                                                                                                             |

### Information Display on the Status Bar

Displays the date and time, along with the system status shown by the various icons to the right of the clock.

The icons in the following table indicate the various types of system status details and events.


| Icon                                                                              | Description                                                                   |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
|  | Displayed when the audio is muted.                                            |
|  | Displays the remaining battery of the Bluetooth phone.                        |
|  | Displayed when connected to Bluetooth for handsfree.                          |
|  | Displayed when connected to Bluetooth for streaming audio.                    |
|  | Displayed when connected to Bluetooth for streaming audio and handsfree.      |
|  | Displayed when downloading contacts or recent calls from the Bluetooth phone. |
|  | Displayed while on a call with the Bluetooth phone.                           |
|  | Displayed when the microphone of the Bluetooth is muted.                      |
|  | Displays the signal strength of the Bluetooth phone.                          |
|  | Displayed when 911 connect is available.                                      |

## Adding Your Favorite Menu Items to My Menu

From the Home screen, select **My Menu** icon, and then **Edit**.

From the Edit My Menu screen, select menu items from the list on the right, then drag and drop them to a desired place on the left.

To remove the item from My Menu, drag item from the left and drop them on the right.



### **i** Information

- Up to eight items can be added to My Menu.

## On-Screen Touch Controls

Learn how to touch the screen to operate the system.

### Select


Tap lightly on a menu or an item to select it.

### NOTICE

- The system will not recognize your touch if you wear a glove or other non-conductive material. Touch the screen using your finger, an electrostatic touch-screen glove, or a stylus pen.

## Drag & Drop


Select a menu or item you want, then drag and drop it to where you want to place it.



Drag or touch the slider along the play bar in the music screens to jump to the point that you want to play from.




Drag the frequency bar to the left or right to move to the frequency that you want.



From the Edit My Menu screen, drag and drop icons to add, delete, or move to/from My Menu.


## Flick (Quick Scrolling)



Quickly moves up and down in the list.

## NOTICE

- Moving the list when there are many items will display a handler on the right of the display. You can easily move many items at a time with the handler.




You can view the previous or next image by flicking left/right on an image on the USB Image screen.



Flick left/right on the frequency bar in the radio player to look up the previous/next frequency available.

## Press and Hold

Pressing the  and  buttons in the music player will fast forward/rewind the music.



## part.2 Radio/Media

FM/AM (with HD Radio™)

HD Radio™ Technology (if equipped)

FM/AM

SiriusXM™

USB

iPod

AUX

Bluetooth® Audio


My Music

# Radio/Media

## FM/AM (with HD Radio™)

You can access the radio player either by pressing the **RADIO** key or by selecting the Radio menu from All Menus on the Home screen.


### FM/AM Mode Display Controls



#### **i** Information

- If you press the **RADIO** key when power is off, the power will turn on and a radio broadcast will be tuned from the current mode.
- If you are in radio mode, select the media widget from the Home screen to access the radio player.

| Features                    | Description                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Preset Frequencies | <ul style="list-style-type: none"><li>• The stored preset frequencies are displayed for user selection.</li><li>• After selecting frequency, press and hold the preset button for more than 0.8 seconds. A beep sound will be heard and the frequency is to be stored in the selected preset button.</li><li>• Flick the preset frequencies up/down to scroll quickly through presets.</li></ul> |
| <b>2</b> Frequency Bar      | <ul style="list-style-type: none"><li>• Flick the frequency bar left/right to search for available radio channels to the left or right of the current channel.</li><li>• Dragging: Drag the frequency bar to the left/right to find the radio channel that you want.</li></ul>                                                                                                                   |
| <b>3</b> Frequency          | Displays the current frequency.                                                                                                                                                                                                                                                                                                                                                                  |
| <b>4</b> Tag                | Saves the current music's tag information to the head unit. If connected to iPod, the tag information can be saved on the device.                                                                                                                                                                                                                                                                |
| <b>5</b> Presets            | Shows the stored presets for user selection.                                                                                                                                                                                                                                                                                                                                                     |
| <b>6</b> Menu               | <ul style="list-style-type: none"><li>• List<br/>Moves to the frequency list.</li><li>• Info<br/>Turns the Radio text information transmitted from the broadcasting station on and off.</li><li>• Preset Scan<br/>Plays preset frequencies for 10 seconds per item.</li><li>• Sound Settings<br/>Moves to the Sound Settings.</li></ul>                                                          |



| Features                        | Description                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>7</b> Scan/Preset Scan       | Displays an active mode from Scan and Preset Scan modes.                                                                                                                                                                                                                                                                        |
| <b>8</b> Band                   | Changes to the desired band from among FM, AM, and SiriusXM.                                                                                                                                                                                                                                                                    |
| <b>9</b> HD Radio (if equipped) | Used to set whether to turn HD Radio™ reception On or Off.                                                                                                                                                                                                                                                                      |
| <b>10</b> Scan                  | Shortly plays the broadcasts for the frequencies with superior reception for 5 seconds per item.                                                                                                                                                                                                                                |
| <b>11</b> SEEK/TRACK            | <ul style="list-style-type: none"> <li>When pressed quickly (less than 0.8 seconds): Seeks the previous/next frequency.</li> <li>When pressed and held (more than 0.8 seconds): Moves quickly through all of the frequencies. The moment that you release the button, the system seeks the next available frequency.</li> </ul> |
| <b>12</b> TUNE                  | Turn the  TUNE knob to manually seek available frequencies. <ul style="list-style-type: none"> <li>FM: Increment/decrement by 200 kHz</li> <li>AM: Increment/decrement by 10 kHz</li> </ul>                                                  |

## HD Radio™ Technology (if equipped)



### PSD

Program Service Data:

Contributes to the superior user experience of HD Radio™ Technology. Presents song name, artist, station IDs, HD2/HD3 Channel Guide, and other relevant data streams.

### HD2/HD3

Adjacent traditional main stations are extra local FM channels. These HD2/HD3 Channels provide new, original music as well as deep cuts into traditional genre.

### Digital Sound

Digital, CD-quality sound. HD Radio™ Technology enables local radio stations to broadcast a clean digital signal. AM sounds like today's FM and FM sounds like a CD.

If an HD Radio™ broadcast is received, the radio mode will switch from analog broadcast to HD Radio™ broadcast.

### **i** Information

- The HD Radio™ screen is displayed only when a HD Radio™ broadcast is being received.

## HD Radio™ Mode Display Controls



| Name                                    | Description                                                                                                                                                                                                          |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 HD Radio™ Reception & Channel buttons | Displays main HD Radio™ channels and used to directly select the current available channels.<br><i>i</i> The HD Radio™ related icon display becomes active within regions where an HD Radio™ signal can be received. |
| 2 HD Channel Number                     | Analog station and corresponding HD Radio™ channel number saved in the pre-set list.                                                                                                                                 |
| 3 HD Broadcast Info                     | Displays detailed information about the current broadcast (the details of the information shown are different depending on whether the Info button is selected)                                                      |
| 4 HD Radio                              | When the HD Radio™ soft button is ON (the red indicator on the HD Radio™ button is illuminated), HD Radio™ signals will be received.                                                                                 |

# FM/AM

You can access the radio player either by pressing the **RADIO** key or by selecting the Radio menu from All Menus on the Home screen.


## FM/AM Mode Display Controls



### **i** Information

- If you press the **RADIO** key when power is off, the power will turn on and a radio broadcast will be tuned from the current mode.
- If you are in radio mode, select the media widget from the Home screen to access the radio player.


| Features                    | Description                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Preset Frequencies | <ul style="list-style-type: none"><li>• The stored preset frequencies are displayed for user selection.</li><li>• After selecting frequency, press and hold the preset button for more than 0.8 seconds. A beep sound will be heard and the frequency is to be stored in the selected preset button.</li><li>• Flick the preset frequencies up/down to scroll quickly through presets.</li></ul> |
| <b>2</b> Frequency Bar      | <ul style="list-style-type: none"><li>• Flick the frequency bar left/right to search for available radio channels to the left or right of the current channel.</li><li>• Dragging: Drag the frequency bar to the left/right to find the radio channel that you want.</li></ul>                                                                                                                   |
| <b>3</b> Frequency          | Displays the current frequency.                                                                                                                                                                                                                                                                                                                                                                  |
| <b>4</b> Presets            | Shows the stored presets for user selection.                                                                                                                                                                                                                                                                                                                                                     |
| <b>5</b> Menu               | <ul style="list-style-type: none"><li>• List<br/>Moves to the frequency list.</li><li>• Preset Scan<br/>Plays preset frequencies for 10 seconds per item.</li><li>• Sound Settings<br/>Moves to the Sound Settings.</li></ul>                                                                                                                                                                    |



| Features                      | Description                                                                                                                                                                                                                                                                                                                     |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>6</b> Scan/<br>Preset Scan | Displays an active mode from Scan and Preset Scan modes.                                                                                                                                                                                                                                                                        |
| <b>7</b> Band                 | Changes to the desired band from among FM, AM, and SiriusXM.                                                                                                                                                                                                                                                                    |
| <b>8</b> Info                 | Turns the Radio text information transmitted from the broadcasting station on and off.                                                                                                                                                                                                                                          |
| <b>9</b> Scan                 | Shortly plays the broadcasts for the frequencies with superior reception for 5 seconds per item.                                                                                                                                                                                                                                |
| <b>10</b> SEEK/TRACK          | <ul style="list-style-type: none"> <li>When pressed quickly (less than 0.8 seconds): Seeks the previous/next frequency.</li> <li>When pressed and held (more than 0.8 seconds): Moves quickly through all of the frequencies. The moment that you release the button, the system seeks the next available frequency.</li> </ul> |
| <b>11</b> TUNE                | Turn the  TUNE knob to manually seek available frequencies. <ul style="list-style-type: none"> <li>FM: Increment/decrement by 200 kHz</li> <li>AM: Increment/decrement by 10 kHz</li> </ul>                                                  |

You can access the radio player either by pressing the **RADIO** key or by selecting the Radio menu option from All Menus on the Home screen. Select the SiriusXM™ band from the radio player.

SiriusXM™ Mode Display Controls



**i** Information

- If you press the **RADIO** key when the power is off, the power will turn on and a radio broadcast will be tuned from the current mode.
- If you are in the SiriusXM™ mode, select the SiriusXM™ radio widget from the Home screen to access the radio player.
- When the power is off, pressing the **RADIO** key will turn the power on and play a SiriusXM™ Radio broadcast.



| Features                             | Description                                                                                                                                                                                                                                                                                 |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Preset Frequencies          | <ul style="list-style-type: none"><li>• Shows the stored presets for user selection.</li><li>• After selecting frequency, press and hold the preset button for more than 0.8 seconds. A beep sound will be heard and the frequency is to be stored in the selected preset button.</li></ul> |
| <b>2</b> Channel Logo                | Displays the current channel logo.                                                                                                                                                                                                                                                          |
| <b>3</b> Channel Info                | Displays the current channel number and name.                                                                                                                                                                                                                                               |
| <b>4</b> Content Info                | Displays the artist, title and other information about the current playing song.                                                                                                                                                                                                            |
| <b>5</b> Category Info               | Displays the category of the currently playing song.                                                                                                                                                                                                                                        |
| <b>6</b> Band                        | Changes to the desired band from among FM, AM, and SiriusXM.                                                                                                                                                                                                                                |
| <b>7</b> Direct Tune                 | Used to search for the desired channel by entering the channel number.                                                                                                                                                                                                                      |
| <b>8</b> Scan                        | Plays all receivable channels for 10 seconds per item.                                                                                                                                                                                                                                      |
| <b>9</b> Category Lock               | If pressed, only the channels for the current category can be searched or scanned.                                                                                                                                                                                                          |
| <b>10</b> Category Selection Buttons | Used to select the previous/next category.                                                                                                                                                                                                                                                  |
| <b>11</b> Play Live                  | Switches to the live broadcast mode.                                                                                                                                                                                                                                                        |
| <b>12</b> Skip Backward              | <p>Repeats the previously broadcasted program.</p> <ul style="list-style-type: none"><li>• Holding for less than 0.8 seconds: Moves to the previous segment.</li><li>• Holding for more than 0.8 seconds: Moves to the previous 5 seconds.</li></ul>                                        |



| Features               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>13</b> Play/Pause   | Pauses/plays the current broadcasting program.                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>14</b> Skip Forward | Moves to the next segment.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>15</b> Tag          | Saves the current music's tag information to the head unit. If connected to iPod, the tag information can be saved on the device.                                                                                                                                                                                                                                                                                                           |
| <b>16</b> Presets      | Shows the stored presets for user selection.                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>17</b> List         | Moves to the channel list.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>18</b> Menu         | <ul style="list-style-type: none"> <li>• What is on My Presets?<br/>The program schedule saved in my preset. (For more details, see Section 3.10. Viewing Menu.)</li> <li>• Featured Favorites<br/>Theme channels recommended by SiriusXM™. (For more details, see Section 3.10. Viewing Menu.)</li> <li>• Preset Scan<br/>Plays preset channels for 10 seconds each.</li> <li>• Sound Settings<br/>Moves to the Sound Settings.</li> </ul> |
| <b>19</b> SEEK/TRACK   | <ul style="list-style-type: none"> <li>• When pressed quickly (less than 0.8 seconds): Plays the previous/next channel.</li> <li>• When pressed and held (more than 0.8 seconds): Continuously changes the channel until the key is released and plays the current channel.</li> </ul>                                                                                                                                                      |
| <b>20</b> TUNE         | Changes the channel.                                                                                                                                                                                                                                                                                                                                                                                                                        |

## Selecting through Channel/Category List


Select the **List** ► Select the desired category and channel.



Select the desired category and the channel. Once selected, the previous screen will be restored and the selected channel will begin playing.

If you select the **Skip** button, you can scan channels using the **SEEK** **TRACK** key or the **TUNE** knob by skipping the channels that you chose to skip.

## Direct Tune




Enter the number of the channel you want to receive.

## Viewing Menu


Using the **Menu** button on the right, you can view the program schedule and information about the Featured Favorites provided by SiriusXM™.




What is on My Presets? (Program Schedule)



You can select Menu to see program information and the schedules of broadcast channels listed in the presets.

| Name                               | Description                                                                                                                                                                                                                                                                                                                              |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>1 Change Broadcast Date</div> | <p>By selecting this option, you can select a broadcasting date.<br/>Broadcast information will be provided for one week from the current date.</p>                                                                                                   |
| <div>2 Preset</div>                | <p>Shows saved presets for user selection<br/><b>i</b> A total of 40 frequencies for SiriusXM™ modes can be displayed.</p>                                                                                                                                                                                                               |
| <div>3 Program Information</div>   | <p>Shows you the program titles to be broadcasted at the time that you have chosen.<br/>Select a program to see more details.<br/><b>i</b> If there is more information on the program you selected, an arrow button will be displayed on the right of the list. You can see more program information by selecting the arrow button.</p> |

## Featured Favorites



Featured Favorites feature allows SiriusXM™ to broadcast additional presets.

- Example 1: “Martha’s Favorites” may represent Martha Stuart’s favorites pre-sets on her radio.
- Example 2: During holidays, “Holiday Music” may represent all the SiriusXM™ channels that are playing the holiday music for easy access by users.

Multiple sets Featured Favorites data can be broadcast by SiriusXM™ and can change from time to time.

## USB

---

### Before Playing a USB MP3

---

Connect the USB device after turning on the engine. The USB device may become damaged if it is already connected when the ignition is turned on.

- Files that are not standard format music/image files will not be played.
- For MP3/WMA/OGG files, only music files with compression rates between 8Kbps ~ 320Kbps can be played.
- Heed caution to static electricity when connecting/disconnecting external USB devices.
- Encoded MP3 Players will not be recognized when connected as an external device.
- When connecting an external USB device, the device may not properly recognize the USB in some states.
- Only products formatted with byte/sectors under 64Kbyte will be recognized.
- USB devices, formatted to the FAT12, FAT16, or FAT32 file system, are recommended. File systems other than FAT12, FAT16, FAT32, exFAT, and NTFS are not supported.
- Some USB devices may not be supported due to compatibility issues.

- Take caution so that the USB connector does not come in contact with body parts or objects.
- Repeated connecting/disconnecting of USB devices within short periods of time may result in product malfunction.
- Make sure to connect/disconnect external USB devices with the audio power turned off.
- The amount of time required to recognize the external USB device may differ depending on the type, size, or file formats stored on the USB.
- The use of USB devices for purposes other than playing music and image files is prohibited.
- Do not use the USB I/F to charge batteries or USB accessories that generate heat. Such acts may lead to worsened performance or damage to the device.
- The device may not recognize the USB device if separately purchased USB hubs and extension cables are being used. Connect the USB directly with the multimedia terminal of the vehicle.
- When using mass storage USB devices with separate logical drives, only files saved to the root drive can be played.
- When application programs are installed to specific USBs, files may not properly play.

- The device may not operate normally if MP3 Players, cellular phones, digital cameras, or other electronic devices (USB devices not recognized as portable disk drives) are connected with the device.
- Charging through the USB may not work for some mobile devices.
- The device may not support normal operation when using a USB memory type besides Metal Cover Type USB Memory.
- The device may not support normal operation when using formats such as HDD Type, CF, or SD Memory.
- When playing iPods, please use a dedicated iPod car cable.
- Normal operation cannot be guaranteed when other cables are being used.
- The device will not support files locked by DRM (Digital Rights Management).
- USB memory sticks used by connecting an Adaptor (SD Type or CF Type) may not be properly recognized.
- Only use Plug type connector products, as shown in the figure below.
- To play USB MP3, the USB device must be connected to the USB port in the front multibox. The USB port in the center console storage (if equipped) is for charging only.



Plug Type Connector

| Product Name       | Manufacturer   |
|--------------------|----------------|
| XTICK              | LG             |
| BMK                | BMK Technology |
| SKY-DRV            | Sky Digital    |
| TRANSCEND JetFlash | Transcend      |
| Sandisk Cruiser    | SanDisk        |
| Micro ZyRUS        | ZyRUS          |
| NEXTIK             | Digiworks      |

#### **i** Information

- Problems that occur through use of USB devices not listed within the above table are not covered by the product warranty.

## Supported USB MP3 music specifications

| Name                                         | Description                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MP3 File Specification                       | Specification: MPEG1 AUDIO LAYER 3                                                                                                                                                                                                                                                                                                                                                                                     |
| Recommended Bit Rates and Sampling Frequency | Acceptable sampling frequency: 32, 44.1, 48 (kHz)                                                                                                                                                                                                                                                                                                                                                                      |
|                                              | Acceptable bit rate: 32, 40, 48, 56, 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (Kbps)                                                                                                                                                                                                                                                                                                                              |
|                                              | 96, 128, 192 Kbps fixed bit rate/44.1kHz                                                                                                                                                                                                                                                                                                                                                                               |
| ID3 Tag                                      | Supports ID3v1.0 and ID3v1.1, ID3v2.2, ID3v2.3, ID3v2.4 ID3 tags                                                                                                                                                                                                                                                                                                                                                       |
| Detailed Specifications                      | Maximum directory layers: 20 layers<br>Maximum length of folder name/file name: 255Bytes<br>Supported characters for folder name/file name: Alphanumeric characters, Korean standard character set 2,350 characters, Simplified Chinese 4888 characters<br>Maximum number of folders which can be stored onto one USB: 2000 folders (including ROOT)<br>Maximum number of files which can be stored onto one USB: 8000 |


## Supported Image Specifications

| Name                      | Description                                               |
|---------------------------|-----------------------------------------------------------|
| Image format              | JPG, GIF, BMP, PNG (animated GIF, etc. are not supported) |
| Supported image file size | 5M pixels for JPG, BMP, PNG (1M pixels maximum for GIF)   |

### Information


- The sound quality of MP3 files that use bitrates exceeding 192 Kbps cannot be guaranteed. When using files without fixed bit rates, some features (FF/REW features) may not properly operate.

## USB Music Mode Display Controls




| Features                       | Description                                                                                                                                                                                                                                                                                                              |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Mode                  | Displays the current operating mode                                                                                                                                                                                                                                                                                      |
| <b>2</b> File Index            | Shows the current file/total files within the USB                                                                                                                                                                                                                                                                        |
| <b>3</b> Repeat/ Shuffle/ Scan | From Repeat/Shuffle/Scan, displays the current operating function                                                                                                                                                                                                                                                        |
| <b>4</b> Play Time             | Displays the current play time/total play time                                                                                                                                                                                                                                                                           |
| <b>5</b> Song Info             | Displays the information of the current track <ul style="list-style-type: none"> <li>When a track in the file tab on the list screen is selected: Displays folder, file, title, artist, album info</li> <li>When a track in the other tabs on the list screen is selected: Displays artist, title, album info</li> </ul> |
| <b>6</b> List                  | Moves to the list screen                                                                                                                                                                                                                                                                                                 |
| <b>7</b> Back Button           | Converts to basic mode screen                                                                                                                                                                                                                                                                                            |

| Features               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>8</b> Previous File | If button is pressed (less than 0.8 seconds): Moves to the previous file or play the current file from the beginning (Depends on the play time) <ul style="list-style-type: none"> <li>If play time is less than 3 seconds, moves to previous file</li> <li>If play time is more than 3 seconds, play the current file from the beginning</li> </ul> If button is pressed (more than 0.8 seconds): It rewinds the track                        |
| <b>9</b> Play/Pause    | Plays/pauses the current file                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>10</b> Next File    | <ul style="list-style-type: none"> <li>If button is pressed (less than 0.8 seconds): Moves to the next file</li> <li>If button is pressed (more than 0.8 seconds): It fast-forwards the track</li> </ul>                                                                                                                                                                                                                                       |
| <b>11</b> Repeat       | Repeats the current file <ul style="list-style-type: none"> <li>If select the song in the file tab on the list screen: Select the <b>Repeat</b> button to switch between repeating one song, repeating folder, and turning repeat off</li> <li>If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the <b>Repeat</b> button to switch between repeating one song and turning repeat off</li> </ul> |
| <b>12</b> Shuffle      | Plays files in random order <ul style="list-style-type: none"> <li>If select the song in the file tab on the list screen: Select the <b>Shuffle</b> button to switch between Shuffle Folder, Shuffle All, and turning shuffle off</li> <li>If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the <b>Shuffle</b> button to switch between Shuffle Category and turning shuffle off</li> </ul>     |



| Features       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>13</b> Scan | <p>Scans the beginning parts of USB files (approx. 10 seconds per file)</p> <ul style="list-style-type: none"> <li>• If select the song in the file tab on the list screen: Select the <b>Scan</b> button to switch between Scan Folder, Scan All, and turning scan off</li> <li>• If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the <b>Scan</b> button to switch between Scan category and turning scan off</li> </ul> |
| <b>14</b> Menu | <ul style="list-style-type: none"> <li>• Add to Playlist: Add the current track to the Playlist: Playlist is placed on the left tab in the list</li> <li>• Save to My Music: You can save the current track to My Music. You can play saved track from My Music without USB. Access to My Music in the Media mode.</li> <li>• Sound Settings: Moves to the Sound Settings screen. You can change the settings of the sound.</li> </ul>                                    |
| <b>15</b> TUNE | <p>Turn the <b>TUNE</b> knob to search a desired track. If the desired track is displayed, select the <b>TUNE</b> knob to play the track.</p> <p><b>i</b> If the <b>TUNE</b> knob is not pressed within 5 seconds of searching tracks, the track info for the current track is restored.</p>                                                                                                                                                                              |




| Features                       | Description                               |
|--------------------------------|-------------------------------------------|
| <b>1</b> Folder/Category Name  | Displays folder/category name in the list |
| <b>2</b> Current Song          | Displays the current playing file name    |
| <b>3</b> Back Button           | Converts to basic mode screen             |
| <b>4</b> Upper Folder/Category | Moves to Upper Folder                     |

| Features             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>5</b> Menu        | <ul style="list-style-type: none"> <li>• Add to Playlist: Adds the current track to the Playlist: Playlist is placed on the left tab in the list (Maximum 100 files) Select a desired track and press “Add to Playlist” to add the track in the playlist.</li> <li>• Delete from Playlist: Select a track you want to delete from the playlist and press “Delete from Playlist” to delete the track in the playlist</li> <li>• Now Playing: When moving to a different list screen, moves to the list page where the current file is located (Becomes disabled when the current list includes the current file)</li> <li>• Save to My Music: Stores the music. The stored music can be played in My Music. (This function is not provided in Playlist.)</li> </ul> |
| <b>6</b> Search Menu | <p>Search tracks by the list type. Search songs according to File, Playlist, Artist, Song and Album.</p> <p><b>i</b> If access the search menu while playing a track, it moves to the previous search mode.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>7</b> SEEK/TRACK  | <ul style="list-style-type: none"> <li>• If button is pressed (less than 0.8 seconds): Plays previous/next track.</li> <li>• If button is pressed (more than 0.8 seconds): Moves to play screen, and then it will rewind or fast-forward the track.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>8</b> TUNE        | <p>Turn the <b>TUNE</b> knob to move the focus to the previous/next list. If the desired track is displayed, press <b>TUNE</b> knob to play the track.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

## USB Image Mode Display Controls



| Features                         | Description                                                    |
|----------------------------------|----------------------------------------------------------------|
| <b>1</b> Mode                    | Displays the current operating mode                            |
| <b>2</b> Folder/<br>File Name    | Displays folder name where image is located                    |
| <b>3</b> File Index              | Shows the current file/total files within the USB              |
| <b>4</b> Slideshow               | Images as slideshow in 5, 10, 20, 30 second intervals          |
| <b>5</b> Rotate                  | Rotate image in clockwise direction                            |
| <b>6</b> Info                    | Shows the file name, resolution and file type of current image |
| <b>7</b> Adjust Image<br>Size    | Enlarge/reduce (zoom-in/zoom-out) image size                   |
| <b>8</b> List                    | Moves to the list screen                                       |
| <b>9</b> Previous/<br>Next image | Swipe image left or right to see Previous/Next image           |



5

| Features       | Description                                                                                                                                                                                                                                    |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Current File | Displays the current playing file name                                                                                                                                                                                                         |
| 2 Back Button  | Converts to basic mode screen                                                                                                                                                                                                                  |
| 3 Menu         | Now Playing: When moving to a different list screen, moves to the list page where the current file is located (Becomes disabled when the current list includes the current file)                                                               |
| 4 SEEK/TRACK   | Controls background mode <ul style="list-style-type: none"> <li>Radio mode: Changes Frequency and Channel</li> <li>Media mode: Changes Track (excluding AUX)</li> </ul>                                                                        |
| 5 TUNE         | Controls background mode <ul style="list-style-type: none"> <li>Radio mode: Changes Frequency and Channel</li> <li>Media mode: Changes track (excluding AUX). If a desired track is displayed, press the knob to move to the track.</li> </ul> |

## Using iPod Devices

- iPod is a registered trademark of Apple Inc.
- iPod mode will not operate if the connected iPod cannot be recognized due to operation of unsupported versions that do not support related protocols, iPod abnormalities, or iPod device defects. Some iPods with unsupported communication protocols may not properly operate with the Multimedia system.
- For fifth generation iPod Nano devices, the iPod may not be recognized when the battery level is low. Please charge the iPod for use.
- Search/play orders shown within the iPod device may differ with the orders shown within the Multimedia system.
- If the iPod malfunctions due to an iPod device defect, reset the iPod and try again. (To learn more, refer to your iPod manual)
- If repeatedly connect and disconnect iPod/iPhone to the Multimedia system with USB cable in a short time, it may cause abnormal operation.
- The time for recognition of iPod/iPhone may vary depending on device type, firmware version and iOS version.
- For some iPod Touch and iPhone devices, connecting Bluetooth® while the iPod is operating may result in discontinued iPod sound. When such devices with Bluetooth® support are connected, this problem occurs as the sound source is changed from the Dock Connector (USB connector cable) to Bluetooth.
- To prevent this symptom, Bluetooth Audio function in the Multimedia system is limited if iPod/iPhone is connected to the system through both cable and Bluetooth. To listen to the iPod sound, use either iPod menu with USB connection or Bluetooth Audio with Bluetooth connection.
- To listen to the iPod sound, reconnect the USB cable or change the audio output settings in iPod/iPhone to Dock.
- In order to use the iPod while operating the keys, you must use a dedicated iPod cable. (the cable that is supplied when purchasing iPod/ iPhone products)
  - ※ During ACC ON state, connecting the iPod through the iPod cable (The cable that is supplied when purchasing iPod/ iPhone product.) will charge the iPod through the head unit.
  - ※ **The use of genuine iPod cables supplied by Apple is recommended. (The use of other products may result in noise or abnormal operation.)**
  - ※ To play iPod music through cable connection, the iPod/USB cable must be connected to the USB port in the front multibox. The USB port in the center console storage (if equipped) is for charging only.

- When connecting with the iPod cable, make sure to fully insert the jack to prevent communication interference. If the iPod is connected to the vehicle while it is playing, a high pitch tone may sound for about 1~2 seconds immediately after connection. If possible, connect the iPod to the vehicle with the iPod stopped/paused.
- Within iPhones, streaming audio and iPod control may occasionally conflict. If problems persist, remove the iPhone and connect again.
- When connecting to iPod Nano/Classic, the Kia Motor logo appears on the Apple device. For the iPod Nano 6 generation, however, the logo image does not appear since it is not supported. Also, all iPhone and iPod Touch products do not support this function.
- In Apple's iOS 6.0 version or later, Podcast and Audiobook media files are designed to be played with the Podcasts and iBooks applications specifically designed for Apple products. If the Apple device does not provide the Podcast and Audiobook lists, the playlist may not be displayed and played in the iPod mode.
- If the Apple Podcasts and iBooks apps are not installed on the Apple device, but the Apple device provides the Podcast and Audiobook lists, you can play files in other categories in iPod mode.
- The screen of multimedia system can be different when you run other music players (e.g. iHeartRadio) on your connected device.

## Caution

- While using a connected iPhone/iPod Touch device, it may not operate normally if the user changed some functions in the device.
- When calling with an iPhone connection, song may stop playing due to an Apple device feature. If sound does not resume after the call is terminated, check the device status.
- If lots of songs have the same information, skipping may occur when previous/next song is executed due to an Apple device feature. Also problems may occur depending on device type or iOS version.
- If lots of songs have the same information, the song that plays may be different between the system and the Apple device. Reset the device or delete the same songs in the Apple device using iTunes.

- If you control pause, repeat, shuffle, or seek songs when the play time is less than 3s before the song is finished playing, it may occur difference of playing song between the Multimedia system and Apple device. Access to iPod music from another mode or pause a song and then play a song again in Apple device.


- We recommend that your Apple device uses the latest firmware since some problems may occur due to an outdated firmware or other software related issues.

| Type         | 1G                                                                | 2G  | 3G | 4G | 5G                     | 6G                  | 6.5G                | 7G           |    |
|--------------|-------------------------------------------------------------------|-----|----|----|------------------------|---------------------|---------------------|--------------|----|
| iPod Mini    | Not Supported                                                     |     |    |    |                        |                     |                     |              |    |
| iPod Shuffle | Not Supported                                                     |     |    |    |                        |                     |                     |              |    |
| iPod Nano    | ○                                                                 | ○   | ○  | ○  | ○                      | ○                   | Not released        | ○            |    |
| iPod Touch   | ○<br>(iOS 1.1 not supported)                                      | ○   | ○  | ○  | ○                      | Not released        |                     |              |    |
| iPad         | ○ (Unable to charge, Not verified, Normal working not guaranteed) |     |    |    |                        |                     |                     |              |    |
| iPad Mini    | ○ (Unable to charge, Not verified, Normal working not guaranteed) |     |    |    |                        |                     |                     |              |    |
| iPod Classic | Not Supported                                                     |     |    |    | ○<br>(iPod with Video) | ○<br>(iPod Classic) | ○<br>(iPod Classic) | Not released |    |
| Type         | 3G                                                                | 3GS | 4  | 4S | 5                      | 5C                  | 5S                  | 6            | 6+ |
| iPhone       | Not verified, Normal working not guaranteed                       | ○   | ○  | ○  | ○                      | ○                   | ○                   | ○            | ○  |

## **Caution**

- If the iPhone/iPod Touch supports Bluetooth, the Apple device will not be able to use the Bluetooth function if the device is connected through both the USB port and via Bluetooth. Disconnect the USB connection then use Bluetooth Audio.
- If iPod/iPhone connected to the Multimedia system through both USB and AUX. iPod/iPhone keeps output sound via AUX, thus it may occur sound will not output in iPod mode.
- If AUX cable connected to iPod/iPhone but not connect to the Multimedia system, it may occur sound will not output in iPod mode due to iPod/iPhone's feature. Especially, if you use AUX cable like pictures, this problem may occur.
- Disconnect AUX cable from iPod/iPhone first, then connect to the Multimedia system via USB. Or change settings to "Dock" in iPod/iPhone.
- If connect to the Multimedia system while podcast or iTunes music downloading to iPod/iPhone, it may occur some problems when you select song in the list. Reconnect iPod/iPhone to the Multimedia system when downloading is finished or the file deleted.
- If connect to the Multimedia system while sync, it may occur some problems. Try to use iPod/iPhone connection after sync complete. (To learn more, refer to your iPod manual)
- iPhone and iPod Touch devices are guaranteed to work normally on iOS 9.3.2 or below. However, they may not work normally on future iOS versions as their operations have not yet been tested.


## iPod Mode Display Controls



| Features                | Description                                                  |
|-------------------------|--------------------------------------------------------------|
| <b>1</b> Mode           | Displays the current operating mode                          |
| <b>2</b> Song Index     | Shows the current song/total songs                           |
| <b>3</b> Repeat/Shuffle | From Repeat/Shuffle, displays the current operating function |
| <b>4</b> Play Time      | Displays the current play time/total play time               |
| <b>5</b> Song Info      | Displays the artist/song title/album info                    |
| <b>6</b> List           | Moves to the list screen                                     |

| Features               | Description                                                                                                                                                                                                                                                                                                                                                                                                                           |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>7</b> Previous File | <p>If button is pressed (less than 0.8 seconds): Moves to the previous file or play the current file from the beginning (Depends on the play time)</p> <ul style="list-style-type: none"> <li>If play time is less than 3 seconds, moves to previous file</li> <li>If play time is more than 3 seconds, play the current file from the beginning</li> </ul> <p>If button is pressed (more than 0.8 seconds): It rewinds the track</p> |
| <b>8</b> Play/Pause    | Plays/pauses the current file                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>9</b> Next File     | <ul style="list-style-type: none"> <li>If button is pressed (less than 0.8 seconds): Moves to the next file</li> <li>If button is pressed (more than 0.8 seconds): It fast-forwards the track</li> </ul>                                                                                                                                                                                                                              |
| <b>10</b> Repeat       | <p>Repeats the current file</p> <p>Select the <b>Repeat</b> button to switch between repeating 1 track, and turning repeat off</p>                                                                                                                                                                                                                                                                                                    |
| <b>11</b> Shuffle      | <p>Plays files in random order</p> <p>When selecting the <b>Shuffle</b> button, it changes to shuffle category → deactivate shuffle then repeat</p> <ul style="list-style-type: none"> <li>Shuffle Category: Shuffle song in the current category</li> </ul>                                                                                                                                                                          |
| <b>12</b> Back Button  | Move to home/previous mode screen                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>13</b> Menu         | Sound Settings: Moves to the Sound Settings screen. You can change the settings of the sound.                                                                                                                                                                                                                                                                                                                                         |

| Features                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>14</div> <div>TUNE</div> | <p>Turn the  TUNE knob to search a desired track. If the desired track is displayed, press the  TUNE knob to play the track.</p> <p> If the  TUNE knob is not pressed within 5 seconds of searching tracks, the track info for the current track is restored.</p> |




| Features                | Description                                                                                                                                                                                                                                                |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Category Name  | Displays the category name                                                                                                                                                                                                                                 |
| <b>2</b> Category List  | Displays the contents of selected category<br><b>i</b> If there are many items in the list, items are added in order and the scroll bar on the right is adjusted accordingly.                                                                              |
| <b>3</b> Back Button    | Converts to basic mode screen                                                                                                                                                                                                                              |
| <b>4</b> Upper Category | Moves to Upper Category                                                                                                                                                                                                                                    |
| <b>5</b> Search Menu    | Search tracks by the list type. Search songs according to Playlist, Artist, Song, Album, Genre, Composer, Podcast and Audiobook.<br><b>i</b> If access the search menu while playing a track, it moves to the previous search mode.                        |
| <b>6</b> SEEK/TRACK     | <ul style="list-style-type: none"> <li>If button is pressed (less than 0.8 seconds): Plays previous/next track.</li> <li>If button is pressed (more than 0.8 seconds): Moves to play screen, and then it will rewind or fast-forward the track.</li> </ul> |
| <b>7</b> TUNE           | Turn the <b>TUNE</b> knob to search a desired track. If the desired track is displayed, press the <b>TUNE</b> knob to play the track. If you do not anything with the knob for 5 seconds, the <b>TUNE</b> knob search will be terminated.                  |

## AUX

### Connecting an External Device

If an external device connector is connected with the AUX terminal, then AUX mode will automatically operate. Once the connector is disconnected, the previous mode will be restored.

- AUX mode can be used only when an external audio player has been connected.
- The AUX volume can also be controlled separately through the connected device.



### NOTICE


- If only a cable is connected to the AUX without an external device, the mode will be changed to AUX, but noise may occur. When an external device is not being used, remove the connector jack.
- When the external device power is connected to the power jack, playing the external device may output noise. In such cases, disconnect the power connection before use.



※ The actual feature in the vehicle may differ from the illustration.

# Bluetooth® Audio

## Bluetooth Audio Mode Display Controls



| Features      | Description                         |
|---------------|-------------------------------------|
| 1 Mode        | Displays the current operating mode |
| 2 Phone Name  | Displays name of connected phone    |
| 3 Artist Info | Name of current artist              |

| Features        | Description                                                                                                                                                                                                                                                                      |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4 Title         | Name of current song                                                                                                                                                                                                                                                             |
| 5 Previous File | <ul style="list-style-type: none"><li>If play time is less than 3 seconds, moves to the previous file</li><li>If play time is more than 3 seconds, plays the current file from the beginning</li></ul> <i>i</i> This function may differ depending on the model of mobile phone. |
| 6 Play/Pause    | Plays/Pauses Bluetooth Audio                                                                                                                                                                                                                                                     |
| 7 Next File     | Moves to the next file                                                                                                                                                                                                                                                           |
| 8 Repeat        | Repeats the current file.<br><i>i</i> This function may differ depending on the model of mobile phone.                                                                                                                                                                           |
| 9 Shuffle       | Plays files in random order.<br><i>i</i> This function may differ depending on the model of mobile phone.                                                                                                                                                                        |
| 10 Menu         | <ul style="list-style-type: none"><li>Connections: Moves to the Bluetooth Settings screen. You can pair a new device or change/delete paired device(s).</li><li>Sound Settings: Moves to the Sound Settings screen. You can change the settings of the sound.</li></ul>          |
| 11 SEEK/TRACK   | Plays the previous/next file                                                                                                                                                                                                                                                     |
| 12 TUNE         | ● TUNE is not supported                                                                                                                                                                                                                                                          |


### *i* Information

- Artist info and Title may not be supported by mobile phone

---

## Bluetooth Connection Settings

Settings for pairing, connection and disconnection of a Bluetooth device.




- In Bluetooth Audio play screen, select **Menu** and then **Connections**.

---

### **i** Information


- If the music in the mobile phone is not played after changing to audio streaming mode, press the play button. Thus check if the music is playing in the Bluetooth device after changing to audio streaming mode. Audio streaming may not be supported for some mobile phones.
  - Please check the Bluetooth compatibility in below website: KIA Motors Corporation <http://www.kia.com>
-

My Music Mode Display Controls




| Features                | Description                                                                                                                                                                                                                                                                                                     |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Mode                  | Displays the current operating mode                                                                                                                                                                                                                                                                             |
| 2 File Index            | Shows the current file/total files                                                                                                                                                                                                                                                                              |
| 3 Repeat/ Shuffle/ Scan | From Repeat/Shuffle/Scan, displays the current operating function                                                                                                                                                                                                                                               |
| 4 Play Time             | Displays the current play time/total play time                                                                                                                                                                                                                                                                  |
| 5 Song Info             | Displays the information about the current track <ul style="list-style-type: none"><li>When a track in the file tab on the list screen is selected: Displays file, artist, title, album info</li><li>When a track in the other tab on the list screen is selected: Displays artist, title, album info</li></ul> |

| Features        | Description                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6 List          | Moves to the list screen                                                                                                                                                                                                                                                                                                                                                                                             |
| 7 Previous File | If button is pressed (less than 0.8 seconds): Moves to the previous file or play the current file from the beginning (Depends on the play time) <ul style="list-style-type: none"><li>If play time is less than 3 seconds, moves to previous file</li><li>If play time is more than 3 seconds, play the current file from the beginning</li></ul> If button is pressed (more than 0.8 seconds): It rewinds the track |
| 8 Play/Pause    | Plays/pauses the current file                                                                                                                                                                                                                                                                                                                                                                                        |
| 9 Next File     | <ul style="list-style-type: none"><li>If button is pressed (less than 0.8 seconds): Moves to the next file</li><li>If button is pressed (more than 0.8 seconds): It fast-forwards the track</li></ul>                                                                                                                                                                                                                |
| 10 Repeat       | Repeats the current file <ul style="list-style-type: none"><li>If select the song in the file tab on the list screen: Select the Repeat button to switch between repeating one song and turning repeat off.</li><li>If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the Repeat button to switch between repeating one song and turning repeat off</li></ul>          |



| Features   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11 Shuffle | <p>Plays files in random order</p> <ul style="list-style-type: none"> <li>• If select the song in the file tab on the list screen: Select the <b>Shuffle</b> button to switch between shuffle and turning shuffle off</li> <li>• If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the <b>Shuffle</b> button to switch between shuffle and turning shuffle off</li> </ul>                    |
| 12 Scan    | <p>Scans the beginning parts of files (approx. 10 seconds per file)</p> <ul style="list-style-type: none"> <li>• If select the song in the file tab on the list screen: Select the <b>Scan</b> button to switch between scan and turning scan off</li> <li>• If select the song in the other tabs (Playlist, Artist, Song, Album) on the list screen: Select the <b>Scan</b> button to switch between scan and turning scan off</li> </ul> |
| 13 Menu    | <ul style="list-style-type: none"> <li>• Add to Playlist: Adds the current song to the Playlist: Playlist is placed on the left tab in the list</li> <li>• Delete Current File: Deletes the current track from My Music.</li> <li>• Sound Settings: Moves to the Sound Settings screen. You can change the settings of the sound.</li> </ul>                                                                                               |
| 14 TUNE    | <p>Turn the <b>TUNE</b> knob to search a desired track. If the desired track is displayed, press the <b>TUNE</b> knob to play the track.</p> <p><b>i</b> If the <b>TUNE</b> knob is not pressed within 5 seconds of searching tracks, the track info for the current track is restored.</p>                                                                                                                                                |



| Features                      | Description                               |
|-------------------------------|-------------------------------------------|
| <b>1</b> Folder/Category Name | Displays folder/category name in the list |
| <b>2</b> Current Song         | Displays the current playing file name    |
| <b>3</b> Back Button          | Converts to basic mode screen             |
| <b>4</b> Upper Folder         | Moves to Root Folder                      |

| Features             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>5</b> Menu        | <ul style="list-style-type: none"> <li>• Add to Playlist: Adds the current track to the Playlist. Playlist is placed on the left tab in the list (Maximum 100 files) Select a track and press “Add to Playlist” to add the track in the playlist</li> <li>• Delete from Playlist: Select a track from the playlist and press “Delete from Playlist” to delete the track in the playlist</li> <li>• Delete Files: Deletes files from My Music</li> <li>• <b>i</b> If delete file from My Music, the information related to song also deleted in the list.</li> <li>• Now Playing: When moving to a different list screen, moves to the list page where the current file is located (Becomes disabled when the current list includes the current file)</li> </ul> |
| <b>6</b> Search Menu | <p>Search tracks by the list type. Search songs according to File, Playlist, Artist, Song and Album.</p> <p><b>i</b> If access the search menu while playing a track, it moves to the previous search mode.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>7</b> SEEK/TRACK  | <ul style="list-style-type: none"> <li>• If button is pressed (less than 0.8 seconds): Plays previous/next track.</li> <li>• If button is pressed (more than 0.8 seconds): Moves to play screen, and then it will rewind or fast-forward the track.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>8</b> TUNE        | <p>Turn the <b>TUNE</b> knob to move the focus to previous/next file. If the file you want to play is displayed, press <b>TUNE</b> knob to play the track.</p> <p><b>i</b> If the <b>TUNE</b> knob is not pressed within 5 seconds of searching tracks, Tune search will be terminated.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

MEMO

# part.3 Bluetooth

Before Using the Bluetooth® Handsfree

Bluetooth Connection

Bluetooth Phone

# Bluetooth

## Before Using the Bluetooth® Handsfree

---

### What is Bluetooth® Wireless Technology?

---

- *Bluetooth®* Wireless Technology refers to a short-distance wireless networking technology which uses a 2.45GHz frequency to connect various devices within a certain distance.
- Supported within PCs, external devices, Bluetooth® phones, PDAs, various electronic devices, and automotive environments, *Bluetooth®* Wireless Technology to be transmitted at high speeds without having to use a connector cable.
- Bluetooth® Handsfree refers to a device which allows the user to conveniently make phone calls with Bluetooth® mobile phones through the Multimedia system.

- The Bluetooth® Handsfree feature may not be supported in some mobile phones. For more information on mobile phone compatibility, visit the KIA Motor website - KIA Motors Corporation: <http://www.kia.com>



#### **WARNING**

##### **- Distracted Driving**

- Focus on the road while driving. The driver's primary responsibility is in the safe and legal operation of the vehicle. Drivers should not use any hand held devices or other equipment or vehicle systems that distract the driver during vehicle operation.
- Do not stare at the multimedia screen for long periods of time while driving. Staring at the screen for prolonged periods of time can lead to traffic accidents and can result in personal injuries.

---

### Precautions for Safe Driving

---

- Bluetooth® is a feature that enables drivers to make handsfree calls. Connecting the head unit with a Bluetooth® phone allows the user to conveniently make calls, receive calls, and manage the phonebook. Before using *Bluetooth®* Wireless Technology, carefully read the contents of this user's manual.
- Excessive use or operations while driving may lead to negligent driving practices and be the cause of accidents. Do not operate the device excessively while driving.
- **Viewing the screen for prolonged periods of time is dangerous and may lead to accidents. When driving, view the screen only for short periods of time.**

---

## CAUTIONS upon Connecting Bluetooth® Phone

---

- Before connecting the head unit with the mobile phone, check to see that the mobile phone supports Bluetooth® features.
- Even if the phone supports *Bluetooth®* Wireless Technology, the phone will not be found during device searches if the phone has been set to hidden state or the Bluetooth® power is turned off. Disable the hidden state or turn on the Bluetooth® power prior to searching/connecting with the head unit.
- If Auto Connection is used, the Bluetooth® phone is automatically connected when the ignition is turned on, making it unnecessary to have to connect the phone with the head unit every time.
- If you do not want automatic connection with your Bluetooth® device, turn the Bluetooth® feature off of the Bluetooth® device.
- Park the vehicle when connecting the head unit with the mobile phone.
- Bluetooth® connection may become intermittently disconnected in some mobile phones. Follow these steps to try again.
  1. Turn the Bluetooth® function within the mobile phone OFF/ON and try again.
  2. Turn the mobile phone power OFF/ON and try again.
  3. Completely remove the mobile phone battery, reboot, and then again.
  4. Reboot the Multimedia System and try again.
  5. Delete all paired devices from both of Phone and Head Unit sides and then try again.
- The Handsfree call volume and quality may differ depending on the mobile phone.
- Pairing Bluetooth® devices and use of other Bluetooth® features are not supported when the vehicle is in motion. For safety, please first park your vehicle.
- If you continue having issue downloading your contacts to your vehicle, contact your mobile phone provider.

# Bluetooth Connection

## Pairing a New Device

Before you can use the Bluetooth feature, you must first pair/connect your mobile phone to your car.

Up to 5 Bluetooth devices can be paired. Only one Bluetooth device can be connected at a time.

## Pairing a New Device by Selecting Phone/Call

Press the **PHONE** key or **☎** key in the steering wheel control. ▶ Pair your car after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorization popup. ▶ Connect Bluetooth.

## Pairing a New Device Through the Phone Settings

Press the **SETUP** key. ▶ Select **Bluetooth**. ▶ Select **Bluetooth Connection**. ▶ Select **Add New**. ▶ Pair your car after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorization popup. ▶ Connect Bluetooth.




The default passkey is 0000.  
The vehicle name above is an example.  
Check the actual information on the product.

## Connecting Bluetooth Devices

Connects the Bluetooth devices that you add.


## Connecting Devices by Selecting Phone/Call

Press the **PHONE** key or **☎** key in the steering wheel control. ▶ Select the name of the device to connect. ▶ Connect Bluetooth.



## Connecting Devices Through the Phone Settings


Press the **SETUP** key. ▶ Select **Bluetooth**.  
▶ Select **Bluetooth Connection**. ▶ Select the name of the device to connect. ▶ Connect Bluetooth.



## Disconnecting Bluetooth Devices

Disconnects Bluetooth devices that are connected.


Press the **SETUP** key. ▶ Select **Bluetooth**.  
▶ Select **Bluetooth Connection**. ▶ Select the name of the device to disconnect.



## Deleting Bluetooth Devices

Deletes the Bluetooth devices that you added. Note that deleting a Bluetooth device will delete all Call History and Contact Info downloaded along with it.


Press the **SETUP** key. ▶ Select **Bluetooth**. ▶ Select **Bluetooth Connection**. ▶ Select **Delete Devices**. ▶ Select the device name to delete. ▶ Select **Delete**.



# Bluetooth Phone

## Phone Status Icons

Shows the current phone status in the right top of the display.



| Icons | Description                                                                                                           |
|-------|-----------------------------------------------------------------------------------------------------------------------|
|       | You can use Bluetooth phones when a Bluetooth Hands-free connection is established.                                   |
|       | You can use Bluetooth audio features when a Bluetooth audio connection is established.                                |
|       | You can use Bluetooth phones and audio features when both Bluetooth Hands-free and audio connections are established. |
|       | Call signal strength indicator                                                                                        |
|       | Battery level of the Bluetooth devices connected                                                                      |
|       | Downloading Call History list                                                                                         |
|       | Downloading Contacts                                                                                                  |
|       | In a Bluetooth phone call                                                                                             |
|       | Microphone muted                                                                                                      |


### Information

- The battery level icon and the call signal strength indicator may not be supported in some Bluetooth devices.
- The battery level may differ from the actual level remaining.

## Dial

Dials a call after the Bluetooth devices are connected.

- Press the **PHONE** key or  key in the steering wheel control.
- You can also select **All Menus** icon, and then **Phone** icon.




| Name              | Description                                                                                                                                                                        |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Keypad   | Use the keypad to enter the phone number that you want to call. Press and hold the last number of a speed dial to dial a number that you added to the Speed Dial list in the phone |
| <b>2</b> Call     | Makes a call after you dial a number and select CALL. If the number is listed in Dialed Calls, you can select CALL to automatically dial that number again.                        |
| <b>3</b> Settings | Moves to a screen of Phone Settings.                                                                                                                                               |
| <b>4</b> Delete   | Deletes the numbers that you entered.                                                                                                                                              |

### **i** Information

- Some types of mobile phones may not support the Speed Dial function.

## Accept/Reject Call




If there is an incoming call after you made a Bluetooth connection, a popup message will appear.

| Name            | Description       |
|-----------------|-------------------|
| <b>1</b> Accept | Answers the call. |
| <b>2</b> Reject | Ignores the call. |

### **i** Information

- In some mobile phones, the caller's number may not be displayed, and the Reject feature may not be supported.

## Using the Menu During a Phone Call



When making a call, you can use the following menu items.


| Name              | Description                                                                                                                                                                                                               |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Use Private     | Switches a voice call from the car Hands-free to the mobile phone.                                                                                                                                                        |
| 2 End             | Ends a call.                                                                                                                                                                                                              |
| 3 Contacts        | Displays the Contacts list.                                                                                                                                                                                               |
| 4 Outgoing Volume | Displays the Mic Volume settings. You can adjust the in-call volume that the other party hears (level 1 - 5).                                                                                                             |
| 5 Keypad          | Moves to a screen for entering ARS numbers.                                                                                                                                                                               |
| 6 Switch          | Switches to a call on hold, if any. You can also switch calls by selecting the number in the Information Display. The Switch function switches the current call to a waiting call in order to answer a new incoming call. |

### **i** Information

- If the caller's number is listed in Contacts, the caller's name will be displayed. Otherwise, only the number will be displayed. In some mobile phones, the phone number may not be displayed.
- In some Bluetooth devices, the Use Private feature may not be supported.
- In some Bluetooth devices, the Switch feature may not be supported.
- During a phone call on a Bluetooth Hands-free, you cannot access other modes, such as Radio and Settings.
- Depending on handset types, the in-call volume the other party hears may differ. If the other party hears your voice too low or too loud, adjust the mic volume.

## Call History

Press the **PHONE** key, and then **Call History**.




| Name                  | Description                                                                 |
|-----------------------|-----------------------------------------------------------------------------|
| <b>1</b> All          | Lists the all call history.                                                 |
| <b>2</b> Dialed       | Lists the calls that you made.                                              |
| <b>3</b> Received     | Lists the calls that you have received.                                     |
| <b>4</b> Missed       | Lists the calls you missed.                                                 |
| <b>5</b> Call History | Displays all of your call history. Select from the list to dial the number. |
| <b>6</b> Download     | Downloads the call history information from your mobile phone.              |

### **i** Information

- In some mobile phones, call records may not be added to your Call History.
- Calls from restricted ID's are not added to your Call History Information.
- Up to 50 calls can be added in each Dialed Calls/Received Calls/Missed Calls list.
- The durations of each dialed/received call are not displayed in your car's Call History list.
- While the call history download is in progress, the status bar displays an icon (📶).
- If the call history download is turned off on the Bluetooth device, the call history download will fail.
- Some devices require a device authentication for downloading your call history. If download fails, check if the Bluetooth settings or display status are normal.
- Some devices do not support call history download. Check if your Bluetooth device supports download feature. For details regarding Bluetooth-supported devices and their functional compatibility, visit <http://www.kia.com>

## Contacts

Press the **PHONE** key, and then **Contacts**.



| Name                   | Description                                                    |
|------------------------|----------------------------------------------------------------|
| <b>1</b> Contacts List | The list of Contacts. Select from the list to dial the number. |
| <b>2</b> Download      | Downloads contacts from your mobile phone.                     |
| <b>3</b> Search        | Searches Contacts.                                             |


### **i** Information

- Up to 5000 phone numbers can be downloaded from a single, paired Bluetooth device.
- You cannot edit or delete downloaded phone numbers from your car.
- Contacts can be viewed only when the Bluetooth device is connected.
- Even if the Bluetooth device is disconnected, the downloaded data will remain. (Note that deleting a paired phone will also delete all downloaded Contacts and Call History data)
- Downloaded phone numbers may be lost depending on the condition of the head unit. Keep your important data in a safe place.
- Contacts from both the SIM card and your mobile phone are downloaded at the same time by default.
- The status bar displays a  while downloading contacts.
- The download will not be available if the contacts download function is turned off on your Bluetooth device.

- Some devices require a device authentication for downloading your contacts. If download fails, check your phone screen and confirm the download if necessary.
- Some devices do not support contacts download feature. Check if your Bluetooth device supports contacts download. For Bluetooth supporting devices details and compatibility, visit <http://www.kia.com>

## Favorites

Press the **PHONE** key, and then **Favorites**.



| Name                  | Description                                                                          |
|-----------------------|--------------------------------------------------------------------------------------|
| <b>1</b> Favorites    | Lists the phone numbers saved as Favorites. Select from the list to dial the number. |
| <b>2</b> Add New      | Adds a new number to Favorites.                                                      |
| <b>3</b> Delete Items | Deletes numbers that you select from Favorites.                                      |
| <b>4</b> Delete All   | Deletes all of the numbers from Favorites.                                           |

MEMO



## part.4 UVO eServices

The 911 Connect feature may not operate in the following situations

About UVO eServices

Before using UVO eServices

Connecting Bluetooth

Pair a device from Bluetooth-enabled phone

Connecting to smartphone via USB

911 Connect

Roadside Assist

Vehicle Diagnostics

My Car Zone

Parking Minder

eServices Guide

## The 911 Connect feature may not operate in the following situations

- ❑ When the vehicle ignition is not turned on.
- ❑ When the phone Bluetooth® feature is set to off.
- ❑ When the phone Bluetooth® cannot be connected or becomes disconnected.
- ❑ When there are no phones paired with the vehicle.
- ❑ When cellular service is unavailable.
- ❑ When the power turns off due to phone power (battery) issues.
- ❑ When a Bluetooth® device without phone feature support has been connected, such as an MP3 device.
- ❑ When the system is booting.
- ❑ When the system power supply is unstable.
- ❑ When the attempted call is blocked due to user operations.
- ❑ When the 9-1-1 call is unstable due to phone or other communication network issues.
- ❑ When the call feature is not operating due to phone settings set by the user.
- ❑ When the phone cannot be controlled via Bluetooth® due to phone specifications or characteristics.

## Using UVO eServices and Precautions

❑ Download the UVO eServices App and install it on your smartphone.  
The app can be downloaded from your smartphone's app store.

❑ For using UVO eServices call features such as 911 Connect, Roadside Assist and eServices Guide, a smartphone must be connected with the vehicle via Bluetooth. Pair and connect your smartphone with the vehicle. For information on connecting your Bluetooth device, refer to the smartphone user's manual and instructions on the Phone Help screen on your radio. Up to five Bluetooth devices can be paired to the vehicle and only one device can be connected at a time.

❑ For using data communication of Vehicle Diagnostics, Parking Minder, and My Car Zone, smartphone must be connected with the vehicle via USB cable.

※ The use of genuine cable is recommended. (The use of other products may result in abnormal or non-proper operation.)

❑ Login and activate the UVO eServices App on your smartphone.

❑ Some UVO eServices features will only be available when your smartphone is connected with the vehicle via USB and the UVO eServices App is running.

❑ UVO eServices may not operate properly with incompatible smartphones. To view the list of compatible smartphones, please visit [MyUVO.com](http://MyUVO.com)

❑ Communication between the vehicle and smartphone app may temporarily disconnect depending on the phone state.

❑ If the feature is not operating properly, you may need to reset the UVO eServices App or the smartphone and try again according to the following steps.

1. Try feature again in the Head Unit
2. Restart smartphone app
3. Re-connect Bluetooth and USB cable
4. Reset smartphone
5. Delete Device and pair again

❑ Some services use the customer's mobile phone data plan for data communication. Therefore, the features will function in accordance with the cellular plan.

❑ Use of the most up-to-date app version is recommended.

❑ For smartphone related inquiries, please visit [MyUVO.com](http://MyUVO.com).

## About UVO eServices

UVO eServices provides the following features through Bluetooth and/or USB connection to your smartphone.

| Name                         | Connection | Description                                                                                                                                                                                                                      |
|------------------------------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> 911 Connect         | BT         | If an airbag deploys, your vehicle automatically initiates a call to 9-1-1 and sends your vehicle's location information to the 9-1-1 operator.                                                                                  |
| <b>2</b> Roadside Assist     | BT & USB   | If a diagnostic issue exists, you can connect with a Roadside Assist.                                                                                                                                                            |
| <b>3</b> Vehicle Diagnostics | USB        | Informs you if there is a diagnostic issue found in your vehicle. If an issue is found, you can contact a call center through Roadside Assist or reserve an appointment with your preferred Kia dealer through Schedule Service. |
| <b>4</b> My Car Zone         | USB        | Keeps track of predefined triggered alerts such as Speed Alert and Curfew Limit Alert from the My Car Zone feature.                                                                                                              |
| <b>5</b> Parking Minder      | USB        | Saves the location of your parked vehicle on your UVO eServices smartphone app. You can check where your vehicle is parked through the UVO eServices App on your smartphone.                                                     |
| <b>6</b> eServices Guide     | BT         | Receive guidance on how to use UVO eServices.                                                                                                                                                                                    |

### **i** Information

- 24-hour Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth within the cellular service coverage area is required.

To use UVO eServices, the following conditions must be met.

1. The UVO eServices smartphone app must be installed and you must log in using your MyUVO account credentials.
2. The smartphone must be connected via Bluetooth and USB cable to the vehicle.
3. Once this is complete, eServices must be activated.

## Before using UVO eServices

Installing the UVO eServices App on your smartphone

1. Download and install the UVO eServices App on your smartphone.

The app can be downloaded from the Apple App Store or Google Play.

2. Register your vehicle and account at MyUVO.com

Note: MyUVO.com is accessible from your phone's browser.

3. Start the UVO eServices App on your smartphone and log in.

## Connecting Bluetooth

Press the  key on the steering wheel or press the **PHONE** key on the head unit. Press **SETUP** ► **Bluetooth** ►


**Bluetooth Connection**



## Pair a device from Bluetooth-enabled phone

1. Turn on the Bluetooth feature on your smartphone's Bluetooth settings screen.
2. Search Bluetooth devices on your smartphone.
3. Select the Vehicle Name on the phone that matches the name shown on the screen.
4. Verify the passkey shown on the touchscreen.

If the phone supports SSP, check the passkey on your Bluetooth® device and confirm the authentication.



## Connecting to smartphone via USB



1. Connect your smartphone with the vehicle via USB cable.

### NOTICE



- For smartphone related inquiries, please visit [MyUVO.com](http://MyUVO.com).

## Activating UVO eServices

Press the **UVO** key, then press the **Vehicle Diagnostics** or **My Car Zone** or **Parking Minder** button.



Press the **Yes** button, then the UVO eServices activation process will begin.



### NOTICE

- Before activating UVO eServices, ensure your phone is connected to the vehicle via USB cable.

# 911 Connect


## 911 Connect

If an airbag deploys, your vehicle automatically initiates a call to 9-1-1 and sends your vehicle's location information to the 9-1-1 operator.

The 911 Connect feature is available only when the mobile phone is connected via Bluetooth.

By default, this feature is turned off. To turn it on, you must turn it on in the eServices Settings menu. By enabling this feature, you are agreeing to the 911 Connect terms of use.

A (📶) icon is displayed at the top of the touch screen as shown below when phone is connected to UVO eServices system via Bluetooth and the 911 connect feature is turned on.



## Initiating a 911 Call


If an airbag deploys, the following screen is displayed and a call is automatically placed to 9-1-1 after 10 seconds.




Once a call is connected with a 9-1-1 operator, it is possible to request emergency services to be dispatched to your location.



The 9-1-1 operator may request information on the current location of your vehicle. When the 9-1-1 operator requests your vehicle location, “Sending Location” is displayed on the screen and the vehicle location is automatically sent to the 9-1-1 operator.



When the 9-1-1 operator attempts to talk to the driver again, the call time is displayed and allows the driver to speak with the 9-1-1 operator.




## Roadside Assist

### Roadside Assist

If there is any issues in the vehicle, you can connect with a Roadside Assist agent. The Roadside Assist feature can be used only when your phone is connected via Bluetooth.

Press the **UVO** key ► **Roadside Assist**.




# Vehicle Diagnostics

## Conducting Vehicle Diagnostics


Vehicle Diagnostics is available only when the ignition is turned on and the vehicle is parked.

It also requires that UVO eServices is activated, and the Phone is connected via USB cable before starting Vehicle Diagnostics.

Press the **UVO** key ► **Vehicle Diagnostics**.



The Vehicle Diagnostics process will begin. When a diagnostics check is in progress, keep the vehicle in park with the ignition on. To cancel diagnostics, press the **Cancel** button on the touch screen or any hardkey.




If diagnostic issues are found, press the **Send Report** button to send to your MyUVO account or press the **Schedule Service** button to schedule an appointment with your preferred or nearby Kia dealer.


## Schedule Service

When scheduling an appointment using the **Schedule Service** button, pressing the **Preferred** button will allow you to request an appointment with your preferred Kia dealer and send your vehicle's diagnostics information.


Pressing the **Nearest** button will allow you to request an appointment with the nearest Kia dealer and send your vehicle's diagnostics information.



Press the **Preferred** or **Nearest** button.




Request an appointment with Preferred or Nearest Kia Dealer and send your vehicle's diagnostics data.



## Send Report

Press the **Send Report** in the vehicle diagnostics result screen.




Vehicle Diagnostics Data is transmitted to your account and you can see the report on MyUVO.com



Even if diagnostic issues are not found after Vehicle Diagnostics, it is recommended that you send the diagnostic results to your MyUVO account.


Press the **Send Report** button to send the diagnostics results to your MyUVO account.




## Scheduled Diagnostics

If you have set up Scheduled Diagnostics on your UVO eServices App, a vehicle diagnostics check will automatically start on the day you selected.

On the date of the Scheduled Diagnostics, the following window will be displayed.



Press the **Yes** button on the touch screen to proceed with diagnostics.




Press the **Send Report** button to see the Vehicle Health Report on MyUVO.com.



## Automatic Diagnostics

If a critical diagnostics issue with your vehicle's powertrain is detected, Automatic Diagnostics will be notified.



### NOTICE

- The screen messages differ based on the vehicle diagnostics severity. Ensure your phone is connected to the system via USB cable before using **Schedule Service** and **Send Report**.

## My Car Zone

My Car Zone is a feature that provides alerts and driving history for Curfew Limit Alerts and Speed Alerts set by the user.

| Name               | Description                                                                                                |
|--------------------|------------------------------------------------------------------------------------------------------------|
| Curfew Limit Alert | Curfew Limit Alerts are alerts that are triggered when a driver is driving within a predefined time range. |
| Speed Alert        | Speed Alerts are alerts that are triggered when a driver exceeds the predefined maximum speed.             |

My Car Zone features are supported only when UVO eServices has been activated.

Press the **UVO** key ► **My Car Zone**


### Curfew Limit Alerts History




### Speed Alerts History



### Curfew Limit Alert



### Speed Alert



### Curfew Limit Alert

You can check the Curfew Limit Alert history for a list of past triggered curfew alerts.



| Name           | Description                                                            |
|----------------|------------------------------------------------------------------------|
| 1 Phone        | Name of phone connected upon triggered curfew limit                    |
| 2 Alert Time   | Initial alert time                                                     |
| 3 Duration     | Total duration of driving while curfew limit was triggered             |
| 4 Driving Time | Total driving time from turning ignition on until turning ignition off |

### Speed Alert

You can check the Speed Alert history for triggered speed limit alerts of the vehicle.



| Name         | Description                                                                 |
|--------------|-----------------------------------------------------------------------------|
| 1 Phone      | Name of phone connected upon triggered speed limit alert                    |
| 2 Max. Speed | Maximum vehicle speed upon triggered speed limit alert                      |
| 3 Alert Time | Time from first triggered alert until last triggered alert                  |
| 4 Duration   | Total triggered alert time from turning ignition on to turning ignition off |

To check My Car Zone alert history from your smartphone, you must first send the alert history to your MyUVO account.


## Parking Minder

### Sending Parking Location


The location where your vehicle is currently parked can be sent to your smartphone.

Ensure that your smartphone is connected via USB and the UVO eServices App is running before using this feature.

After parking the vehicle, press the **UVO** key ► **Parking Minder** to send the vehicle's location to your smartphone.



Once the parking location has been sent, you can view your vehicle's location from the UVO eServices App on your smartphone.



### NOTICE

- When the parking location is being sent, do not drive the vehicle. Ensure that you have logged into the UVO eServices App, and your phone is connected to the multimedia system via USB cable.
- When ignition is turned off while the phone is connected via USB, Parking Minder can be transferred automatically if the option is set up in UVO eService Settings


# eServices Guide

## eServices Guide

eServices Guide provides guidance on how to use UVO eServices.

This feature is only available when the mobile phone is connected via Bluetooth.

Press the **UVO** key ▶ **eServices Guide**



## UVO eServices Settings

Refer to **SETUP** key ▶ **UVO eServices**.

MEMO

# part.5 Voice Recognition

What is Voice Recognition?

Precautions Required for Successful Voice Recognition

Starting/Ending and Setting Voice Recognition

Voice Recognition Screen Overview

Voice Commands

Siri Eyes Free

# Voice Recognition

## What is Voice Recognition?

The voice recognition feature operates the multimedia system by recognizing voice commands and enables hands-free operation of the system while you are driving your car.

Not all possible voice commands are recognized by the system due to technological limitations. To make up for these limitations, the system displays the voice commands that are available for you to use.

There are errors in communication between people. Likewise, voice recognition sometimes misunderstands your voice command in some circumstances. If this happens, either check the screen for the available options and say the command again, or manually select and press the button for the corresponding command on the screen.

## Precautions Required for Successful Voice Recognition

1. Voice recognition supports only the commands that are displayed on the screen and written in the User's Guide.
2. To ensure the correct recognition and execution of your command, say your command when you hear the beep after a voice prompt.
3. Voice recognition automatically ends if:
  - 1) A call is incoming or outgoing
  - 2) A media device (USB or iPod, etc.) is connected or disconnected
  - 3) The rear view camera is operated
  - 4) The car engine starts or stops
  - 5) A system key, such as **RADIO** key or **MEDIA** key is selected
4. The microphone used for the voice recognition system is located in the headliner directly above the driver's head. To make your commands better understood, keep your body straight in the driver's seat when speaking the command.
5. Speaking naturally and clearly will ensure better recognition of your voice commands.
6. In the following cases voice recognition will be affected by ambient noise.
  - 1) The sound of the wind if any window or the sun roof is open.
  - 2) High speed blower from the air vents. Set climate control to blow lower than level 3.
  - 3) Vibrations from passing through a tunnel.
  - 4) Vibrations from driving on an uneven road.
  - 5) Storms and heavy rain.

## Starting/Ending and Setting Voice Recognition


### Starting Voice Recognition

Press the  key briefly (less than 0.8 seconds) on the steering wheel control to activate voice recognition.



### Ending Voice Recognition

1. Select "Exit" to the left of the bottom to end voice recognition.
2. Press and hold (more than 0.8 seconds) the  key on the steering wheel control to end voice recognition.




### Combining Voice Recognition with On-Screen Commands

After pressing the  key, say a command after the beep. The voice recognition system will execute the desired operation after understanding the command.

Alternatively, you may touch any of the corresponding Commands on the screen while the Voice Recognition system is in operation.


Combining voice recognition with available on-screen commands is useful when the system is taking longer than expected or the voice command did not execute as desired.



## Extending the Listening Time

When the system is waiting for your command, after the voice prompt and beep have been heard, if you press the  key (less than 0.8 seconds), then the beep will sound again and standby mode will restart.

When activated, voice recognition waits for your command for 5 seconds. If you say nothing for 5 seconds, a voice prompt will ask for your command again.



---

## Skiping Prompt Messages

---

When you hear the prompt message, press the  key on the steering wheel control to skip the message and go directly to listening mode to say your command.


This results in faster operation when you feel the message is too long or you already know the command to use.

---

### Information

---

- Refer to Part 8 for instructions on how to change the Voice Recognition Settings.
- 



---

## Adjusting Voice Recognition Volume


---

During voice recognition, rotate the volume knob to adjust the message volume.



# Voice Recognition Screen Overview


## Start Screen



| Name                      | Description                                                                                                                                                                                                                |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Representative Commands | Displays the representative commands.                                                                                                                                                                                      |
| 2 Not available command   | Displays commands that are not available due to a failure in meeting the conditions for using them and thus need additional settings. The conditions required for using them will be described briefly under each command. |


| Name                                      | Description                                                                                                  |
|-------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| 3 Voice recognition status icons          | <ul style="list-style-type: none"><li>Standby</li><li>Voice guidance</li><li>Voice command process</li></ul> |
| 4 Recognized results                      | Displays the voice recognition result.                                                                       |
| 5 User's speaking volume being recognized | Displays the voice command volume in real time.                                                              |
| 6 Help                                    | Displays all available help commands in a tree format.                                                       |
| 7 Exit                                    | Ends the voice recognition.                                                                                  |

## Help Display



| Name                           | Description                                                                                                                                             |
|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Command list                 | <ul style="list-style-type: none"><li>Shows the available commands.</li><li>Select or say a command to display additional commands in detail.</li></ul> |
| 2 How to use for selected item | This section shows how to use voice recognition for the selected item.                                                                                  |
| 3 How to use in general        | This section displays how to use voice recognition in general.                                                                                          |

# Instructions for Using Voice Recognition



| Name                 | Description                                                    |
|----------------------|----------------------------------------------------------------|
| 1 Detail instruction | This section describes how to use voice recognition in detail. |
| 2 Close button       | Closes the screen and restarts voice recognition.              |

## Information

- In the instructions screen, no voice is recognized, so you must manually issue commands. Because the instructions screen displays a lot of content, you cannot view it while driving for safety precautions.

# Voice Commands

## Types of Commands

Voice recognition commands are classified as “Global Commands” and “Local Commands”.

- 1. Global Commands (●): Commands that can be used immediately after activating voice recognition.
- 2. Local Commands (○): Commands that can be used when a multimedia or Bluetooth function is running, or displayed on the screen, after activating voice recognition.

## Call Commands

\* Check the following before using call commands:

- 1. Voice commands related to phone calls can be used after connecting a Bluetooth device.
- 2. To call a person, for example “Call <John Smith>” whose name is listed in Contacts, you must first download the Contacts list. For details on downloading contacts, see “Part 3. Bluetooth > Chapter 3. Bluetooth Phone > 3.10 Contacts”.
- 3. After downloading the Bluetooth contacts, it will take some time to convert the Contacts into voice data during which time you cannot make a call by name yet. The time it takes to convert voice data may vary depending on the number of Contacts downloaded on the phone.

| Command |                       | Operation                                                                                                                                                                 |
|---------|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ●       | Call                  | Displays downloaded Contacts, after this you can make a call by saying the name.                                                                                          |
| ●       | Call <Name>           | You can directly call a person by <Name> in the downloaded Contacts.                                                                                                      |
| ●       | Call <Name> on Mobile | You can call a person <name> directly to the number that is saved as “Mobile” in the downloaded Contacts.<br>e.g.) Call “John Smith” on Mobile                            |
| ●       | Call <Name> at Work   | You can call a person <name> directly to the number that is saved as “Work” in the downloaded Contacts.<br>e.g.) Call “John Smith” at Work                                |
| ●       | Call <Name> at Home   | You can call a person <name> directly to the number that is saved as “Home” in the downloaded Contacts.<br>e.g.) Call “John Smith” at Home                                |
| ●       | Call <Name> on Other  | You can call a person <name> directly to the number that is saved as “Other” than “Mobile, Home, or Work” in the downloaded Contacts.<br>e.g.) Call “John Smith” on Other |
| ●       | Dial Number           | Displays a screen where you can say a phone number to dial.                                                                                                               |
| ●       | Dial <Phone #>        | You can directly say the number to call.<br>e.g.) Dial 111 555 1234                                                                                                       |
| ●       | Redial                | Directly calls at the number that you last dialed.                                                                                                                        |
| ●       | Call History          | Displays your Call History, where you can say the list number to make a call.                                                                                             |

## Radio Commands

| Command |                     | Operation                                                                                                          |
|---------|---------------------|--------------------------------------------------------------------------------------------------------------------|
| ●       | Radio               | Plays the most recent radio channels from FM, AM, and SiriusXM™.                                                   |
| ●       | FM                  | Plays FM radio.                                                                                                    |
| ●       | FM<br><87.5~107.9>  | Tunes to FM <Frequency> according to what you say.<br>e.g.) FM 87.5: FM eighty seven point five                    |
| ●       | SiriusXM            | Plays SiriusXM™ radio.                                                                                             |
| ●       | SiriusXM<br><0~999> | Tunes to SiriusXM™ Channel <Channel Number> according to what you say.<br>e.g.) SiriusXM 23: SiriusXM Twenty three |
| ●       | AM                  | Plays AM radio.                                                                                                    |
| ●       | AM <530~1710>       | Tunes to AM <Frequency> according to what you say.<br>e.g.) AM 530: AM Five thirty                                 |
| ○       | Preset <1~40>       | Tunes to your preset stations (1 to 40).                                                                           |
| ○       | Channel<br><0~999>  | In SiriusXM™ Radio mode, turns on the <Channel Number> that you say.                                               |

## Media Commands

\* Check the following before you use media commands.

1. If no media is connected or if no playable files exist at the time when you use these commands, a voice message will tell you that this is not available.
2. If you say the name of the media that is currently playing again, then that media will continue playing.  
e.g.) Saying “USB” while USB content is playing.

| Command |                 | Operation                                                                                                                                                   |
|---------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ●       | Music           | Continues the last media you played.                                                                                                                        |
| ●       | iPod            | Plays the iPod currently connected. This will work the same when an iPhone is connected. If a USB is connected, then it will be played instead of the iPod. |
| ●       | USB             | Plays the music on the USB currently connected.<br>If an iPod is connected, then the iPod will be played instead of the USB.                                |
| ●       | Bluetooth Audio | Plays the music on the Bluetooth phone currently connected.<br>This may not be supported depending on the Bluetooth connection status.                      |
| ●       | AUX             | Plays external devices that are currently connected.                                                                                                        |
| ●       | My Music        | Plays My Music files stored in the system.                                                                                                                  |

## 1. USB Music/iPod/My Music Command

| Command |             | Operation                                                                                                        |
|---------|-------------|------------------------------------------------------------------------------------------------------------------|
| ○       | Play        | Plays a selected file.<br>Maintains the current settings during playback.                                        |
| ○       | Pause       | Pauses a file that is playing.<br>Maintains current settings while paused during playback.                       |
| ○       | Shuffle     | Plays tracks or files randomly.<br>Maintains current settings during shuffled playback.                          |
| ○       | Shuffle Off | Cancels Shuffle and plays tracks sequentially.<br>Maintains current settings during sequential playback.         |
| ○       | Repeat      | Plays the current track or file repeatedly.<br>Maintains the current settings during repeat playback.            |
| ○       | Repeat Off  | Cancels Repeat and plays multiple tracks or files.<br>Maintains current settings during multiple track playback. |

## 2. Bluetooth audio/AUX Command

For Bluetooth audio and external devices (AUX), local commands are unavailable, including Play, Pause, Repeat and Shuffle.

## UVO eServices Commands List

| Command |                     | Operation                                                  |
|---------|---------------------|------------------------------------------------------------|
| ●       | Roadside Assist     | Connect with a Roadside Assist agent.                      |
| ●       | Vehicle Diagnostics | Informs you if diagnostic issues are found in your vehicle |
| ●       | eService Guide      | Provides guidance on how to use UVO eServices              |

## Other Commands List (Commands used in List/Help)

| Command |                     | Operation                                                                                                                                                                       |
|---------|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ●       | Help                | Moves to the voice recognition help screen. All available commands can then be identified and used.                                                                             |
| ○       | Line 1~4 (One~Four) | When you cannot select a certain name, such as in Call History, you can select it using numbers. Simple numbers can be recognized, such as "One" or "Two".                      |
| ○       | Yes/No              | When voice recognition is activated, this command is used when an answer is requested for a confirmation question.                                                              |
| ○       | Previous/Next       | When four or more searched items are listed, you can move to the previous or next page using a voice command.                                                                   |
| ○       | Manual Input        | When Dial entry results are displayed, this command is used to search manually, rather than to search with a voice command. Voice recognition stops after this command is used. |
| ○       | Go Back             | Moves to the previous screen.                                                                                                                                                   |
| ●       | Exit                | Ends the voice recognition.                                                                                                                                                     |

# Siri Eyes Free

---

## How to start Siri

---

If you want to use Siri, you have to connect your iOS device to the Multimedia system through Bluetooth.

(Please check whether your iOS device supports Siri and turning Siri On)


Then you can use Siri while pressing and holding  key on the steering wheel.

---

## How to use Siri

---

When you access the Siri screen while pressing and holding  key on the steering wheel, you select the  button and then you can speak what you want. Note that the Multimedia system only supports “Phone” related functions. Other functions will be performed in your iOS device. If you press voice key quickly, Siri would re-start. If you hold down voice key, Siri would be terminated and the screen would go back to the previous screen. Eyes-Free mode would be activated automatically while you are driving. When shifting gears into P or putting the Parking brake on, Eyes-Free mode would be deactivated automatically.



---

### Information

---

- Functions and feedbacks from voice commands via Siri are executed in the iOS device. If the iOS version is changed, the functions and response may be different according to the iOS device and the latest version.
-

MEMO

# part.6 Apps/Info

SiriusXM™ Data

# Apps/Info

## SiriusXM™ Data

### About SiriusXM™ Data Service

The SiriusXM™ Data Service is a paid membership satellite radio service that provides users with information such as Weather, Sports, Stocks, Fuel Prices and Movies.

However, weather information is not supported for vehicles purchased in Canada.

### Accessing SiriusXM™ Data

Select the **SiriusXM Data** icon after selecting All Menus or the

**APPS/?** key to enter the SiriusXM™ Data mode.



## SiriusXM™ Weather Announcement

At the “SiriusXM Data” screen, select the **Weather** icon to enter the Weather Announcement mode.



### Weather Forecast

This service provides current weather information and weather forecasts for the next five days in your region. To change the region, select the **Other City** button and select the desired region.



### Warnings and Advisories


This service provides weather warnings and advisories, such as tornado, storm, flood, etc.



## SiriusXM™ Sports Information

Select the **Sports** icon to enter the Sports mode.

This service provides real-time updated information on scores and schedules for major sports, such as NFL, NBA, NCAA football, NCAA basketball, NHL, MLB, NASCAR and more.





## My Teams


You can save teams which you are interested in as part of My teams to easily view related scores and schedules.

Select the My Teams menu and then select the **Add** button to search for and register your favorite teams.



Search for your favorite teams and select the ☆ button on the right to add it to the “My Teams” list.



You can always check the list of teams that you added in the “My Teams” menu. Select the ☆ button on the right side of the team name to delete the team from “My Teams” or select the **Add** button to add other teams.



Select the team name to check daily results and recent schedules for that team.



## SiriusXM™ Stock Information

In the “SiriusXM Data” screen, select the


**Stocks** icon to enter the Stocks mode.

Stocks is a feature that shows the current value and change of stocks.

For symbols which you are interested in, select the icon to save the symbol as a part of the “Saved” symbols which can be viewed from the “My Favorites” button on the Stocks Main screen.

## My Favorites


My Favorites shows a list of stocks added by the user. When entering the Stocks menu for the first time, a screen is displayed for you to add your favorite stock information. Select the **Add** button to move to the stock search screen.




## Stock Search

Use the Stock Search menu to search for specific stocks.

Select the ☆ button after searching for your favorite stocks to save them in “My Favorites”.




In the My Favorites screen, you can find the selected stock information that you registered.



## SiriusXM™ Fuel Price Information

At the “SiriusXM Data” screen, select the **Fuel Prices** icon to enter the Fuel Prices Information mode.




### Search for Nearby Stations, and Register Key Locations as Favorite Stations.

Search for nearby stations with the “Nearby Stations” menu.

It shows station locations, starting from the nearest one, and select “Nearest” menu on the top right side to further sort them by price or brand name.




Select the  button to the right of the list to register key locations as a Favorite Station so that you can go there again with the “Favorite Stations” menu.



## My Fuel Type Settings

With the “Filters” menu, you can select fuel types and favorite brands.


When searching for Nearby Stations, the results will reflect selected fuel types and brand information.



## SiriusXM™ Movie Information

Select the **Movies** icon to enter the Movie mode.



You can check recent movies and nearby theaters, and also register your favorite theater locations.





## Search for Nearby Theaters, and Register Any Key Locations as Favorite Theaters.

In the “Nearby Theaters” menu, you can search for any nearby theaters.

It shows theaters, starting from the nearest one, and selecting the “Nearest” menu at the top right side will sort them by name.



Select the  button to the right of the list to register your favorite theater so that you can always check it again using the “Favorite Theaters” menu and selecting the  button to view the current movie information for that theater.



In the “Top Movies” menu, you can check for any movies that are currently popular. Select the  button to the right of a movie title to view the plot summary and any other detailed information.



MEMO

# part.7 Other Features

Climate Mode

Camera

# Other Features


## Climate Mode

### Operating Climate Mode

Press the **CLIMATE** key for the climate system to see status information in the full screen display.

While multimedia or navigation is in use, the climate system information will be displayed over top when you control the temperature (TEMP) or turn on the air conditioner (A/C).

### Basic Mode Screen



| Name                                                                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Set the temperature of the driver's seat and passenger seats | Displays the configured temperature settings for the driver's seat and the passenger seats. Cooling or heating will continue until the temperature matches the configured temperature settings.<br><b>i</b> The internal temperaure can be controlled in incrmnts of 1°F within a range of 63°F to 89°F.<br><b>i</b> LOW is displayed when the temperature is set to anything below 63°F, and HIGH is displayed when it is set to anything above 89°F.         |
| <b>2</b> Air direction                                                | Displays the configured air direction settings.                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>3</b> Air volume                                                   | Displays the configured air volume settings                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>4</b> Cooling/heating control status (AUTO)                        | Displayed when the <b>AUTO</b> key is pressed and cooling/heating operates automatically according to the configured temperature settings.<br><b>i</b> AUTO will be turned off when you try to do the following with AUTO on: <ul style="list-style-type: none"><li>- Control the air volume</li><li>- Control the air direction</li><li>- Turn the air conditioning (A/C) on/off</li><li>- Turn on the moisture removal function for the windshield</li></ul> |
| <b>5</b> Air conditioning control status                              | Displayed when the <b>A/C</b> key is pressed and the air conditioning starts cooling/heating.                                                                                                                                                                                                                                                                                                                                                                  |



| Name                                                                                     | Description                                                                                                                                  |
|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 6 Simultaneous temperature settings for the driver's seat and the passenger seats (SYNC) | Displayed when the SYNC key is pressed and the temperatures of the driver's seat and the passenger seats can be configured at the same time. |

# Camera

## ⚠ WARNING

### - Backing Up & Using Camera

- Never rely solely on the rear view camera when backing up. Prior to entering your vehicle always do a visual check of the area behind your vehicle, and before backing up be aware of your surroundings and supplement the rear view camera by looking over your shoulders and checking your rear view mirrors. Due to the difficulty of ensuring that the area behind you remains clear, always back up slowly and stop immediately if you even suspect that a person, and especially a child, might be behind you.

## i Information


- A separate chipset is used for the camera screen while booting up, so it may be different after booting up.

## Steering-linked camera

- This device is connected to a rear detection camera to see behind the car for safe reversing.
- The Rear View Camera turns on automatically if you shift the gear to R when the power is on or the engine has started.
- While the device boots up, shift the gear to "R" to activate the rear detection cameras. Shift the gear to another position to deactivate the rear detection camera.

## 🔧 NOTICE

- A wide-angle lens is installed as the rear detection camera to get a wider view, so there may be some difference between the actual distance and the distance that appears on-screen. For safety, make sure to view the back, right, and left sides of the car for yourself.
- The color of the parking guidelines displayed in the picture may differ from the actual screen.
- When booted up, blinking may occur when you switch to a UI screen.



| Name            | Description                                   |
|-----------------|-----------------------------------------------|
| 1 Red Line      | About 0.5 m from the rear bumper              |
| 2 Yellow Line 1 | About 1 m from the rear bumper                |
| 3 Yellow Line 2 | About 3 m from the rear bumper                |
| 4 Yellow Line 3 | Trajectory of the wheel on the driver's side  |
| 5 Yellow Line 4 | Trajectory of the wheel on the passenger side |
| 6 Blue Line     | Neutral steering trajectory                   |

As you reverse your car and monitor the area behind your car, the steering-linked driving trajectory and the neutral driving trajectory are both displayed.

# part.8 Setup

- Setup
  - Sound Settings
  - Display Settings
  - Bluetooth Settings
  - UVO eServices Settings
  - Home Screen Settings
  - Clock Settings
  - Voice Recognition Settings
  - Language Settings
  - Keyboard Settings Screen
  - Saver Settings System Info

# Setup

## Setup

Setup is the screen to control Audio system settings.

To enter the screen, press the **SETUP** key or the **Setup** icon in All Menus.




| Features                  | Description                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------------------|
| <b>1</b> Sound            | Provides the sound control options for Position, Bass, Mid, Treble, Volume and Advanced settings.           |
| <b>2</b> Display          | Provides the Mode/Illumination settings.                                                                    |
| <b>3</b> Bluetooth        | Provides the Bluetooth Connection/Auto Connection Priority/Bluetooth System Information settings.           |
| <b>4</b> UVO eServices    | Provides the 911 Connect/Parking Minder/My Car Zone/Scheduled Diagnostics/Trip Info Sync Reminder Settings. |
| <b>5</b> Phone projection | For more details, refer to Phone projection guide.                                                          |
| <b>6</b> Home Screen      | Provides the function to customize the three menu items at the bottom of the Home Screen.                   |



| Features                     | Description                                            |
|------------------------------|--------------------------------------------------------|
| <b>7</b> Wi-Fi (Not support) | Provides the Wi-Fi On and Network Connection settings. |
| <b>8</b> Clock               | Provides the Time and View settings.                   |
| <b>9</b> Voice Recognition   | Provides the Guidance and Priority settings.           |
| <b>10</b> Language           | Provides the Change Language settings.                 |
| <b>11</b> Keyboard           | Provides settings to switch keyboard layouts.          |
| <b>12</b> Screen Saver       | Provides the Clock/None settings.                      |
| <b>13</b> System Info        | Provides software and storage space information.       |
| <b>14</b> Display Off        | Provides the Display Off (touch activation) function.  |

# Sound Settings

Adjusts the sound effects for the whole system.



| Features   | Description                                                                                                                                |
|------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Position | Select the Up/Down/Left/Right button to control sound positioning. Select <b>Center</b> to concentrate the sound on the center of vehicle. |
| 2 Tone     | Drag the slide bar to control bass/mid/treble settings. Select <b>Center</b> to initialize the settings.                                   |


| Features   | Description                                                                                                                                                            |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3 Advanced | Select additional audio options such as “Speed Dependent Volume Control” that automatically controls Audio volume according to vehicle speed as well as “Variable EQ”. |
| 4 Default  | Resets the sound to factory default settings.                                                                                                                          |
| 5 Beep     | Select to activate a beep when pressing buttons.                                                                                                                       |

## i Information

- Advanced sound settings may differ according to selected AMP option.
- The seat shape may differ according to vehicle model.

# Display Settings

Adjusts the level of illumination for the entire system.




| Features       | Description                                                                                                    |
|----------------|----------------------------------------------------------------------------------------------------------------|
| 1 Mode         | Select any of LCD illumination change modes: Automatic (changes the level automatically), Daylight, and Night. |
| 2 Illumination | Set the levels of illumination for day and night. Select <b>Default</b> to initialize the settings.            |
| 3 Default      | Resets the display to factory default settings                                                                 |
| 4 Display Off  | Provides the Display Off (touch activation) function.                                                          |

# Bluetooth Settings

Changes Bluetooth phone settings.


## Bluetooth Settings

Press the **SETUP** key ► Select **Bluetooth** icon.



## Bluetooth Connection Settings

Press the **SETUP** key ► Select **Bluetooth** ► Select **Bluetooth Connection**.



| Features                                 | Description                                                                                                       |
|------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| 1 Paired Device List                     | Displays the paired Bluetooth device list. When selecting from the list, the device is connected or disconnected. |
| 2 Bluetooth Audio Connection Status      | An icon appears when you make a Bluetooth Audio connection.                                                       |
| 3 Bluetooth Hands-Free Connection Status | An icon appears when you make a Bluetooth Hands-free connection.                                                  |
| 4 Add New                                | Register a new Bluetooth device.                                                                                  |
| 5 Delete Devices                         | Select and delete a paired device.                                                                                |
| 6 Help                                   | Switches to the Bluetooth Connection Help screen.                                                                 |


### **i** Information

- Up to 5 Bluetooth devices can be paired.
- Only one Bluetooth device can be connected at a time.
- During a Bluetooth device connection, another device cannot be paired.
- When you delete a paired device, the Call History and Contacts stored in the head unit are also deleted.
- Bluetooth Hands-free and Bluetooth Audio functions are supported.
- Hands-free and audio-supported devices, such as a Bluetooth smartphone or audio, will function normally.
- When a Bluetooth device is connected, if the Bluetooth connection is unexpectedly disconnected, due to being out of communication range, the device powering off, or a Bluetooth communication error, the Bluetooth device automatically searches for and connects to nearby Bluetooth devices.
- If the system is not stable, due to a vehicle-Bluetooth device communication error, restore the Default Factory Settings.
- For Default Factory Settings, the bluetooth settings are reset to factory settings.
- Press the **SETUP** key ► Select **Bluetooth** ► Select **Default Factory Settings**.

## Auto Connection Priority

Press the **SETUP** key ► Select **Bluetooth**

► Select **Auto Connection Priority**.




When the engine is running, the selected Bluetooth device is automatically connected. If you fail to connect the selected device, the previously-connected device is automatically connected, and if it also fails, then it tries to connect all paired devices sequentially.

Depending on auto connection priority, connection to a device may take time.

## Bluetooth System Information

Press the **SETUP** key ► Select **Bluetooth**

► Select **Bluetooth System Info**.



| Features       | Description                                                                                       |
|----------------|---------------------------------------------------------------------------------------------------|
| 1 Vehicle Name | You can change the Bluetooth device name of the vehicle.                                          |
| 2 Passkey      | You can change the passkey used for Bluetooth device authentication. the initial passkey is 0000. |

### **i** Information

- The vehicle name above is an example. Check the actual information on the product.

---

## Default Factory Settings

---


You can delete all paired devices and restore the Default Bluetooth Settings. For Default Factory Settings, all paired devices are deleted, and the system is reset to factory settings.

## UVO eServices Settings

Within the eServices Settings screen, UVO eServices related features can be set, such as activating 911 Connect, Parking Minder and setting the My Car Zone.

For safety reasons, My Car Zone Settings cannot be adjusted while driving. Park the vehicle before making any changes to your settings.

Press the **SETUP** key ► **UVO eServices**




---

## 911 Connect


---

This feature is used to turn on or off the 911 Connect feature.




When enabling this feature, you must first agree to the 911 Connect terms of use.

After reading the terms of use, press the **Agree** button on the touch screen to accept.



## Parking Minder

If you want to send vehicle location to your smartphone automatically when you turn the ignition off, turn the Parking Minder feature On.




## My Car Zone

This feature is used to set My Car Zone (Curfew Limit, Speed) alert conditions.

My Car Zone Settings is unavailable when UVO eServices has not been activated.



Press the **SETUP** key ► **UVO eServices** ► **My Car Zone**.

The PIN must be entered to use My Car Zone Settings.




This screen is used to set Curfew Limit and Speed Alert features.

Set the alert conditions On ► Settings .



### Curfew Limit Alert Settings

Within Curfew Limit Alert Settings, you can set the Curfew Limit Alert Start and End Time. You can also set the Alert Interval of alerts upon Curfew Limit.




### Speed Alert Settings

Within Speed Alert Settings, you can set the vehicle speed limit and Alert Interval of alerts upon overspeeding.



### PIN


This feature is used to change the PIN to enter My Car Zone Settings.



### NOTICE


- Before pressing Done , ensure your smartphone is connected to UVO eServices system via USB cable.

Press the **Done** button to transmit the new PIN to your My UVO com account.



## Restore Factory Settings


This feature is used to restore all My Car Zone alert history and settings back to default state.



## Scheduled Diagnostics

This feature is for setting when scheduled diagnostics alerts display.

Press **SETUP** key ► **UVO eServices** ► Set the Scheduled Diagnostics On ► **Settings**



### NOTICE

- For months without the corresponding day, the last day of the month will automatically be set as the scheduled diagnostics date.

---

## Trip Info Sync Reminder


---

Trip Info is a feature used to set whether system displays alert when trip info(Driving Distance, Driving Speed, Driving Time, etc). reaches 90% of memory.

UVO eServices must be activated to use this feature.

Press **SETUP** key ► **UVO eServices** ►


Set Trip Info Sync Reminder On



## Home Screen Settings

You can customize the three menu items at the bottom right of the Home Screen into the ones you want.

On the Home Screen Settings screen, drag the menu items on the right to the area marked in red in the screen below.



---


### **i** Information

---

- You can select the **Default** button to reset to the factory default settings.
-

# Clock Settings


Configure the settings for time and date. Using the arrow buttons, you can change the values. Clock settings do not automatically change when crossing into different time zones. The time must be changed manually on this screen.



| Features                      | Description                                                                      |
|-------------------------------|----------------------------------------------------------------------------------|
| <b>1</b> Daylight Saving Time | The daylight saving time (DST) is applied.                                       |
| <b>2</b> 24 Hours             | The time display is set in 24-hour format.                                       |
| <b>3</b> Direct entry         | If you tap any value, you can directly enter the number in the following screen. |

# Voice Recognition Settings


Configure how to make a call with Voice Recognition Guidance and Voice Recognition.



| Features          | Description                                                                               |
|-------------------|-------------------------------------------------------------------------------------------|
| <b>1</b> Beginner | For beginners, the voice recognition system provides voice prompts.                       |
| <b>2</b> Normal   | For normal users, the voice recognition system provides simple and short voice guidances. |

## Language Settings

You can configure the displayed system language.



When the language is changed, the system language is automatically changed. Unique data including MP3 file name is not changed and voice recognition does not support some languages.

## Keyboard Settings

You can configure the keyboard layout for each language.



You can configure ABCD or QWERTY keyboards for the system.

### **i** Information

- Configured keyboard layouts are applied to all input modes.

## Screen Saver Settings


You can select any of the following screen formats to be displayed when the screen or power is turned off (Press and hold the Power button).

- Digital clock and date
- Analog clock and date
- None



# System Info

At the System Info screen, software version information, updates, and storage status details are available.



| Features  | Description                                                                                                                                                                 |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 SW Info | System version information and update details are available. Select the Update button to update the system. After update is complete, the system will reboot automatically. |
| 2 Storage | Displays the memory space available for media storage.                                                                                                                      |

## System Update

At the System Info screen, insert the USB memory with the latest file downloaded, and then select the Update button to begin updating. The system will then reboot automatically.

### Information

- This product needs supplemented software updates and additional functions, which collectively may take some time to complete, depending on the amount of data.

### CAUTION

- If the power is disconnected or the USB is removed during an update, the data might be damaged. Please do not turn off the vehicle while an update is in progress.

MEMO

# part.9 Appendix

Product Specification

Troubleshooting

FAQ

# Appendix

## Product Specification

### TFT-LCD

|                   |                                         |
|-------------------|-----------------------------------------|
| Screen Size       | 7 inch(152.4 X 91.44 mm)                |
| Resolution        | 384000 pixels (Resolution: 800 x 480)   |
| Operating Method  | TFT(Thin Film Transistor) Active Matrix |
| Viewing Angle     | Left/Right, Top/Bottom: ALL 89°         |
| Internal Lighting | LED                                     |

### Radio

|                   |                                         |
|-------------------|-----------------------------------------|
| Channels          | FM: 87.5 MHz ~ 107.9 MHz(Step: 200 kHz) |
|                   | AM: 530 kHz ~ 1710 kHz(Step: 10 kHz)    |
| Sensitivity       | FM: Under 10 dBu/AM: Under 35 dBu       |
| Distortion Factor | Within 2 %                              |

### Common

|                       |                                |                     |                                 |
|-----------------------|--------------------------------|---------------------|---------------------------------|
| Name                  | Car TFT LCD Display Audio Unit |                     |                                 |
| Power Supply          | DC 14.4 V                      | Operating Power     | DC 9 V ~ DC 16 V                |
| Current Consumption   | 2.5 A                          | Sleep Current       | 1 mA<br>(Head Unit Only)        |
| Operating Temperature | -20 ~ +70 °C<br>(-4 ~ +158 °F) | Storage Temperature | -30 ~ +80 °C<br>(-22 ~ +176 °F) |
| Dimensions            | 178 X 140.2 X 60 mm (Main BOX) |                     |                                 |
| Weight                | 1.940 kg                       |                     |                                 |

### **Bluetooth® Wireless Technology**

|                    |                                                  |                                    |     |
|--------------------|--------------------------------------------------|------------------------------------|-----|
| Frequency Range    | 2402 ~ 2480 MHz                                  | Supported Bluetooth® Specification | 3.0 |
| Supported Profile  | Handsfree(1.6), A2DP(1.2), AVRCP(1.4), PBAP(1.0) |                                    |     |
| Output             | -6~4 dBm (Power Class2, Conducted)               |                                    |     |
| Number of Channels | 79 channels                                      |                                    |     |

#### **CAUTION**

- The producer and installer cannot provide services related to life safety as the concerned radio equipment is liable to radio interference.

## Troubleshooting

1. Errors which occur during the operation or installation of the device may be mistaken as a malfunction of the actual device.
2. If you are having problems with the device, try the suggestions listed below.
3. If the problems persist, contact your Kia dealer.

| Problem                                                         | Possible Cause                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| There are small red, blue, or green dots on the screen          | <ul style="list-style-type: none"> <li>• Because the LCD is manufactured with technology requiring high point density, a pixel or lighting deficiency may occur within 0.01% of total pixels</li> </ul>                                                         |
| The sound or image is not working                               | <ul style="list-style-type: none"> <li>• Has the Switch for the vehicle been turned to [ACC] or [ON]?</li> <li>• Has the SYSTEM been turned OFF?</li> </ul>                                                                                                     |
| The screen is being displayed but sound is not working          | <ul style="list-style-type: none"> <li>• Has the volume been set to a low level?</li> <li>• Has the volume been muted?</li> </ul>                                                                                                                               |
| When the power is turned on, the corners of the screen are dark | <ul style="list-style-type: none"> <li>• The display appearing somewhat dark after prolonged periods of use is normal with LCD panels. It is not a malfunction</li> <li>• If the screen is very dark, contact your nearest Kia dealer for assistance</li> </ul> |
| Sound is working from only one speaker                          | <ul style="list-style-type: none"> <li>• Are the positions of Fader or Balance sound controls adjusted to only one side?</li> </ul>                                                                                                                             |

| Problem                                                             | Possible Cause                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sound does not work in AUX mode                                     | <ul style="list-style-type: none"> <li>• Are the audio connector jacks fully inserted into the AUX terminal?</li> </ul>                                                                                                                                                                                                                                                                                                                                                              |
| The external device is not working                                  | <ul style="list-style-type: none"> <li>• Is the external device connected with a standard connector cable?</li> </ul>                                                                                                                                                                                                                                                                                                                                                                |
| Upon turning power on, the most recent mode screen is not displayed | <p>Within modes that play files by reading external sources, such as USB, iPod, or Bluetooth® streaming mode, the most recently played mode screen prior to turning off power may not properly load</p> <ul style="list-style-type: none"> <li>• If the corresponding device is not connected, the mode operated prior to the most recent mode will operate</li> <li>• If the previous mode still cannot be properly played, the mode operated prior to that will operate</li> </ul> |

| Problem                    | Possible Cause                   | Countermeasure                                                                                                                                                                     |
|----------------------------|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The power does not turn on | The fuse is disconnected         | <ul style="list-style-type: none"> <li>• Replace with a suitable fuse</li> <li>• If the fuse is disconnected again, please contact your point of purchase or Kia dealer</li> </ul> |
|                            | Device is not properly connected | <ul style="list-style-type: none"> <li>• Check to see that the device has been properly connected</li> </ul>                                                                       |
| The system does not play   | The vehicle battery is low       | <ul style="list-style-type: none"> <li>• Charge the battery If the problem persists, contact your point of purchase or Kia dealer</li> </ul>                                       |

| Problem                             | Possible Cause                                                                                                                                                            | Countermeasure                                                                                                                                                                                       |
|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The image color/tone quality is low | <ul style="list-style-type: none"> <li>• The brightness, saturation, hue, and contrast levels are not set properly</li> </ul>                                             | <ul style="list-style-type: none"> <li>• Properly adjust the brightness, saturation, hue, and contrast levels through Display Setup</li> </ul>                                                       |
| Sound does not work                 | <ul style="list-style-type: none"> <li>• The volume level is set to the lowest level</li> <li>• The connection is not proper</li> </ul>                                   | <ul style="list-style-type: none"> <li>• Adjust the volume level</li> <li>• Check to see that the device has been properly connected</li> </ul>                                                      |
|                                     | <ul style="list-style-type: none"> <li>• The device is currently fast-forwarding, rewinding, scanning, or playing in slow mode</li> </ul>                                 | <ul style="list-style-type: none"> <li>• The sound will not work when the device is fast-forwarding, rewinding, scanning, or playing in slow mode</li> </ul>                                         |
| The sound or image quality is low   | <ul style="list-style-type: none"> <li>• Vibration is occurring from where the conversion switch has been installed</li> <li>• Image color/tone quality is low</li> </ul> | <ul style="list-style-type: none"> <li>• The sound may be short-circuited and the image distorted if the device vibrates</li> <li>• The device will return to normal once vibrations stop</li> </ul> |

| Problem               | Possible Cause                                                                                                                                                                                                                                                                                                                        | Countermeasure                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The USB does not work | <ul style="list-style-type: none"> <li>• USB memory is damaged</li> <li>• USB memory has been contaminated</li> </ul>                                                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>• Please use the USB after formatting it.</li> <li>• Remove any foreign substances on the contact surface of the USB memory and multimedia terminal</li> </ul>                                                                                                                                                                                              |
|                       | <ul style="list-style-type: none"> <li>• A separately purchased USB HUB is being used</li> <li>• A USB extension cable is being used</li> <li>• A USB which is not a Metal Cover Type USB Memory is being used</li> <li>• An HDD type, CF, SD Memory is being used</li> <li>• There are no music files which can be played</li> </ul> | <ul style="list-style-type: none"> <li>• Directly connect the USB memory with the multimedia terminal on the vehicle</li> <li>• Directly connect the USB memory with the multimedia terminal on the vehicle</li> <li>• Use standard USB Memory</li> <li>• Use standard USB Memory</li> <li>• Only MP3, WMA file formats are supported. Please use only the supported music file formats</li> </ul> |

| Problem                                                        | Possible Cause                                                                                                                                                                                                         | Countermeasure                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The iPod is not recognized even though it has been connected   | <ul style="list-style-type: none"> <li>• There are no titles which can be played</li> <li>• The iPod firmware version has not been properly updated</li> <li>• The iPod device does not recognize downloads</li> </ul> | <ul style="list-style-type: none"> <li>• Use iTunes to download and save MP3 files into the iPod</li> <li>• Use iTunes to update the firmware version and reconnect the iPod with the device</li> <li>• Reset the iPod and reconnect with the device</li> </ul> |
| Bluetooth does not work or its limited functions are available | <ul style="list-style-type: none"> <li>• Bluetooth on your mobile phone is set to OFF</li> <li>• The Bluetooth connection is not made</li> </ul>                                                                       | <ul style="list-style-type: none"> <li>• Set it to ON</li> <li>• Make the connection active</li> </ul>                                                                                                                                                          |

### **i** Information

- While operating the device, if an abnormality occurs that cannot be corrected with the above described measures, press the RESET key to reset the system.
- Press and hold the RESET key (more than 1 second). The device power will turn off and the system will reset.

## FAQ

### About Pairing Mobile Phones

---

**Q** I cannot pair my mobile phone. What is the cause?

**A** Check to see that the mobile phone supports Bluetooth® function. Verify if Bluetooth on the cell phone is set to OFF. If so, set it to ON. If the cell phone still can't be registered, try again after turning Bluetooth off and on, or delete the device registration on the multimedia system and cell phone and then register the cell phone again.

**Q** What is the difference between pairing a mobile phone and connecting a mobile phone?

**A** Pairing occurs through authenticating the head unit and mobile phone. Mobile phones paired to the head unit can be connected and disconnected until the paired mobile phone is deleted from the system. Bluetooth® Handsfree features, such as making/answering calls or managing contacts, are supported only in mobile phones connected with the head unit.

**Q** What is a Passkey?

**A** A passkey is the password used to authenticate the connection between the head unit and mobile phone. The passkey only needs to be entered once when pairing the mobile phone for the first time.

The initial passkey is 0000. You can change it with **SETUP** ►

**Bluetooth** ► **Bluetooth System Info** ► **Passkey** menu options.

---

## About Making/Answering Phone Calls

---

**Q** How can I answer a call?

**A** When there is an incoming call, a notification pop-up will become displayed. To answer the incoming call, select the  button on the screen or the  key on the steering wheel control.

To reject the call, select the  button on the screen or press the  key on the steering wheel control.

**Q** What should I do if I am talking on the Handsfree but want to switch the call to the mobile phone?

**A** While on a call, press and hold (more than 0.8 seconds) the  key on the steering wheel control or select the  button at the bottom of the Phone screen to switch the call to your mobile phone.

---

## About *Bluetooth*<sup>®</sup> Wireless Technology/ Head Unit Use Environment

---

**Q** What is the range of my wireless connection?

**A** The wireless connection can be used within 15 yards.

**Q** How many mobile phones can be paired?

**A** It is possible to pair up to five mobile phones.

**Q** Why is call quality sometimes poor?

**A** Check the reception sensitivity of the mobile phone when call quality becomes worsened. The call quality may deteriorate when the signal strength is low. Call quality may also worsen if metal objects, such as beverage cans, are placed near the mobile phone. Check to see if there are metal objects in the vicinity of the mobile phone. The call sound and quality may differ depending on the type of mobile phone.

## Important Information

Before using your Multimedia system, read and follow all instructions and safety information provided in this end user manual ("User's Guide"). Not following precautions found in this User's Guide can lead to an accident or other serious consequences.

### **Keep User's Guide in Vehicle**

When kept in the vehicle, the User's Guide will be a ready reference for you and other users unfamiliar with the Multimedia system. Please make certain that before using the system for the first time, all persons have access to the User's Guide and read its instructions and safety information carefully.

### **Warning**

Operating certain parts of this system while driving can distract your attention away from the road, and possibly cause an accident or other serious consequences. Do not change system settings or enter data non-verbally (using your hands) while driving. Stop the vehicle in a safe and legal manner before attempting these operations. This is important since while setting up or changing some functions as you may to distract your attention away from the road and remove your hands from the wheel.

# General Operation

## Voice Command Control

Functions within the Multimedia system may be accomplished using only voice commands. Using voice commands while driving allows you to operate the system without removing your hands from the wheel.

## Prolonged Views of Screen

Do not access any function requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Even occasional short scans to the screen may be hazardous if your attention has been diverted away from your driving task at a critical time.

## Volume Setting

Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.

## Use of Speech Recognition Functions

**Speech recognition software is inherently a statistical process which is subject to errors. It is your responsibility to monitor any speech recognition functions included in the system and address any errors.**

## FCC/IC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The antenna(s) must be installed such that a minimum separation distance of at least 20 cm is maintained between the radiator

(antenna) and all persons at all times. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

l'exposition aux RF

L'antenne (ou les antennes) doit être installée de façon à maintenir à tout instant une distance minimum de au moins 20 cm entre la source de radiation (l'antenne) et toute personne physique.