


6.5 Setup Photographs:


13.56 MHz RFID (NTB-Push Button)







13.56 MHz RFID (NTB-Touchscreen)







BLE (NTB-Push Button)





BLE (NTB-Touchscreen)





7.5 Setup Photographs:

BLE (NTB-Push Button)





BLE (NTB-Touchscreen)





8.5 Setup Photographs:

BLE (NTB-Push Button)




BLE (NTB-Touchscreen)



9.5 Setup Photographs:


13.56 MHz RFID (NTB-Push Button)







13.56 MHz RFID (NTB-Touchscreen)







BLE (NTB-Push Button)




BLE (NTB-Touchscreen)



10.5 Setup Photographs:


13.56 MHz RFID (NTB-Push Button)





13.56 MHz RFID (NTB-Touchscreen)







13.56 MHz RFID (NTB-Touchscreen), RE 30-1000 MHz



BLE (NTB-Push Button), RE 9 kHz-30 MHz [X-axis]




BLE (NTB-Push Button), RE 9 kHz-30 MHz [Y-axis]



BLE (NTB-Push Button), RE 9 kHz-30 MHz [Z-axis]



BLE (NTB-Push Button), 30-1000 MHz




BLE (NTB-Push Button), RE 1-18 GHz



BLE (NTB-Push Button), RE 18-25 GHz



BLE (NTB-Touchscreen), RE 9 kHz-30 MHz [X-axis]



BLE (NTB-Touchscreen), RE 9 kHz-30 MHz [Y-axis]





BLE (NTB-Touchscreen), RE 9 kHz-30 MHz [Z-axis]



BLE (NTB-Touchscreen), RE 30-1000 MHz



BLE (NTB-Touchscreen), RE 1-18 GHz




BLE (NTB-Touchscreen), RE 18-25 GHz



11.5 Setup Photographs:

BLE (NTB-Push Button), 30-1000 MHz



BLE (NTB-Push Button), 1-13 GHz



BLE (NTB-Touchscreen), RE 30-1000 MHz



BLE (NTB-Touchscreen), RE 1-13 GHz

--Photo not available--