

USER'S GUIDE

LW1741SERIES



USER'S GUIDE **LW1741 SERIES**

Thank you for purchasing this product. Lorex is committed to providing our customers with a high quality, reliable security solution.

This manual refers to the following models:

LW1741

LW1742

LW1744

For the latest online manual, downloads and product updates, and to learn about our complete line of accessory products, please visit our website at:

www.lorextechnology.com



WARNING

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**



WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER. NO USER SERVICABLE PARTS INSIDE.

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF THE PLUG TO THE WIDE SLOT AND FULLY INSERT.

Table of contents

1	Important Safeguards	1
1.1	General Precautions	1
1.2	Installation	1
1.3	Service	3
1.4	Use	3
2	LW1740 Series Features	4
3	Getting Started	5
4	Installing the Camera(s)	6
4.1	Installation Tips	6
4.2	Mounting Positions	6
5	Installing the Receiver	9
6	Camera Overview	12
7	LCD Receiver Overview	13
7.1	Front Panel	13
7.2	Side Panel	14
7.3	Rear Panel	14
8	Using the System	15
8.1	Understanding the On-screen Display	15
8.2	Navigating Menu Screen	16
8.3	Viewing Modes	17
8.3.1	Auto Sequence Viewing Mode	17
8.3.2	Quad Mode	18
8.4	Digital Zoom	18
8.5	Changing Audio Volume	18
9	Setting the Time	20
10	Recording	21
10.1	Format Memory	22
10.2	Scheduled Recording	22
10.2.1	Creating a Recording Schedule	22
10.2.2	Stopping Scheduled Recording	24
10.2.3	Modifying or Disabling a Recording Schedule	24
10.3	Manual Recording	26
10.4	Enabling / Disabling File Overwrite	26
11	Playback	28
11.1	Video Playback	28
11.2	Viewing Video Directly from the microSD Card	28
11.2.1	PC	29
11.2.2	Mac	29
12	Pairing Additional Cameras	30
13	Technical Specifications	32
13.1	General Specifications	32
13.2	Camera Specifications	32
13.3	Receiver Specifications	32
13.4	Dimensions	33
13.4.1	LCD Receiver	33
13.4.2	Camera with Metal Stand	33
14	Troubleshooting	34
15	Frequently Asked Questions	35

Important Safeguards

In addition to the careful attention devoted to quality standards in the manufacturing process of your product, safety is a major factor in the design of every instrument. However, safety is your responsibility too. This sheet lists important information that will help to ensure your enjoyment and proper use of the product and accessory equipment. Please read them carefully before operating and using your product.

1.1 General Precautions

1. All warnings and instructions in this manual should be followed.
2. Remove the plug from the outlet before cleaning. Do not use liquid aerosol detergents. Use a water-dampened cloth for cleaning.
3. Do not use this product in humid or wet places.
4. Keep enough space around the product for ventilation. Slots and openings in the storage cabinet should not be blocked.
5. It is highly recommended to connect the product to a surge protector to protect from damage caused by electrical surges. It is also recommended to connect the product to an uninterruptible power supply (UPS), which has an internal battery that will keep the product running in the event of a power outage.



CAUTION

Maintain electrical safety. Power line operated equipment or accessories connected to this product should bear the UL listing mark or CSA certification mark on the accessory itself and should not be modified so as to defeat the safety features. This will help avoid any potential hazard from electrical shock or fire. If in doubt, contact qualified service personnel.

1.2 Installation

1. **Read and Follow Instructions** - All the safety and operating instructions should be read before the product is operated. Follow all operating instructions.
2. **Retain Instructions** - The safety and operating instructions should be retained for future reference.
3. **Heed Warnings** - Comply with all warnings on the product and in the operating instructions.
4. **Polarization** - Do not defeat the safety purpose of the polarized or grounding-type plug.

A polarized plug has two blades with one wider than the other.



A grounding type plug has two blades and a third grounding prong.



The wide blade or the third prong are provided for your safety.

If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

-
5. **Power Sources** - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your location, consult your video dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
 6. **Overloading** - Do not overload wall outlets or extension cords as this can result in the risk of fire or electric shock. Overloaded AC outlets, extension cords, frayed power cords, damaged or cracked wire insulation, and broken plugs are dangerous. They may result in a shock or fire hazard. Periodically examine the cord, and if its appearance indicates damage or deteriorated insulation, have it replaced by your service technician.
 7. **Power-Cord Protection** - Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
 8. **Surge Protectors** - It is highly recommended that the product be connected to a surge protector. Doing so will protect the product from damage caused by power surges. Surge protectors should bear the UL listing mark or CSA certification mark.
 9. **Uninterruptible Power Supplies (UPS)** - Because this product is designed for continuous, 24/7 operation, it is recommended that you connect the product to an uninterruptible power supply. An uninterruptible power supply has an internal battery that will keep the product running in the event of a power outage. Uninterruptible power supplies should bear the UL listing mark or CSA certification mark.
 10. **Ventilation** - Slots and openings in the case are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided and the product manufacturer's instructions have been followed.
 11. **Attachments** - Do not use attachments unless recommended by the product manufacturer as they may cause a hazard.
 12. **Water and Moisture** - Do not use this product near water — for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement, near a swimming pool and the like.
 13. **Heat** - The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
 14. **Accessories** - Do not place this product on an unstable cart, stand, tripod, or table. The product may fall, causing serious damage to the product. Use this product only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Any mounting of the product should follow the manufacturer's instructions and use a mounting accessory recommended by the manufacturer.



15. **Camera Extension Cables** – Check the rating of your extension cable(s) to verify compliance with your local authority regulations prior to installation.
16. **Mounting** - The cameras provided with this system should be mounted only as instructed in this guide or the instructions that came with your cameras, using the provided mounting brackets.

17. **Camera Installation** - Cameras are not intended for submersion in water. Not all cameras can be installed outdoors. Check your camera environmental rating to confirm if they can be installed outdoors. When installing cameras outdoors, installation in a sheltered area is required.

1.3 Service

1. **Servicing** - Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
2. **Conditions Requiring Service** - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - When the power supply cord or plug is damaged.
 - If liquid has been spilled or objects have fallen into the product.
 - If the product has been exposed to rain or water.
 - If the product has been dropped or the cabinet has been damaged
 - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - When the product exhibits a distinct change in performance. This indicates a need for service.
3. **Replacement Parts** - When replacement parts are required, have the service technician verify that the replacements used have the same safety characteristics as the original parts. Use of replacements specified by the product manufacturer can prevent fire, electric shock, or other hazards.
4. **Safety Check** - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks recommended by the manufacturer to determine that the product is in safe operating condition.

1.4 Use

1. **Cleaning** - Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
2. **Product and Cart Combination** - When product is installed on a cart, product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
3. **Object and Liquid Entry** - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or "short-out" parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
4. **Lightning** - For added protection of this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power line surges.

- 7" rechargeable wireless LCD monitor.¹
- Weather resistant wireless camera.²
- Manual, motion, and schedule recording.
- Listen-in audio monitoring.³
- Expandable up to 4 cameras.
- 4GB SD card included; 32GB supported.
- Easy to use menu with icons.
- Simple installation. No video cables required.
- Up to XXXXXX days of recording.
- Video motion detection.
- Time and date stamped recordings for easy retrieval.
- Front panel feather touch controls.
- Motorized camera filter provides accurate color reproduction in all lighting conditions.
- Night time viewing up to XXXXXXXXft (20m) away in ambient night time lighting conditions and up to XXXXXXXXft (14m) away in total darkness.⁴
- View and record up to 4 cameras at the same time in quad screen.
- Secure wireless signal (FHSS).
- Up to 150ft (50m) indoor / 450ft (150m) outdoor wireless range.⁵
- Record in real time video.
- 2x Digital Zoom.

Note

1. Up to 3 hours of portable wireless monitoring. For extended monitoring ensure the wireless monitor is connected to a local power outlet.
2. Wireless cameras require a wired connection to power outlet. Not intended for direct exposure to rain or snow. For outdoor applications, install under shelter protected from the elements.
3. Audio recording without consent is illegal in certain jurisdictions. Lorex Corporation assumes no liability for use of its products that does not conform with local laws.
4. Stated IR illumination ranges are based on ideal conditions in total darkness and typical outdoor night time ambient lighting. Actual range and image clarity depends on installation location, viewing area and light reflection / absorption.
5. Range up to 450ft/150m outdoor, 150ft/50m indoor based on line of sight. Actual range will vary depending on obstructions.

Getting Started

The system includes the following components:



Indoor / outdoor wireless camera (s)*



7" rechargeable LCD receiver / recorder



Power adapters for receiver and camera(s)*



Rechargeable Lithium polymer battery



Camera mounting stand*




Wireless antenna for camera (SMA)*



4GB microSD memory card



Mounting kit(s)*



Quick Start Guide

* Configuration may vary by model

Note


Camera configuration, memory card size, and the number of accessories may vary by model. Please refer to your package for specific details. Check your package to confirm that you have received the complete system.

4 Installing the Camera(s)



CAUTION

Cameras are suitable for outdoor installation, but are weather resistant, not weatherproof. **Cameras are not intended for direct exposure to rain or snow.** For outdoor applications, install under shelter protected from the elements, such as beneath roof eaves. The diagram below shows an example of an ideal location for outdoor placement.



4.1 Installation Tips

- Before you install the camera, plan where and how it will be positioned, and where you will route the cable that connects the camera to the power adapter.
- Before starting permanent installation, check the camera image on the receiver when camera is positioned in the same place it will be permanently installed.
- It is recommended to ensure a clear line-of-sight between the camera and receiver and to limit the amount of obstructions, such as walls and tree branches, between the camera and receiver. Walls made of heavy building materials such as brick or concrete will significantly reduce signal range.
- If the signal will have to pass through a wall, placing the receiver or camera next to a window will improve the signal strength.
- Do not install the camera pointing out of a window. The nighttime picture will be unusable due to reflection from the night vision LED's.
- The cameras are pre-paired so they work out of the box. Each camera has a channel number sticker indicating what channel they are paired to. If you have purchased additional cameras, you will need to pair them to the receiver, see 12 *Pairing Additional Cameras*, page 30.

4.2 Mounting Positions

You may mount your cameras on a wall or ceiling. See the images below for recommended configurations of the camera stand and antenna.



Wall



Counter

To install the camera(s):

1. Use the included mounting screws to attach the camera stand(s) to the mounting surface:



- Mark the positions of the screw holes on the mounting surface with the base of the mounting stand.
- Drill holes and insert the drywall plugs (included) as needed.
- Firmly attach the camera(s) to the mounting surface using the included screws.

Note


If you run the power cable through the mounting surface, connect power before attaching the camera to the wall.

2. Attach the camera stand(s) to the camera(s).

-
- Loosen the adjustment ring on the metal camera stand(s) and move the camera to the desired position. Tighten the adjustment ring when finished, holding the camera firmly in position.



- Connect one end of the camera's power adapter to the camera and the other end to an electrical outlet or surge protector. Make sure the power connector is fully inserted to avoid water getting in the plug.


**Note**

Power cables are only weatherproof when fully inserted at the connection point. Power cables may not be submerged in water.


- Remove the protective film from the front of the camera. If the film is not removed, it will block the built-in microphone and affect the quality of the picture.

Installing the Receiver

1. Use a Phillips screwdriver (not included) to open the battery compartment on the back panel.




2. Insert the included battery so the statement **"THIS SIDE UP"** is visible, and the clear plastic tabs on the side of the battery face outwards. Replace the battery compartment cover.




CAUTION

If you do not plan to use the unit for a prolonged period of time, remove the battery or ensure you charge it at least once every 3 months.

3. Connect the included power adapter to the receiver and to an electrical outlet.



4. Charge the receiver overnight before using for the first time.
5. Pull up the antenna on the back of the LCD receiver.



6. Press and hold the power button on the front panel for 2 seconds. The startup screen appears, followed by live video from your camera(s).


Note

If one or more cameras do not appear when selected (for example, Camera 2 is plugged in but does not appear on channel 2), see *12 Pairing Additional Cameras*, page 30.

Tips:


- Place the receiver in a location that will have a clear reception to your camera. Try to maintain line-of-sight and minimize the number of obstructions between the camera and receiver.
- Adjust the antenna on the receiver as necessary to provide the clearest reception.

-
- The receiver comes with a 4 GB microSD card pre-inserted, so you can start recording right away. The receiver is compatible with most major brands of microSD cards up to 32 GB. For recording times on microSD cards, see [CROSSREF](#).



1. **Antenna:** Removable wireless antenna (SMA)
2. **IR LEDs:** Night vision IR LEDs.
3. **Lens**
4. **Pair:** Press to pair additional cameras to the system. See 12 *Pairing Additional Cameras*, page 30 for full details.
5. **Microphone:** Built-in microphone for listen-in audio.
6. **Attachment Point:** Attach the included metal stand to the camera. See 4 *Installing the Camera(s)*, page 6 for full details.

7.1 Front Panel



1. **LCD Screen**

2. **Indicator LED:** Indicates system status in the following ways:

- **Solid green:** Indicates that battery life is half-full or greater.
- **Solid red:** Indicates that the receiver is plugged in and turned off.
- **Flashing red:** Indicates that the battery is low **OR**, the receiver is plugged in but the battery is not inserted.

3. **Power Button:** Press and hold for 2 seconds to turn the receiver on or off.

4. **Menu:** Press to enter the system menu.

5. **Enter / Play / Pause:**

- In menus, press to confirm a selection.
- In live view, press to switch the viewing mode between single channel mode, quad mode, or scan mode. For more details on viewing modes, see CROSSREF.
- In video playback, press to play / pause video.

6. **Left / Rewind:** Press to move selection to the left in menus, or press and hold to rewind in video playback.

7. **Right / Fast-Forward:** Press to move selection to the right in menus, or press and hold to fast-forward in video playback.

8. **Down / Decrease Volume:** Press to move selection to the down in menus, or to decrease volume in live view.

9. **Up / Increase Volume:** Press to move selection to the up in menus, or to increase volume in live view.


10. **Back / Stop:** Press to go back to the previous menu or to stop video playback.

11. **Record / Snapshot / Delete:**

- Press in live view to begin manually recording video. For full details on manual recording, see CROSSREF.
- Press and hold in live view to take a snapshot. For full details on taking snapshots, see CROSSREF.
- Press while selecting a snapshot or video in the playback menu to delete the file. For full details on deleting snapshots, see CROSSREF. For full details on deleting video recordings, see CROSSREF.

12. **Zoom:** Press to enter 2x digital zoom.

7.2 Side Panel




1. **Power Port:** Connect the included 5V DC adapter to the power port and an electrical outlet or surge protector to provide power to the receiver.
2. **microSD Card Slot:** The included 4 GB microSD card comes pre-inserted.

Note

- The receiver supports microSD cards up to 32 GB.
- Lorex recommends microSD or microSDHC cards for use with this receiver. The following brands of microSD cards are confirmed by Lorex: Adata, Kingston, Patriot, Sandisk, and Toshiba.

7.3 Rear Panel



1. **Wireless Antenna:** Position the antenna as needed for best reception.
2. **Battery Compartment:** Insert the included rechargeable battery. See for full installation instructions.
3. **Support Stand:** Pull out the support stand to for placement on a flat surface.
4. **Speaker**


By default, the camera(s) included with your system are automatically paired to the receiver. The camera(s) and receiver will communicate with each other once they are powered on.

Note


It is recommended to power on the camera(s) before powering on the receiver.


8.1 Understanding the On-screen Display

With camera 1 properly connected and powered on, the system displays a full-screen live view of the camera.



With more than one camera properly connected and powered on, the system displays up to 4 channels in split screen with the live view of each camera.



1. **Channel indicator:** Displays the camera you are presently viewing. If viewing multiple cameras at once, the camera indicator will appear above each video display.
2. **Viewing mode indicator:** Indicates the viewing mode by showing a different icon for Single Channel Viewing (, Quad Viewing (, and Auto Sequence Viewing () modes.
3. **Zoom indicator:** Indicates that the current live view is zoomed in to twice the original size.
4. **Signal indicator:** The signal indicator shows the strength of the signal being received from the camera. The number of bars in the Signal Indicator shows the strength of the signal. One, or no bars indicates the signal is poor, and 4 bars indicate a very strong signal.

Note

- If the signal is low (for example, 1 or 2 bars) adjust the antennas, or reposition the camera(s) or receiver for best performance.

5. **Battery indicator:** Shows remaining battery life. Icon turns red when battery is critically low to indicate that the receiver should be plugged into a local power outlet right away.
6. **Recording countdown:** Counts down until system recording starts.
7. **Time & date stamp:** The current date and time on the system.
8. **Recording indicator:** A red circle appears when recording is in progress. If viewing and recording video from multiple cameras at once, the recording indicator will appear above each video display where recording is enabled.
9. **Volume indicator:** Shows the current volume of the receiver. The volume indicator appears on screen when you change the volume using the  /  keys.

8.2 Navigating Menu Screen

Use the system menus to configure settings.



- Press  to open the Main Menu.
- Press the   keys to move the cursor left, right, up, and down.
- Press **OK** to open sub-menus and confirm menu selections.
- Press  to save changes and exit menus.

8.3 Viewing Modes


There are 3 different viewing modes available on the system: Single Channel Viewing mode, Auto Sequence Viewing mode (view individual channels automatically in sequence), and Quad Viewing mode (view all 4 channels at once in split-screen).

To change viewing modes:

- Press  to select between channels 1–4 in single channel view, as well as to enable Quad Viewing and Auto Sequence Viewing modes.

8.3.1 Auto Sequence Viewing Mode

Auto Sequence Viewing mode cycles through connected channels in full-screen.



Auto Sequence Example

To enable Auto Sequence Viewing:


- Press  until a single channel is shown on screen with the Auto Sequence icon () at the top of the display. The receiver automatically switches through connected channels.
- To return to single channel viewing, press  until the Single Channel icon () appears at the top of the display.

8.3.2 Quad Mode

Use Quad Viewing mode to view up to four cameras simultaneously.

To enable Quad mode:

- Press  until a split-screen display appears with the Quad icon () at the top of the display. The receiver displays all 4 channels simultaneously.



Quad Example

8.4 Digital Zoom

The digital zoom feature allows you to zoom in 2x on a single camera during live viewing. This is useful if you need a closer look at something happening far away from the camera.

To use digital zoom:

- Select the desired camera in full-screen mode (press  to select the channel) and press  on the front panel of the receiver to zoom in.
- When digital zoom is activated, the live view zooms in to 2x normal magnification. The word **ZOOM** appears in the top of the screen, and 4 directional arrows appear over the camera image. Use the  keys to pan in the desired direction and look at different parts of the image.
- Press  again to exit digital zoom.


8.5 Changing Audio Volume

The receiver can play and record audio from the camera you are currently viewing.

To change the volume:

- Press  /  to change the audio volume.

The volume meter appears on screen to indicate the volume of audio coming from the currently selected camera:



Note

There is no audio in Quad mode.

Setting the Time


It is highly recommended to set the date and time on the system prior to recording, as they will be used to stamp recordings. You must set the correct date and time in order to use schedule recording.

To set the time:

1. Press  to open the main menu.
2. Select the system settings icon using the  /  keys, then press **OK**.



3. Select **Clock setup**, then press **OK**.
4. Press  /  to configure the current date and time. Press  /  to move between items.



5. Press  to save your settings and close any remaining menu windows. The date and time appears at the bottom of the screen in live viewing mode and on recorded video.

The following recording modes are available on the system: *manual recording*, *scheduled continuous recording*, and *scheduled motion recording*. The system records video to the included microSD card.

Recording Prerequisites:

- A microSD card must be inserted into the receiver in order to record video. You should always format the microSD card prior to initial recording. For details, see 10.1 *Format Memory*, page 22.

Maximum Recording Times:

The system supports microSD cards up to 32 GB. Use the table below to help you estimate the recording times on various sizes of microSD cards. Times shown are in hours and minutes.

microSD Card Capacity	Single Channel Recording @ VGA Resolution
1 GB	6.5 hours
2 GB	13 hours
4 GB	26 hours
8 GB	52 hours
16 GB	104 hours
32 GB	208 hours

Note

The system supports microSD or microSDHC cards up to 32 GB. The following brands of microSD cards are confirmed by Lorex: Adata, Kingston, Patriot, Sandisk, and Toshiba.

Recording Mode Summary:

Mode	Description	How to Operate
Manual Recording	Continuous recording from a single channel in full screen or all 4 channels in a single video file.	During live viewing, press  to begin manual recording. Press  again to stop manual recording.
Scheduled Continuous Recording	Records continuously from all 4 channels in a single video file. Recording starts and stops automatically based on a daily schedule.	Press  and select the recording schedule icon. Press OK to confirm. Set a time range for the system to record continuous video during each day. For full set-up instructions, see CROSSREF.
Scheduled Motion Recording	Records motion-events only from all 4 channels in a single video file. Recording starts and stops automatically based on a daily schedule.	Press  and select the recording schedule icon. Press OK to confirm. Set a time range for the system to record motion-events during each day. For full setup instructions, see CROSSREF.

10.1 Format Memory

It is highly recommended to format the microSD card prior to initial recording.

To format the microSD card:

 CAUTION
Formatting erases all data on the microSD card. This step cannot be undone.

1. Insert the microSD card into the card slot on the receiver until you hear a "click."
Please insert the card according to the diagram on the side panel of the receiver.
 2. Press , then select the **Record Setting** icon. Press **OK** to confirm.
 3. Select **Format card** and press **OK** to confirm.
 4. Select **Confirm** and press **OK** to confirm.
- Note**
Please allow a few moments for formatting to finish. Formatting time will vary depending on the size of the card.
5. A message appears to confirm formatting. Press  repeatedly until all menus are closed.

10.2 Scheduled Recording

Use scheduled recording to have the system automatically record continuously or just motion-events during a set period of time. The system records all 4 channels in Quad mode.

Note
Auto Sequence Viewing mode and Quad mode are available during schedule recording without affecting the recording files.

Prerequisite:

Please ensure you have set the proper date and time on the receiver prior to setting a recording schedule. See 9 *Setting the Time*, page 20.

When should I use schedule recording?

- Use scheduled continuous recording if the camera is pointed at an area with high traffic, such as an entrance way or a road.
- Use scheduled motion recording if the camera is pointed at an area with low traffic, such as a back door or a storage room.

 CAUTION
Do not remove the microSD card while the system is recording. Disable all recording on the system before ejecting the microSD card.

10.2.1 Creating a Recording Schedule

 CAUTION
Scheduled recording overrides manual recording.

To create a recording schedule:


1. Press , then select the **Recording Schedule Setting** icon. Press **OK** to confirm.




2. Use the  /  keys to select the first available slot and press **OK**.



3. Use the ◀/▶ keys to move the selection between the start time, end time, and schedule type. Use the ▼/▲ keys to configure each item. Press **OK** to save the schedule.
- **For scheduled continuous recording:** See the following example. The system begins recording continuously at 7:00PM and stops recording at 10:00AM each day. The word **SCHEDULE** at the end indicates that the system will record continuously between these times.



- **For scheduled motion recording:** See the following example. The system begins recording motion-events only at 7:00PM and stops recording at 10:00AM each day. The word **MOTION** at the end indicates that the system will record continuously between these times.



Note

The appearance of the start and end time will vary depending on the time format. The system supports both 12-hour and 24-hour time.

4. Press ◀ repeatedly until all menus are closed.

10.2.2 Stopping Scheduled Recording

When the stop time arrives, the system stops recording automatically. If necessary, you can temporarily stop schedule recording manually in order to access the main menu.

To stop schedule recording:

- Press [Stop] to temporarily stop scheduled recording. If you remain in live view, the system starts the recording schedule again after 10 seconds. You can access the main menu during this time to stop the countdown and configure settings. The recording schedule starts 10 seconds after you re-enter live view.

10.2.3 Modifying or Disabling a Recording Schedule

You can modify or disable any recording schedule after it has been created.

To modify a recording schedule:

1. Press , then select the **Recording Schedule Setting** icon. Press **OK** to confirm.



2. Use the  /  keys to select the schedule you would like to modify and press **OK**.
3. Use the  /  keys to move the selection between the start time, end time, and schedule type. Use the  /  keys to modify each value. Press **OK** to save the modified schedule.
4. Press  repeatedly until all menus are closed.

To disable a recording schedule:

1. Press , then select the **Recording Schedule Setting** icon. Press **OK** to confirm.



2. Use the  /  keys to select the schedule you would like to delete and press **OK**.
3. Use the  /  keys to move the selection to the schedule type. Use the  /  keys to select **NONE**. Press **OK** to save your settings.
4. Press  repeatedly until all menus are closed.

10.3 Manual Recording

Manual recording allows you to manually start and stop recording. You can record video from one channel in full-screen, or all 4 channels in Quad or Auto Sequence Viewing mode.

When should I use manual recording?

- Recording of unexpected events or emergencies.

To enable manual recording:

1. Use the  /  keys to select the viewing mode you want to record.
2. Press  to begin recording the current view.

A recording indicator () appears on screen to indicate the system is recording.

3. Press  again to stop recording.



CAUTION


Do not remove the microSD card while the system is recording. Disable all recording on the system before ejecting the microSD card.

10.4 Enabling / Disabling File Overwrite


Enabling file overwrite will delete the oldest recorded data on the microSD card once it is full to make room for new recordings.

To enable file overwrite:

1. Press , then select the **Record Setting** icon. Press **OK** to confirm.



2. Select **Overwrite** and press **OK**.



3. Select **ON** and press **OK** to enable file overwrite.



4. Press  repeatedly until all menus are closed.

Playback mode allows you to playback recorded video files and view snapshots from the microSD card. You can view videos and snapshots directly on the system or by connecting the microSD card to your computer.


11.1 Video Playback

To playback recorded video on the system:

1. Press , then select the **Event List** icon. Press **OK** to confirm.



2. Select **Video** and press **OK**.



3. Use the  /  keys to choose a date to search for video from. Press **OK** to confirm.
4. Use the  /  keys to choose an hour to search for video from. Press **OK** to confirm.

11.2 Viewing Video Directly from the microSD Card

You can view the saved video files on your computer (PC or Mac) by using a microSD card reader (not included). Saved video files are in ASF format.

Note

Some PCs and Macs may have a microSD card reader built-in. Please refer to your computer's instruction manual for more details.

11.2.1 PC

Note

You can view ASF files natively in Windows Media Player™, as well as other media players such as VLC. VLC is an open-source software application available at www.videolan.org

To playback recorded video on a PC:

1. Remove the microSD card from the receiver by gently pushing on the microSD card and then releasing. The card will eject.
2. Insert the microSD card into a microSD card reader (not included) connected to your PC. Your PC should load the microSD card as a new Removable Drive and an Autorun window opens.
3. Click **Open folder to view files** or open the folder in Computer. Open the folder **MFG**. You will then see a folder for each page of recorded video in Playback mode. Folders are named by page number (e.g. recordings found on the second page are in the folder **00000002**).
4. Double-click any of the ASF files. The video will begin playing in your default ASF media player.

11.2.2 Mac

Note

Downloading and installing the Flip4Mac WMV Components will allow you to play ASF files in QuickTime. VLC Player is recommended for viewing ASF files on a Mac. VLC is an open-source software application available at www.videolan.org

To playback recorded video on a Mac:

1. Remove the microSD card from the receiver by gently pushing on the microSD card. The card will eject.
2. Insert the microSD card into a microSD card reader (not included) connected to your Mac. Your Mac should load the microSD card as a new disk on your desktop.
3. Double-click the disk on your desktop or open it through Finder. Open the folder **MFG**. You should see a folder for each page of recorded video in Playback mode. Folders are named by page number (e.g. recordings found on the second page are in the folder **00000002**).
4. Double-click any of the ASF files. The video will begin playing in your default ASF media player.

Note

If you have purchased additional cameras, it is highly recommended to pair the cameras to the receiver before permanent installation.

"Pairing" is an electronic handshake between wireless devices. Wireless devices and components need to be paired in order to communicate with each other.

The camera(s) provided with the system have already been paired to the receiver. By default, the camera(s) included are automatically paired to channels 1 & 2 on the receiver. See the channel label on the camera to check which channel it has been set to.

If you have purchased additional accessory cameras, you will need to pair them to the receiver. When pairing cameras, you can select the channel you would like the cameras to be assigned to. You can also use the steps below to reassign your existing cameras to different channels.

Note

Accessory cameras (model# **LW1741AC1**) are available from www.lorextechnology.com.

To pair an additional camera:

1. Connect the new camera to a power outlet. Place the camera and the receiver within 1ft of each other.

2. Press , then select the **Camera Setting** icon. Press **OK** to confirm.




3. Select **Pairing** and press **OK**.



4. Use the arrow keys on the receiver to select the channel you want to pair the camera to. Channels that are paired to an existing camera show the statement **PAIR OK**, while open channels show **NO PAIR**. Press **OK** on the desired channel to begin pairing.



- If you pair a new camera to a channel that is already being used by an existing camera, the new camera will be connected to that channel. The old camera will automatically be disconnected.
5. Following the on-screen prompt (the selected channel shows the statement **PAIRING**), press the **Pair** button behind the camera. You have 10 seconds to press the **Pair** button on the camera. If pairing was successful, the pairing channel shows the statement **PAIR OK**.



6. Press  until you have exited all menus. You can now view live video from the camera by selecting the channel using the arrow keys on the receiver.

Note

- If pairing was unsuccessful, the pairing channel shows the statement **TIME OUT**. Repeat steps 2~5 to try the pairing process again.
- If the speaker begins squealing, move the camera and receiver away from each other.

13.1 General Specifications

Description	Specification
Transmission Frequency	2,400 ~ 2,483.5MHz
Transmission Power	16dBm(Camera) 20dBm(Monitor)
Data Rate	3 Mbps
Unobstructed Wireless Range	Up to 450ft (m) outdoors Up to 150ft (m) indoors (disclaimer!)
Spread Spectrum	FHSS
Modulation	GFSK
Operating Humidity	< 80%

13.2 Camera Specifications

Description	Specification
Image Sensor	1/5" CMOS Image Sensor
Supported Resolutions	VGA (640x480) up to 25 fps
Minimum Illumination	< 20Lux (IR on) / > 60Lux (IR off)
AGC	Auto
AES Speed	1/60~1/10,000 Second
IR LEDs	24 pieces; 850nm
Night Vision Range	65ft (20m) / 45ft (14m) (disclaimer!)
Lens / Lens Type	2.8mm F2.8 / Fixed
Field of View (Diagonal)	65°
Power Consumption	???mA
Power Supply	6V DC 800mA ±5%
Indoor / Outdoor	Both (IP65) (disclaimer!)
Operating Temperature	14 ~ 122°F / -10 ~ 50°C
Dimensions (W x D x H)	5.4" x 3.1" x 9.1" 138mm x 78mm x 232mm
Weight	???


13.3 Receiver Specifications

Description	Specification
LCD Display	7" Diagonal
LCD Resolution	800x480
Receiving Sensitivity	-88dBm
Image Processing	MPEG4
Battery	3.7V 3000mAh Li-polymer
Power Consumption	?????mA
Power Supply	5V DC 2A ±5%
Operating Temperature	32 ~ 122°F / 0 ~ 50°C


Description	Specification
Dimensions (W x D x H)	7.4" x 5.2" x 0.7" 188mm x 132mm x 17mm
Weight	???

13.4 Dimensions

13.4.1 LCD Receiver



13.4.2 Camera with Metal Stand



Q: Does a wireless camera require power?






A: Yes. Wireless cameras require two power sources: one connected to the camera, and the other to the receiver. The term "wireless" refers to the lack of a video cable between the camera and the receiver.

Q: How far can a wireless camera transmit a video signal?

A: In an open field (with line of sight), a typical wireless camera has a range between 250 - 500 feet. 'Line-of-sight' means that there are no obstructions between the camera and receiver. Obstructions include walls, buildings, trees, and certain electronic devices. Materials containing moisture (for example, leaves) may also act as an obstruction. Cubical walls, drywall, glass, and windows generally do not degrade wireless signal strength.

In a closed environment—such as the interior of a house—the wireless camera range is between 100 - 165 feet. The signal range varies depending on the type of building materials or objects the wireless signal must pass through.

The signal range also depends on whether there are competing signals using the same frequency as the camera. For example, signals from cordless phones or routers may affect signal strength. Adaptive Frequency Hopping Spread Spectrum (FHSS) technology featured in the latest Lorex models greatly reduces signal interference.

Range Limiting Factors ¹				
				
Reflection	Scattering	Refraction	Diffraction	Attenuation
The signal reflects back	The signal scatters back into multiple new signals	The signal bends as it travels through an object (e.g. glass window)	The signal changes direction as it passes around an object	The signal strength weakens as it passes through an object

Note

1. Source: Xirrus (2010). "Wi-Fi Range Dynamics". Retrieved online at http://xirrus.gcsmarket.com/pdfs/Xirrus_Wi-Fi_Range.pdf

Signal Reduction Through Materials


Signal strength decreases as it passes through different types of material. The table below shows how signals become reduced when passing through different materials:

Material	Signal Reduction (%)
Plaster & Wood	10 - 30%
Brick	30 - 50%
Concrete Cinder Blocks	50 - 70%
Metal & Metal Cladding	70 - 90%

Note

Signals that must pass through wet or moist materials (e.g. shrubs and trees) may be significantly reduced.

The stronger the signal strength, the higher the video frame rate. The lower the signal strength, the lower the video frame rate.



Q: Are digital wireless camera signals secure?

A: Yes. Lorex digital wireless products feature a wireless transmission method called Frequency Hopping Spread Spectrum (FHSS). This type of signal is highly resistant to eavesdropping as it generates a channel hopping sequence using an algorithm generated by the receiver, which only the camera can follow through the "pairing" function.

Pairing is an electronic handshake between digital wireless devices. Digital wireless cameras can only be paired to one receiver. This is to prevent interception by third parties, and prevents any other device from picking up the signal—this also means that you cannot pair one camera to multiple receivers.

Q: How many frames per second should I expect from a digital wireless camera?

A: Current Lorex digital wireless cameras offer 10 - 30 FPS (Frames Per Second) performance. Actual frame rate depends mainly on signal strength (see the chart in section above).



Website

www.lorextechnology.com

Copyright

© 2014, Lorex Corporation

All rights reserved worldwide. Names and marks appearing herein are either registered trademarks or trademarks of Lorex Corporation and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

Legal disclaimer

As our product is subject to continuous improvement, Lorex Corporation & subsidiaries reserve the right to modify product design, specifications & prices without notice and without incurring any obligation. E&OE.

Publ. No.: LX400030
Commit: 16602
Head: 16610
Language: en-US
Modified: 2014-08-22
Formatted: 2014-08-25

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment for camera should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC Warning:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

CAUTION: 1. To comply with IC RF exposure compliance requirements, a separation distance of at least 20 cm for camera must be maintained between the antenna of this device and all persons. 2. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.