



DRAWER MICROWAVE OVEN

Use & Care Guide

For questions about features, operation/performance, parts, accessories or service, call:
1-866-698-2538, or visit our website at www.whirlpool.com/owners

Horno microondas de cajón

Guía de uso y cuidado

Para consultas sobre características, funcionamiento/rendimiento, piezas, accesorios o servicio, llama al:
1-866-698-2538, o visita nuestro sitio web en www.whirlpool.com/owners



TABLE OF CONTENTS

CONTENT	2
MICROWAVE OVEN SAFETY	3
PARTS AND FEATURES	6
COMBINATION INSTALLATION	6
CONTROL PANEL	7
SETTINGS	8
STANDBY MODE	8
SETTING THE CLOCK	9
SETTING THE TIMER	9
MUTE FUNCTION	9
CONTROL LOCK	9
MICROWAVE OVEN COOKING FUNCTIONS	10
COOK TIME/POWER	10
EXPRESS COOKING	10
COOK	11
DEFROST	11
REHEAT	12
POPCORN	12
POTATOES	13
VEGGIES	13
SOFTEN/MELT	13
KEEP WARM	14
STEAM CLEAN	14

ÍNDICE

CONTENIDO	2
SEGURIDAD DEL HORNO MICROONDAS	16
PARTES Y CARACTERÍSTICAS	19
INSTALACIÓN COMBINADA	19
PANEL DE CONTROL	20
CONFIGURACIONES	21
MODO DE ESPERA	21
AJUSTE DEL RELOJ	21
AJUSTE DEL CRONÓMETRO	22
FUNCIÓN DE SILENCIO	22
CERRADURA PARA NIÑOS	22
FUNCIONES DE COCCIÓN DEL HORNO MICROONDAS.....	23
TIEMPO DE COCCIÓN/POTENCIA	23
COCCIÓN RÁPIDA	23
COCINAR	24
DESCONGELAR	24
RECALENTAR	25
DERRETIR	25
ABLANDAR	25
PALOMITAS DE MAÍZ	25
FUNCIONES DE COCCIÓN DEL HORNO	26
FREÍDO AL AIRE	26
HORNEAR	27
PARRILLA	27
ASAR	28
MANTENER CALIENTE.....	28
LIMPIEZA A VAPOR	28

MICROWAVE OVEN SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

⚠ DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

⚠ WARNING

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING: To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:

- Read all instructions before using the appliance.
- Read and follow the specific "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" found in the PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY section.
- This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" section.
- Install or locate this appliance only in accordance with the provided Installation Instructions.
- Some products such as whole eggs and sealed containers - for example, closed glass jars - are able to explode and should not be heated in this oven.
- Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook, or dry food. It is not designed for industrial or laboratory use.
- HOT CONTENTS CAN CAUSE SEVERE BURNS. DO NOT ALLOW CHILDREN TO USE THE MICROWAVE. Use caution when removing hot items.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
- This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair, or adjustment.
- Do not cover or block any openings on the appliance.
- Do not store this appliance outdoors. Do not use this product near water - for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar locations.
- Do not immerse cord or plug in water.
- Keep cord away from heated surfaces.
- Do not let cord hang over edge of table or counter.
- Do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3D printer).
- See door surface cleaning instructions in the "Microwave Oven Maintenance and Care" section.
- Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present. THIS COULD RESULT IN VERY HOT LIQUIDS SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.
- Do not operate any heating or cooking appliance beneath this appliance.
- Do not mount unit over or near any portion of a heating or cooking appliance.
- Do not mount over a sink.
- Do not store anything directly on top of the appliance surface when the appliance is in operation.

SAVETHESEINSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING: To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:

- To reduce the risk of fire in the oven cavity:
 - Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - Remove wire twist-ties from paper or plastic bags before placing bag in oven.
 - If materials inside the oven ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.
- Oversized foods or oversized metal utensils should not be inserted in a microwave/toaster oven as they may create a fire or risk of electric shock.
- Do not clean with metal scouring pads. Pieces can burn off the pad and touch electrical parts involving a risk of electric shock.
- Do not use paper products when appliance is operated in the toaster mode.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not cover racks or any other part of the oven with metal foil. This will cause overheating of the oven.

SAVE THESE INSTRUCTIONS

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) Door (bent),
 - (2) Hinges and latches (broken or loosened),
 - (3) Door seals and sealing surfaces
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

MICROWAVE OVEN MAINTENANCE AND CARE

General Cleaning

IMPORTANT: Before cleaning, make sure all controls are off and the microwave oven is cool. Always follow label instructions on cleaning products.

Soap, water, and a soft cloth or sponge are suggested first, unless otherwise noted.

STAINLESS STEEL AND BLACK STAINLESS STEEL (on some models)

NOTE: To avoid damage to stainless steel surfaces, do not use soap-filled scouring pads, abrasive cleaners, Cooktop Cleaner, steel-wool pads, gritty washcloths, or abrasive paper towels. Damage may occur to stainless steel surfaces, even with one-time or limited use.

Rub in direction of grain to avoid damaging.

Cleaning Method:

- Affresh[®] † Stainless Steel Cleaners Part Number W10355016 (not included) or affresh[®] Stainless Steel Cleaning Wipes Part Number W1055049 (not included): See the Quick Start Guide for ordering information.
- Vinegar for hard water spots.

MICROWAVE OVEN DOOR EXTERIOR

Cleaning Method:

- Glass cleaner and a soft cloth or sponge: Apply glass cleaner to soft cloth or sponge, not directly on panel.
- Affresh[®] Kitchen Appliance Cleaners Part Number W10355010 (not included): See "Online Ordering Information" section from Quick Start Guide to order.

NONSTICK CAVITY COATING (on some models)

To avoid damage to the microwave oven cavity, do not use metal or sharp utensils or scrapers or any type of abrasive cleanser or scrubbers.

MICROWAVE OVEN CAVITY

To avoid damage to the microwave oven cavity, do not use soap-filled scouring pads, abrasive cleaners, steel-wool pads, gritty washcloths, or some paper towels.

On stainless steel models, rub in direction of grain to avoid damaging.

The area where the microwave oven door and frame touch when closed should be kept clean.

Cleaning Method:

Average soil

- Mild, nonabrasive soaps and detergents:
Rinse with clean water and dry with soft, lint-free cloth.

Heavy soil

- Mild, nonabrasive soaps and detergents:
Heat 1 cup (250 mL) of water for 2 to 5 minutes in microwave oven. Steam will soften soil. Rinse with clean water and dry with soft, lint-free cloth.

Odors

- Lemon juice or vinegar:
Heat 1 cup (250 mL) of water with 1 tbs (15 mL) of either lemon juice or vinegar for 2 to 5 minutes in microwave oven.

Microwave Oven Use

Odors and smoke are normal when the microwave oven is used the first few times or when it is heavily soiled.

IMPORTANT: The health of some birds is extremely sensitive to the fumes given off. Exposure to the fumes may result in death to certain birds. Always move birds to another closed and well ventilated room.

Safe Use of Aluminum Foil in a Microwave:

1. Small, Smooth Pieces: Use only small, flat, new, and smooth pieces of foil. Avoid wrinkled or crumpled foil.
2. Shielding: Use foil to shield small or thin areas of food to prevent overcooking. Shape the foil smoothly around the food without sharp edges.
3. Limited Coverage: Do not cover more than one-quarter of the food with foil.
4. Keep Away from Walls: Ensure the foil is at least one inch away from the microwave walls, top, and bottom.
5. No Metal Contact: Avoid contact between the foil and any other metal parts inside the microwave.
6. Short Durations: Use foil for the shortest possible heating time, ideally no more than 30 seconds.
7. Monitor Closely: Watch the microwave carefully. If you see sparks, stop the microwave immediately and remove the foil.

Safe Use of Microwave-Safe Metal Containers:

1. Check for the "Microwave-Safe" Label: Only use metal containers that are explicitly labeled as microwave-safe by the manufacturer.
2. Read the Manufacturer's Instructions: Follow any specific guidelines provided by the manufacturer.
3. Ensure Smooth, Rounded Edges: Avoid containers with sharp or irregular edges, dents, or damage.
4. Avoid Contact with Microwave Walls: Keep the container away from the sides, top, and bottom of the microwave cavity.
5. Do Not Use with Other Metals: Avoid placing metal utensils inside the container and ensure no metal parts in the microwave can touch the container.
6. Short Heating Intervals: Heat in shorter intervals and check frequently.
7. Monitor Closely: Stay near the microwave, especially the first few times you use a new container. Stop immediately if you see sparks.
8. Remove Lids (If Not Microwave-Safe): Remove any non-microwave-safe lids before microwaving.
9. Be Aware of Longer Heating Times: Metal containers and their contents may take longer to heat.

†affresh[®] is a registered trademark of Whirlpool, U.S.A.

Electrical Requirements

⚠ WARNING



Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Observe all governing codes and ordinances.

Required:

- A 120 V, 60 Hz, AC-only, 15- or 20-amp electrical supply with a fuse or circuit breaker.

Recommended:

- A time-delay fuse or time-delay circuit breaker.
- A separate circuit serving only this microwave oven.

GROUNDING INSTRUCTIONS

For a grounded, cord-connected appliance:

This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING: Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the appliance is properly grounded. Do not modify the plug provided with the appliance: if it will not fit the outlet, have a proper outlet installed by a qualified electrician.


Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or serviceman install an outlet near the microwave oven.

SAVE THESE INSTRUCTIONS

This device complies with Part 18 of the FCC Rules.

PARTS AND FEATURES

This manual may cover several different models. The model you have purchased may have some or all of the features shown here. The appearance of your particular model may differ slightly from the illustrations in this manual.



A. Trim

B. Control panel

C. Door lock system

D. Door and window panels

E. Frame

F. Cavity back cover

G. Microwave oven light
(inaccessible – in ceiling)

H. Cooking guide label

I. Rating label

CONTROL PANEL



DISPLAY SCREEN

Time, power and indicators are displayed.

COOK

Press to select cooking menus.

DEFROST

Press to defrost food.

REHEAT

Press to select reheating menus.

KEEP WARM

Used to set keeping warm function.

STEAM CLEAN

Used to set steam clean function.

POPCORN

Press to cook popcorn.

POTATOES

Press to cook potatoes.

VEGGIES

Press to cook veggies.

SOFTEN/MELT

Press to soften/melt food.

Press and hold for 3 seconds to mute all sounds.

COOK TIME/POWER

Press to set microwave cooking program.

TIMER

Press once to set kitchen timer function.

Press and hold to set clock time function.

NUMBER BUTTONS

Press to set time, food weight or servings.

START/+30 s

Press to start a cooking program.

Press to quick start the microwave oven for 30 seconds at full power.

CANCEL

Press once to cancel cooking.

Press and hold for 3 seconds to set control lock.

OPEN/CLOSE

When the Control Lock is deactivated, press the OPEN/CLOSE button to automatically open or close the drawer. The drawer can be manually pushed or pulled to open or close at any time.

CAUTION: The maximum load capacity for the automatic drawer is 7.7 lbs (3.5 kg). Exceeding this limit may damage the motor or drive mechanism.

SETTINGS

- When the oven is plugged in, a "DE" will sound and all icons light up for 2 seconds. After 2 seconds, the display screen will show "12HR" (12 flashing),  (flashing), you can press TIMER button to select 24- hour or 12-hour clock.
 - During cooking, if open the oven door, the program will be paused, then close the door, press START/+30 s button to resume. During setting, a "DE" will sound and the system will return to standby mode if there is not any operation within 60 seconds.
 - If there is no operation for 60 seconds in standby mode, a "DE" will sound, the backlight will dim, and the system will enter power saving mode. Pressing any button once and opening the oven door will exit the power saving mode.
 - After cooking ends, the display will show End and 3 "DE" will sound. After 1 minute, a second prompt sound will be emitted, and the system will emit a prompt sound every 3 minutes. After the fifth prompt is completed, it will automatically return to standby mode, or press CANCEL button once or open the oven door, and the system will return to standby mode.
 - During cooking without opening the oven door, if there is no operation for more than 10 minutes after pausing, the work will automatically end and return to the standby interface.
 - The electronically controlling system of the microwave oven has the feature of cooling. As for microwave cooking mode which cooking time above 2 minutes, after cooking ends, the oven fan will work about 3 minutes automatically to cool the oven for prolonging the life of the oven.
 - When the door is opened or during cooking, the oven light is turned on by default.
 - When the microwave is in operation, if the remaining cooking time is less than 6.8 seconds when adjusting the time by pressing START/+30 s, the time cannot be modified
 - After cooking is completed, press START/+30 s button to immediately start a new cooking. The parameters for the new cooking will continue from the previous cooking parameters, and the cooking time will default to 30 seconds.
 - If the oven door is not closed, cooking cannot be started, and the display screen shows "DOOR" for 3 seconds, prompting the user to close the oven door
- When the unit is just powered on or returns to the default mode, it will enter the protection mode. At this time, the prompt "DOOR" will appear on the startup screen for three seconds, and you need to open and close the door once to start the cooking. Do not open the door or press the "CANCEL" button during the the humidity menu is in operation; otherwise, the cooking will malfunction and stop working, returning to the standby screen.

STANDBY MODE

When no functions are being used, the microwave oven will switch to standby mode and slightly dim the display brightness after about 1 minutes. Press any button or open the door, the display will return to normal lightness.

SETTING THE CLOCK

The first method:

1. When the oven is first plugged in, the display screen will show "12 HR" (12 flashing), you can press TIMER button repeatedly to select 24- hour or 12-hour clock.
2. Press START/+30 s button once.
3. Use number buttons to set correct time.
4. Press START/+30 s or TIMER button once to confirm.

The second method:

1. In idle state, press Timer button to activate oven.
2. Press and hold TIMER button for 3 seconds.
3. Use number buttons to set the correct time.
4. Press START/+30 s or TIMER button once to confirm

NOTE:

- During the clock setting period after power on, if the clock is not set or if there is not any operation within 60 seconds, the system returns to standby, the display screen will show ":" (not flashing) indicating that the clock has not been set. If there is not any operation in 10 seconds on the clock selection interface, directly enter the clock setting interface.
- After setting the clock value incorrectly, press START/+30s button, and the system will display "00:00" (flashing) and emit an error prompt sound.

SETTING THE TIMER

1. In idle state, press TIMER button once.
2. Use number buttons to enter desired time. The longest time is 90 minutes.
3. Press START/+30 s button to confirm.

NOTE: When the countdown ends, the buzzer will beep to remind you. During setting or cooking, you can check the countdown time by pressing TIMER button, and if CANCEL button is pressed when the display shows the time, the function can be cancelled.

MUTE FUNCTION

To set: Press and hold SOFTEN/MELT button for 3 seconds, the display will show "". The system has entered mute mode.

To exit: In mute mode, press and hold SOFTEN/MELT button for 3 seconds, the "" will go off. The system has exited mute mode.

CONTROL CLOCK

The child proof lock prevents unsupervised operation by children.

To set: In idle state, press and hold CANCEL button for 3 seconds, the oven will auto enter child lock mode and the lock indicator light will turn on. In the lock state, all buttons are disabled.

To exit: In child lock mode, press and hold CANCEL button for 3 seconds, the lock indicator will go off. The system has exited child lock mode.

MICROWAVE OVEN COOKING FUNCTIONS

WARNING

Food Poisoning Hazard

Do not let food sit in oven more than one hour before or after cooking.

Doing so can result in food poisoning or sickness.

COOK TIME/POWER

1. While in the Idle State, press CookTime/Power button once.
2. Use the number pad to enter the desired cooking time. (Maximum time: 90 minutes).
3. Press CookTime/Power again to adjust the power level. (Default is 100%). Use the number pad to select a power level.
4. Press START / +30 Sec to begin cooking.

During microwave cooking, press the "Cook Time/Power" button once. The current cooking time will pause (the countdown continues in the background), and you will enter the time adjustment interface. At this time, press the number keys to set the desired time. The new time setting will take effect automatically after 5 seconds, or you can press the "START/+30Sec" button to confirm and activate it immediately. (Note: Time and power level cannot be adjusted if the remaining cooking time is less than 6 seconds.)

In the time setting interface, press the "Cook Time/Power" button once. The "%" indicator will flash, and you will enter the power level adjustment interface. At this time, press the number keys to set the desired power level. The new power setting will take effect automatically after 5 seconds, or you can press the "START/+30Sec" button to confirm and activate it immediately.

Number	Percent/ Name	Use
10	100%	Quick heating convenience foods and foods with high water content, such as cooking soups with raw ingredients, heating beverages, and cooking most vegetables.
9	90%	Cooking small, tender pieces of meat, ground meat, poultry pieces, and fish fillets. Heating cream soups.
8	80%	Heating rice, pasta, or casseroles. Cooking and heating foods that need a cook power lower than high, for example, whole fish and meat loaf.
7	70%	Reheating ready-cooked food, single or multiple dishes.
6	60%	Cooking sensitive foods such as cheese and egg dishes, pudding, and custards.
5	50%	Cooking non-stirtable casseroles, such as lasagna.
4	40%	Cooking ham, whole poultry, and pot roasts.
3	30%	Simmering stews, melting butter.
2	20%	Defrosting, melting chocolate. Heating bread, rolls, and pastries.
1	10%	Taking chill out of fruit, Softening butter, cheese, and ice cream.

Tips and suggestions:

For a better cooking performance, it is recommended to stir/turn and let the food stand 1 minutes after cooking and reheat.

When cooking foods with high water content (such as potatoes), moisture may form inside the door and oven cavity. After the oven cavity and door cool down, wipe them off with a dry cloth.

EXPRESS COOKING

Use this feature to program the oven to microwave food at 100% power conveniently. In idle state, press START/+30 s. button once (Default cooking time is 30 seconds), the oven will start automatically at 100% high power level.

NOTE: The longest cooking time is 90 minutes.

COOK

1. In idle state, press the Cook button repeatedly to select your food category.
2. Press the START/+30 s button, then use the number buttons to select the food quantity (this step can be skipped for sensor-based food categories).
3. Press the START/+30 s button to begin.

Item	Food Category	Display	Quantity	Food weight		Instruction
				Ounce	Gram	
1	Bacon	BACN	1-6 slices	0.7 oz / slice	20 g / slice	Average thickness: Follow directions on the package. For best results, place bacon on a microwave-safe bacon rack.
2	Rice	RICE	Senses 0.5- 2.0 cups	3.4 oz - 13.6 oz (6.8 oz rice / cup)	96 g - 384 g (192 g rice /cup)	Follow measurements on the package for ingredient amounts. Place rice and liquid in a microwave-safe dish. Cover with a loose fitting lid. Stir and let stand for 5 minutes after cooking, or until liquid is absorbed.
3	Frozen Entree	FRZN MEAL	Senses 10 - 40 oz	10 - 40 oz	283 - 1134 g	Loosen film covering on 3 sides of the container leaving one of the short sides still attached. Let stand for 3-5 minutes after cooking.
4	Oatmeal	OAT MEAL	Senses 1-4 cups	1.2 oz / serving	35 g / serving	Cover with plastic wrap and vent. Stir after cooking.

DEFROST

1. In idle state, press the Defrost button repeatedly to select your food category.
 2. Press the START/+30 s button, then use the number buttons to enter the defrost time or food quantity..
 3. Press the START/+30 s button to begin.
- For the better cooking performance, try to use the preset button firstly.
 - For optimal results, food should be 0°F (-18°C) or colder when defrosting.
 - Unwrap foods and remove lids (from fruit juice) before defrosting.
 - Shallow packages will defrost more quickly than deep blocks.
 - Separate food pieces as soon as possible during or at the end of the cycle for more even defrosting.
 - Foods left outside the freezer for more than 20 minutes or frozen ready-made food should not be defrosted using the Defrost feature but should be defrosted manually.
 - Use small pieces of aluminum foil to shield parts of food such as chicken wings, leg tips, and fish tails. See the “Aluminum Foil and Metal” section first.
 - Times and cooking powers have been preset for defrosting a number of food types.
 - Let stand 5-20 minutes after defrosting.

Item	Food Category	Display	Quantity	Food weight		Instruction
				Ounce	Gram	
1	Manual Defrost	MDEF	Enter time	/	/	Use microwave safe plate
2	Chicken	CHKN	Enter 0.2-6.6 lb	3.2 - 106 oz	91 - 2994 g	Use microwave safe plate
3	Ground Beef	BEEF	Enter 0.2-6.6 lb	3.2 - 106 oz	91 - 2994 g	Use microwave safe plate

REHEAT

1. In idle state, press the REHEAT button repeatedly to select your food category.
2. Press the START/+30 s button, then use the number buttons to select the food quantity (this step can be skipped for sensor-based food categories).
3. Press the START/+30 s button to begin.

Item	Food Category	Display	Quantity	Food weight		Instruction
				Ounce	Gram	
1	Dinner plate	MEAL	Sense 1 plate	10 - 15 oz	284 - 425 g	Place food on a plate. Cover with plastic wrap and vent. Let stand for 3 minutes after reheating.
2	Pizza	PIZZ	Sense 1-3 slices	3.5 oz / slice	100 g / slice	Place on a paper towel lined microwave-safe plate.
3	Casserole	CASS	1-4 cups	7.8 oz / cup	220 g / cup	Place in a microwave-safe container. Cover with plastic wrap and vent. Stir and let stand for 3 minutes after reheating.
4	Soup	SOUP	Sense 1-4 cups	8.8 oz- 35.2 oz	250 g - 1 kg	Place in a microwave-safe container. Cover with plastic wrap and vent. Stir and let stand for 3 minutes after reheating.
5	Beverage	BEV	1-4 cups	8 oz - 32 oz (8 oz / each)	236 g - 944 g (236 g / cup)	Place in microwave-safe container. Do not cover.

Keep Warm

⚠ WARNING

Food Poisoning Hazard

Do not let food sit in oven more than one hour before or after cooking.

Doing so can result in food poisoning or sickness.

1. In idle state, press KEEP WARM button repeatedly or use number buttons (1~4) to select time.
2. Press START/+30 s button to start.

Steam Clean

This automatic cleaning cycle will help you to clean the microwave oven cavity and to remove unpleasant odors.

Before starting the cycle:

1. Put 250 mL water into a container (see our recommendations in the below section “Tips and suggestions”).
2. Place the container directly on the middle of the oven bottom.
3. Close the door.

To Start The Cycle:

1. Press the Steam Clean button.
2. Press the START / + 30 s button to start the function.

When The Cycle Is Finished:

1. Press the CANCEL button.
2. Remove the container.
3. Use a soft cloth or a paper towel with mild detergent to clean the interior surfaces.

Tips and suggestions:

For a better cleaning result, it is recommended to use a container with a diameter of 17-20 cm, and a height that is lower than 6.5 cm.

It is recommended to use a container of light plastic material that is suitable for the microwave.

As the container will be hot after the cleaning cycle is completed, it is recommended to use a heat resistant glove when removing the container from the microwave.

For a better cleaning effect and removal of unpleasant odors, add some lemon juice or vinegar to the water.

POPCORN

1. Press the Popcorn button once, the display screen shows “POPC”.
2. Press START/+30 s button to start.

Quantity	Display	Food weight		Instruction
		Ounce	Gram	
Sense 3.0 ~ 3.5 oz	POPC	3.0 ~ 3.5 oz	85 ~99 g	Do not use regular paper bags or glassware. Follow manufacturer's instructions when using a microwave popcorn popper. Listen for popping to slow to one pop every 1 or 2 seconds, and then stop the cycle. Do not repop unpopped kernels. For best results, use fresh bags of popcorn. Cooking results may vary by brand and fat content. Follow the instructions provided by themicrowave popcorn manufacturer.

Potato

1. Press the Potato button repeatedly to select potato size.
2. Press the START/+30 s button, then use number buttons to select potato quantity.
3. Press the START / + 30 s button to cook.

Item	Food Category	Display	Quantity	Food Weight		Instruction
				Ounce	Gram	
1	Large potatoes	LRG	1-4 potatoes	8 - 12 oz / each	227 - 340 g / each	Pierce each potato several times with a fork. Place on a paper towel, around ceramic plate edges, at least 1" (2.5 cm) apart. Place a single potato to the side of the glass tray. Place 4 or more potatoes in a spoke pattern (long-axis of potato pointing toward the center). Let stand for 5 minutes after cooking.
2	Small potato	SML	1-16 potatoes	3 - 5 oz / each	85 - 142 g / each	Pierce each potato several times with a fork. Place on a paper towel, around ceramic plate edges, at least 1" (2.5 cm) apart. Place 4 or more potatoes in a spoke pattern (long-axis of potato pointing toward the center). Let stand for 5 minutes after cooking.

Veggies

1. In idle state, press the Veggies button repeatedly to select food category.
2. Press the START / + 30 s button to cook.

Item	Food Category	Display	Quantity	Food weight		Instruction
				Ounce	Gram	
1	Fresh Vegetables	FRSH	Sense 1-4 cups	3.5 oz - 14 oz (3.5 oz / each)	100 g - 400 g (100 g / cup)	Place in a microwave-safe container and add 2-4 tbs water. Cover with plastic wrap and vent. Stir and let stand for 3 minutes after cooking.
2	Frozen Vegetables	FRZN	Sense 1-4 cups	3.5 oz - 14 oz (3.5 oz / each)	100 g - 400 g (100 g / cup)	

SOFTEN/MELT

1. In idle state, press SOFTEN/MELT button repeatedly to select food category.
2. Press START/+30 s button, then use number buttons to select the quantity.
3. Press START/+30 s button to start.

Item	Food Category	Display	Quantity	Food weight		Instruction
				Ounce	Gram	
1	Soften Butter	SOF 1	0.5, 1.0, 1.5, 2.0 sticks	2, 4, 6, 8 oz (4.0 oz / stick)	57, 113, 170, 227 g (113 g / stick)	Unwrap and place in a microwave-safe container. Stir after melting.
2	Soften Cream Cheese	SOF 2	3, 8 oz	3, 8 oz	85, 227 g	Place in a microwave-safe container. Stir after melting.
3	Soften Ice Cream	SOF 3	16, 32oz	16, 32 oz	454, 907 g	Cut squares into small pieces or use chips. Place in a microwave safe container. Stir after melting.
4	Melt Butter	MLT 4	0.5, 1.0, 1.5, 2.0 sticks	2, 4, 6, 8 oz (4.0 oz / stick)	57, 113, 170, 227 g (113 g / stick)	Unwrap and place in a microwave-safe container. Stir after melting.
5	Melt Chocolate Chips	MLT 5	4, 8, 12 oz	4, 8, 12 oz	113, 227, 340 g	Cut squares into small pieces or use chips. Place in a microwave safe container. Stir after melting.
6	Melt Cheese	MLT 6	8, 16 oz	8, 16 oz	227, 454 g	Cut into small pieces and place in a microwave safe container. Stir after melting.