



802.11ax-HE160 Ant 2

Channel 15 (6025MHz)

The Reference Level



The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11ax-HE160 Ant 2

Channel 111 (6505MHz)

The Reference Level




The Mask Data




Channel 143 (6665MHz)

The Reference Level




The Mask Data




Channel 175 (6825MHz)

The Reference Level




The Mask Data




802.11ax-HE160 Ant 2

Channel 207 (6985MHz)

The Reference Level




The Mask Data




802.11a - Ant 3

Channel 01 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11a - Ant 3

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




Channel 113 (6515MHz)

The Reference Level




The Mask Data




802.11a - Ant 3

Channel 117 (6535MHz)

The Reference Level




The Mask Data




Channel 149 (6695MHz)

The Reference Level




The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data




802.11a - Ant 3

Channel 185 (6875MHz)

The Reference Level




The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data




Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11a - Ant 3

Channel 229 (7095MHz)

The Reference Level




The Mask Data



802.11ax-HE20 – Ant 3

Channel 01 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data




802.11ax-HE20 Ant 3

Channel 97 (6435MHz)

The Reference Level




The Mask Data



Channel 105 (6475MHz)

The Reference Level



The Mask Data



Channel 113 (6515MHz)

The Reference Level




The Mask Data



802.11ax-HE20 Ant 3

Channel 117 (6535MHz)

The Reference Level




The Mask Data



Channel 149 (6695MHz)

The Reference Level




The Mask Data




Channel 181 (6855MHz)

The Reference Level




The Mask Data



802.11ax-HE20 Ant 3

Channel 185 (6875MHz)

The Reference Level




The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data



Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11ax-HE20 Ant 3

Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11ax-HE40 Ant 3

Channel 03 (5965MHz)

The Reference Level




The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data



Channel 91 (6405MHz)

The Reference Level



The Mask Data

