


SERVO-DRIVE for AVENTOS/SERVO-DRIVE uno for AVENTOS

SERVO-DRIVE for AVENTOS supports the opening and closing of lift systems in furniture.

Reference diagram




- 1 Lift mechanism, drive unit and cover cap
- 2 Lever arm
- 3a SERVO-DRIVE transformer
- 3b SERVO-DRIVE plug-in transformer
- 4 SERVO-DRIVE switch
- 5 Blum distance bumper
- 6 Cabinet
- 7 Front/Lift system

SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM

SERVO-DRIVE supports the opening of drawers.

Reference diagram




- 1 Drive unit
- 2 Eject lever
- 3 SERVO-DRIVE transformer
- 4 Blum distance bumper



SERVO-DRIVE flex for refrigerators and freezers

SERVO-DRIVE flex allows handle-less refrigerators and freezers to be opened electromechanically by pressing the front.

Orientation diagram




- 1 Drive unit
- 2 Catch plate
- 3 Mounting plate
- 4 Front fixing
- 5 Blum distance bumper
- 6 Assembly jig
- 7 Front cover
- 8 Chipboard screws

SERVO-DRIVE flex for dishwashers

SERVO-DRIVE flex allows handle-less dishwashers to be opened electromechanically by pressing the front.

Orientation diagram




- 1 Drive unit
- 2 Catch plate
- 3 Mounting plate
- 4 Front fixing
- 5 Assembly jig
- 6 Front cover
- 7 Chipboard screws



SERVO-DRIVE for AVENTOS/SERVO-DRIVE uno for AVENTOS


Electrical motion support system

The SERVO-DRIVE switch triggers the automatic opening and closing action of SERVO-DRIVE for AVENTOS.



Press on the front

- The lift system opens automatically




Press on the SERVO-DRIVE switch

- The lift system closes automatically




Manual operation

The lift system can be opened or closed manually at any time without damaging SERVO-DRIVE for AVENTOS.




- Manual opening of the lift system by moving it upwards




- Manual closing of the lift system by moving it downwards

Collision detection



The opening and closing action is interrupted automatically via the integrated collision detection feature when the front hits a body part or other object.

Lean protection feature



SERVO-DRIVE for AVENTOS is only triggered by a brief touch. Leaning on the lift system will not open it.



Power failure

If the power supply is interrupted during the opening or closing process, the SERVO-DRIVE for AVENTOS lift system will remain in that position. The front can be closed manually, or when power is restored; simply touch the switch to re-activate SERVO-DRIVE function.

The following parameters must be observed to ensure the error-free functioning of SERVO-DRIVE for AVENTOS:


- Blum distance bumpers must be attached to the front to maintain the required distance between the lift system and the cabinet.
- No items should be placed between the front and the cabinet.

NOTE

- Improper use may cause SERVO-DRIVE for AVENTOS to wear prematurely!
- Do not press or pull with force against the movement direction when opening or closing the lift system.
- Never remove the front. Front removal may only be carried out by qualified personnel. See also the safety section at the first pages of this leaflet.

SERVO-DRIVE switch

The SERVO-DRIVE switch is battery-operated (CR2032). Only use batteries from reputable manufacturers.




- 1 Battery display (LED)
- 2 Connect (LED)



Replacing the battery

When the battery power begins to weaken, the battery display (LED) will begin to flash red.



- ❶ Open the SERVO-DRIVE switch and remove the battery holder
- ❷ Remove the battery
- ❸ Insert new battery (type CR2032), observing the correct pole connections
- ❹ Close battery holder

If the battery is inserted incorrectly, the SERVO-DRIVE switch battery display will light up red.


NOTE

The SERVO-DRIVE switch battery must not be recharged or discarded into fire.




SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM

Electrical motion support system



When the front and/or handle of the drawer (A) is pulled or pressed, the eject lever of the drive unit (B) swivels forward and opens the pull-out unit a short distance.


Lean protection feature



The electrical opening support function is only triggered by a brief touch or pull. Leaning on the pull-out unit, for example, will not open it.




The following parameters must be observed to ensure the error-free functioning of SERVO-DRIVE:



- Blum distance bumpers must be attached to the front to ensure the required triggering signal (2 mm) between the pull-out unit and the cabinet.
- No items can be clamped between the pull-out unit and the cabinet back and/or SERVO-DRIVE.

SERVO-DRIVE transformers

SERVO-DRIVE transformers provide power to the drive unit. SERVO-DRIVE transformer function can be checked via the operating mode indicator (LED).



- 1 Power connection
- 2 Operating mode display (LED) Serial tag
- 3

NOTE


- Improper use may cause SERVO-DRIVE for pull-out systems to wear prematurely!
- Do not press or pull with force against the movement direction when opening or closing the drawer.



SERVO-DRIVE flex


Electrical motion support system

Pressing the handle-less front will trigger the electromechanical opening of SERVO-DRIVE flex.



1) Press (do not pull) the front

- The door (refrigerator or dishwasher) will open slightly for 2.5 sec




2) User utilises opening to grip door

- Continues opening process

2b) User does not touch door

- Door closes again





Problems

Possible cause

Remedy

Battery display on SERVO-DRIVE switch flashes red.	SERVO-DRIVE switch battery is losing power.	➤ Replace the battery.
Battery display lights up red	Battery has been inserted incorrectly.	➤ Insert the battery correctly.
SERVO-DRIVE for AVENTOS does not open or close completely.	The front is not balanced or does not lie flat on the cabinet evenly.	➤ Contact your distributor's customer service to readjust the front.
SERVO-DRIVE for AVENTOS does not work on one particular lift system when pressing on the front or using the SERVO-DRIVE switch.	SERVO-DRIVE switch battery has run out of power.	➤ Replace the battery.
	Battery was inserted incorrectly.	➤ Insert the battery correctly.
	SERVO-DRIVE switch is defective.	➤ Contact your distributor's customer service to replace the SERVO-DRIVE switch.
	Drive unit is defective.	➤ Contact your distributor's customer service to replace the drive unit.
	Cabling is defective.	➤ Contact your dealer's customer service to correct the problem.
SERVO-DRIVE for AVENTOS does not close completely.	An object is between the lift system and cabinet or jammed between the lever and front.	➤ Remove the obstruction.
	An object juts out over the front edge of the cabinet.	➤ Remove the obstruction.
[OK] button of drive unit lights up red continuously.	Drive unit is defective.	➤ Replace drive unit.



Problems	Possible cause	Solution
The balance misadjustment indicator lights up.	Front is not balanced.	➤ Adjust the balance on the lift mechanism.
The BLUMOTION adjustment indicator lights up.	BLUMOTION adjustment is incorrect.	➤ Change the BLUMOTION adjustment on the lift mechanism.



Problems

Possible cause

Solution

SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM will not work on any drawers when pushing or pulling.

SERVO-DRIVE transformer is not connected to the outlet.

- Plug in the SERVO-DRIVE transformer to the outlet.

The power supply has been interrupted

- Check the circuit breaker/fuse box.
- If necessary, contact an authorised electrician.

SERVO-DRIVE transformer is defective.

- If necessary, have the distributor's customer service replace the SERVO-DRIVE transformer.

SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM will not work for an entire cabinet when pushing or pulling.

Cabling is defective.

- Contact your distributor's customer service to correct the problem.

SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM will only work when drawer is pulled – not by pushing.

Object is obstructing path.

- Remove the obstruction.

Blum distance bumper was removed or is defective.

- Contact your distributor's customer service to replace the Blum distance bumper.

SERVO-DRIVE for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM does not work for an individual pull-out – neither pulling nor pushing.

Max. fill height of drawer has been exceeded.

- Open the drawer manually.
- Remove the items that are too high from the pull-out.

SERVO-DRIVE is defective.

- Contact your distributor's customer service to replace the drive unit.



Problems

The refrigerator door does not open

Possible cause

If the door of the device is left open for a relatively long time, for example when putting away shopping, a vacuum may be created inside the refrigerator or freezer after it has been closed. This may result in it not being possible to open the door of the device for a few seconds.

Remedy

- Wait for the pressure to neutralise (this may take up to 20 sec)

SERVO-DRIVE flex for refrigerators, freezers and dishwashers:

- Unit does not respond to activation
- Unit responds slowly to activation
- Unit does not open fully

Mounting plate has been installed too far back

- Check position using assembly template
- Ensure dimensions correspond to assembly instructions

Blum distance bumper pad not inserted or positioned incorrectly

- Install Blum distance bumper pad
- Correct positioning

Front gap too small
Front gap too large

- Adjust front gap to 2.5–3 mm (in accordance with instructions for white goods)

Trigger fails to initiate movement across entire front height

- Wireless switches are recommended

Incorrect drilling cover (blocked rod)

- Drill a new front

Refrigerator assembly stops have not been removed

- Remove in accordance with white goods instructions

The reference run has not been carried out correctly (e.g. due to manual interference during the reference run).

- Reset system, begin a new reference run

**Problems****Possible cause****Remedy**

Door does not close

Catch plate is not installed

➤ Install catch plate


Catch plate is positioned incorrectly

➤ Reposition the catch plate

Dishwasher does not close completely

Dishwasher locking mechanism has become stiff (depending on model)

➤ Push front until it closes (this is NOT a product defect)



Technical data


The appliances must only be used in dry, closed rooms. All SERVO-DRIVE appliances are of protection class III and must only be supplied with safety extra-low voltage (SELV). They are only to be used with the transformers provided by Blum.

SERVO-DRIVE transformer Z10NE030

Input voltage:	100–240 V AC / 50–60 Hz
Input current:	0.6 A
Output voltage:	24.0 V DC
Output current:	1.0 A
Output power:	24.0 W
Average active efficiency:	86.8 %
Efficiency at low load (10%):	84.0 %
No-load power consumption:	≤ 0.08 W
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	2000 m (at an ambient temperature of 25 °C)
Protection category:	IP40

SERVO-DRIVE transformer Z10NE040

Input voltage:	100–240 V AC / 50–60 Hz
Input current:	2.5 A
Output voltage:	24.0 V DC
Output current:	3.0 A
Output power:	72.0 W
Average active efficiency:	≥ 88.0 %
Efficiency at low load (10%):	≥ 80.0 %
No-load power consumption:	≤ 0.15 W
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	4000 m (at an ambient temperature of 25 °C)
Protection category:	IP40


**SERVO-DRIVE plug-in transformer Z10NA300**

Input voltage:	100–240 V AC / 50–60 Hz
Input current:	0.3 A
Output voltage:	24.0 V DC
Output current:	0.5 A
Output power:	12.0 W
Average active efficiency:	83.3 %
Efficiency at low load (10%):	78.0 %
No-load power consumption:	≤ 0.08 W
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	2000 m (at an ambient temperature of 25 °C)
Protection category:	IP44

SERVO-DRIVE plug-in transformer Z10NA40x*

Input voltage:	100–240 V AC / 50–60 Hz
Input current:	2.0 A
Output voltage:	24.0 V DC
Output current:	1.0 A
Output power:	24.0 W
Average active efficiency:	≥ 86.4 %
Efficiency at low load (10%):	≥ 77.0 %
No-load power consumption:	≤ 0.10 W
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	4000 m (at an ambient temperature of 25 °C)
Protection category:	IP44

* x = B, E, H, K, N, R, S, U, Z




SERVO-DRIVE drive unit for AVENTOS 21FA001, 21SA001, 21LA001, 21KA001

Supply voltage:	24.0 V DC
Rated current:	2.0 A
Power consumption in standby mode:	≤ 0.55 W (front closed)
Operating mode:	S3 5 % (max. 10 motions/10 min.)
Emission sound pressure level:	< 70 dB(A)
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	2000 m (at an ambient temperature of 25 °C)
Protection category:	IP20
Radio equipment:	
Frequency band:	2.404 to 2.452 GHz
Maximum radio-frequency power:	+4 dBm / 2.5 mW
Range:	typically 10 m (depending on material and contents)
Transmission method:	bidirectional, via a coded wire

SERVO-DRIVE drive unit for AVENTOS top 23.A001, 23KA001


Supply voltage:	24.0 V DC
Rated current:	2.0 A
Power consumption in standby mode (23.A001):	≤ 0.15 W (front closed)
Power consumption in standby mode (23KA001):	≤ 0.40 W (front closed)
Operating mode:	S3 5 % (max. 10 motions/10 min.)
Emission sound pressure level:	< 70 dB(A)
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	4000 m (at an ambient temperature of 25 °C)
Protection category:	IP20
Radio equipment:	
Frequency band:	2.404 to 2.452 GHz
Maximum radio-frequency power:	+4 dBm / 2.5 mW
Range:	typically 10 m (depending on material and contents)
Transmission method:	bidirectional, via a coded wire

**SERVO-DRIVE drive unit for LEGRABOX/TANDEMBOX/MOVENTO/TANDEM Z10A3000.03,
Z10A3000.50**

Supply voltage: 24.0 V DC
Rated current: 2.0 A
Power consumption in standby mode: ≤ 0.15 W (front closed)
Operating mode: S3 5 % (max. 10 motions/10 min.)
Emission sound pressure level: < 70 dB(A)
Ambient conditions:
 Transport / Storage: -30 to $+70$ °C / 0 to 90 % r.H.
 Operation: 0 to $+40$ °C / 5 to 80 % r.H. non condensing
 Maximum altitude: 2000 m (at an ambient temperature of 25 °C)
Protection category: IP20

SERVO-DRIVE flex drive unit Z10C5000

Supply voltage: 24.0 V DC
Rated current: 2.0 A
Power consumption in standby mode: ≤ 0.15 W (front closed)
Power consumption in standby mode (with wireless receiver): ≤ 0.35 W (front closed)
Operating mode: S3 5 % (max. 10 motions/10 min.)
Emission sound pressure level: < 70 dB(A)
Ambient conditions:
 Transport / Storage: -30 to $+70$ °C / 0 to 90 % r.H.
 Operation: 0 to $+40$ °C / 5 to 80 % r.H. non condensing
 Maximum altitude: 2000 m (at an ambient temperature of 25 °C)
Protection category: IP20
Radio equipment (with wireless receiver):
 Frequency band: 2.404 to 2.452 GHz
 Maximum radio-frequency power: $+4$ dBm / 2.5 mW
 Range: typically 10 m (depending on material and contents)
 Transmission method: bidirectional, via a coded wire




SERVO-DRIVE switch 23P5020

Supply voltage:	3.0 V Lithium button cell CR2032
Rated current:	10 mA
Power consumption in standby mode:	≤ 1 µW
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	4000 m (at an ambient temperature of 25 °C)
Protection category:	IP20
Radio equipment:	
Frequency band:	2.404 to 2.452 GHz
Maximum radio-frequency power:	+4 dBm / 2.5 mW
Range:	typically 10 m (depending on material and contents)
Transmission method:	bidirectional, via a coded wire

Wireless receiver Z10C5007

Supply voltage:	24.0 V DC
Rated current:	10 mA
Power consumption in standby mode:	≤ 0.20 W
Ambient conditions:	
Transport / Storage:	-30 to +70 °C / 0 to 90 % r.H.
Operation:	0 to +40 °C / 5 to 80 % r.H. non condensing
Maximum altitude:	2000 m (at an ambient temperature of 25 °C)
Protection category:	IP20
Radio equipment:	
Frequency band:	2.404 to 2.452 GHz
Maximum radio-frequency power:	+4 dBm / 2.5 mW
Range:	typically 10 m (depending on material and contents)
Transmission method:	bidirectional, via a coded wire

**Quake sensor Z10ZE000**


Supply voltage: 24.0 V DC
Rated current: 25 mA
Power consumption in standby mode: ≤ 0.20 W
Switching current: ≤ 10.0 A
Switching threshold: $0.2 \text{ m/s}^2 \approx 0.02 \text{ g}$
Ambient conditions:
 Transport / Storage: -30 to $+70$ °C / 0 to 90 % r.H.
 Operation: 0 to $+40$ °C / 5 to 80 % r.H. non condensing
 Maximum altitude: 2000 m (at an ambient temperature of 25 °C)
Protection category: IP20

COMBOX Z10ZC000

Supply voltage: 24.0 V DC
Rated current: 10 mA
Power consumption in standby mode: ≤ 0.10 W
Ambient conditions:
 Transport / Storage: -30 to $+70$ °C / 0 to 90 % r.H.
 Operation: 0 to $+40$ °C / 5 to 80 % r.H. non condensing
 Maximum altitude: 2000 m (at an ambient temperature of 25 °C)
Protection category: IP20

Connecting nodes Z10V1000.01, Z10V100E.01

Rated voltage: 24.0 V DC
Rated current: 10.0 A
Ambient conditions:
 Transport / Storage: -30 to $+70$ °C / 0 to 90 % r.H.
 Operation: 0 to $+40$ °C / 5 to 80 % r.H. non condensing
 Maximum altitude: 4000 m (at an ambient temperature of 25 °C)



Simplified EU declaration of conformity

Julius Blum GmbH hereby declares that all electrical and electronic article types of Julius Blum GmbH conform to Directive 2011/65/EU.

Julius Blum GmbH hereby declares that the machine types Z10A3000 and Z10C5000 conform to the Directive 2006/42/EC and Directive 2014/30/EU.

Julius Blum GmbH hereby declares that the machine types 23.A001, 23KA001, 21FA001, 21LA001, 21SA001 and 21KA001 conform to the Directive 2006/42/EC and Directive 2014/53/EU.

Julius Blum GmbH hereby declares that the radio equipment types 23P5020 and Z10C5007 conform to the Directive 2014/53/EU.

Julius Blum GmbH hereby declares that the electrical and electronic article types Z10ZE000 and Z10ZC000 conform to the Directive 2014/30/EU.

Julius Blum GmbH hereby declares that the Blum transformer types Z10NA300, Z10NA40x*, Z10NE030 and Z10NE040 conform to the directive 2014/35/EU and Directive 2014/30/EU.

The complete text of the EU declaration of conformity is available at the following Internet address:
www.blum.com/compliance

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Unique Identifier

Product-Family: SERVO-DRIVE

Product-Types: 23xA00y | x ∈ {., K} ∧ y ∈ {0, 1}, 23.A00L83
21xA00y | x ∈ {F, L, S, K} ∧ y ∈ {0, 1}, Z10C5007
Z10A3000, Z10C5000
23P5020 with PCB 23P502L00 or PCB 23P502L00.01
Z10NA40x | x ∈ {B, E, H, K, N, R, S, U, Z}, Z10NA300
Z10NE040, Z10NE030

Responsible Party-U.S. Contact Information


Blum Inc.
7733 Old Plank Rd.
Stanley, North Carolina
28164

Mr. Christopher Muck
Email: chris.muck@blum.com

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

* x = B, E, H, K, N, R, S, U, Z



Spare parts form

Name of kitchen distributor/cabinet maker: _____

Address: _____

In order to receive your SERVO-DRIVE spare parts as quickly as possible, your SERVO-DRIVE and/or kitchen distributor requires the following data:

Name of kitchen owner: _____

Address: _____

Commission number: _____

Fault description: _____

Part number and batch number of the defective SERVO-DRIVE component:

	Part number	Batch number	Quantity
Blum transformer:	Z10NE _____	_____	_____
Blum plug-in transformer:	Z10NA _____	_____	_____
Drive unit:	Z10 _____	BAU _____	_____
Drive unit:	21 _____	BAU _____	_____
Drive unit:	23 _____	BAU _____	_____
SERVO-DRIVE switch:	21 23 _____	BAU _____	_____
Wireless receiver:	Z10C5007 _____	BAU _____	_____



The part number and the batch number can be found here


Blum transformer



Blum plug-in transformer



Drive unit



SERVO-DRIVE switch




Wireless receiver



Blum partners worldwide can be found at:
www.blum.com/addresses

Look for our
FSC™-certified
products



BA-139/5 · 01.22 · © Copyright by Blum

Julius Blum GmbH
Furniture Fittings Mfg.
6973 Höchst, Austria
Tel.: +43 5578 705-0
Fax: +43 5578 705-44
E-mail: info@blum.com
www.blum.com

Our sites in Austria, Poland and China are certified
to the international standards mentioned below.
Our site in the USA is certified to ISO 9001.
Our site in Brazil is certified to ISO 9001, ISO 14001 and ISO 45001.



ISO 9001
Certified Quality
System



ISO 14001
Certified Environmental
System



ISO 50001
Certified Energy
System

