

KENNETH COLE
NEW YORK

Thank you for choosing this Wellness Watch as your fitness transformation companion. Allow this manual to guide you through the functioning of your Wellness Watch. Please read this manual thoroughly before using your Wellness Watch for a smooth sail. You may refer these instructions for later use as well.

Package Contains:
1 x Wellness Watch
1 x Magnetic Charging Cable
1 x User Manual

Charge Your Wellness Watch
The Wellness Watch must be charged before initial use. It takes 2-3 hours to be fully charged. Connect and charge the watch according to the adjacent image as a reference. Using a 5V/1A adapter. Please note that the positive charge cable must be connected to the watch to be aligned correctly with the watch for the charger to connect correctly. A battery icon appears on the screen to indicate your Wellness Watch is charging.

Wake screen on by tapping the screen, pressing button or wrist raise.

Note: Once your Wellness Watch is at 10% battery, it will be automatically switched to power saving mode which will disable some functions.


Turning Your Wellness Watch On/Off
Power On: Press and hold the button for 3 seconds, the watch face will light on. The watch face is the home screen.

Power Off: Press and hold the button for 3 seconds or choose settings ⚙ then choose "POWER OFF". The POWER OFF window pops up as shown below. Choose .

Installing the App
Download the WELLNESS WATCH App on your phone. Available on both the App Store (iOS 8.0 or above) and Google Play Store (Android 5.0 or above). You can also scan the QR code below to download the App to your phone. Be sure to search and download the App before moving on to the instructions.



Bluetooth Connection
1. Connect the device directly via the App. Do not connect via your smartphone's Bluetooth.

2. Make sure your Bluetooth is enabled on your smartphone. Select device icon  on the home screen and tap the device and tap "ADD A DEVICE" to connect.

3. Find and connect "GEN2.0".

Once App and Wellness Watch are connected, time will be synced as per your smartphone, and data will be synced from Wellness Watch to App.

Note: Make sure that your watch and WELLNESS WATCH App are connected via Bluetooth. Do not exit the downloading. If interface until it displays 100% downloaded. It may take up to 2 minutes to sync the watch face with the App.

Swipe left from the home screen to access all data

You can access daily activity and sports records: (Today, Step, Sleep, Exercise), Health (Heart Rate, HRV, BP, SpO2, Temperature, Stress), Weather, Shutter, Music, Meditation.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

Swipe right from the home screen to Split Screen

Swipe left from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe down from the home screen to Quick Widgets: Power saving, Timer, Stopwatch, Vibration, Brightness, Notification, Weather, Date, Day, Battery capacity and Bluetooth connected icon.

Swipe left from the home screen to function list

We can change Menu View on Wellness Watch. Choose SETTINGS → Choose MENU VIEW. Choose GRID VIEW or the VIEW. Note: When we → choose GRID VIEW, only 12 main functions will be showed.

<