



Using Terminal UltraLight

October 13, 2014

TABLE OF CONTENTS

1	FCC statements	4
2	Overview	5
3	Using the keypad	8
4	Logging in at the printer	9
4.1	Logging out	9
5	Printing all print jobs	11
5.1	Print all jobs	11
5.2	Print with Credit balance	11
6	Copying	12
6.1	Copy and scan	12
6.2	Copy and scan with Credit balance	12
7	Terminal specifications	13
8	Terminal UltraLight beep and LED code sequences	14
9	Beep code sequences	15
10	LED code sequences	16

DOCUMENT DESCRIPTION

At a Glance

- FCC statements
- Overview
- Using the keypad
- Logging in at the printer
 - Logging out
- Printing all print jobs
 - Print all jobs
 - Print with Credit balance
- Copying
 - Copy and scan
 - Copy and scan with Credit balance
- Terminal specifications
- Terminal UltraLight beep and LED code sequences
- Beep code sequences
- LED code sequences

1 FCC STATEMENTS

§ 15.21 Information to user

The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

§ 15.105 Information to the user

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

2 OVERVIEW

YSoft SafeQ Terminal UltraLight provides a compact, fast, and easy-to-use interface for users to access multifunction printers (MFPs) and network printers to perform print, copy, and scan operations. The terminal supports [Print roaming](#) and [Authorized copying](#).


The terminal has a touch keypad for user interaction. Users can authenticate with an ID card and/or by entering a PIN.

- Terminal UltraLight Print & Copy can provide authentication for printing and copying.
- Terminal UltraLight Print Only can provide authentication only for printing.




You use the terminal to log in before using the printer.

When logging in with a PIN, touch the keys to enter your PIN; then touch **OK**.



Terminal UltraLight is equipped with a 2-port Ethernet switch — the MFP or printer connects to the Ethernet network via the terminal. The terminal communicates with the YSoft SafeQ server over the Ethernet network. MFPs and other printers communicate with the YSoft SafeQ server via the terminal. The terminal also includes an Emergency button for performing service procedures.



The terminal also features:

- Microcomputer
- Flash ROM
- (Optional) Card reader – Various optional card readers are available to meet the compatibility requirements of your existing identification cards. (PINs can be used instead of the card reader.)

3 USING THE KEYPAD

Terminal UltraLight's capacitive touch keypad does not require finger pressure — a light touch is enough. (The terminal may have been configured to emit a short beep to signal when it registers a touch.) (See [Terminal UltraLight beep and LED code sequences](#).)

NOTE: Do not touch the keypad when the terminal is starting up. The keypad is calibrated every time the terminal starts up --- essential for proper operation — and touching the keypad during startup interferes with this process.

To use the keypad:

- Use fingerpads — not fingertips. Fingerpads cover a larger area, enabling better detection by the terminal.
- Use a light touch.
- Use only fingers — not instruments such as nails, pens, or screwdrivers.
- Do not wear gloves (other than latex gloves such as those used in the medical or food industries).

The keypad may become more sensitive or less sensitive after a long period of use or when electrostatic or electromagnetic properties in the surrounding area change. If this occurs, reboot the terminal or turn the power off/on to automatically recalibrate the keypad.

4 LOGGING IN AT THE PRINTER

To use the YSoft SafeQ functions at the printer, you must first log in. The method you use depends on how the system is set up at your location.

Your system may be configured so that you can choose to log in either with a PIN or a card.

- 1 To log in, Place your ID card on the terminal as shown here.



OR

- 2 Press the keys to enter your PIN (2 to 8 numbers); then press **OK**.

If authentication is successful:

You can now use the printer.

If authentication is unsuccessful:

This LED sequence indicates that the terminal did not recognize your ID card:




Place the card again. If authentication is still not successful, contact your SafeQ administrator.

4.1 LOGGING OUT

To log out, touch the **X** button or **OK** button on the terminal or **swipe any card** (if available).

 **NOTE:** If you do not log out, the printer automatically logs you out after a period of time set by your system administrator (typically 3 minutes).



5 PRINTING ALL PRINT JOBS

5.1 PRINT ALL JOBS

After you log in, press the **Print** icon to print all your jobs waiting in the queue. If your terminal is Terminal UltraLight Print Only, your waiting jobs are printed automatically after you log in.



5.2 PRINT WITH CREDIT BALANCE

When you are using Credit (Payment system) your print jobs are printed only when you have sufficient credit balance. Once your jobs are printed, the credit balance is automatically decreased.

When you don't have sufficient balance for your jobs, the printing is not possible and the Terminal UltraLight informs you with . - - **beep code**.

When you have sufficient balance only for few waiting jobs, these jobs are printed and the remaining jobs are refused. In this case Terminal UltraLight informs you with . - - **beep code**.

6 COPYING

6.1 COPY AND SCAN

If your terminal is the Terminal UltraLight Print & Copy model, you can make copies or scans (depends on your SafeQ system configuration).

Press the **Copy** icon; then use the copier's panel to choose copy or scan options and make copies or scans.

Terminal UltraLight Print & Copy



6.2 COPY AND SCAN WITH CREDIT BALANCE

When you are using Credit (Payment system) your copy / scan jobs are performed only when you have sufficient credit balance. Once your copy / scan jobs are finished, the credit balance is automatically decreased.

When you don't have sufficient balance for your copy / scan jobs, the copying / scanning is not possible and the Terminal UltraLight informs you with . - - **beep code**.

When you have sufficient balance only for few copy / scan jobs, these jobs are performed and the remaining copy / scan jobs are refused. In this case Terminal UltraLight informs you with . - - **beep code**.

7 TERMINAL SPECIFICATIONS

Item	Specification
Terminal power supply input	12 VDC
Maximum current input	1.0 Amp
Working temperature	+5°C to +35°C (41°F to 95°F)
Storage temperature	0°C to +50°C (32°F to 122°F)
Working air humidity	20% to 85% without condensation
Storage air humidity	8% to 85% without condensation
Resistance to magnetic field	no added resistance
Network interface	2-port 10/100 Mbit switch (auto MDI/MDIX)
RAM	64KB
Flash memory	512KB
Control	Capacitive keyboard
Identification	Card reader, PIN, or card reader + PIN
Processor	Freescale Coldfire version 2

8 TERMINAL ULTRALIGHT BEEP AND LED CODE SEQUENCES

The Terminal Ultralight contains status LEDs that serve for interaction with user. This chapter describes the beeps the terminal emits and LED codes it displays to notify the user about various status conditions.

9 BEEP CODE SEQUENCES

In the following table, a period (.) represents a short beep and a dash (-) represents a long beep.

 **NOTE:** This option is available only if sound is enabled.

Sequence	Description
-	Card read error. Place the card again or use a different card.
. -	Terminal validation failed. Server reports that the terminal is not registered on SafeQ.
- -	No print job is waiting in queue.
. . -	User quota has been exceeded or user has no billing code assigned.
- . -	User authentication failed. The PIN is not valid or the ID card is not registered in SafeQ. If YSoft Payment System is used, it can indicate account is disabled.
. - -	The terminal received an error or warning message from the SafeQ server. If YSoft Payment System is used, it can indicate insufficient credit balance for current user (according SafeQ system settings for YSoft Payment System - <i>pricePerPageReservationStrategyForCopyOnHwTerminal</i>) to perform copies/scans.
- - -	Connection to SafeQ server failed.
. . . -	Hardware configuration is corrupt and the terminal cannot continue booting.
- . . -	Maximum number of firmware update attempts reached but no valid firmware detected.
. . . -	Firmware update failed.
- . . .	Software configuration cannot be saved. Probably faulty terminal EEPROM.
. . . -	Software configuration is damaged and the terminal is loading defaults.
- . . .	Maximum number of firmware update attempts reached and the terminal is resuming normal boot.
. . . -	Firmware damaged.
- . . .	Network initiation failed.
. . . .	Keyboard PCB failure.
- . . .	No reader is connected. Reader is required for operation.
. . . .	Firmware update failed. Error in server response. SafeQ server is probably not configured correctly.
- . . .	Firmware update failed. Cannot connect to SafeQ server.


10 LED CODE SEQUENCES


The following table shows the various LED code sequences and explains what they indicate.

There are following colors used for icons:

- Green - Led is green
- Red - Led is red
- Orange - Led is orange
- Grey - Led is off



Sequence	Description
	<i>Animated</i> Unsuccessful authentication. The terminal does not recognize the card, PIN, or Card Activation Code code.
	<i>All LEDs are off</i> Terminal power is off.
	<i>Animated</i> Terminal is processing; please wait.
	<i>Animated</i> Firmware upgrade in progress; please wait.
	Firmware upgrade in progress; please wait.
	Swipe card or enter PIN.
	Enter PIN (when authentication requires card + PIN).

Sequence	Description
	Enter Card Activation Code (when Card Activation Codes are enabled on the SafeQ server).
	Print jobs are available and copying is possible. Press the Print or Copy icon. NOTE: This code appears only on SafeQ Terminal UltraLight Print & Copy.
	No print jobs are available in the queue. Copying is possible. Press the Copy icon. NOTE: This code appears only on SafeQ Terminal UltraLight Print & Copy.
	Flashing Copying in progress. To cancel, press X or OK , or place a card. NOTE: This code appears only on SafeQ Terminal UltraLight Print & Copy.
	Flashing Copying in progress. Server issued a warning. See the MFP display panel for details. NOTE: This code appears only on SafeQ Terminal UltraLight Print & Copy.
	Flashing Printing in progress. Please wait until the print job is finished.
	Flashing Printing in progress. Server issued a warning. See the MFP display panel for details.
	Flashing An error occurred. See beep codes for details (page).
	Sequential... Sequence that appears as a user enters a PIN.

Sequence	Description
	<i>During boot</i> WARNING: Do not perform this action unless instructed to do so by Y Soft. Enter the terminal model. For UltraLight Print & Copy, press 1. For UltraLight Print Only, press 3.
	<i>During initialization beep sequence</i> Indicates UltraLight Print & Copy model.
	<i>During initialization beep sequence</i> Indicates UltraLight Print Only model.
	<i>During initialization beep sequence</i> Indicates Ethernet Reader model.