



GLS-005 LoRaWAN Water MIU
USER'S GUIDE
Version 1.0 Draft

NOTICES

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Equipment that this document is applicable to will be labeled in a visible area with FCC ID:

Y8E-GLS005

CAUTION: Any changes or modifications not expressly approved by Vision Metering LLC could void the user's authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated at a minimum distance of 0cm between the radiator and a person's body. Avoid alternative operating configurations.

Installation

The GLS-005 is a sealed, potted device with integral antennas. There are no user-serviceable parts, and the antennas cannot be replaced or modified.

Install the device in its intended meter pit, meter box, or wall-mount location. Maintain the 20 cm separation distance specified above. Avoid surrounding the device with metal or other conductive materials that would block RF transmission. Do not open, drill, or otherwise modify the enclosure.