





- Insert the batteries in the correct positive (+) and negative (-) polarity direction.
- Do not use batteries of different types or use a mixture of old and new batteries. The batteries may leak and cause malfunction.

4) Replace the battery cover.



This product can be charged using the included USB Type-C - USB-A cable when the separately sold battery pack is inserted into the battery compartment.

2. Pair with an iPad or an iPhone


To connect this product to an iPad or iPhone, you need a device with a USB-A port, such as a commercially available USB Type-C hub. This product does not come with a USB Type-C hub.

1) Start up your PC.

Please wait until the PC has started up and can be operated.

2) Connect a commercially available USB Type-C hub with a USB-A port to the USB Type-C port on your iPad or iPhone.

3) Insert the USB-A plug of the receiver unit into a USB-A port such as ones on a USB Type-C hub.



You may use any USB-A port.



- Ensure that the connector is correctly oriented to the port.
- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.

3) Turn the connection selection dial to to select the connection destination.



Please refer to ["Switch connected device"](#) to switch between connected devices.



When removing the receiver unit

This product supports hot plugging. The receiver unit can be removed while the iPad or iPhone is on.

4) The driver is automatically installed and the trackball can be used.

The LED lights up white for 3 seconds.

You can now use the trackball.


Using wired connection



Pairing with an iPad or an iPhone

To connect this product to an iPad or iPhone, you need a device with a USB-A port, such as a commercially available USB Type-C hub. This product does not come with a USB Type-C hub.

- 1) **Plug the Type-C connector of the included USB Type-C - USB-A cable to the USB Type-C port of this product.**




2) Start up your PC.

Please wait until the PC has started up and can be operated.

3) Connect a USB Type-C hub with a commercially available USB-A port to the USB Type-C port of your iPad or iPhone.

4) Plug the USB-A connector of the USB Type-C - USB-A cable into the USB-A port of, for example, a USB Type-C hub.



You may use any USB-A port.



- Do not pull or bend the cable using excessive force. A fire or electric shock may result from broken wires.
- Ensure that the connector is correctly oriented to the port.

- If there is strong resistance when inserting, check the shape and orientation of the connector.
Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.

5) Turn the connection selection dial to to select the connection destination.



Please refer to “[Switch connected device](#)” to switch between connected devices.



To remove the trackball

This product supports hot plugging. The trackball may be removed while your iPad or iPhone is in operation.

6) The driver is automatically installed and the trackball can be used.

The LED lights up green for 3 seconds.

You can now use the trackball.

Register custom actions to the buttons.

Only the 2 buttons and the wheel can be used under the initial settings.

- Button 1: Single-Tap
- Button 2: Secondary Click

Follow the steps below to assign all other button functions.

1. Turn ON AssistiveTouch.

1) Tap on “Accessibility” under “Settings”.

2) Tap on “Touch”.




* Screenshots will be replaced with English version when it's ready.

3) Tap on “AssistiveTouch”.




4) Tap on “AssistiveTouch” to turn ON.



2. Assign custom actions to the buttons.

1) Tap on “Devices” under “POINTING DEVICES”.

* Screenshots will be replaced with English version when it's ready.



2) Tap on this product.

- Bluetooth connection: ELECOM IST PRO
- Wireless connection: Elecom Bridge G1000
- Wired connection: ELECOM IST PRO



3) Tap on “Customize Additional Buttons...”.

* Screenshots will be replaced with English version when it's ready.



4) When the “Customize Button” page loads, click on the button on the trackball to be added.



* When adding “Button 3”.

* Screenshots will be replaced with English version when it's ready.

Button 3



5) A list of all assignable functions will load. Tap on the desired function to assign.

* When assigning "Screenshot" to "Button 3".



6) A function is assigned to the button. To assign other buttons, repeat the steps above.

* Screenshots will be replaced with English version when it's ready.



When AssistiveTouch is OFF, the Custom Action function is disabled and only the initial right click, left click and wheel scroll functions may be used.

Android




Using Bluetooth connection




1. Turn the power ON


1) Remove the battery cover.




2) Remove the battery insulating tab.



3) Put the battery cover back on.



4) Slide the power switch to the ON position.



* When the battery level is running low, the LED light will blink red slowly for a period of time.



Power-saving mode


When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

Moving the trackball restores it from energy saving mode.


* For two to three seconds after restoring from energy saving mode, trackball operation may be unstable.

Replacing the batteries...


1) Remove the battery cover.



2) Remove the batteries.




3) Insert the batteries according to the positive (+) and negative (-) marks indicated in the battery compartment.



- Insert the batteries in the correct positive (+) and negative (-) polarity direction.
- Do not use batteries of different types or use a mixture of old and new batteries. The batteries may leak and cause malfunction.

4) Replace the battery cover.

* Screenshots will be replaced with English version when it's ready.



This product can be charged using the included USB Type-C - USB-A cable when the separately sold battery pack is inserted into the battery compartment.

2. Pairing with an Android device.

- Pairing involves registering Bluetooth devices (in this case, this product and an Android device) with each other, and authorizing a connection between them.
- Tap to operate the Android device until pairing is complete.
- Instructions for the Pixel Tablet (Android 13) are as follows. There may be differences depending on the OS version or device.

1) Tap on “Settings” from the home page.

2) Tap on “Connected devices”.



3) Tap on “Pair new device”

* Screenshots will be replaced with English version when it's ready.



4) Turn the connection selection dial to either ❶ or ❷ to select the connection destination.

- You can register up to 2 Bluetooth® devices.
- The selected connected Bluetooth device will be registered under your paired devices.




Please refer to [“Switch connected device”](#) to switch between connected devices.

5) Hold down the pairing button on the bottom for around 3-4 seconds.

The pairing mode is entered, and the LED light on the side (blue) and the connection destination light (white) on the bottom will blink slowly.

Connection destination light

Pairing button



6) Tap on “ELECOM IST PRO” under “Available devices”.

* Screenshots will be replaced with English version when it's ready.



7) Tap on “Pair”.



Pairing begins.

8) Pairing is complete when this product is added to “Other devices”.

* Screenshots will be replaced with English version when it's ready.



When pairing is complete, the connection destination light (white) on the bottom will blink quickly then stop. The LED light on the side also lights up blue for 3 seconds.


You can now use the trackball.

Using wireless connection




1. Turn the power ON


1) Remove the battery cover.




2) Remove the battery insulating tab.




3) Put the battery cover back on.



4) Remove the receiver unit.



5) Slide the power switch to the ON position.



* When the battery level is running low, the LED light will blink red slowly for a period of time.



Power-saving mode


When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

Moving the trackball restores it from energy saving mode.


* For two to three seconds after restoring from energy saving mode, trackball operation may be unstable.

Replacing the batteries...


1) Remove the battery cover.



2) Remove the batteries.




3) Insert the batteries according to the positive (+) and negative (-) marks indicated in the battery compartment.



- Insert the batteries in the correct positive (+) and negative (-) polarity direction.
- Do not use batteries of different types or use a mixture of old and new batteries. The batteries may leak and cause malfunction.

4) Replace the battery cover.



This product can be charged using the included USB Type-C - USB-A cable when the separately sold battery pack is inserted into the battery compartment.

2. Connect to your Android device


To connect this product to an Android device, you need a device with a USB-A port, such as a commercially available USB Type-C hub. This product does not come with a USB Type-C hub.

1) Start up your PC.

Please wait until the PC has started up and can be operated.

2) Connect a USB Type-C hub with a commercially available USB-A port to the USB Type-C port of your Android device.

3) Insert the USB-A plug of the receiver unit into a USB-A port such as ones on a USB Type-C hub.



You may use any USB-A port.



- Ensure that the connector is correctly oriented to the port.
- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.

• Do not touch the terminal portion of the USB connector.

3) Turn the connection selection dial to to select the connection destination.



Please refer to ["Switch connected device"](#) to switch between connected devices.



When removing the receiver unit

This product supports hot plugging. The receiver unit can be removed while your Android device is on.

4) The driver is automatically installed and the trackball can be used.

The LED lights up white for 3 seconds.

You can now use the trackball.


Using wired connection



Connecting to your Android device

To connect this product to an Android device, you need a device with a USB-A port, such as a commercially available USB Type-C hub. This product does not come with a USB Type-C hub.

1) Plug the Type-C connector of the included USB Type-C - USB-A cable to the USB Type-C port of this product.




2) Start up your PC.

Please wait until the PC has started up and can be operated.

3) Connect a USB Type-C hub with a commercially available USB-A port to the USB Type-C port of your Android device.

- 4) Plug the USB-A connector of the USB Type-C - USB-A cable into the USB-A port of, for example, a USB Type-C hub.



You may use any USB-A port.



- Do not pull or bend the cable using excessive force. A fire or electric shock may result from broken wires.
- Ensure that the connector is correctly oriented to the port.
- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.

- 5) Turn the connection selection dial to  to select the connection destination.



Please refer to "[Switch connected device](#)" to switch between connected devices.



To remove the trackball

This product supports hot plugging. The trackball may be removed while your Android device is in operation.


- 6) The driver is automatically installed and the trackball can be used.

The LED lights up green for 3 seconds.


You can now use the trackball.

1. Turn the power ON


1) Remove the battery cover.




2) Remove the battery insulating tab.



3) Put the battery cover back on.



4) Slide the power switch to the ON position.



* When the battery level is running low, the LED light will blink red slowly for a period of time.



Power-saving mode


When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

Moving the trackball restores it from energy saving mode.


* For two to three seconds after restoring from energy saving mode, trackball operation may be unstable.

Replacing the batteries...


1) Remove the battery cover.



2) Remove the batteries.




3) Insert the batteries according to the positive (+) and negative (-) marks indicated in the battery compartment.



- Insert the batteries in the correct positive (+) and negative (-) polarity direction.
- Do not use batteries of different types or use a mixture of old and new batteries. The batteries may leak and cause malfunction.

4) Replace the battery cover.



This product can be charged using the included USB Type-C - USB-A cable when the separately sold battery pack is inserted into the battery compartment.

2. Pairing with a PC

- Pairing involves registering Bluetooth devices (in this case, this product and your device) with each other, and authorizing a connection between them.
- This section covers Chrome OS standard Bluetooth functions. Depending on your computer, unique Bluetooth functions may be used. Please read the respective manuals for each function.
- Use your current mouse or the touchpad on your device to operate your device until pairing is complete.
- The following instructions are for Chrome OS (124.0.6367.95).


1) Click on the battery icon at the bottom right.

2) Bluetooth on the Quick Settings panel.

* Screenshots will be replaced with English version when it's ready.



3) Under “Bluetooth”, click on “Pair new device”.



4) Turn the connection selection dial to either ❶ or ❷ to select the connection destination.

- You can register up to 2 Bluetooth® devices.
- The selected connected Bluetooth device will be registered under your paired devices.

 Please refer to [“Switch connected device”](#) to switch between connected devices.

5) During the device search, hold down the pairing button on the bottom for 3-4 seconds.


* Screenshots will be replaced with English version when it's ready.

The pairing mode is entered, and the LED light on the side (blue) and the connection destination light (white) on the bottom will blink slowly.



Connection destination light

Pairing button




6) Click on "ELECOM IST PRO".

Pairing begins.

* Screenshots will be replaced with English version when it's ready.




7) "ELECOM IST PRO connected" will be displayed at the bottom of the screen.



Click "Bluetooth" like in step 2. Pairing is complete when "ELECOM IST PRO" appears under "Previously connected".

* Screenshots will be replaced with English version when it's ready.



When pairing is complete, the connection destination light (white) on the bottom will blink quickly then stop. The LED light on the side also lights up blue for 3 seconds.


You can now use the trackball.

Using wireless connection




1. Turn the power ON


1) Remove the battery cover.




2) Remove the battery insulating tab.




3) Put the battery cover back on.



4) Remove the receiver unit.



5) Slide the power switch to the ON position.



* When the battery level is running low, the LED light will blink red slowly for a period of time.



Power-saving mode


When the trackball is left untouched for a fixed period of time while the power is ON, it automatically shifts to power-saving mode.

Moving the trackball restores it from energy saving mode.


* For two to three seconds after restoring from energy saving mode, trackball operation may be unstable.

Replacing the batteries...


1) Remove the battery cover.



2) Remove the batteries.




3) Insert the batteries according to the positive (+) and negative (-) marks indicated in the battery compartment.



▪ Insert the batteries in the correct positive (+) and negative (-) polarity direction.

• Do not use batteries of different types or use a mixture of old and new batteries. The batteries may leak and cause malfunction.

4) Replace the battery cover.




This product can be charged using the included USB Type-C - USB-A cable when the separately sold battery pack is inserted into the battery compartment.

2. Connect to a PC

1) Start up your PC.

Please wait until the PC has started up and can be operated.


2) Insert the receiver unit into the PC's USB-A port.



You may use any USB-A port.



• For devices that do not have a USB-A port, please use a USB Type-C® hub.



- Ensure that the connector is correctly oriented to the port.
- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.

3) Turn the connection selection dial to to select the connection destination.



Please refer to ["Switch connected device"](#) to switch between connected devices.



When removing the receiver unit

This product supports hot plugging. The receiver unit can be removed while the PC is on.

3) The driver is automatically installed and the trackball can be used.

The LED lights up white for 3 seconds.


You can now use the trackball.

Using wired connection



Connecting to a PC


- 1) Plug the Type-C connector of the included USB Type-C - USB-A cable to the USB Type-C port of this product.



2) Start up your PC.

Please wait until the PC has started up and can be operated.


3) Plug the USB-A connector of the USB Type-C - USB-A cable into the USB-A port of the PC.



You may use any USB-A port.



• For devices that do not have a USB-A port, please use a USB Type-C® hub.



- Do not pull or bend the cable using excessive force. A fire or electric shock may result from broken wires.
- Ensure that the connector is correctly oriented to the port.
- If there is strong resistance when inserting, check the shape and orientation of the connector. Forcibly inserting the connector may damage the connector, and there is a risk of injury.
- Do not touch the terminal portion of the USB connector.

4) Turn the connection selection dial to to select the connection destination.



Please refer to ["Switch connected device"](#) to switch between connected devices.



To remove the trackball

This product supports hot plugging. The trackball may be removed while your PC is in operation.

5) The driver is automatically installed and the trackball can be used.

The LED lights up green for 3 seconds.

You can now use the trackball.

Change the mouse pointer speed


Adjust the mouse pointer movement speed on your PC if the mouse pointer moves too fast or too slow.

1) Click on the battery icon at the bottom right.

2) Click on (settings) on the Quick Settings panel.

The settings page will appear.

* Screenshots will be replaced with English version when it's ready.



3) Click "Mouse" under "Devices".



4) Adjust the speed of the mouse pointer using the "Cursor speed" slider of "ELECOM IST PRO".

* Screenshots will be replaced with English version when it's ready.




Change the number of lines scrolled in one wheel turn

1) Click on the battery icon at the bottom right.

2) Click on  (settings) on the Quick Settings panel.

The settings page will appear.



3) Click "Mouse" under "Devices".

* Screenshots will be replaced with English version when it's ready.



4) If "Controlled scrolling" for "ELECOM IST PRO" is disabled, click to enable it.



5) Adjust the number of lines to be scrolled at a time using the slider for "Scroll speed" under "ELECOM IST PRO".

* Screenshots will be replaced with English version when it's ready.



Specifications



Interface	USB Type C - Type A * For wired/wireless 2.4 GHz connection mode
Connector type	USB-A * For wired/wireless 2.4 GHz connection mode Charging port: USB Type-C® connector
Connection method	Bluetooth® wireless / USB 2.4 GHz wireless / USB wired
Bluetooth standard	Bluetooth 5.3 Class2
Supported profiles	HOGP (HID Over GATT Profile)
Product Specifications	WindowsOS, Android, macOS, iOS, iPadOS, ChromeOS devices that support Bluetooth® HOGP / WindowsOS, macOS, ChromeOS devices that support USB-port equipped devices.
Supported OS	Windows 11/10, Android 12 - 13, macOS Ventura 13, iOS 16, iPadOS 16, ChromeOS
Communication method	GFSK
Radio frequency	2.4 GHz

Radio wave range	Maximum distance approx. 10 m * May vary depending on the environment.
Sensor type	IR LED
Sensor Resolution	500/1000/1500 DPI
Buttons	8 * including wheel button
Number of wheels	1
Ball diameter	Diameter approx. 36 mm
Ball support type	Bearing
Receiver unit storage compartment	Supported
Power source	2 × AA alkaline batteries or AA manganese batteries / USB bus power / battery pack M-BP10 (sold separately)
Polling rate	Up to 1000 Hz
Battery life	Maximum duration approx. XX months (estimated operating time when using alkaline batteries) * May vary depending on the environment.
Cable Length	Approx. 1.5 m / 4.9 ft
External dimensions (main unit)	Width approx. 96 × Length approx. 126 mm × Height approx. 52 mm / W 3.8 × L 5.0 × H 2.0 in.
External dimensions (receiver)	Width approx. 16 × Length approx. 18.5 mm × Height approx. 8.6 mm / L 0.6 × W 0.7 × H 0.3 in.
Weight (main unit)	Approx. 1584 g / 55.9 oz * excluding batteries
Mass (receiver unit)	Approx. 2 g / 0.1 oz
What's Inside	1 × trackball main unit, 2 × AA alkaline batteries for confirming operability, 1 × removal tool, 1 × cable for wired connection

Compliance status



Model/모델명/设备型号/型號: MIPT10MR, MGR10

www.elecom.co.jp/global/certification/

▼ Australia



▼ China / 中国

CMIIT ID: XXXXXXXXXXXX

RoHS Compliance (产品中有毒有害物质或元素的名称及含量)

https://www.elecom.co.jp/global/certification/pdf/RoHS_China.pdf

▼ EU



CE Declaration of Conformity

https://www.elecom.co.jp/global/certification/pdf/CE_DoC.pdf

RoHS Compliance

https://www.elecom.co.jp/global/certification/pdf/RoHS_EU_UK_Vietnam.pdf

* XXX will be determined when it's fixed.

European Authorized Representative (For CE and GPSR matters only)

VISHTEC Ltd

3rd floor office 5, Plovdiv 2 Liuben Karavelov bul, 4002 Bulgaria

compliance@vish-tec.com



WEEE Disposal and Recycling Information

This symbol means that waste of electrical and electronic equipment (WEEE) should not be disposed as general household waste. WEEE should be treated separately to prevent possible harm to the environment or human health. Consult your retailer or local municipal office for collection, return, recycle or reuse of WEEE.

DE: Informationen zu Elektro- und Elektronikgeräten

https://www.elecom.co.jp/global/certification/pdf/DE_WEEE.pdf

FR: INFORMATION DES CONSOMMATEURS SUR LA RÈGLE DE TRI

<https://www.elecom.co.jp/global/certification/pdf/FR-Info-Tri.pdf>

▼ **Korea / 대한민국**



인증번호: R-R-ELJ-X-XXXXXX

인증번호: R-R-ELJ-X-XXXXXX

제작자 및 설치자는 해당 무선설비가 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.

안전인증번호: YUXXXXX-XXXXX

Safety Certification (전기용품 안전인증)

https://www.elecom.co.jp/global/certification/pdf/KC_Safety.pdf

▼ **Malaysia / Bahasa Melayu**



XXXXXXXXXXXXX



XXXXXXXXXXXXX

* XXX will be determined when it's fixed.

▼ Singapore

Complies with
IMDA standards
DA106058.

Model Name/No.: MIPT10MR

Operating Frequencies: XXXX-XXXXMHz

Maximum field intensity / RF Output power: X.XX dBm / X.XX mW

Model Name/No.: MGR10

Operating Frequencies: XXXX-XXXXMHz

Maximum field intensity / RF Output power: X.XX dBm / X.XX mW

▼ Taiwan / 台灣



BSMI RoHS Compliance (限用物質含有情況標示聲明書)

<https://www.elecom.co.jp/global/certification/pdf/RoHSTaiwan.pdf>



XXXXXXXXXXXXXXXXXX

XXXXXXXXXXXXXXXXXX

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

▼ UK



UK Declaration of Conformity

https://www.elecom.co.jp/global/certification/pdf/UK_DoC.pdf

* XXX will be determined when it's fixed.

RoHS Compliance

https://www.elecom.co.jp/global/certification/pdf/RoHS_EU_UK_Vietnam.pdf



WEEE Disposal and Recycling Information

This symbol means that waste of electrical and electronic equipment (WEEE) should not be disposed as general household waste. WEEE should be treated separately to prevent possible harm to the environment or human health. Consult your retailer or local municipal office for collection, return, recycle or reuse of WEEE.

▼ US

FCC ID: YWO-MIPT10MR

FCC ID: YWO-MGR10

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE; This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

NOTICE: The manufacture is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. Such modifications could void the user's authority to operate the equipment.

In order to make improvements to this product, the design and specifications are subject to change without prior notice.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Responsible party

ELECOM USA, Inc.

4041 MacArthur Blvd Suite 400, Newport Beach, CA 92660 USA

elecomusa.com

▼ Vietnam / Việt Nam

RoHS Compliance (Chứng Nhận Đạt Tiêu Chuẩn RoHS)

https://www.elecom.co.jp/global/certification/pdf/RoHS_EU_UK_Vietnam.pdf

Support information



ELECOM CO., LTD.

Fushimimachi 4-1-1, Chuo-ku, Osaka City

Go to Global Site

Global Support

Please contact the shop where you purchased this product if you have any feedback or questions about the contents of this manual.

Specifications and external appearance of this product may be changed without prior notice for the purpose of product improvement.

ELECOM is not responsible for any damages to, or failure of other devices caused by using this product.

The images are for illustration purposes only and may differ from your actual product.

When exporting this product, check the export regulations for the country of origin.

A customer who purchases outside Japan should contact the local retailer in the country of purchase for enquiries. In "ELECOM CO., LTD. (Japan)", no customer support is available for enquiries about purchases or usage in/from any countries other than Japan. Also, no foreign language other than Japanese is available. Replacements will be made under stipulation of the ELECOM warranty.

Bei Fragen zum Inhalt dieses Handbuchs wenden Sie sich bitte an das Geschäft, in dem Sie dieses Produkt erworben haben.

Die technischen Daten und das äußere Erscheinungsbild dieses Produkts können zum Zweck der Produktverbesserung ohne vorherige Ankündigung geändert werden.

ELECOM haftet nicht für Schäden oder Ausfälle an anderen Geräten, die durch die Verwendung dieses Produkts verursacht werden.

Die Abbildungen dienen nur der Veranschaulichung und können vom tatsächlichen Produkt abweichen. Prüfen Sie bei der Ausfuhr dieses Produkts die Ausfuhrbestimmungen für das Herkunftsland.

Ein Kunde, der außerhalb Japans kauft, sollte sich für Rückfragen an den örtlichen Händler im jeweiligen Erwerbsland wenden. Bei „ELECOM CO., LTD. (Japan)“ steht, außer in Japan, kein Kundendienst für Anfragen zum Kauf oder zur Verwendung in/aus anderen Ländern zur Verfügung. Zudem ist keine andere Fremdsprache als Japanisch verfügbar. Ersatz wird im Rahmen der ELECOM-Garantie geleistet.

Por favor, póngase en contacto con la tienda en la que adquirió este producto si tiene algún comentario o pregunta sobre el contenido de este manual.

Las especificaciones y la apariencia externa de este producto pueden modificarse sin previo aviso con el fin de mejorar el producto.

ELECOM no se hace responsable de los daños o fallos de otros dispositivos causados por el uso de este producto.

Las imágenes son solo para fines ilustrativos y pueden diferir del producto real.

Al exportar este producto, compruebe la normativa de exportación del país de origen.

Los clientes que compren fuera de Japón deben ponerse en contacto con el distribuidor local del país de compra para realizar consultas. En "ELECOM CO., LTD. (Japón)", no se brinda servicio de atención al cliente para consultas sobre compras o uso en/desde otros países que no sean Japón. Además, no está disponible ninguna otra lengua extranjera que no sea el japonés. Los reemplazos se efectuarán bajo la estipulación de la garantía de ELECOM.

Veuillez contacter le magasin où vous avez acheté ce produit si vous avez des commentaires ou des questions sur le contenu de ce manuel.

Les spécifications et l'aspect extérieur de ce produit peuvent être modifiés sans préavis dans le but d'améliorer le produit.

ELECOM n'est pas responsable des dommages ou des défaillances d'autres appareils causés par l'utilisation de ce produit.

Les images sont fournies à titre d'illustration uniquement et peuvent différer du produit réel.

Lorsque vous exportez ce produit, vérifiez les réglementations d'exportation du pays d'origine.

Un client qui achète hors du Japon doit contacter le détaillant local du pays d'achat pour toute question. Chez « ELECOM CO., LTD. (Japon) », aucun support client n'est disponible pour les questions relatives aux achats ou à l'utilisation dans/à partir de tout pays autre que le Japon. De même, aucune langue étrangère autre que le japonais n'est disponible. Les remplacements seront effectués conformément aux dispositions de la garantie ELECOM.

Entre em contato com a loja onde você comprou este produto se tiver alguma sugestão ou dúvida sobre o conteúdo deste manual.

As especificações e aparência externa deste produto podem ser alteradas sem aviso prévio para fins de melhoria do produto.

A ELECOM não é responsável por quaisquer danos ou falhas de outros dispositivos causados pelo uso deste produto.

As imagens são apenas para fins ilustrativos e podem diferir do produto real.

Ao exportar este produto, confira os regulamentos de exportação para o país de origem.

Um cliente que compra fora do Japão deve entrar em contato com o revendedor local no país de compra para obter informações. Na "ELECOM CO., LTD. (Japão) ", nenhum suporte ao cliente está disponível para consultas sobre compras ou uso em/de quaisquer outros países além do Japão. Além disso, nenhum outro idioma estrangeiro está disponível além do japonês. As trocas serão feitas sob estipulação da garantia ELECOM.

如果您对本手册内容有任何反馈或疑问，请与购买本产品的零售商联系。

本产品的规格及外观如有变更以对产品进行改进，恕不另行通知。

因使用本产品而造成其他设备故障或问题时，ELECOM概不负责，敬请知悉。

图片仅供参考，您所收到的实际产品可能有所差异。

出口本产品至海外时，请检查原产国的出口法规。

在日本境外购买产品的客户应与当地的的零售商联系进行咨询。“ELECOM CO., LTD. (日本)” 不对日本之外的其他国家的客户提供有关购买或使用的咨询服务。另外，公司不提供日语之外的其他外语服务。产品如需更换，需要在 ELECOM 保修期规定范围之内。

若您對本手冊的內容有任何回饋或疑問，請聯絡您購買本產品的商店。

為了改進產品，本產品的規格和外觀可能會發生變化，恕不事先通知。

ELECOM 對因使用本產品而造成的其他裝置損壞或故障不承擔責任。

圖片僅用於說明目的，可能與您的實際產品有所出入。

出口這款產品時，需檢查原產國的出口規定。

客戶若在日本以外地區購買本產品，如有任何問題，應聯絡購買當地的經銷商。對於在日本以外的任何其他地區購買的產品，或於此類地區使用產品，「ELECOM CO., LTD.(Japan)」皆不針對相關問題提供支援。與此同時，除日語以外，不提供其他的外國語言服務。您可以根據ELECOM的規定於保固期間要求更換產品。

본 취급설명서는 설명서에 대한 의견 또는 질문이 있으신 경우 본 제품을 구매한 대리점으로 문의하시기 바랍니다.

본 제품의 사양 및 외관은 제품 개선을 위해 사전 통지 없이 변경될 수 있습니다.

본 제품의 사용에 따른 다른 기기의 고장이나 트러블에 관해서는 책임을 지지 않으므로 양해 바랍니다.

일부 형태가 달라지는 경우도 있습니다.

본 제품을 수출할 때, 원산지의 수출 규정을 확인합니다.

일본 외 다른 국가에서 구입하는 고객은 문의 사항이 있는 경우 제품 구입 국가의 대리점에 연락하십시오. 'ELECOM CO., LTD.(일본)'는 일본 이외의 국가에서 구입 또는 사용 문의에 대한 고객 지원을 제공하지 않습니다. 또한 일본어 이외의 외국어는 지원되지 않습니다. 제품의 교환은 ELECOM 보증 규정에 따라 이루어 집니다.