



Stina

PC Speakers User Manual

Compliant model: SP10

Precautions



This manual describes the important precautions you should take for safe operation of this product. Observe these precautions carefully to avoid personal injury, damage, fire, and other problems.

■ Meaning of symbols

WARNING

Failure to observe precautions carries the possibility of serious personal injury or death due to fire, electric shock, or other causes.

CAUTION

Failure to observe precautions may result in personal injury due to electric shock or other causes, and may damage other equipment.



Prohibited action



Mandatory action



Situation that needs attention



Notes and reference information



WARNING



If a foreign object (water, metal chips) enters this product, stop using immediately and turn OFF the power. Disconnect the USB cable from the USB AC adaptor, USB power supply, or computer as well.

Continuing to use the product as it is may cause a fire or an electric shock.



If abnormalities such as overheating, emitting smoke, or emitting strange odors occur, stop using the product immediately. To prevent burns, first ensure that the device is not overheating, then turn OFF the power and do not use the device any longer. Disconnect the USB cable from the USB AC adaptor, USB power supply, or computer as well. Afterwards, please contact your dealer.

Continuing to use the product as it is may cause a fire or an electric shock.



Please do not drop or hit this product.

In the event that the product is damaged, cease usage immediately and turn OFF the power. Disconnect the USB cable from the USB AC adaptor, USB power supply, or computer as well. Cease usage after that and consult your retailer.

Fires or electric shocks may occur if this product is used when damaged.



Do not attempt to disassemble, modify, or repair this product.

Doing so may cause a fire, electric shock, or product damage.

Such malfunctions are not covered under warranty.



Do not put this product in fire.

Breakage may cause fire or injury.



Do not use or store this product near water.

If any liquid gets inside the product, it may cause malfunction, fire, or electric shock.

 Do not use this product in a hospital or an aircraft.

Never use this product in places where a high level of safety is required. Doing so may cause errors in the operation of instruments in special medical institutions or aircrafts.

 CAUTION

 Do not leave the product exposed to high temperatures.

This product is a sensitive electronic device. Avoid using or storing in places with high temperature, high humidity, or long-term direct sunlight or leaving in hot cars for extended periods. In addition, rapid changes in the surrounding temperature may lead to malfunction caused by internal condensation.

 Do not use or store this product in any of the following environments:

- In a car exposed to sunlight or a place exposed to direct sunlight.
- In a place that becomes hot, such as around a heater.
- In a moist place or a place where condensation may occur.
- In an uneven place or a place exposed to vibration.
- In a place where a magnetic field is generated (such as near a magnet.)
- In a place where static electricity is generated.
- In a dusty place.

 If the product becomes wet, please wipe it dry with a dry cloth as soon as possible.

The product may become discolored, mold may grow, or the color may run if the water is not wiped off.

 Please be careful of excessive volume.

Please be cautious of excessive volume when connecting etc., to prevent damage to your ears due to the sudden loud noise.

■ Cleaning the Product

If this product becomes dirty, wipe it with a soft, dry cloth.



Using a volatile liquid such as paint thinner, benzene or alcohol can affect the material quality and/or discolor this product.

Please take caution regarding the following for disinfection.



Gently soak a cleaning cloth, such as a microfiber cloth, in the disinfectant solution. Ensure there are no loose droplets and gently wipe the product using the cloth.

After wiping, dry thoroughly and wipe off any residual liquid.

*Do not spray any liquid onto the product directly. Doing so can cause electric malfunctions.

IMPORTANT

Do not spray any liquid onto the product directly.

Doing so can cause electric malfunctions.

Do not use organic solvents or expose the product to ultraviolet light.

Using these can cause damage to the exterior such as the deterioration of the housing components or paints.

We recommend using disposable gloves.

When using any alcohol-based products, please check its associated precautions and that it is appropriate for the specific purpose.

Please note that the customer is fully responsible for repair costs in the event that the product is damaged or operates abnormally due to the disinfection process.

It is recommended that you sanitize your hands before and after using PCs and peripherals that are used by multiple people to prevent the spread of infection through the equipment.

■ **Regarding disposal**

Follow the guidance of the local municipal government when disposing of this product. Enquire about the regulations with your local government.

Precautions regarding radio waves

The band of frequencies used by this product are used to operate local wireless base stations (wireless stations that require a license) and designated low-power wireless stations (wireless stations that do not require a license) for the detection of moving objects on factory production lines in addition to microwave ovens, kitchenware and other industrial/scientific/medical devices.

1. Before using this product, make sure that there are no local wireless base stations and designated low-power wireless stations for the detection of moving objects being operated in the vicinity.
2. If this product has created radio wave interference for a local wireless base station for moving object detection, quickly change the frequency that is used or stop radio wave emission and then contact the retailer from whom you purchased the product or the support desk indicated under the provided support information for information on how to avoid interference (such as installing a partition).
3. In the case of any issues, such as if this product creates radio wave interference to a local wireless base station for moving object detection, please contact the retailer from whom you purchased this product or the support desk indicated under the provided support information.

Frequency band used	2.4 GHz
Frequency modulation	Frequency Hopping Spread Spectrum (FHSS)
Estimated Impedance Distance	Approx. 10m
Frequency change	All bands useable and possible to avoid “premises radio station” or “specified low power radio station” bands
Technical Standards Conformity Certification Number	  210-236834

How to use



Items included in this package




The following items are included in this package. Verify the package to ensure all items are accounted for prior to using this product. While every effort has been made to ensure proper packaging, in the event that any shortage or damage is discovered, please contact the retailer where the product was purchased.

- **Speaker x1**
- **USB-A adaptor x1**
- **ø3.5mm mini plug cable x1**

Name and function of each part





① Speaker


Outputs audio or music.

● is the left channel. ● is the right channel.



After purchasing, there will be a sheet affixed to the base of the product to prevent dirtying of the silicone portion.

Please peel it off before use.



② USB cable USB Type-C® plug

- Supplies power to the product when connected to a computer or USB AC adaptor.
- Sends audio to a speaker while in USB cable mode.

③ AUX jack

Connects to the ø3.5mm audio output jack of a computer or similar device using the included ø3.5mm mini plug cable.

④ Headphone connection jack

Connects to the ø3.5mm mini plug of your headphones or ear buds.

Audio will stop playing from the speaker once you connect in this way.

⑤ Controller

Power the product ON/OFF, switch modes, or adjust the volume.

⑥ LED light

Displays power ON/OFF, pairing status, Bluetooth mode, USB cable mode and AUX mode.

⑦ Power button

- Hold down the power button for 2 seconds to power the product ON.
- Hold down the power button for 4 seconds while the product is in operation to power the product OFF.
- Hold down the power button for 2 seconds while the product is in operation to change the connection mode.

⑧ Volume button (+)

Increases the volume.

⑨ Volume button (-)

Decreases the volume.

⑩ USB-A adaptor

The product can be used while connected to a USB-A port by inserting into the USB Type-C connector of the USB cable.

■ List of Operations

Function	Operation	Light status	Voice Guidance
Power on	Hold down power button for 2 seconds *Please refer to " Changing connection mode " concerning connection mode while power is ON.	Red: Slow blinks (once every 3 seconds) or Blue: Rapid flashing	Power On USB Cable or Power On Pairing


Function	Operation	Light status	Voice Guidance
Power off	Hold down power button for 4 seconds	Light is off.	Power Off
Switch connection mode	Hold down the power button for 2 seconds to change from USB cable mode → Bluetooth mode → AUX mode, in that order. *Please refer to "Changing connection mode" for more details.		
	USB cable mode	Red: Slow blinks (once every 3 seconds)	Mode Change USB Cable
	Bluetooth mode	Blue: Slow blinks (once every 3 seconds)	Mode Change Pairing
	AUX mode	Green: Slow blinks (once every 3 seconds)	Mode Change AUX
AUX mode	Connect to device with ø3.5mm mini plug cable Automatically switch to AUX mode *It is possible to switch to other modes while connected	Green: Slow blinks (once every 3 seconds)	AUX
Bluetooth pairing	Automatically switches to pairing mode upon entering Bluetooth mode	Rapid blue flashing	Pairing
Pairing successful	–	Blue: Slow blinks (once every 3 seconds)	Bluetooth connected

Function	Operation	Light status	Voice Guidance
Pairing failed	–	Rapid blue flashing	Bluetooth disconnected
Play/Pause	Press power button for a moment	During playback: Flashing During pause: Slow blinks (once every 3 seconds) *The color of the LED light changes depending on the mode.	-
Volume up	Press volume button (+) for a moment	-	-
Volume down	Press volume button (-) for a moment	-	-


Playback in USB cable mode




- 1) Connect the USB Type-C plug of the USB cable that comes with this product into your computer's USB Type-C port.



If your computer does not have a USB Type-C port, you can use the included USB-A adaptor to connect to the USB-A port instead.




2) Hold down the power button of the controller for 2 seconds to power the product ON.



Press and hold for 2 seconds

The LED light will slowly blink red (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".



3) Playback the audio source with the connected device.




The volume adjustment of this product is not synchronized with the connected device. Adjust the volume of the connected device as well.

Change your computer settings


Please confirm whether this product is configured to be your computer speaker. If this product is not selected, please change it to be this product.

1) Click “Start” and then “All apps”.




2) Click “Windows Tools”.


The “Windows Tools” screen will appear.




3) Double-click “Control Panel”.



4) Click “Hardware and Sound”.




5) Click “Sound”.




6) If  is shown under “Speakers USBAudio2.0” in the “Playback” tab, then this product is currently selected.

If there is no  icon, click “Speakers USBAudio2.0”, then click “Set Default”.




7) Click “Speakers USBAudio2.0” then click “Properties”.



8) Click on the “Levels” tab; if the volume level is not set to 0, sound will play from this product.

If the volume level is set to 0, please adjust the volume level.



9) Click “OK” then close “Properties”.

10) Click “OK” then close “Sound”.


Your computer settings are now complete.

Playback in AUX mode




1) Connect the USB Type-C plug of the USB cable that comes with this product into your computer's USB Type-C port or into your USB AC adaptor.

- If connecting to your computer's USB Type-C port







If your computer does not have a USB Type-C port, you can use the included USB-A adaptor to connect to the USB-A port instead.




- If connecting to a USB AC adaptor



2) Insert the head of the included $\varnothing 3.5\text{mm}$ mini plug cable into the AUX jack of this product.




3) Hold down the power button of the controller for 2 seconds to power the product ON.



Press and hold for 2 seconds


• **If connecting to a USB AC adaptor**

Activates in Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Power On", followed by "Pairing".




• **If connected to your computer's USB Type-C port**


Activates in USB cable mode. There will be blinking (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".



4) Insert the plug on the opposite end of the included $\varnothing 3.5\text{mm}$ mini plug cable into the $\varnothing 3.5\text{mm}$ audio output jack on your computer.



Automatically switches to AUX mode. The LED light will slowly blink green (once every 3 seconds), then the voice guidance will announce "AUX".



5) Playback the audio source with the connected device.




The volume adjustment of this product is not synchronized with the connected device. Adjust the volume of the connected device as well.

Change your computer settings


Please confirm whether this product is configured to be your computer speaker. If this product is not selected, please change it to be this product.

1) Click "Start" and then "All apps".




2) Click "Windows Tools".


The "Windows Tools" screen will appear.




3) Double-click "Control Panel".



4) Click “Hardware and Sound”.




5) Click “Sound”.




6) If a  icon is displayed next to “Headphones (connected audio device name)” under the “Playback” tab, then this product has been selected.

If there is no  icon, click “Headphones (connected audio device name)”, then click “Set Default”.




7) Click “Headphones (connected audio device name)”, then click “Properties”.



8) Click on the “Levels” tab; if the volume level is not set to 0, sound will play from this product.

If the volume level is set to 0, please adjust the volume level.



9) Click “OK” then close “Properties”.

10) Click “OK” then close “Sound”.

Your computer settings are now complete.

Playback in Bluetooth mode



Windows®




1. Enable the pairing mode


Pairing involves registering Bluetooth devices (in this case, this product and your device) with each other, and authorizing a connection between them.

1) Connect the USB Type-C plug of the USB cable that comes with this product into your computer's USB Type-C port or into your USB AC adaptor.


- If connecting to your computer's USB Type-C port




If your computer does not have a USB Type-C port, you can use the included USB-A adaptor to connect to the USB-A port instead.



- If connecting to a USB AC adaptor




2) Hold down the power button of the controller for 2 seconds to power the product ON.



Press and hold for 2 seconds


- **If connecting to a USB AC adaptor**

Activates in Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Power On", followed by "Pairing". Please proceed to [step 4](#)).




- **If connected to your computer's USB Type-C port**

Activates in USB cable mode. There will be blinking (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".




3) Hold down the power button of the controller for 2 seconds.




Press and hold for 2 seconds

It will switch to Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Mode Change", followed by "Pairing".



4) Enter Bluetooth pairing mode.




- **If a connected device that has already been paired is in the vicinity**

If the automatic connection function or the trusted devices setting of a connected device is enabled, it will connect to that device automatically.

The LED light will blink blue slowly (once every 3 seconds).

The voice guidance will announce "Bluetooth Connected".



- If connected with a device unintentionally, turn off the device and start over.
- Pairing should finish within 5 minutes. If it takes more than 5 minutes, this product will power OFF. In this case, please start over.
- Depending on the device you want to pair with, you may need to "Allow communication from SP-P10CUB" on the device in advance.

2. Pairing with a PC


- This section covers Windows standard Bluetooth functions. Depending on your device or Bluetooth adaptor, unique Bluetooth functions may be used. Please read the respective manuals for each

function.

- The following instructions are for Windows 11 (23H2). Depending on the version and manufacturer, the displayed contents and screen design may differ.


1) Right click on “Start” on the bottom of the screen and select “Settings”.

The “Settings” page will appear.




2) Under “Home”, select “Add device” under “Bluetooth devices”.


The “Add a device” page will appear.



If “Bluetooth” is off, turn it on.




3) Select “Bluetooth”.




4) Once the “Add a device” screen is displayed, click “SP-P10CUB”.

Pairing begins.




5) "Your device is ready to go!" will be displayed.




6) Once the LED light of this product lights up a constant blue, pairing is complete.


The voice guidance will announce "Bluetooth connected".



7) Click on "Finish".



8) This product will be added to "Bluetooth devices" and connection is complete.



You can now use this product.




- Pairing information can be saved for up to 8 devices. If you register a ninth device, the oldest pairing will be deleted. To reconnect to a device that has been deleted, you need to pair it again.
- If pairing is incomplete due to the settings of the device to be paired, turn off the power and try again.
- Enter "0000" (four zeros) when prompted to enter a passkey.
- Depending on the application you are using, you may need to configure the audio device in the application.
- Depending on the device, you may need to manually perform the "Connect" operation to the device after pairing. Read the instruction manual of your device and manually perform the "Connect" operation.
- Depending on the device, it may be necessary to change the audio output source. Please refer to the user's manual of the connected device before use.

Change your computer settings


Please confirm whether this product is configured to be your computer speaker. If this product is not selected, please change it to be this product.

1) Click "Start" and then "All apps".




2) Click "Windows Tools".


The "Windows Tools" screen will appear.




3) Double-click "Control Panel".



4) Click "Hardware and Sound".




5) Click "Sound".




6) If a  icon is displayed next to “Headphones SP-P10CUB” under the “Playback” tab, then this product has been selected.

If there is no  icon, click “Headphones SP-P10CUB”, then click “Set Default”.




7) Click “Headphones SP-P10CUB”, then click “Properties”.



8) Click on the “Levels” tab; if the volume level is not set to 0, sound will play from this product.

If the volume level is set to 0, please adjust the volume level.



9) Click “OK” then close “Properties”.

10) Click “OK” then close “Sound”.

Your computer settings are now complete.

iPhone, iPad




1. Enable the pairing mode


Pairing involves registering Bluetooth devices (in this case, this product and an iPad or an iPhone) with each other, and authorizing a connection between them.

1) Connect the USB Type-C plug of the USB cable that comes with this product into your computer's USB Type-C port or into your USB AC adaptor.


- If connecting to your computer's USB Type-C port




If your computer does not have a USB Type-C port, you can use the included USB-A adaptor to connect to the USB-A port instead.



- If connecting to a USB AC adaptor




2) Hold down the power button of the controller for 2 seconds to power the product ON.



Press and hold for 2 seconds


- **If connecting to a USB AC adaptor**

Activates in Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Power On", followed by "Pairing". Please proceed to [step 4](#)).




- **If connected to your computer's USB Type-C port**

Activates in USB cable mode. There will be blinking (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".




3) Hold down the power button of the controller for 2 seconds.




Press and hold for 2 seconds

It will switch to Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Mode Change", followed by "Pairing".



4) Enter Bluetooth pairing mode.




- **If a connected device that has already been paired is in the vicinity**

If the automatic connection function or the trusted devices setting of a connected device is enabled, it will connect to that device automatically.

The LED light will blink blue slowly (once every 3 seconds).

The voice guidance will announce "Bluetooth Connected".




- If connected with a device unintentionally, turn off the device and start over.
- Pairing should finish within 5 minutes. If it takes more than 5 minutes, this product will power OFF. In this case, please start over.
- Depending on the device you want to pair with, you may need to "Allow communication from SP-P10CUB" on the device in advance.


2. Pairing with an iPad or an iPhone

The following instructions are for iOS Ver.17.4.1. Depending on the version, the displayed contents and screen design may differ.

1) Select “Settings” from the home page.



2) Tap on “Bluetooth”.




3) Turn “Bluetooth” ON.




4) Tap on “SP-P10CUB” when it is detected under “DEVICES”.

Pairing begins.




5) "Connected".



6) Once the LED light of this product lights up a constant blue, pairing is complete.

The voice guidance will announce "Bluetooth connected".



You can now use this product.



- Pairing information can be saved for up to 8 devices. If you register a ninth device, the oldest pairing will be deleted. To reconnect to a device that has been deleted, you need to pair it again.
- If pairing is incomplete due to the settings of the device to be paired, turn off the power and try again.
- Enter "0000" (four zeros) when prompted to enter a passkey.
- Depending on the application you are using, you may need to configure the audio device in the application.

- Depending on the device, you may need to manually perform the “Connect” operation to the device after pairing. Read the instruction manual of your device and manually perform the “Connect” operation.
- Depending on the device, it may be necessary to change the audio output source. Please refer to the user's manual of the connected device before use.

Android




1. Enable the pairing mode


Pairing involves registering Bluetooth devices (in this case, this product and an Android device) with each other, and authorizing a connection between them.

1) **Connect the USB Type-C plug of the USB cable that comes with this product into your computer's USB Type-C port or into your USB AC adaptor.**


- **If connecting to your computer's USB Type-C port**




If your computer does not have a USB Type-C port, you can use the included USB-A adaptor to connect to the USB-A port instead.



- If connecting to a USB AC adaptor




2) Hold down the power button of the controller for 2 seconds to power the product ON.



Press and hold for 2 seconds


- If connecting to a USB AC adaptor

Activates in Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Power On", followed by "Pairing". Please proceed to [step 4](#)).




- **If connected to your computer's USB Type-C port**

Activates in USB cable mode. There will be blinking (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".




3) Hold down the power button of the controller for 2 seconds.




Press and hold for 2 seconds

It will switch to Bluetooth mode. The LED light will quickly blink blue (once every 3 seconds), then the voice guidance will announce "Mode Change", followed by "Pairing".



4) Enter Bluetooth pairing mode.




- **If a connected device that has already been paired is in the vicinity**

If the automatic connection function or the trusted devices setting of a connected device is enabled, it will connect to that device automatically.

The LED light will blink blue slowly (once every 3 seconds).

The voice guidance will announce "Bluetooth Connected".




- If connected with a device unintentionally, turn off the device and start over.
- Pairing should finish within 5 minutes. If it takes more than 5 minutes, this product will power OFF. In this case, please start over.
- Depending on the device you want to pair with, you may need to "Allow communication from SP-P10CUB" on the device in advance.


2. Pairing with an Android device.

Instructions for Pixel 6a (Android 14) are as follows. Depending on the version and manufacturer, the displayed contents and screen design may differ.


- 1) Swipe from the bottom to the top of the screen on the home screen to bring up the list of applications.**




2) Tap on "Settings".




3) Select “Connected devices”.




4) Tap on “Connection preferences”.




5) Tap on "Bluetooth".




6) Turn “Use Bluetooth” ON.



7) Select “Pair new device”




8) Tap on “SP-P10CUB” when it is detected under “Available devices”.




9) While “Also allow access to contacts and call history” is set to OFF, tap “Pair”.

Pairing begins.




10) Once the LED light of this product lights up a constant blue, pairing is complete.

The voice guidance will announce "Bluetooth connected".



11) This product is now added to "Media devices".



You can now use this product.




- Pairing information can be saved for up to 8 devices. If you register a ninth device, the oldest pairing will be deleted. To reconnect to a device that has been deleted, you need to pair it again.
- If pairing is incomplete due to the settings of the device to be paired, turn off the power and try again.
- Enter "0000" (four zeros) when prompted to enter a passkey.
- Depending on the application you are using, you may need to configure the audio device in the application.
- Depending on the device, you may need to manually perform the "Connect" operation to the device after pairing. Read the instruction manual of your device and manually perform the "Connect" operation.
- Depending on the device, it may be necessary to change the audio output source. Please refer to the user's manual of the connected device before use.

Turning the product ON




- 1) Hold down the power button of the controller for 2 seconds.



Press and hold for 2 seconds


Activates in USB cable mode. The LED light will slowly blink red (once every 3 seconds), then the voice guidance will announce "Power On", followed by "USB cable".



Turning the product OFF




- 1) Hold down the power button of the controller for at least 4 seconds.



Press the multi-function button for more than 4 seconds.

- 2) The light will turn OFF and the power supply will be turned OFF as well.

The voice guidance will announce "Power OFF".




Even after turning the power OFF, the previous connection mode will be remembered until the USB cable is unplugged from your computer.

Unplugging and plugging in the USB cable will cause it to reset to USB cable mode.

Changing connection mode




- 1) **Hold down the power button of the controller for at least 2 seconds while the power is ON.**



Press and hold for 2 seconds

- 2) **The connection mode will change every time you hold down the power button for at least 2 seconds.**

Voice Guidance



Please change to Aux mode after connecting the $\varnothing 3.5$ mm mini plug cable.



- Even after turning the power OFF, the previous connection mode will be remembered until the USB cable is unplugged from your computer or your computer is powered OFF. Unplugging and plugging in the USB cable will cause the connection mode to be reset.
- Turning the product ON after plugging the USB Type-C plug of the USB cable that comes with this product into your computer will cause it to activate in USB cable mode.
- Turning the product ON after plugging the USB Type-C plug of the USB cable that comes with this product into a USB AC adaptor will cause it to activate in Bluetooth mode.
- To set to AUX mode, change the mode after connecting the $\varnothing 3.5$ mm mini plug cable.

Listening to music




The following operations are available while playing music.



- Depending on the application, some features may not be available.

■ Play/Pause

Press the power button of the controller.



Adjusting the volume



Volume can be adjusted during audio or music playback.




This functionality may not be available depending on the connected device.

If you cannot obtain the desired volume even by setting the volume to maximum, adjust the volume of the connected device.


■ Volume up

The volume will increase each time you press the controller's Volume Up button (+).



■ Volume down

The volume will decrease each time you press the controller's Volume Down button (-).



Speaker type	Bass reflex
Maximum Output Power	4.4 W (2.2 W+2.2 W)
Speaker unit size	ø51 mm
Speaker unit impedance	4 Ω
Playback frequency response	90 Hz to 18 kHz
Input terminal	Power supply input: USB Type-C® plug (USB-A adaptor included) Audio input: ø3.5 mm mini plug - USB Type-C plug (USB-A adaptor included)
Communication method	Bluetooth® standard Version 5.3
Rated output	Bluetooth Power Class2
Max. communication range	Approx. 10 m / 32.8 ft *When unobstructed
Frequency band used	2.4 GHz band
Supported profiles	A2DP
Compatible codec	SBC
Content protection supported	SCMS-T method
Transmission band frequency (A2DP)	20 Hz to 20 kHz (44.1 kHz sampling)
Maximum number of devices that can be registered	8 devices
Multipoint	Non-compatible
Cable Length	USB power cable: approx. 133 cm / 52.4 in. *Includes controller
Dimensions (W x D x H)	Approximately 96 × 100 × 90 mm / 3.78 × 3.94 × 3.55 in.
Weight	Approximately 400 g / 14.1 oz
Included	USB-A adaptor, ø3.5 mm mini plug cable

If the speakers do not work correctly



Please check the status of the speaker.



➡ The product cannot be turned ON.

Check that the USB cable is connected to your computer.

Check that the computer is turned ON.

Check the status of the connected device.



➡ Please restart the connected device.

This product may become unstable depending on the condition of the connected device.

Please restart the connected device.

Afterwards, follow these steps once more.

➡ Update the OS and Bluetooth driver on the connected device to the latest versions.

If the OS or Bluetooth driver version of the connected device is outdated, this product may become unstable. Please update to the latest version.

➡ Check that the speaker output is properly configured in the Settings screen.

When selecting a speaker output source, the display name may differ depending on the connection method.

How to connect	Display name
Bluetooth mode	Headphones (SP-P10CUB)
USB cable mode	Speakers (USBAudio2.0)
AUX mode	Headphones (Connected device name)

➡ When using Bluetooth mode, check the Bluetooth connection.

- Check that this product's and the connected device's Bluetooth function are turned on.
- Check pairing status to ensure that this product is paired correctly with the connected device and that pairing has not been cancelled.
- Check that the connected device supports the profile for this product.

➡ **When using a USB Bluetooth adaptor, check the adaptor's connection.**

Depending on the specifications of the PC's USB port or USB hub, other USB 3.0 devices used simultaneously with this product may generate noise that can worsen the 2.4 GHz signal in the vicinity.



Examples of USB devices that may degrade the 2.4 GHz band signal


- USB memory
- Hard disk or SSD
- Optical disk drive
- Card reader/writer
- LAN adaptor
- Others, all devices communicating data with a PC via USB 3.0.

You may be able to improve the situation with the following method.

- **Connect the Bluetooth adaptor to another USB port away from other USB3.0 devices that are in use simultaneously.**



- **Connect the Bluetooth adaptor to a USB 2.0 hub or to an extension cable.**



Check the placement status of the speaker and the connected device and environment they are used in.



➡ **Check the distance between this product and the connected device (or USB Bluetooth adaptor).**

This wireless device uses the 2.4 GHz band. Please use this product within range of the connected device.



Average radio wave range

Non-magnetic surface (such as wooden desks): approximately 10 m

Magnetic surface (such as steel desks): approximately 3 m

*These values were obtained in ELECOM's test environment and are not guaranteed.

The 2.4 GHz band signal may be shorter depending on the environment you use it in.



When Bluetooth communication disconnects easily

This product is not guaranteed to work with all Bluetooth devices. In addition, Bluetooth communication may be interrupted in the following environments.

- There is a human body between this product and the connected device.
- There is an obstacle such as a metal item or a wall between this product and the connected device.
- There are many Bluetooth devices connected in the vicinity.
- The product is used near wireless LAN (IEEE802.11g/b/n) devices that use the 2.4GHz band or a microwave oven in use
- It is near an environment where USB 3.0 cables are being used, such as for external HDD.

In these environments, please move this product and the connected device closer to each other and as far away from these environments as possible, and check if they can be paired or connected.

➡ **Check that there are no obstructions such as steel desks or other metal obstructions.**

Metal surfaces such as steel desks, or metal obstructions may reduce the range of the radio waves.

➡ **Check that multiple wireless devices are not being used at the same time.**

Radio wave interference may occur if multiple units of this product are used or if this product is used at the same time with other wireless devices. Change the channel of the other wireless device.

When using Windows® PC



Please check the Windows® power saving settings on the connectivity device.




In Windows®, in order to reduce power consumption depending on the PC, the power of the product to be connected to the USB is set to turn off automatically.

You can change this setting in the following ways:


■ For Windows® 11

1) Click “Start” and then “All apps”.




2) Click “Windows Tools”.


The “Windows Tools” screen will appear.




3) Double-click "Control Panel".



4) Click "System and Security".




5) Click "Power Options".




For Power Options settings, please refer to step 2 and beyond when using “For Windows® 10”.

■ For Windows® 10


- 1) Right-click the Start button at the bottom left of the screen, click “Power Options”, and then click “Additional power settings” under “Related settings” on the right side of the “Power & sleep” screen.
- 2) Click “Change plan settings” on the right side of the item selected in “Power Plan”.



- 3) On the “Edit Plan Settings” screen, click “Change advanced power settings”.




- 4) On the “Power Options” screen, click the “+” mark in “USB settings” from the list, and then click the “+” mark in “USB selective suspend setting”.



The items displayed in the list on the “Power Options” screen may differ depending on the computer you are using. If “USB selective suspend setting” is not displayed, the setting cannot be changed.

5) In the dropdown next to “Setting”, select “Disabled”.

If you are using a laptop, there are two items instead of “Settings”: “On battery” and “Plugged in”. In that case, please set the “Plugged in” setting to “Disabled”.



6) Click “OK” to confirm the settings.

7) Click the “x” (close) in the upper right corner to close “Edit Plan Settings”.

▼ China / 中国

CMIIT ID: 25J996UUS001

RoHS Compliance (产品中有毒有害物质或元素的名称及含量)

https://www.elecom.co.jp/global/certification/pdf/RoHS_China.pdf

▼ Taiwan / 台灣



BSMI RoHS Compliance (限用物質含有情況標示聲明書)

https://www.elecom.co.jp/global/certification/pdf/RoHS_Taiwan.pdf



XXXXXXXXXXXXXXXXXX

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

▼ US

FCC ID: YWO-SP10

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE; This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

NOTICE: The manufacture is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. Such modifications could void the user's authority to operate the equipment.

In order to make improvements to this product, the design and specifications are subject to change without prior notice.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Responsible party

ELECOM USA, Inc.

2211 Michelson Dr. Suite 900, Irvine, CA 92612 USA

elecomusa.com

Intellectual property rights



* ELECOM CO., LTD. owns the copyright to this manual.

- * All products and company names on this product and the package are trademarks or registered trademarks of their respective owners.
- * Duplicating and transferring this document in part or whole is prohibited.
- * The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ELECOM CO., LTD. is under license.
- * USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- * iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries and regions.
- * Android is a trademark of Google LLC.

Support information



ELECOM CO., LTD.

Fushimimachi 4-1-1, Chuo-ku, Osaka City

[Go to Global Site](#)

Global Support

Please contact the shop where you purchased this product if you have any feedback or questions about the contents of this manual.

Specifications and external appearance of this product may be changed without prior notice for the purpose of product improvement.

ELECOM is not responsible for any damages to, or failure of other devices caused by using this product.

The images are for illustration purposes only and may differ from your actual product.

When exporting this product, check the export regulations for the country of origin.

A customer who purchases outside Japan should contact the local retailer in the country of purchase for enquiries. In "ELECOM CO., LTD. (Japan)", no customer support is available for enquiries about purchases or usage in/from any countries other than Japan. Also, no foreign language other than Japanese is available. Replacements will be made under stipulation of the ELECOM warranty.

Bei Fragen zum Inhalt dieses Handbuchs wenden Sie sich bitte an das Geschäft, in dem Sie dieses Produkt erworben haben.

Die technischen Daten und das äußere Erscheinungsbild dieses Produkts können zum Zweck der Produktverbesserung ohne vorherige Ankündigung geändert werden.

ELECOM haftet nicht für Schäden oder Ausfälle an anderen Geräten, die durch die Verwendung dieses

Produkts verursacht werden.

Die Abbildungen dienen nur der Veranschaulichung und können vom tatsächlichen Produkt abweichen.

Prüfen Sie bei der Ausfuhr dieses Produkts die Ausfuhrbestimmungen für das Herkunftsland.

Ein Kunde, der außerhalb Japans kauft, sollte sich für Rückfragen an den örtlichen Händler im jeweiligen Erwerbsland wenden. Bei „ELECOM CO., LTD. (Japan)“ steht, außer in Japan, kein Kundendienst für Anfragen zum Kauf oder zur Verwendung in/aus anderen Ländern zur Verfügung. Zudem ist keine andere Fremdsprache als Japanisch verfügbar. Ersatz wird im Rahmen der ELECOM-Garantie geleistet.

Por favor, póngase en contacto con la tienda en la que adquirió este producto si tiene algún comentario o pregunta sobre el contenido de este manual.

Las especificaciones y la apariencia externa de este producto pueden modificarse sin previo aviso con el fin de mejorar el producto.

ELECOM no se hace responsable de los daños o fallos de otros dispositivos causados por el uso de este producto.

Las imágenes son solo para fines ilustrativos y pueden diferir del producto real.

Al exportar este producto, compruebe la normativa de exportación del país de origen.

Los clientes que compren fuera de Japón deben ponerse en contacto con el distribuidor local del país de compra para realizar consultas. En “ELECOM CO., LTD. (Japón)”, no se brinda servicio de atención al cliente para consultas sobre compras o uso en/desde otros países que no sean Japón. Además, no está disponible ninguna otra lengua extranjera que no sea el japonés. Los reemplazos se efectuarán bajo la estipulación de la garantía de ELECOM.

Veuillez contacter le magasin où vous avez acheté ce produit si vous avez des commentaires ou des questions sur le contenu de ce manuel.

Les spécifications et l’aspect extérieur de ce produit peuvent être modifiés sans préavis dans le but d’améliorer le produit.

ELECOM n’est pas responsable des dommages ou des défaillances d’autres appareils causés par l’utilisation de ce produit.

Les images sont fournies à titre d’illustration uniquement et peuvent différer du produit réel.

Lorsque vous exportez ce produit, vérifiez les réglementations d’exportation du pays d’origine.

Un client qui achète hors du Japon doit contacter le détaillant local du pays d’achat pour toute question. Chez « ELECOM CO., LTD. (Japon) », aucun support client n’est disponible pour les

questions relatives aux achats ou à l'utilisation dans/à partir de tout pays autre que le Japon. De même, aucune langue étrangère autre que le japonais n'est disponible. Les remplacements seront effectués conformément aux dispositions de la garantie ELECOM.

Entre em contato com a loja onde você comprou este produto se tiver alguma sugestão ou dúvida sobre o conteúdo deste manual.

As especificações e aparência externa deste produto podem ser alteradas sem aviso prévio para fins de melhoria do produto.

A ELECOM não é responsável por quaisquer danos ou falhas de outros dispositivos causados pelo uso deste produto.

As imagens são apenas para fins ilustrativos e podem diferir do produto real.

Ao exportar este produto, confira os regulamentos de exportação para o país de origem.

Um cliente que compra fora do Japão deve entrar em contato com o revendedor local no país de compra para obter informações. Na "ELECOM CO., LTD. (Japão)", nenhum suporte ao cliente está disponível para consultas sobre compras ou uso em/de quaisquer outros países além do Japão. Além disso, nenhum outro idioma estrangeiro está disponível além do japonês. As trocas serão feitas sob estipulação da garantia ELECOM.

如果您对本手册内容有任何反馈或疑问，请与购买本产品的零售商联系。

本产品的规格及外观如有变更以对产品进行改进，恕不另行通知。

因使用本产品而造成其他设备故障或问题时，ELECOM概不负责，敬请知悉。

图片仅供参考，您所收到的实际产品可能有所差异。

出口本产品至海外时，请检查原产国的出口法规。

在日本境外购买产品的客户应与当地的的零售商联系进行咨询。“ELECOM CO., LTD. (日本)”不对日本之外的其他国家的客户提供有关购买或使用的咨询服务。另外，公司不提供日语之外的其他外语服务。产品如需更换，需要在 ELECOM 保修期规定范围之内。

若您對本手冊的內容有任何回饋或疑問，請聯絡您購買本產品的商店。

為了改進產品，本產品的規格和外觀可能會發生變化，恕不事先通知。

ELECOM 對因使用本產品而造成的其他裝置損壞或故障不承擔責任。

圖片僅用於說明目的，可能與您的實際產品有所出入。

出口這款產品時，需檢查原產國的出口規定。

客戶若在日本以外地區購買本產品，如有任何問題，應聯絡購買當地的經銷商。對於在日本以外的任何其他地區購買的產品，或於此類地區使用產品，「ELECOM CO., LTD.(Japan)」皆不針對相關問題提供支援。與此同時，除日語以外，不提供其他的外國語言服務。您可以根據ELECOM的規定於保固期間要求更換產品。

본 취급설명서는 설명서에 대한 의견 또는 질문이 있으신 경우 본 제품을 구매한 대리점으로 문의하시기 바랍니다.

본 제품의 사양 및 외관은 제품 개선을 위해 사전 통지 없이 변경될 수 있습니다.

본 제품의 사용에 따른 다른 기기의 고장이나 트러블에 관해서는 책임을 지지 않으므로 양해 바랍니다.

일부 형태가 달라지는 경우도 있습니다.

본 제품을 수출할 때, 원산지의 수출 규정을 확인합니다.

일본 외 다른 국가에서 구입하는 고객은 문의 사항이 있는 경우 제품 구입 국가의 대리점에 연락하십시오. 'ELECOM CO., LTD.(일본)'는 일본 이외의 국가에서 구입 또는 사용 문의에 대한 고객 지원을 제공하지 않습니다. 또한 일본어 이외의 외국어는 지원되지 않습니다. 제품의 교환은 ELECOM 보증 규정에 따라 이루어 집니다.

Silakan hubungi toko tempat Anda membeli produk ini jika Anda memiliki masukan atau pertanyaan tentang isi manual ini.

Spesifikasi dan tampilan luar produk ini dapat berubah tanpa pemberitahuan sebelumnya untuk tujuan peningkatan produk.

ELECOM tidak bertanggung jawab atas segala kerusakan atau kegagalan perangkat lain yang disebabkan oleh penggunaan produk ini.

Gambar-gambar yang tertera hanyalah untuk ilustrasi dan mungkin berbeda dari produk asli.

Saat produk diekspor, harap periksa dengan saksama semua peraturan ekspor negara asal.

Pelanggan yang membeli di luar Jepang harus menghubungi peritel lokal di negara pembelian untuk pertanyaan apa pun. Di "ELECOM CO., LTD. (Jepang)", tidak tersedia dukungan pelanggan untuk pertanyaan tentang pembelian atau penggunaan di/dari negara lain selain Jepang. Selain itu, tidak tersedia bahasa asing lain selain Jepang. Penggantian akan dilakukan sesuai dengan ketentuan garansi ELECOM.

Sila hubungi kedai tempat anda membeli produk ini jika anda mempunyai sebarang maklum balas atau pertanyaan tentang kandungan manual ini.

Spesifikasi dan rupa luaran produk ini boleh diubah tanpa notis awal untuk tujuan penambahbaikan produk.

ELECOM tidak bertanggungjawab ke atas sebarang kerosakan, atau kegagalan peranti lain yang disebabkan oleh penggunaan produk ini.

Imej adalah bagi tujuan ilustrasi sahaja dan mungkin berbeza daripada produk sebenar anda.

Apabila mengeksport produk ini, periksa peraturan eksport bagi negara asal.

Pelanggan yang membeli di luar Jepun harus menghubungi peruncit tempatan di negara pembelian untuk pertanyaan. Di "ELECOM CO., LTD. (Jepun)", tiada sokongan pelanggan yang disediakan untuk pertanyaan mengenai pembelian atau penggunaan di/dari mana-mana negara selain Jepun. Selain itu, tiada bahasa asing yang tersedia selain daripada bahasa Jepun. Penggantian akan dibuat di bawah penetapan jaminan ELECOM.