

User Manual

IP PDU

Caution:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Product function:

LIU - 0816 - WN is a kind of PDU product which can provide a steady power supply better for the server. LIU - 0816 - WN can provide relevant information for users and makes corresponding measures of warning or overload power by monitoring the electricity and environment status. The user can get the equipment's current status and start or shut off each output port by accessing LIU - 0816 - WN through the network port, so as to realize the function of the remote server restart.

Product features:

- 8 power output, the total current 16A
- current, voltage (total input) measurement
- built-in temperature and humidity sensor to monitor the using environment
- embedded technology, support Java, web browsing
- can set up two level values of warning and overload
- set each circuit delay time to prevent the impact of power surge to the power supply system
- LED indicates power supply condition of each switch
- LED digital display shows the current value of voltage and current
- provides local query buttons of PDU equipment
- built-in lightning protection circuit and resisting voltage surge circuit can protect the server effectively

Product specifications:

Rated input: 220VAC 20A 50/60Hz

Rated output: 220VAC 3A 50/60Hz *8 bits

Input socket type: IEC320 C20 *1 bit

Output socket type: IEC320 C13 *8 bits

Protection type: 16A overload protection、 lightning protection


Voltage measuring range: 90-264VAC resolution 1 V

Current measuring range: 0-20A resolution 0.1 A

Temperature measurement range: 20% -90%RH resolution 1%RH

Humidity measurement range: 0 °C-50 °C resolution 1 °C

Product Diagram



#

,1 1-3° "11 1 1#

- 1、 Power Input Socket IEC320 C20
- 2、 Output Socket IEC C13
- 3、 Reset Key
- 4、 Function Key, Check the machine ip adress
- 5、 Meter Panel, Display voltage, current, temperature, humidity, etc
- 6、 Network Port, Connect LAN or WAN

Using Directions:

1. Equipment connection Connect LIU - 0816-8 IEC C13 output plug with one side of the output line, connect 8 output line respectively with the power input end of the server which needs power supply. Connect one side of input line plug with the LIU - 0816 - WN IEC320 C20 input socket, and the other side with the AC power supply socket. After that, LIU - 0816 - WN will start from the first port to the 8th port with interval of 1 second, and supply power for the server. Display panel will show the current supply voltage and total output current of 8 circuits, 8 LED indicator light indicates the state of current 8 output port.

2. Check the IP address The display will show LIU - 0816 - current IP address after pressing the FUNC button when the display shows the voltage and current. The default IP address is 192.168.0.100

3. Check the temperature and humidity The display will show temperature and humidity of LIU - 0816 - WN built-in temperature and humidity sensor after pressing the FUNC button in the state of screen shows the IP address. The left screen shows temperature and the right screen shows humidity.

4. Reset of the equipment Press the LIU - 0816 - WN RST button on the front panel, it will reset .

5. Network access and control With LIU - 0816 - WN power-on, users can achieve the function that PC host access and control LIU - 0816 - WN in the same LAN by connecting RJ45 socket with network

①. Login control interface Open the IE browser on any PC in LAN host, the address bar: Http://192.168.0.10, uses can login LIU - 0816 - WN control interface after inputting user name (admin), password (admin) in the jumped login screen as shown in the picture below.

PDU		
Loading: nullA Temp: null℃ Moisture: null% Status: normal		
Info	PDU	
PDU	PDU: Current: 0.0A Status: normal	
System	Threshold	
Control	Voltage	
Socket	Warning	250v
Allocation	Overload	300v
PDU	Current:	
Threshold	Warning	17A
User	Overload	17A
Internet	Temperature:	
	Warning(≤)	5
	Overload (≥)	50
	Moisture:	
	Warning:	80%

②. PDU system information Click the "System" on the left side of the information bar, to indicate the PDU system information as the following picture.

Item No.	LANBE IP PDU
Firmware Version	1.0.0
MAC Address	00:04:A3:00:00:00
System Name	IP PDU
Admin	admin
System Address	office

③. **The power port control** Click "Socket" in the control bar which is on the left side of the interface , display as shown below.

Soket Name	Status	
outlet 1	disconnect	☐
outlet2	disconnect	☐
outlet3	disconnect	☐
outlet4	disconnect	☐
outlet5	disconnect	☐
outlet6	disconnect	☐
outlet7	disconnect	☐
outlet8	disconnect	☐

Operate

Users can start or shut off LIU - 0816 - WN 8-way output in this interface.

Start all: click drop-down box behind the action box, choose "Start", click the "Apply" button

Shut off all : click drop-down box behind the action box, choose "Shut off", click the "Apply" button

Custom start and shut off : illustrate the method of custom start and shut off, if the user needs to start 1, 2, 3, 4 circuit, but shut off 5, 6, 7, 8, **the first method**: click the drop-down box behind the action box, choose "Start". And then, click the small box behind outlet1, outlet2, outlet3, outlet4 respectively, click "Apply" button. **The second method**: click the drop-down box behind the action box, choose "Shut off ". And then, click the small box behind outlet5, outlet6, outlet7, outlet8 respectively, click "Apply" button.

④. **Start and shut off time-delay** Click "PDU" in the configuration box which is on the left side of the interface, display interface as shown below.

Socket Name	Starting-up Delay(sec)	Disconnection Delay(sec)
outlet1	1	1
outlet2	2	2
outlet3	3	3
outlet4	4	4
outlet5	5	5
outlet6	6	6
outlet7	7	7
outlet8	8	8

Users can start or shut off time-delay of LIU - 0816 - WN 8-way output. The picture above is the factory Settings, it means that the 8 circuit of LIU - 0816 - WN will output from the 1st to the 8th port in sequence in the interval of one second after connecting with power. When open the 8 output through the network, the starting delay time will display on the 8 output port. It is important to note that when the user disconnect the input power of LIU - 0816 - WN, shutting off the time-delay function is invalid. Shutting off the time-delay function is only applicable to control 8-way output through a network.

⑤. **Threshold value setting** Click “Threshold value” in the configuration box which is on the left side of the interface, display interface as shown below.

Name	Shreshold				
Current	Warning	17.0	A	Overload	17.0 A
Voltage	Warning	250	V	Overload	300 V
Temperature	Less than	5	℃	more than	50 ℃
Moisture	Warning	80	%		

The picture above is the factory Settings, the meaning is:

Current warning value 17A: When the total current exceeds 17A, LIU - 0816 - WN buzzer sends out "beep, beep" sound alarm

Current overload value 17A: When the total current exceeds 17 a, LIU - 0816 - WN will cut off the power supply of all output port


Warning voltage 250V: When the input voltage exceeds 250V, LIU - 0816 - WN buzzer sends out "beep, beep" sound alarm

Current overload value 300V: When the input voltage exceeds 300V, LIU - 0816 - WN cut off the power supply of all output port

Temperature is under 5 ℃, or exceed 50 ℃: When LIU - 0816 - WN built-in temperature and humidity sensor sensing the environment temperature is under 5 ℃ or exceed 50 ℃, LIU - 0816 - WN buzzer sends out "beep, beep" sound alarm

Humidity warning value 80%: When LIU - 0816 - WN built-in temperature and humidity sensor sensing environment humidity is more than 80%, LIU - 0816 - WN buzzer sends out "beep, beep" sound alarm

⑥. **The user name and password setting** Click “user” in the configuration box which is on the left side of the interface, display interface as shown below.




The interface for user name and password settings is displayed on a light blue background. It is divided into two sections: 'Old' and 'New'. The 'Old' section has two green input fields for 'User Name' and 'Password'. The 'New' section has three green input fields for 'User Name', 'Password', and 'Confirm password'. Below the 'New' section is a small, empty rectangular button.

Old	
User Name	
Password	
New	
User Name	
Password	
Confirm password	

The login user name and password of LIU - 0816 - WN can be modified in this interface. After filling in the original and new user name, password and password confirmation respectively, click apply button, the new user name and password will be used at the next time login LIU - 0816 - WN.

⑦. **IP address and DNS Setting.** Click “network” in the configuration box which is on the left side of the interface, display interface as shown below.



The interface for IP address and DNS settings is displayed on a light blue background. It contains several input fields for network configuration. The 'IP Address' field is empty. The 'Host Name' field contains 'LANBEPDUBOARD'. The 'IP Address' field contains '192.168.0.74'. The 'Subnet Mask' field contains '255.255.255.0'. The 'Gateway' field contains '192.168.0.1'. There is a checkbox for 'DHCP' which is currently unchecked. The 'DNS' section has a 'Primary DNS IP' field containing '180.168.255.118' and a 'Secondary DNS IP' field containing '116.228.111.18'. At the bottom is an 'Apply' button.

IP Address	
Host Name	LANBEPDUBOARD
IP Address	192.168.0.74
Subnet Mask	255.255.255.0
Gateway	192.168.0.1
☐	DHCP
DNS	
Primary DNS IP	180.168.255.118
Secondary DNS IP	116.228.111.18
Apply	

Host name: The name showed in the LAN, users can set itself

IP address: The current LAN IP address of LIU - 0816 - WN

Subnet mask: The current LAN subnet mask of LIU - 0816 - WN

Gateway: The current gateway of LIU - 0816 - WN

Enable the DHCP: The superior router of the current LAN will distribute network parameters automatically for LIU - 0816 - WN, it will come into force after clicking the apply button

Primary DNS IP refer to the supervisor router setting of current LAN

Secondary DNS IP refer to the supervisor router setting of current LAN