

料 号 705-CBZP31-00

项 目 Cube-OP3 Kit1 中英文说明书

成品尺寸 75*85 mm

公 差 $\pm 0.5\text{mm}$

材 质 105g 哑粉纸

工 艺 骑马钉

颜色要求 单色印刷

其 他

设计师 邱光宇 包装结构 文案 吴水宁 伍青蕾

项目 产品 结构工程 ID 王震

重要: PDF 文件仅供预览, 实际印刷请使用 AI 转曲文档
或 Cdr 转曲文档)



刀模线
标示线



标示线刀模线
请勿印刷!

印刷要求:

色相正确、印迹牢固、套印准确、各色套印不露杂色,
套印误差 $\leq 1\text{mm}$, 模切走位 $\leq \pm 1\text{mm}$

合格证
QC PASS




Godox Audio
Wechat
Official Account
神牛影音微信公众号



Overseas Official
Accounts & Updates
海外社媒平台及资讯

Godox



Cube-OP3

无线麦克风
Wireless Microphone

使用手册
Instruction Manual

www.godox.com

Made in China | 705-CBZP31-00



前言

感谢您购买神牛无线麦克风。

在使用前，请仔细阅读说明书，以确保正确使用。

主要特点

- 适用于云台相机 Osmo Pocket 3 直插收音；
- 小巧迷你，即插即用；
- 最远无线传输距离可达 200 米（视距）；
- 发射器续航长达 10 小时；
- 1/4"螺丝口，可拓展三脚架等附件。
- 接收器支持边充边用 / 拓展续航手柄。
- 可通过配线连接手机、电脑等收音。

警告

△麦克风是精密设备。请勿使其掉落或受到撞击，以避免发生故障。


△请勿私自拆卸、改装或尝试维修本产品。产品如出现故障须由本公司或授权的维修人员进行检查维修。

△产品含强磁，请远离磁卡、植入性医疗设备（如心脏起搏器）硬盘、RAM 芯片等易受干扰设备。

△请勿将电池彻底放电后长时间存储，避免电池因过放而无法继续使用。

- △请保持干燥，请勿用湿手握持本产品，亦不可将产品浸入水中或暴露于雨中。
- △请勿将本产品存放在阳光直射的地方、加热装置附近或者炎热、潮湿或多尘的地方。请勿放置在超过 50 度的高温环境中。
- △请勿让儿童接触本产品，以避免发生意外。
- △请勿在易燃易爆环境中使用。在这些场合下，请注意相关警告标识。
- △请仔细阅读并遵守由厂商提供的警告或指示。
- △若使用电源适配器充电，应购买获得 CCC 认证并满足标准要求的电源适配器。


Cube-OP3 RX 物品清单



接收器 Cube-OP3 RX×1




USB-C 母转 USB-A 公转接头 ×1



USB-C 母转 USB-C 公转接线 ×1


Cube-OP3 Kit1 物品清单



接收器 Cube-OP3 RX×1



发射器 Cube-S TX×1



USB-C 母转 USB-C 公转接线 ×1 USB-C 母转 USB-A 公转接头 ×1



防风兔毛 ×1



说明书 ×1



磁吸充电线 ×1



磁铁 ×2



磁吸背夹 ×1



收纳包 ×1



挂绳 ×1




卡通贴纸 ×1

温馨提示：说明书中的图片均为示意图，仅供参考。由于产品不断更新与升级，产品实物与图片可能存在差异，请以实物为准。

使用说明

发射器 Cube-S TX



开 / 关机

长按 < 电源 / 降噪 / 配对键 > 2s 开 / 关机。

■ 绿色闪烁 ---- 开机未配对

注：超过 5 分钟未配对，会自动关机。

配对

短按两次 < 电源 / 降噪 / 配对键 > 键进入配对状态。

■ 绿色快闪 ---- 正在配对

■ 绿色长亮 ---- 配对成功，未开降噪

降噪

短按一次 < 电源 / 降噪 / 配对键 > 键开启 / 关闭降噪。

■ 橙色长亮 ---- 开启降噪

充电


使用磁吸充电线为产品充电。


■ 红色闪烁 ---- 电量低。

■ 蓝色呼吸闪烁 ---- 充电中

■ 蓝色长亮 ---- 已充满

接收器 Cube-OP3 RX





开 / 关机

将接收器 USB-C 插头插入 Osmo Pocket 3 USB-C 接口，相机开机状态下，接收机会自动开机，或者长按 <  /  > 按键 2s 开机 / 关机。

 绿色闪烁 → 开机未配对

注：如接收器 2 分钟内未配对自动进入休眠。

若您不需要外接麦克风收音，请长按开关键 2S 进行接收机关机或拔出接收机，以免拍摄的视频出现无声音情况。

配对

短按两次 <  /  > 按键进入配对状态，连接成功退出配对状态，未连接成功 10s 后退出配对状态。

 绿色快闪 → 正在配对

降噪

短按一次 <  /  > 按键开启 / 关闭降噪。


 →  指示灯橙色常亮 → 开启降噪

TX1/TX2 指示灯

 TX1/TX2 指示灯红色闪烁 → TX1/TX2 发射器电量低


注：发射器需另购。

发射器佩戴




接收器安装示意

直插 USB-C 接口, 无需按住两侧解锁扣。



拆卸示意

取下时，按住两侧解锁扣的同时往下拔出。




APP 下载

扫码下载 Godox Mic APP。




接收器与手机 / 电脑连接

使用 USB-C 母头转 USB-C 公头转接线可与手机连接使用；



使用 USB-C 母头转 USB-A 公头转接线可与电脑连接使用。



规格参数

名称	发射器	接收器
型号	Cube-S TX	Cube-OP3 RX
传输类型	2.4GHz 数字跳频系统	
拾音模式	全向型	/
频率范围	20Hz-20KHz	/
最大 SPL	115dB	/
信噪比	> 70dB	/
最大无线距离	200 米（视距）	
输入参数	5V  90mA	9V  2A
锂电池参数	3.87V, 97mAh, 0.376Wh	/
续航时间	约 10 小时	/
充电时间	约 1.5 小时	/
工作环境温度	-10~50°C	
充电温度	0°C ~45°C	/
尺寸	24.5x24.8x12.5mm	38x28x31mm
净重	≈ 7g	≈ 20g

规格参数如有变更，恕不另行通知。

有害物质标识

弃置本产品时，请不要将其与一般生活垃圾放在一起，应将其交给政府指定的回收中心有利于环保。

电子电气产品有害物质申明						
部件名称	铅(Pb)	镉(Cd)	汞(Hg)	六价铬(Cr6+)	多溴联苯(PBB)	多溴二苯醚(PBDE)
外壳	○	○	○	○	○	○
电路板组件*	×	○	○	○	○	○
电池组	○	○	○	○	○	○
其他配件	○	○	○	○	○	○
本表格依据 SJ/T11364 的规定编制。 *：电路板组件包括印刷电路板及其构成的零部件，如电阻、电容、集成电路、连接器等。 ○：表示该有毒有害物质在该部件所有均质材料中的含量在 GB/T 26572 规定的限量要求以内。 ×：表示该有毒有害物质至少在该部件的某一均质材料中含量超出 GB/T26572 规定的限量要求。 上表中打 × 的部件，由于技术原因目前无法实现替代，今后随着技术进步，将实现替代或改进。						
 在本说明书所述的正常使用条件下，本仪器的环保使用期限为 10 年，在环保使用期内可以放心使用，超过环保使用期限之后则应该进入回收循环系统。						

Foreword

Thank you for purchasing!

Please read this manual carefully before using to make sure the correct operation and exert the optimum function.

Main Features

- Receiver Cube-OP3 RX is suitable for Osmo Pocket 3.
- Compact and portable, plug and play.
- The maximum wireless transmission distance up to 200m (sight distance).
- Built-in lithium battery in transmitter provides 10 hours of working time.
- 1/4 " screw plug is compatible with accessories such as tripods.
- USB-C port on receiver supports using while charging, and battery handle.
- Compatible with various smartphones and cameras.


Warning

- ⚠ This product is high-precision instrument, please avoid falling, collision or pounding.
- ⚠ Do not disassemble. Should repairs become necessary, this


product must be sent to our Company or an authorized maintenance center.

- ⚠ The product contains strong magnetism, please keep it away from magnetic cards, implantable medical devices (such as pacemakers), hard disks, RAM chips and other devices that are susceptible to interference.
- ⚠ Do not store the battery for a long period of time after it has been completely discharged to avoid over-discharging the battery and rendering it unusable.
- ⚠ Always keep this product dry. Do not use in rain or damp conditions.
- ⚠ Do not leave or store this product in the environment of direct sunlight, near heating devices, or in hot, humid or dusty. Do not leave or store the product if the ambient temperature reads over 50°C .
- ⚠ Keep out of reach of children.
- ⚠ Do not use in flammable and explosive environments. Pay attention to the relevant warning signs.
- ⚠ Please read carefully and follow the warnings or instructions provided by the manufacturer.
- ⚠ Consumers who use a power adapter for charging should purchase a CCC-certified power adapter that meets the requirements of the standard.

What's Inside Cube-OP3 RX



Receiver Cube-OP3 RX x1




USB-C Female to USB-C
Male Adapter Cable x1



USB-C Female to USB-A
Male Adapter x1


What's Inside Cube-OP3 Kit1



Receiver Cube-OP3 RX x1




Transmitter Cube-S TX x1



USB-C Female to USB-C
Male Adapter Cable x1




USB-C Female to USB-A
Male Adapter x1



Note: Due to continuous updates and upgrades of the products, there may be differences between the actual products and the pictures. Therefore, the pictures are for reference only, products to prevail in kind.

Using Instructions

Transmitter Cube-S TX



Power Switch

Long press the power switch button <  > for 2s to turn on or off the transmitter.

 **Flash green** --- Unpaired after powered on

Note: The transmitter will be turned off if it stays unpaired in 5min after powered on.

Pairing

Short press twice the pairing button <  > to pair it with the receiver.

-  **Flash green rapidly** ---- Pairing status
-  **Constant on green** ---- Paired with denoise off

Denoise

Short press the denoise button <  > to turn on or off the denoise function.


-  **Constant on orange** ---- Denoise function is on

Charging

The transmitter can be charged with the magnetic charging cable.

-  **Flash red** ---- Low battery level
-  **Breathe blue** ---- Charging
-  **Constant on blue** ---- Fully charged

Receiver Cube-OP3 RX



Power On/Off

Insert the USB-C plug on the receiver into the USB-C port of Osmo Pocket 3, the receiver will be automatically powered on after Osmo Pocket 3 is turned on. Long press the <  /  > button for 2s to turn it on or off.

 **Flash green → Unpaired after powered on**

Note: The receiver will be turned off if it stays unpaired in 2min after powered on. If you don't need an external microphone, please press and hold the power switch button for 2S to turn off or unplug the receiver to avoid no sound in the video.

Pairing

Short press twice the <  /  > button to pair it with the transmitter. It will exit pairing status once paired, while exit after 10s if unpaired.

 **Flash green rapidly → Pairing status**

Denoise

Short press once the <  /  > button to turn on or off the denoise function.


 →  **Constant on orange → Denoise function is on**

TX1/TX2 Indicator

 **Flash red ---- Battery level of TX1 or TX2 transmitter is low**


Note: Transmitter is sold separately.

Transmitter Installation




Receiver Installation

Directly plug in to install without pressing the locking buckles on both sides.



Receiver Disassembly

Press the locking buckles on both sides and pull out the receiver.




APP Downloading

Scan the QR code to download Godox Mic app.




Connecting the Receiver to Smartphone and Computer

The receiver can be connected to smartphone with USB-C female to USB-C male adapter cable.



The receiver can be connected to computer with USB-C female to USB-A male adapter cable.



Technical Data

Name	Transmitter	Receiver
Model	Cube-S TX	Cube-OP3 RX
Transmission Type	2.4GHz Frequency Hopping System	
Pickup Pattern	Omnidirectional	/
Frequency Range	20Hz-20KHz	/
Max. SPL	115dB	/
SNR	> 70dB	/
Max. Wireless Distance	300m (sight distance)	
Input Parameters	5V  90mA	9V  2A
Lithium Battery Parameters	3.87V, 97mAh, 0.376Wh	/
Working Time	Approx. 10h	/
Charging Time	Approx. 1.5h	/
Working Environment Temperature	-10~50°C	
Charging Temperature	0°C ~45°C	/
Dimension	0.96"x0.98"x0.49"	1.5"x1.1"x1.22"
Net Weight	≈7g	≈20g

Specifications and data may subject to changes without notice.

Warning

Operating frequency: 2402MHz - 2480MHz

Maximum EIRP Power: 5dBm

Declaration of Conformity

GODOX Photo Equipment Co., Ltd. hereby declares that this equipment are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states.

For more information of DoC, Please click this web link:

<https://www.godox.com/eu-declaration-of-conformity/>

The device complies with RF specifications when the device used at 0mm from your body.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to

operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

Marking Information

Model: Cube-OP3 RX



R-R-gdx-051



Input: 9V $\bar{\sim}$ 2A (Max.)

CAN ICES-003(B)/NMB-003(B)

Made in China



219-247157

IC : 20034-143

FCC ID: 2ABYN143

Model: Cube-S TX



R-R-gdx-018



Made in China

Li-ion Battery: 3.87V, 97mAh, 0.376Wh

FCC ID: 2ABYN120

Input: 5V $\bar{\sim}$ 90mA

CAN ICES-003(B)/NMB-003(B)



210-234905

产品保修

尊敬的用户，本保修卡是申请保修服务的重要凭证，请您配合销售商填写并妥善保管，谢谢！

产品信息	型号	产品条码
用户信息	姓名	联系电话
	通讯地址	
销售商信息	名称	
	联系电话	
	通讯地址	
	销售日期	
备注		

规格参数如有变更，恕不另行通知。

产品信息

本文件适用于相关《产品保修信息》(见后面说明)所列产品,其他非属此范围的产品或部件(如促销品、赠品及其他出厂后附加的部件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算,购买日以购买产品时保修卡登记日期为准。

如何获得保修服务

要保修服务,您可直接与产品销售商或授权服务机构联系,也可拨打神牛产品售后服务电话,与我们联系,由我们的服务人员为您安排服务。申请保修时,您应提供有效的保修卡作为保修凭证,方可获得保修。如您不能提供有效的保修卡,则在我们可确认产品或部件属于保修范围的情况下,也可以为您提供保修,但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况,本文件项下的保证和服务将不适用 ①产品或部件超过相应保修期;②错误或不适当使用、维护或保管导致的故障或损坏,如:不当搬运;非按产品合理预期用途使用;不当插拔外接设备;跌落或外力挤压;接触或暴露于不适当温度、溶剂、酸碱、水浸或潮湿环境;③由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏;④产品或部件原有识别信息被修改变更或删除;⑤无有效保修卡;⑥使用非合法授权、非标准或非公开发行的软件造成的故障或损坏;⑦因不可抗力或意外事件造成的故障或损坏;⑧其他非因产品本身质量问题导致的故障或损坏。遇上述情况,您应向相关责任方寻求解决,神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的,不是保修范围内的故障。产品使用过程中正常的脱色,磨损和消耗,不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行：

产品类型	选件名称	保修期(月)	保修服务类型
部件	主机	12	客户送修
	电池	3	客户送修
	充电器等 带电性能的部件	12	客户送修
其他	如电源线、同步线、电池盒、防风棉、防风毛罩、锁紧装置、手提绳、扎带、魔术贴、领夹、便携袋、包装等	无	无保修

神牛产品售后服务电话 0755-29609320-8062

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note		

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance information (see below for further information). Other products or accessories (e.g. promotional items, giveaways

and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day (purchase date) when the product is bought for the first time, and the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ①. **The product or accessory has expired its warranty period;** ②. **Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc;** ③. **Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment;** ④. **The original identifying information of product or accessory is modified, alternated, or removed;** ⑤. **No valid warranty card;** ⑥. **Breakage or damage caused by using illegally authorized, nonstandard or non-public released software;** ⑦. **Breakage or damage caused by force majeure or accident;** ⑧. **Breakage or damage that could not be attributed to the product itself.** Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Product Main Body	12	Customer sends the product to designated site
	Battery	3	Customer sends the product to designated site
	Charger, Electrical Parts etc.	12	Customer sends the product to designated site
Other Items	Power Cable, Sync Cable, Battery Case, Windscreen Foam, Wind Cap, Locking Device, Lanyard, Tie, Velcro Tape, Clip, Bag, Package etc.	No	Without warranty

Godox After-sale Service Call 0755-29609320-8062