

Label

122.80 mm±0.25

PORTABLE GENERATOR

Type: G500

Battery Capacity: 22.2V, 23.4Ah, 519.48Wh

DC Input: 12V-26V-4A

DC5525 Output×2: 14V—4A

Cigarette Lighter Output: 14V_{DC} 8A

USB-A Output ×3: 5V=2.5A, 9V=2A, 12V=1.5A

USB-C Output: 5V $\times$ 3A, 9V $\times$ 3A, 12V $\times$ 3A

15V=3A, 20V=3A (Max.60W)

AC Output: Pure Sine Wave

110V~ 60Hz, 500W

Wireless Charger: 10W

Manufacturer:

ShenZhen Intel

Production Date : 20210809

SN:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID :2A4UPG500MV1000

Made In China



株式会社 泰成商事
TaiSeisyoujiCo.,Ltd

Li-ion 20

WARNING!

1. Do not short-circuit the unit. To avoid short-circuiting, keep the unit away from all metal objects (e.g. coins, hair-pins, keys, etc. . .)
2. Do not heat the unit, or dispose of it in fire, water or other liquids. Keep away from high temperatures. Do not expose the unit to direct sunlight.
3. Keep away from high humidity, dusty places.
4. Do not disassemble or reassemble this unit.
5. Do not drop and place heavy objects on, or allow strong impact to this unit.
6. Do not intend to use the unit on persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning proper use of the appliance by a person responsible for their safety.
7. Children should be supervised to ensure that they do not play with the appliance.
8. The unit may become hot when charging. This is normal. Be careful when handling.
9. Use the unit properly to avoid electronic shock.
10. The product is only used for emergency power station, it can not replace the standard DC or AC power of household appliances or digital products
11. Do not overcharge the internal battery. See Instruction Manual.

AVERTISSEMENT!

1. Ne court-circuitez pas l'appareil. Pour éviter tout court-circuit, éloignez l'appareil de tout objet métallique (par exemple, pièces de monnaie, épingles à cheveux, clés, etc.).
2. Ne court-circuitez pas l'appareil et ne le jetez pas dans le feu, l'eau ou d'autres liquides. Tenir à l'écart des températures élevées. N'exposez pas l'appareil à la lumière directe du soleil.
3. Tenir à l'écart des endroits humides et poussiéreux.
4. Ne démontez pas et ne rassemblez pas cet appareil.
5. Ne laissez pas tomber, ne placez pas d'objets lourds dessus et ne laissez pas de chocs violents sur cet appareil.
6. Cet appareil n'est pas destiné à être utilisé par des personnes (y compris des enfants) ayant des capacités physiques, sensorielles ou mentales réduites, ou un manque d'expérience et de connaissances, à moins qu'elles n'aient reçu une supervision ou des instructions concernant l'utilisation de l'appareil par une personne responsable de leur sécurité.
7. Les enfants doivent être surveillés pour s'assurer qu'ils ne jouent pas avec l'appareil.
8. Ne laissez pas l'enfant chahuter pendant la charge. C'est normal. Soyez prudent lors de la manipulation.
9. Utilisez l'appareil correctement pour éviter les chocs électroniques.
Le produit n'est utilisé que pour la centrale électrique de secours, il ne peut pas remplacer l'alimentation CC ou CA standard des appareils ménagers ou des produits numériques.
11. Ne pas surcharger la batterie interne. Consulter le manuel d'utilisation.

89.40 mm $\pm$ 0.25

0.15

Label positions

