

134.40±0.25

77.40±0.25

PORTABLE POWER STATION

Type:T300
Battery Capacity: 11.1V, 26Ah, 288.6Wh
DC Input: 12V-26V-4A
DC Output 5525 x2: 12V-5A
Cigarette Lighter Output: 12V-10A

USB-A Output x3: 5V-2.5A, 9V-2A, 12V-1.5A
USB-C Output: 5V-3A, 9V-3A, 12V-3A
15V-3A, 20V-3A (Max.60W)
AC Output: Pure Sine Wave 110V-60Hz, 330W
Wireless Charge: 5W
Charge temperature: 0-40°C
Discharge temperature: -15-45°C
Production Date:
Shenzhen Intelligent Energy Co.,Ltd - Dongguan
SN:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
FCC ID : ZA4UPT300MV1000



WARNING!

1. Do not short-circuit the device. To avoid short circuits, keep the device away from all metal objects (such as coins, hairpins, keys, etc.).
2. Do not heat the device or put it in fire, water or other liquids for disposal. Keep away from high temperatures. Do not expose the device to direct sunlight.
3. Please keep away from high humidity and dusty places.
4. Do not disassemble or reassemble this device.
5. Do not put heavy objects on the device or cause strong impact on the device.
Be careful when handling & transporting.
6. This equipment is not suitable for persons with reduced physical, sensory or mental abilities or lack of experience and knowledge (including children), unless they have been supervised or instructed on the use of equipment by persons responsible for their safety.
7. Children should be supervised to ensure that they do not play with equipment.
8. When charging, the adapter and the device may become hot. This is normal.
9. Please use the device correctly to avoid electric shock.
10. This product is only used in emergency power stations. It can not replace standard DC or AC power, home appliances or digital products.
11. Do not overcharge the internal battery. See Instruction Manual.

AVERTISSEMENT!

1. Ne court-circuitiez pas l'appareil. Pour éviter tout court-circuit, éloignez l'appareil de tout objet métallique (par exemple, pièces de monnaie, épingles à cheveux, clés, etc.).
2. Ne chauffez pas l'appareil et ne le jetez pas dans le feu, l'eau ou d'autres liquides.
Tenir à l'écart des températures élevées. N'exposez pas l'appareil à la lumière directe du soleil.
3. Tenir à l'écart des endroits humides et poussiéreux.
4. Ne démontez pas et ne réassemblez pas cet appareil.
5. Ne laissez pas tomber, ne placez pas d'objets lourds dessus et ne laissez pas de chocs violents sur cet appareil.
6. Cet appareil n'est pas destiné à être utilisé par des personnes (y compris des enfants) ayant des capacités physiques, sensorielles ou mentales réduites, ou un manque d'expérience et de connaissances, à moins qu'elles n'aient reçu une supervision ou des instructions concernant.
7. L'utilisation de l'appareil par une personne responsable de leur sécurité.
8. Les enfants doivent être surveillés pour s'assurer qu'ils ne jouent pas avec l'appareil.
9. L'appareil peut devenir chaud pendant la charge. C'est normal. Soyez prudent lors de la manipulation.
10. Utilisez l'appareil correctement pour éviter les chocs électroniques. Le produit n'est utilisé que pour la centrale électrique d'urgence, il ne peut pas remplacer l'alimentation CC ou CA standard des appareils ménagers ou des produits numériques.
11. Ne pas surcharger la batterie interne. Consulter le manuel d'utilisation.

0.15

Label position

