

This device complies with parts 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this device not approved by the party responsible for compliance could void the user's authority to operate the device.

These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to another radio receiving device, you may wish to take one or more of the following measures, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Safety:

1. Follow the instructions described in this manual closely to ensure your safety. Before using this stereo headphone(s), we strongly encourage you to read through the user manual.
2. Do not modify, repair or dismantle the bluetooth stereo headphone(s). In doing so, it may result in fires, electric shocks, malfunction of this bluetooth stereo headphone(s), which will not be covered under the warranty.
3. Do not use any volatile liquid to clean the headphone(s).
4. Do not use the Bluetooth stereo headphone(s) in hazardous environment.

Diagram illustrating the contents of the package:

- Ear Tips: Large, Medium, Small
- Headphones: Left, Right
- Battery Case
- USB to USB-C Cable
- User manual

1. Touch control surface
2. Microphone 1 and LED indicator
3. Microphone 2
4. Ear tip
5. Headphones Magnetic charging
6. USB-C charging port
7. Digital battery case charging status display
8. Headphone(s) battery life status

In order to get best audio performance, please try each of the eartips (small, medium and large). The correct fit in your ears will help achieve optimal performance and comfort.

-

*Ulo PULSE Elite 2 headphones playtime may varies on volume setting, ANC on/off and music type
-

When charging: LED indicator flashing in white
Fully-charged: LED indicator will turn off
Charging time: 1.5-4 hours
-

When charging: LED indicator stay solid red
Fully-charged: Headphone will turn off
- ▲ Note : When charging with a cable, use a USB-C cable and a 5V output USB charger to charge the battery case. A 5V10A (5W) charger is recommended. Compatible with PD Charger

ANC Mode	: Reduce unwanted background/low frequency noise.
Regular Mode	: Physical noise isolation with the headphones earcup plugs only.
Transparency Mode	: Lets outside sound in, so you can hear what's going on around you.
Music Mode	: 330ms latency optimized for longer battery life.
Game Mode	: 60ms dynamic low latency optimized for game playing experience. This mode consumes more battery and may affect bluetooth connection distance.

L Touch Control Surface 8

1 1 tap Play/Pause/Answer/ Hang up/De-activate Siri/Google 2 Double tap : Increase volume Triple tap : Next song 3 4 tap To switch ANC / Regular / Transparency mode 5 5 tap To switch between Game & Music mode 6 Press & Hold 1 sec To Wake up Siri/Google 8 Press & Hold 5 sec To turn off headphones/	2 Double tap : Reduce volume Triple tap : Previous song 7 7 tap To clear pairing list (earbuds will announce: pairing list cleared)
---	---

Note : ANC function cannot be turn on/off during a call

Make sure the device is fully charged. Take out the headphone(s) from the charging case, the headphone(s) will power on automatically. The LED indicator(s) of the headphone(s) will flash red to get into the pairing mode with the "Pairing" voice prompt.

Turn on the Bluetooth of your device (smartphone, laptop, etc), and find the pairing ID "Uolo Pulse Elite 2". Select to connect. The pairing is successful if you see it's connected on your device or hear the "Uolo Pulse Elite Connected" voice prompt.

Note :

1. The LED indicator(s) on the headphone(s) will flash red when the battery is low.

Note: If both headphones are not connected within 60 seconds headphones will turn off automatically. Please put the headphones back to the charging case or turn them back on and follow the above steps to pair again.

Turn on ANC/Transparency mode, the headphone(s) will stay on continuously

Short press the headphone 7 times, you will hear a voice prompt "pairing list cleared". Repeat above steps for the second headphone to complete hard reset.
Repeat the pairing steps to reconnect the headphone(s) to your device.

The headphone(s) will power on automatically and connect with each other when taken out of the battery case. The headphones will auto connect with the Bluetooth device which has been previously connected to.

- Device name: Uolo Pulse Elite 2
- Bluetooth version: 5.3
- ANC: Up to -30dB
- Headphones driver size: 13mm
- Microphone sensitivity: - 42 ± 3dB
- Headphones battery capacity: 40mAh
- Charging case battery capacity: 400 mAh
- Talk/Play time: 5+ hours (at 70% volume)
- Charging time: 1.5+ hour
- Charging Power input: USB-C 5V/1A (PD compatible)

Limited Lifetime Warranty

*This warranty does not cover normal aging of the battery due to usage

For more info visit us at:
www.uoloonline.com

1. Do not leave this product in extremely low or high temperature environment, which may cause deformation, reduced battery performance or malfunction (not covered by warranty).
2. Do not use the device during severe thunderstorm, which may cause device failure.
3. Do not modify the product for any reason, which may lead to device failure or cause fire.
4. Keep the device and all accessories out of reach of children and pets, small parts may be swallowed causing suffocation and serious consequences.
5. Do not submerge the ear buds or the charging case in the water.

Manuel de l'Utilisateur

Sécurité:

1. Suivez attentivement les instructions décrites dans ce manuel pour assurer votre sécurité. Avant d'utiliser ce(s) casque(s) stéréo, nous vous encourageons fortement à lire le manuel d'utilisation.
2. Ne modifiez, réparez ou démontez pas la chaîne stéréo Bluetooth (écouteurs). Ce faisant, cela peut entraîner des incendies, des décharges électriques, dysfonctionnement de ce(s) casque(s) stéréo bluetooth, qui ne sera pas couverts par la garantie.
3. N'utilisez aucun liquide volatil pour nettoyer le(s) casque(s).
4. N'utilisez pas le(s) casque(s) stéréo Bluetooth dans des endroits dangereux.

Embouts d'oreille

Écouteuses

Casque de piles

Large

Medium

Small

Left

Right

Câble USB vers USB-C

Manuel de l'utilisateur

1. Surface de contrôle tactile
2. Microphone 1 et indicateur LED
3. Microphone 2
4. Embout d'oreille
5. Casque Charge magnétique
6. Port de charge USB-C

7. Chargement du boîtier de batterie numérique affichage d'état
8. État de la batterie des écouteurs

Afin d'obtenir les meilleures performances audio, veuillez essayer chacune des embouts (petits, moyens et grands). Le bon ajustement dans vos oreilles aider à atteindre des performances et un confort optimaux.

Appeler / Jouer : Jusqu'à 5+ heures
Etre prêt : Jusqu'à 150

Charge jusqu'à **5** fois avec **étui** de charge

* Temps de lecture du casque Uno Pulse Elite 2 peut varier selon le réglage du volume, ANC activé/désactivé et type de musique

Boîtier de charge noire

• Temps de charge : Indicateur LED clignotant en blanc. Entièrement chargé : Indicateur LED s'éteint. Temps de charge : 1,5+ heures

Écouteuses

Lors de la charge : Indicateur LED reste rouge. Entièrement chargé : le casque s'éteint

▲ Remarque : Lors de la charge avec un câble, utilisez un câble USB-C et une sortie USB-C pour recharger le boîtier de la batterie. Un chargeur 5V/1A (5W) est recommandé. Compatible avec le chargeur PD

Mode ANC	Réduire les bruits de fond indésirables/basses fréquences bruit.
Mode régulier	Isolation physique du bruit avec le casque bouchons d'oreille uniquement.
Mode transparence :	Laisser entrer le son extérieur pour que vous puissiez entendre ce qui se passe passe autour de vous.
Mode musique	Latence de 330 ms optimisée pour une plus longue durée de vie de la batterie
Mode de jeu	Stabilité latence dynamique de 60 ms optimisée pour l'expérience de jeu. Ce mode consomme plus de batterie et peut affecter la distance de connexion Bluetooth.

L Surface de contrôle tactile R

1 1) **Lecture/ Pause/ Répondre/ Raccourcir/ Désactiver Siri/ Google**

2 Appuyez deux fois : Augmenter le volume
Appuyez trois fois : Prochaine chanson

3 Appuyez deux fois : Réduire le volume
Appuyez trois fois : Chanson précédente

4 4) **4 tap** | Pour basculer entre les modes **AN** / Régulier / Transparence

5 5) **5 tap** | Pour basculer entre les modes **Jeu** et **Musique**

6 Appuyez et maintenez 2 secondes | Pour réveiller Siri/Google

7 Appuyez et maintenez 5 secondes | Pour éteindre led(s) (casque(s))

7 7) **7 tap** | Pour effacer la liste d'appariement (les écouteurs n'arrivent pas à se connecter)
- liste d'appariement effacée

▲ Remarque : la fonction **AN** ne peut pas être activée/désactivée pendant un appel

Assurez-vous que l'appareil est complètement chargé. Sortez le(s) casque(s) du boîtier de charge, le ou les écouteurs s'allumeront automatiquement. Le(s) voyant(s) LED du(des) casque(s) clignote(nt) en rouge pour passer en mode appairage avec l'invite vocale "Appairage".

Activez le Bluetooth de votre appareil (smartphone, ordinateur portable, etc.), et trouvez l'ID d'appairage "Uolo Pulse Elite 2". Sélectionnez pour vous connecter. L'appairage est réussi si vous voyez qu'il est connecté sur votre appareil ou écoutez l'invite vocale "Uolo Pulse Elite Connected".

Note :

1. Le(s) voyant(s) LED sur le(s) casque(s) clignote(nt) en rouge lorsque la batterie est faible.

Remarque : si les deux écouteurs ne sont pas connectés dans les 60 secondes, les écouteurs s'éteindra automatiquement. Veuillez remettre le casque dans boîtier de charge ou rallumez-les et suivez les étapes ci-dessus pour les coupler à nouveau.

Activez le mode ANC/Transparence, le ou les écouteurs resteront allumés en continu.

Appuyez brièvement sur le casque 7 fois, vous entendrez une invite vocale "liste de couplage effacée". Répétez les étapes ci-dessus pour le deuxième casque pour terminer la réinitialisation matérielle. Répétez les étapes de couplage pour reconnecter le(s) casque(s) à votre appareil.

Le ou les écouteurs s'allumeront automatiquement et se connecteront avec l'un à l'autre lorsqu'ils sont retirés du boîtier de la batterie. Les écouteurs seront connexion automatique avec le périphérique Bluetooth qui a été précédemment connecté à.

- Nom de l'appareil: Udo Pulse Elite 2
- Version Bluetooth: 5.3
- ANC : jusqu'à -30 dB
- Taille du pilote du casque: 13mm
- Sensibilité du micro : -42 ±3dB
- Capacité de la batterie du casque: 40mAh
- Capacité de la batterie du boîtier de charge : 400 mAh
- Autonomie en conversation/jeu : plus de 5 heures
(à 70 % de volume)
- Temps de charge : 1,5+ heure
- Entrée d'alimentation de charge : USB-C 5 V/1 A (compatible PD)

Garantie à vie limitée

* Cette garantie ne couvre pas le vieillissement normal de la batterie en raison de son utilisation

Pour plus d'informations, visitez-nous à :

www.uoloonline.com

1. Ne laissez pas ce produit à des températures extrêmement basses ou élevées, environnement raté, ce qui peut provoquer une déformation, réduire performances ou dysfonctionnement de la batterie (couvert par la garantie).
2. N'utilisez pas l'appareil pendant un orage violent, ce qui peut provoquer une défaillance de l'appareil.
3. Ne modifiez pas le produit pour quelque raison que ce soit, à une défaillance de l'appareil ou à un incendie.
4. Gardez l'appareil et tous les accessoires hors de portée des enfants et les animaux domestiques, de petites pièces peuvent être avalées, provoquant une suffocation et de graves conséquences.
5. Ne plongez pas les écouteurs ou le boîtier de charge dans l'eau.