

87.00±0.25mm

50.00±0.25mm

Portable Power Station

- Model: VP11
- Capacity: 12.0Ah (24Ah 5000Wh)
- DC Charging Input: 20V-45A
- USB-C In/Out: 5A-3A, 9V-3A, 12V-3A
- 15V-3A, 20V-3A 100W Max
- AC Rated Output: 600W 110V~ 50/60Hz Total 300W
- (2) AC Output: 12V-3A Total 120W
- Car Output: 12V-15A
- (2) AC Output + Car Output: Total 1200W
- (2) USB-A Output: 5A-3A, 9V-3A, 12V-1.5A Total 30W
- Wireless Output: 2V-4A, 9V-3A
- Max Output: 300W
- Discharging Temperature: -10~40°C
- Charging Temperature: 0~40°C
- S/N

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
FCC ID: JAS5VFP11330



VIGORPOOL



WARNING!

- Do not short-circuit the unit. To avoid short-circuiting, keep the unit away from all metal objects (e.g. coins, hair-pins, keys, etc.).
- Do not touch the unit or dispose of it in fire, water or other liquids. Keep away from high temperatures. Do not expose the unit to direct sunlight.
- Keep away from high humidity, dusty places.
- Do not disassemble or reassemble this unit.
- Do not drop and place heavy objects on or allow strong impact to this unit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The unit may become hot when charging. This is normal. Be careful when handling.
- Use the unit properly to avoid electric shock.
- The product is only used for emergency power station, it can not replace the standard DC or AC power of household appliances or digital products.
- Do not overcharge the internal battery. See instruction Manual.
- This device is intended to be used indoors only. Do not use outdoors.
- This device is not intended for use in a commercial repair facility.

AVERTISSEMENT!

- Ne court-circuitez pas l'appareil. Pour éviter tout court-circuit, éloignez l'appareil de tout objet métallique (par exemple, pièces de monnaie, épingles à cheveux, clés, etc.).
- Ne chauffez pas l'appareil et ne le placez pas dans le feu, l'eau ou d'autres liquides. Tenez à l'écart des températures élevées.
- Éloignez l'appareil des endroits humides, poussiéreux.
- Ne démontez pas et ne réassemblez pas cet appareil.
- Ne laissez pas tomber, ne placez pas d'objets lourds dessus et ne laissez pas de choses violentes sur cet appareil.
- Cet appareil n'est pas destiné à être utilisé par des personnes ayant des capacités physiques, sensorielles ou mentales réduites, ou un manque d'expérience et de connaissances, à moins qu'elles n'aient reçu une supervision ou des instructions concernant.
- L'utilisation de l'appareil par une personne responsable de leur sécurité.
- Les enfants doivent être surveillés pour s'assurer qu'ils ne jouent pas avec l'appareil.
- L'appareil peut devenir chaud pendant la charge. C'est normal. Soyez prudent lors de la manipulation.
- Utilisez l'appareil correctement pour éviter les chocs électrostatiques. Le produit n'est utilisé que pour la centrale électrique de secours. Il ne peut pas remplacer l'alimentation CC ou CA standard des appareils ménagers ou des produits numériques.
- Ne pas surcharger la batterie interne. Consultez le manuel d'utilisation.
- Cet appareil est destiné à être utilisé à l'intérieur uniquement. Ne pas l'utiliser à l'extérieur.
- Cet appareil n'est pas destiné à être utilisé dans un atelier de réparation commerciale.

Label Positions

