



平面印刷品基本技术要求			
科沃斯机器人股份有限公司			
物料名称	开普勒 S- 高配水箱版 - 美国 yeedi 说明书	尺 寸	145*210mm
型 号	ZJ2498	印刷颜色	单色 K
物料编码	451-2498-0630	装订方式	骑马钉
版 次	A	阶 段	A
材 质	封面 157 哑粉纸 + 内页 80g 双胶纸	页 数	60p
变更记录：			
		设计	批准
		PLD 2025.04.01 彭召艳	

YEEDI

S16 PLUS

Instruction Manual

Instruction Manual.....	EN		P03
Manuel d'instructions.....	FR-CA		P32
Manual de instrucciones.....	ES-LA		P62

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical Appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE SAVE THESE INSTRUCTIONS

1. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
2. Clear the area to be cleaned. Remove power cords and small objects from the floor that could entangle the Appliance. Tuck rug fringe under the rug base, and lift items such as curtains and tablecloths off the floor.
3. If there is a drop off in the cleaning area due to a step or stairs, you should operate the Appliance to ensure that it can detect the step without falling over the edge. It may become necessary to place a physical barrier at the edge to keep the unit from falling. Make sure the physical barrier is not a trip hazard.
4. Only use as described in this manual. Only use attachments recommended or sold by the

manufacturer.

5. Do not handle plug or appliance with wet hands.
6. Non-rechargeable batteries are prohibited.
7. Do not use without Dust Bin and/or Filters in place.
8. Do not operate the vacuum in an area where there are lit candles or fragile objects on the floor to be cleaned.
9. Do not use and store in extremely hot or cold environments (below -5°C /23°F or above 40°C/104°F). Please charge the robot in temperature above 0°C/32°F and below 40°C/104°F.
10. Keep hair, loose clothing, fingers, and all parts of body away from any openings and moving parts.
11. Do not operate the Appliance in a room where an infant or child is sleeping.
12. For INDOOR use ONLY. Do not use the Appliance in outdoor, commercial or industrial environments. Do not use Appliance on wet surfaces or surfaces with standing water.
13. Do not allow the Appliance to pick up large objects like stones, large pieces of paper, or any item that may clog the Appliance.
14. Do not use to pick up flammable or combustible materials such as gasoline, printer, or copier

- toner, or use in areas where they may be present.
15. Do not pick up anything that is burning or smoking, such as cigarettes, matches, hot ashes, or anything that could cause a fire.
 16. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
 17. Take care not to damage the power cord. Do not pull on or carry the Appliance or Docking Station by the power cord, use the power cord as a handle, close a door on the power cord, or pull power cord around sharp edges or corners. Do not run Appliance and Docking Station over the power cord. Keep power cord away from hot surfaces. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
 18. If the power cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a hazard.
 19. Do not use with a damaged power cord or plug. Do not use the Appliance or Docking Station if it is not working properly, has been dropped, damaged, left outdoors, or come in contact with water. It must be repaired by the manufacturer or its service agent in order to avoid a hazard.
 20. Turn OFF the power switch before cleaning or maintaining the Appliance. Turn off all controls before unplugging. Always turn off this appliance before connecting or disconnecting motorized nozzle.
 21. Turn OFF the Power Switch before removing the Dust Bin.
 22. Remove the Appliance from the Docking Station, and turn OFF the power switch to the Appliance before removing the battery for disposal of the Appliance.
 23. The battery must be removed and discarded according to local laws and regulations before disposal of the Appliance.
 24. Please dispose of used batteries according to local laws and regulations.
 25. Do not incinerate the Appliance even if it is severely damaged. The batteries can explode in a fire.
 26. When not using the Docking Station, unplug from outlet when not in use and before servicing.
 27. The Appliance must be used in accordance with the directions in this Instruction Manual. Ecovacs Home Service Robotics cannot be held liable or responsible for any damages or injuries caused by improper use.
 28. Prevent unintentional starting. Ensure the switch

- is in the off position before connecting to battery pack, picking up or carrying the appliance.
29. When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws, or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
 30. Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
 31. Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury.
 32. Do not expose a battery pack or appliance to fire or excessive temperature. Exposure to fire or temperature above 130°C may cause explosion. The temperature of 130°C can be replaced by the temperature of 265°F.
 33. Follow all charging instructions and do not charge the battery pack or appliance outside of the temperature range specified in the instructions.
- Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
34. Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
 35. Do not modify or attempt to repair the appliance or the battery pack (as applicable) except as indicated in the instructions for use and care.
 36. Place the cords from other appliances out of the area to be cleaned.
 37. Do not operate the vacuum in a room that has lit candles on furniture that the vacuum may accidentally hit or bump into.
 38. Do not allow children to sit on the vacuum.
 39. Use only as described in this manual. Use only manufacturer's recommended attachments.
 40. Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
 41. Use appliances only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
 42. The robot contains batteries that are only

- replaceable by skilled persons. To replace the robot's battery, please contact Customer Service.
43. If the robot will not be used for a long time, fully charge the robot and power OFF for storage and unplug the Docking Station.
 44. To Reduce The Risk Of Electric Shock – Do not use on wet surfaces. Do not expose to rain. Store indoors.
 45. To Reduce The Risk Of Injury From Moving Parts – Unplug Before Servicing.
 46. Risk Of Injury. Brush May Start Unexpectedly. Unplug Before Cleaning or Servicing.
 47. To reduce the risk of injury, user must read the Instruction Manual.
 48. To Reduce The Risk Of Electric Shock – Do not use outdoors or on wet surfaces.
 49. Please make sure your power supply voltage matches the power voltage marked on the Docking Station.
 50. Do not use the Docking Station if it is damaged.
 51. The plug must be removed from the receptacle before cleaning or maintaining the Docking Station.
 52. Power Switch: "I"=ON, "O"=OFF.
 53. Connect to a properly grounded outlet only. See Grounding Instructions.

==	Direct current
~	Alternating current

This Device Complies with DHHS Radiation Rules, 21CFR Chapter 1, Subchapter J.

Federal Communications Commission (FCC) Interference Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

MPE caution (for mobile device under Part 15.247device)

To satisfy FCC & IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

To disable the Wi-Fi module on the robot, follow these steps: power on the robot, then place it on the OMNI Station, ensuring that the Charging Contacts on the robot and the Station are properly connected, and press and hold the  for 30 s until you hear beeps.

To enable the Wi-Fi module on robot, please restart the robot. Additionally, unplug and plug in the Station.


SAVE THESE INSTRUCTIONS

GROUNDING INSTRUCTIONS

This appliance must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be inserted into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING – Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance – if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This appliance is for use on a nominal 120 V circuit and has a grounding attachment plug that looks like the plug illustrated as the following photo. Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adaptor should be used with this appliance.



For INDOOR household use ONLY.

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

To satisfy FCC&IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.


Device Update

Typically, some devices are updated bi-monthly, but not always so specific.


Some devices, especially those that went on sale more than three years ago, will only be updated if a critical vulnerability is found and fixed.

PACKAGE CONTENTS


1 PACKAGE CONTENTS




Robot




OMNI Station



Base



Power Cord



Instruction Manual

Note:

*Figures and illustrations are for reference only and may differ from actual product appearance. Product design and specifications are subject to changes without notice.

2 Product Diagram

1. Robot Front View


Button on the robot

Short Press: Start/Pause

Long Press for 3s: Return to charge

Double tap: Roller Mop Release/Retract

(Robot not in the station)



2. Robot Bottom View

Anti-drop Sensors


Side Brush

Carpet Detection Sensor

Brush Release Button

Drip Tray

Replaceable Roller Mop




3. Internal View (Under the Cover)


RESET Button

Network Setup: Press the RESET Button and follow the voice prompt to set up the network.


Restore to default settings: Long press the RESET Button for 5 seconds. After you hear the voice prompt, the startup music will be played and the robot will be restored to default settings.



4. Dust Bin




5. OMNI Station Front View




Note:

- If the Indicator flashes red, go to the YEEDI App for details about the malfunction.
- If the robot cannot charge, wipe the corresponding charging contacts on the OMNI Station with a dry cloth.

6. Dust Bag



7. OMNI Station Back View



8. Sensors

Product Diagram	Functional Description
Navigation Module	Laser Ranging is applied to measure the distance between the robot and surrounding objects based on the time difference of reflection, allowing the module to map against the objects around while the robot is moving. The detection range is 10 m.
Obstacle Avoidance Module	With Infrared Ranging-detection and the concept of similar triangles, the sensor emits infrared rays and receives the light from the objects ahead to calculate the distance between the object and the robot. When the sensor detects an object nearby, the robot will automatically take a turn to avoid bumping into the object. The detection range is 0.3 m.
Anti-drop Sensors	Infrared Ranging is applied by the sensor at the bottom of the robot to measure the height between the bottom of the robot and the ground. When at the top of the stairs, for example, with a height above 55mm on white-colored ground or a height above 30mm on black-colored ground, the robot will stop advancing, fulfilling the feature of Anti-drop.
Carpet Detection Sensor	The ultrasound probe can emit ultrasonic waves with a frequency of 300KHZ. The energy of the ultrasonic waves can be absorbed by carpets. If the reflected energy is below the threshold, the robot will recognize the presence of a carpet. According to lab tests, currently, over 50 types of carpets available on the market can be identified.
Anti-collision Sensor	When the transmitted signal is blocked by an object, the signal receiver will not be able to receive it. With this principle, the robot will avoid obstacles when encountering them.
Edge Sensor	With ToF distance measurement, the robot can detect the distance between itself and objects on its right side. When there is a wall or obstacle on the right side, the robot will perform edge cleaning to avoid missing spots or collisions.
AIVI Camera	Use AI cameras to collect images of the surrounding environment. *Realize video recording. Through interaction with MIC, remote video call can be realized(For some models).


NOTES BEFORE CLEANING

1 Warnings




Prepare the Area

Tidy up the area to be cleaned by putting furniture, such as chairs, in their proper place. Put away low-lying items, such as weight scales, before using the robot.



Set up Protective Barriers

It may be necessary to place a physical barrier at the edge of a steep drop to stop the robot from falling over the edge.



Keep Doors Open

During the first use, make sure each room door is open to help the robot fully explore your house.



Put away objects including cables, cloths and slippers, etc. on the floor to improve the cleaning efficiency.



Before using the product on a rug or carpet with tasseled edges, please fold the rug and tuck the tassels under the rug.



Please do not stand in tight spaces such as doorways and hallways, and make sure not to block the robot's path when it's identifying areas.



Ensure the clarity of the robot's vision and avoid scratching or smudging the AI camera lens with fingerprints or oily stains. Use a clean, soft cloth to wipe the camera, instead of cleaning agents, detergents, or sprays.



Provide Sufficient Lighting


The robot can avoid shoes, sockets and cords etc., and make sure all areas to be cleaned are well illuminated, which can improve obstacle avoidance.

2 Quick Start

Before using, please remove all protective materials from the robot and OMNI Station.


1. Installation

The sound of "click" indicates proper installation.



2. Power Cord Connection and Station Placement

Place the station against a wall on a level, hard ground. Ensure there are no objects within 0.05 m on either side and 0.8 m in front of it.




Note:

- If there are reflective objects such as mirrors and skirting lines near the OMNI Station, the bottom 14 cm of them should be covered.
- Do not place the OMNI Station under direct sunlight.
- Place the station in a location with a strong Wi-Fi signal.

3 Power ON and Charge the Robot

Turn on the power switch under the robot's cover ('I' indicates power on, and 'O' indicates power off). Place the robot in front of the station, ensuring the station is connected to a power supply. Use the YEEDEI App to recall the robot to start charging at the OMNI station, or long press the robot button  for 3 seconds, and it will return to the station to charge.




Note:

- The robot can't be charged when the power is turned off.
- After the robot finishes its cleaning task, it is recommended not to power it off but to keep it charging, to better prepare for the next cleaning session.
- It is recommended that the robot start cleaning from the OMNI Station. Do not move the OMNI Station while cleaning.

4 Download the YEEDI App

Download the YEEDI App to enjoy more features.

You may scan the QR Code on the robot to download the App.



Or search for the YEEDI in your mobile App store to download the App.



Note: Follow the guide of the App to register, log in, and connect the product with the App.

5 Connect Robot with App

Via Bluetooth: Turn on the robot and mobile phone Bluetooth. Allow the App to obtain mobile phone Bluetooth permission. Tap to scan the QR Code on the robot or tap  or **Add** in the App to find the nearby robot.

Via Wi-Fi: You can also choose to connect the robot with the App through other methods according to the prompts on the App's page.

Note: Please connect via Bluetooth for a better experience.

Wi-Fi Network Requirements:

- You are using a 2.4GHz or 2.4/5 GHz mixed network.
- Your router supports 802.11b/g/n and IPv4 protocol.
- Do not use a VPN (Virtual Private Network) or Proxy Server.
- Do not use a hidden network.
- WPA and WPA2 using TKIP, PSK, AES/CCMP encryption.
- WEP EAP (Enterprise Authentication Protocol) is not supported.
- Use Wi-Fi channels 1-11 in North America and channels 1-13 outside North America (refer to local regulatory agency).
- If you are using a network extender/repeater, the network name (SSID) and password are the same as your primary network.
- Please enable the WPA2 on your router.

Wi-Fi Indicator Light

	White Flashing Slow	Disconnected to Wi-Fi
	White Flashing Fast	Connecting
	Solid White	Connected to Wi-Fi

Please note that to access smart features such as remote startup, 2D/3D map display and control settings, and personalized cleaning (features may vary depending on the product), you'll need to download and use the YEEDI App, which receives constant updates. You must agree to our Privacy Policy and User Agreement before we can process some of your basic and necessary information and enable you to operate the product via the YEEDI App. Without your agreement, some of the aforementioned smart features cannot be accessed through the YEEDI App. Nevertheless, you can still use the product's basic functions for manual operation.


Network Interface Information

Name	Description
Charging Interface	The infrared interface is turned off by default, and it is activated when the robot is in the station. Provides power to the station, and the main unit can connect with the charging contacts on the station for charging.
Bluetooth	Enable Bluetooth to connect the robot to the network during the network setup process.
Wi-Fi*	Facilitate data transfer between the app and the robot, enabling control of the robot through the app.
YEEDI App	YEEDI products offer smart functions such as network setup, mapping, and cleaning mode selection (specific to each product). To utilize these features, users need to download and use the official YEEDI App.


* The robot series robotic vacuums are designed for domestic cleaning scenarios. A home Wi-Fi network is required for operation, and anti-DDOS protection needs to be configured by users through route settings.

6 Add Cleaning Solution (sold separately)

1. Take off the dust container cover, pull out the cleaning solution unit, and place it on a level, hard surface.




2. Unlid the cleaning solution unit and fill it with YEEDI cleaning solution. Put the lid on and the unit back to the station.



Note: Cleaning solution is pumped automatically from the cleaning solution unit. Do not add cleaning solution to the water tanks.

3. Insert the top latch of the dust container cover into the slot, and then press downward to ensure a proper seal.



Note:

- Please use YEEDI cleaning solution in case of malfunction.
- Please make sure that no foreign objects fall into the cleaning solution unit.

7 Start Cleaning

1. Start Mapping

Start mapping via YEEDI App.

When creating a map for the first time, please follow the robot to help eliminate some minor issues. For example, the robot may get stuck under the furniture. Please refer to the following solutions:

1. Raise the low sitting furniture if possible;

2. Cover the bottom of the furniture;

3. Set up Virtual Boundary via the App.

When mapping, the robot will explore the house environment automatically. The exploration path may be different from cleaning path.

2. Start Cleaning

- The robot's Water Tank is automatically refilled through the OMNI Station. Manual refilling is not needed.
- When mopping, the robot will recognize floor types and is able to lift mops automatically when encountering carpets. Please do not use the robot on shaggy rugs or carpets with fibres longer than 10 mm. It is recommended to fold up the shaggy rugs with fibres longer than 10 mm during the cleaning process, or go to Map > Carpet Cleaning Strategy in the YEEDI App to set the shaggy carpeted area as a No-Entry Zone.


Before cleaning for the first time, please make sure the robot is in the OMNI Station and fully charged. Tap  button on the robot to start cleaning. You can also use the YEEDI App to start cleaning.

3. Pause

Tap  on the robot to pause while it is working. You can also use the YEEDI App to pause the robot.


4. Wake up

After pausing for a while, all indicator lights on the robot will go out. To wake up the robot, short press .




5. Return to OMNI Station

Use the YEEDI App or long press the robot button  for 3 seconds to recall the robot back to the Station for charging.



6. Deep Sleep Mode

The robot will enter deep sleep mode to protect the battery if it stays outside the OMNI Station for about 10h. Please switch OFF and ON to wake up the robot.



Regular Maintenance

① Maintenance Frequency


To ensure optimal performance, maintain and replace parts at the following frequencies:

Part	Maintenance Frequency	Replacement Frequency
Replaceable Roller Mop	Every week	Every 1-2 months
Drip Tray	Every week	/
Dirty Water Box	Every week	/
Dust Bag	/	Every 2-3 months
Side Brush	/	Every 3-6 months
Main Brush	Every week	Every 6-12 months
Filter	Every week	Every 3-6 months
Edge Sensor Universal Wheel Anti-drop Sensors Bumper Charging Contacts on Robot Charging Contacts on OMNI Station Navigation Module Obstacle Avoidance Module AIVI Camera	Approx. every month	/
Clean Water Tank	Every 3 months	/
Dirty Water Tank	Every month	/
Dust Container Inside	Every month	/
Body and Bottom of Station	Every month	/
Mop Washing Tray	Every 5 months	/


Note: Explore more accessories at YEEDI App or at <https://www.yeedi.com>.

② Dust Bin


1. Remove the dust bin and then open its cover to empty the bin.



2. Open the dust bin cover to remove the filter and filter net.




3. You can rinse the components. Afterwards, give them a good shake to remove leftover water droplets.



Note:

- Please rinse the filter with water.
- Do not use fingers or brushes to clean the filter.

4. Air-dry the dust bin and filter.




Note: Completely dry the filter before use.


③ Maintain Main Brush and Side Brush

Clean the Main Brush.


1. Remove the cover on the main brush.




2. Remove and clean the main brush.



3. Remove, clean and dry the brush comb.




4. Install the brush comb, main brush and the cover.



Clean the Side Brush.

Remove the side brush using a screwdriver and clean it.




Note: Explore more accessories in the YEEDI App or at <https://www.yeedi.com>.

4 Roller Mop, Drip Tray and Dirty Water Box


Clean the Roller Mop.

1. Double tap  button to release roller mop component.




Note: Please avoid excessive force when handling the roller; it should be removed and placed with care.


2. Press the unlock button to remove the roller.



3. Clean the roller mop.




4. Clean inside the roller.




Note: Do not use water to clean the main body.

5. Push roller mop into roller end cover and double tap  button to retract.




Clean Drip Tray

1. Remove drip tray.




Note: A small amount of residual water may leak out when flipping the robot if it's not in drying mode.

2. Remove and clean drip tray components.




3. Please install drip tray filter components as shown in the illustration.




Clean Dirty Water Box


1. Remove dirty water box and the filter.



2. Clean the filter, box and sewage outlet.




3. Reinstall the filter, press securely and then reattach the dirty water box cover.




5 Other Components

Clean the Obstacle Avoidance Module Lens




Clean the Bumper




Note: Use a dry cloth when cleaning the Anti-drop sensors and bumper to prevent water damage.

Clean Navigation Module




Note: Rotate the Module lens to the front and clean it gently with a brush when cleaning .

Clean Charging Contacts




Note: Wipe the contacts with a dry cloth. Avoid using wet cloth to prevent water damage.


Clean the Edge Sensor




Clean the Anti-drop Sensors



Clean the Universal Wheel




Clean the Driving Wheels




Note: Use dry cloth when cleaning the charging contacts to prevent water damage.

6 Mop Washing Tray and Station Base

1. Remove and clean mop washing tray and station base.




2. Install the tray and base.




Note: Please install the tray and base properly to prevent malfunction.

7 Dust bag

1. Remove dust container cover.




2. Remove the disposable dust bag in the direction of the arrow and discard it.




Note: Hold the Handle to lift out the dust bag, which can effectively prevent dust leakage.

3. Clean the dust container with a dry cloth, install a new dust bin, and confirm proper installation with a secure click sound.




4. Return dust bag and press the cover firmly to secure it in position.



8 Storage

Please fully charge and switch OFF the robot before storage. Please recharge it every 1.5 months to prevent the battery from over-discharging.



! Please note that the robot cannot charge when powered OFF.

Note:

- After the robot finishes its cleaning task, it is recommended not to power it off but to keep it charging, to better prepare for the next cleaning session.
- If the battery is over-discharged or not used for a long time, the robot may not be charged. Please contact YEEDI for help. Do not disassemble battery by yourself.
- If you do not use the product for a long time, keep the dirty water box, water tanks empty and the mop dry.

TROUBLESHOOTING

For the following possible issue, refer to the corresponding solutions.

No.	Malfunction	Possible Cause	Solution
1	The robot is not able to connect to the YEEDI App.	Incorrect Wi-Fi username or password entered.	Enter the correct Wi-Fi username and password.
		The robot is not within range of your home Wi-Fi signal.	Make sure the robot is within range of your home Wi-Fi signal. Try to stay as close to the router as possible.
		The robot is not in the configuration state.	Press the Reset Button to connect the robot to your phone by Bluetooth. If failed, please press the Reset Button +  , and to connect via the YEEDI App.
		There is no home Wi-Fi on the Wi-Fi list.	Check if the Wi-Fi name contains special characters. Please do not use special characters like ! @#& ¥%/\.
		Incorrect App installed.	Do not use a 5 Ghz network. Please download and install the YEEDI App.
2	Unable to create the furniture map in the App.	Move the robot when cleaning might cause the map to be lost.	During cleaning, do not move the robot.
		Auto cleaning is not finished.	Make sure the robot automatically return to the OMNI Station after cleaning.
3	The side brush drops out of place during use.	The side brush is not properly installed.	When installing the side brush with a screwdriver, ensure the screws are tightened.
4	No signal found. Unable to return to the station.	The station is incorrectly placed.	Please place the station correctly according to the instructions in the [Quick Start] section.
		The station is out of power or moved.	Check whether the OMNI Station is connected to the power supply. Do not move the OMNI Station.
		The robot does not start cleaning from the OMNI Station.	It is recommended that the robot starts cleaning from the OMNI Station.
		The docking route is blocked. For example, the door is closed to the room where the station is placed.	Keep the charging route clear.

No.	Malfunction	Possible Cause	Solution
5	The robot returns to the station before it has finished cleaning.	The room is so large that the robot needs to return to recharge.	Please enable auto resume. For more details, please follow the App instructions.
		In highly complex home layouts, cleaning efficiency may decrease, possibly resulting in incomplete cleaning.	Simplify your home layout.
6	The robot is unable to charge.	The robot is not switched ON.	Switch ON the robot.
		The robot's charging contacts are not connected to the OMNI Station's charging contacts.	Make sure that the robot's charging contacts have connected to the station's charging contacts and 🔌 flashes. Check whether the robot's and OMNI Station's charging contacts are dirty. Please clean these parts according to the instructions in the [Regular Maintenance] section.
		The OMNI Station is not connected to the power supply.	Make sure the OMNI Station is connected to power supply.
		Base has not been installed in place.	Refer to the [Quick Start] section for correct installation.
7	The robot is very loud during cleaning.	The main brush/side brush is tangled, or the dust bin/filter is blocked.	It is recommended to clean the main brush, side brush, dust bin, filter, etc. regularly.
		The robot is in strong mode.	Switch to standard mode.
8	The robot gets stuck while working and stops.	The robot is tangled with objects on the floor (electrical wires, curtains, carpet fringing, etc.).	The robot will try various ways to free itself. If its attempts fail, manually remove the obstacles and restart.
		The robot might be stuck under furniture with an entrance of similar height.	Please raise the furniture, set a physical barrier, or set a virtual boundary via the YEEDI App.
		The robot is stuck in a narrow area.	Tidy up your home, set a physical barrier, or set a virtual boundary via the YEEDI App.

No.	Malfunction	Possible Cause	Solution
9	During cleaning, the robot may encounter issues like a disorderly route, biased movement, repeated cleaning over the same spots, and missing small areas. (If there is a large area that has not been cleaned temporarily, the robot will automatically clean the missed area. Sometimes the robot will re-enter a cleaned room, which may not be repeated cleaning, but the robot finds any missed area.)	Objects such as wires and slippers placed on the ground block the robot.	Before cleaning, please tidy up scattered wires, slippers, and other objects on the ground as possibly can. If there is any area missed during cleaning, the robot will correct it automatically. Please refrain from interfering (such as moving the robot or blocking its route).
		The driving wheels may slip on the ground when the robot climbs steps, thresholds, and door bars, which can affect its judgement of the entire home environment.	It is recommended to close the door of the affected area and clean it separately. After cleaning, the robot will return to its starting location.
		On freshly waxed or polished floors, as well as smooth tiles, there may be less friction between the driving wheels and the floor.	Please wait for the wax to dry before cleaning.
		Due to variations in home layouts, some areas cannot be entered by the robot.	Tidy up your home to ensure that the robot can enter the areas to be cleaned.
10	Delay in remote control.	The Wi-Fi signal is poor, causing the video loading to be slow.	Use the robot in areas with good Wi-Fi signal.
11	After returning to the OMNI station, the robot does not empty its dust bin.	The auto-empty function has not been turned on in the YEEDI App.	Turn on the auto-empty function in the YEEDI App.
		Manually moving the robot back to the station may not trigger the auto-empty function.	It is recommended to allow The robot return to the OMNI Station on its own. Please do not manually move it.
		In do not disturb mode, the robot will not empty the dust after returning back to the OMNI Station.	Turn off do not disturb in the YEEDI App or manually start dust-emptying.
		The station detects a decrease in empty efficiency.	Replace the dust bag according to the [Regular Maintenance] section and close the dust collection cabin. If the dust bag is not full when prompted by the App, you can put it back again.
		If the above possible causes have been ruled out, components of the station may be abnormal.	Please contact customer service for assistance.

No.	Malfunction	Possible Cause	Solution
12	Auto-empty unsuccessful.	The station detects a decrease in empty efficiency.	Replace the dust bag according to the [Regular Maintenance] section and close the dust collection cabin. If the dust bag is not full when prompted by the App, you can put it back again.
		The outlet of the dust bin is blocked by foreign objects.	Remove the dust bin and clear the foreign objects on the outlet.
13	The inner side of the dust collection cabin is dirty.	Fine particles pass through the dust bag and accumulate on the inner side of the dust collection cabin.	Clean the inner side of the dust collection cabin.
		The dust bag is broken.	Check and replace the dust bag.
		The dust bag is not properly installed.	Please install the dust bag properly.
		The dust container cover is not closed.	Please check if the dust container cover is closed properly.
14	Dust leakage occurs while the robot is working	The outlet of the dust bin is blocked by foreign objects.	Remove the dust bin and clear the foreign objects on the outlet.
15	Roller mop will not rotate.	Roller mop is not correctly installed.	Install the roller mop properly according to the 【REGULAR MAINTENANCE】 section.
		Roller mop is blocked by foreign objects.	Clean and install roller mop properly according to the 【REGULAR MAINTENANCE】 section.
16	The driving wheel is stuck.	wheel is entangled or stuck due to foreign objects.	Rotate and press the driving wheel to check for any wrapping or obstruction by foreign objects. If any foreign objects are found, please clean them promptly. If this issue persists, please contact customer service for assistance.

No.	Malfunction	Possible Cause	Solution
17	The mop washing tray is full of water and can't be emptied. A voice prompt reports mop washing tray malfunction.	The dirty water tank is not properly installed.	Tap down on the dirty water tank to ensure it is properly installed.
		The sealing plugs in the dirty water tank are not installed properly.	Make sure that the two sealing plugs are properly installed.
		Mop washing tray is not properly installed.	Please check and make sure that the mop washing tray is properly installed.
		Mop washing tray base gets dirty.	Ensure that there is no foreign object in the suction port of the mop washing tray.
		Check if the floating ball gets stuck when there is no water in the mop washing tray base.	Take out the mop washing tray to put the floating ball back in place.
		The OMNI Station cannot drain water normally.	Put the robot into the station and double tap  , if the issue persists, please contact our customer service for help.
		The suction port of the mop washing tray is blocked by foreign objects.	Ensure that there is no foreign object in the suction port of the mop washing tray.
		The voice alert persists after all the above solutions are tried.	Power off and on the station. If this issue persists, please contact customer service for assistance.
18	Dirty water box malfunction.	The drainage outlet of dirty water box gets blocked and the draining pole can't work normally.	Remove and empty the dirty water box, and then rinse it and reinstall. If this issue persists, please contact customer service for assistance.

Please contact our customer service for assistance if the problem persists despite the recommended solutions.


TECHNICAL SPECIFICATIONS

Model	DEX61-Y		
Rated Input	20 V === 2 A	Charging Time	about 4.0 h
Station Model	CH2497D		
Rated Input	110-120 V ~ 50-60 Hz	Rated Output	20 V === 2 A
Rated Input Current (Charging)	1 A	Power (Emptying)	4.5 A
Power (Hot Water Washing Mop)	12 A		
Robot Dimensions (L*W*H mm)	353*351.5*98mm/13.90"*13.84"*3.86"		
Station Dimensions (L*W*H mm)	338*459*500mm/13.31"*18.07"*19.69" (with base) 338*276*500mm/13.31"*10.87"*19.69" (without base)		

Output power of the wireless module is less than 100 mW.

Note: Technical and design specifications may be changed for continuous product improvement.

Explore more accessories at <https://www.yeedi.com>.



Please use the mobile camera to scan the QR code and obtain the user guide.

INSTRUCTIONS IMPORTANTES DE SÉCURITÉ

INSTRUCTIONS IMPORTANTES DE SÉCURITÉ

LIRE TOUTES LES INSTRUCTIONS AVANT D'UTILISER L'APPAREIL.

Lors de l'utilisation d'un appareil électrique, les précautions de base suivantes doivent toujours être suivies :

AVERTISSEMENT : Lisez tous les avertissements et toutes les instructions de sécurité. Le non-respect des avertissements et des instructions peut entraîner une décharge électrique, un incendie ou des blessures graves.

1. L'appareil ne doit pas être utilisé comme un jouet. Une attention particulière est nécessaire lorsqu'il est utilisé par des enfants ou près d'eux.
2. Rangez la zone à nettoyer. Retirez les cordons d'alimentation et les petits objets sur le plancher qui pourraient s'enchevêtrer dans l'appareil. Glissez les franges sous le tapis et relevez les bouts des rideaux et des nappes pour dégager le plancher.
3. En cas de présence d'un point de chute dans la zone de nettoyage à cause d'une marche ou d'un escalier, vous devriez faire fonctionner l'appareil

de manière à vous assurer qu'il peut détecter la marche sans tomber. Il pourrait être nécessaire de placer une barrière physique au bord du point de chute pour empêcher l'appareil de tomber. Assurez-vous que la barrière ne présente pas un risque de trébuchement.

4. Utilisez l'appareil seulement de la manière décrite dans ce manuel. Utilisez seulement les accessoires recommandés ou vendus par le fabricant.
5. Ne manipulez pas la fiche électrique ou l'appareil avec des mains mouillées.
6. Les batteries non rechargeables sont interdites.
7. N'utilisez pas l'appareil si le bac à poussière ou les filtres ne sont pas en place.
8. N'utilisez pas l'aspirateur dans un endroit où il y a des chandelles allumées ou des objets fragiles sur le plancher à nettoyer.
9. N'utilisez pas et ne rangez pas l'appareil dans un environnement extrêmement chaud ou froid (température inférieure à -5 °C/23 °F ou supérieure à 40 °C/104 °F). Veuillez charger le robot à une température supérieure à 0 °C/32 °F et inférieure à 40 °C/104 °F.
10. Gardez les vêtements amples, les cheveux, les doigts et toutes les autres parties du corps à l'écart de toute ouverture et de toute pièce mobile.
11. N'utilisez pas l'appareil dans une pièce où dort un nourrisson ou un enfant.
12. Pour utilisation À L'INTÉRIEUR SEULEMENT. N'utilisez pas l'appareil à l'extérieur ou à des

fins commerciales ou industrielles. N'utilisez pas l'appareil sur des surfaces mouillées ou contenant de l'eau stagnante.

13. Ne laissez pas l'appareil ramasser de gros objets, comme des pierres, de grandes feuilles de papier ou tout autre objet pouvant le boucher.
14. N'utilisez pas l'appareil pour ramasser des produits inflammables ou combustibles comme de l'essence, ou de l'encre pour imprimante ou photocopieur, et ne l'utilisez pas dans des endroits où ces produits peuvent être présents.
15. N'utilisez pas l'appareil pour ramasser des objets qui brûlent ou qui émettent de la fumée, comme des cigarettes, des allumettes, des cendres chaudes, ou tout autre objet pouvant causer un incendie.
16. Ne placez pas d'objets dans les ouvertures. N'utilisez pas l'appareil si une ouverture est bouchée; gardez-le exempt de poussière, de peluches, de cheveux et de tout ce qui peut réduire l'écoulement d'air.
17. Veillez à ne pas endommager le cordon d'alimentation. Ne tirez pas et ne transportez pas l'appareil ou la station d'accueil par le cordon d'alimentation, n'utilisez pas le cordon d'alimentation comme une poignée, ne refermez pas une porte sur le cordon d'alimentation et ne tirez pas le cordon d'alimentation autour de rebords ou de coins coupants. Ne faites pas passer l'appareil ni la station d'accueil sur le cordon d'alimentation. Gardez le cordon

d'alimentation à l'écart de toute surface chaude. Ne débranchez pas l'appareil en tirant sur le cordon. Pour débrancher l'appareil, saisissez la fiche électrique, et non le cordon.

18. Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant ou par son agent du service à la clientèle pour éviter tout danger.
19. N'utilisez pas un appareil avec une fiche électrique endommagée ou un cordon d'alimentation endommagé. N'utilisez pas l'appareil ou la station d'accueil s'ils ne fonctionnent pas correctement, s'ils ont été échappés, endommagés, laissés à l'extérieur, ou s'ils sont entrés en contact avec un liquide. Si une réparation est nécessaire, elle doit être effectuée par le fabricant ou par son agent du service à la clientèle pour éviter tout danger.
20. Avant de nettoyer l'appareil ou d'en faire l'entretien, mettez-le HORS TENSION en utilisant l'interrupteur d'alimentation. Fermez toutes les commandes avant de le débrancher. Éteignez toujours l'appareil avant de brancher ou de débrancher la buse motorisée.
21. Éteignez l'interrupteur d'alimentation avant de retirer le bac à poussière.
22. Retirez l'appareil de la station d'accueil et mettez l'appareil HORS TENSION en utilisant son interrupteur d'alimentation avant de retirer la batterie pour la mise au rebut de l'appareil.
23. La batterie doit être retirée et mise au rebut conformément aux lois et aux réglementations locales avant la mise au rebut de l'appareil.

24. Veuillez mettre les batteries usagées au rebut conformément aux lois et aux réglementations locales.
25. N'incinerez pas l'appareil, même s'il est gravement endommagé. Les batteries peuvent exploser si elles sont exposées au feu.
26. Lorsque vous n'utilisez pas la station d'accueil et avant d'en faire l'entretien, débranchez-la de la prise.
27. L'appareil doit être utilisé conformément aux instructions du présent manuel d'instructions. **Ecovacs Home Service Robotics** ne saurait être tenue responsable des blessures ou dommages causés par une utilisation incorrecte.
28. Prévenez tout démarrage accidentel. Assurez-vous que l'interrupteur est à la position de mise hors tension avant de connecter l'appareil au bloc-batterie, de le ramasser ou de le transporter.
29. Lorsque le bloc-batterie n'est pas utilisé, gardez-le à l'écart d'autres objets métalliques comme des trombones, des pièces de monnaie, des clés, des vis, des clous ou d'autres petits objets métalliques qui peuvent établir une connexion d'une borne à l'autre. Un court-circuit des bornes de la batterie peut causer des brûlures ou un incendie.
30. Dans des conditions abusives, du liquide peut être éjecté de la batterie; évitez tout contact avec ce liquide. En cas de contact accidentel, rincez immédiatement les parties atteintes avec de l'eau. Si du liquide entre en contact avec les yeux, consultez également un professionnel de la santé. Le liquide éjecté de la batterie peut causer des irritations ou des brûlures.
31. N'utilisez pas un bloc-batterie ou un appareil qui est endommagé ou modifié. Les batteries endommagées ou modifiées peuvent avoir un comportement imprévisible susceptible de causer un incendie, une explosion ou des blessures.
32. N'exposez pas un bloc-batterie ou un appareil au feu ou à une température excessive. Une exposition au feu ou à une température supérieure à 130 °C peut causer une explosion. La température de 130 °C est équivalente à 265 °F.
33. Suivez toutes les instructions de recharge et ne rechargez pas le bloc-batterie ou l'appareil si la température est en dehors de la plage spécifiée dans les instructions. Une recharge incorrecte ou à une température en dehors de la plage spécifiée peut endommager la batterie et augmenter le risque d'incendie.
34. Faites effectuer l'entretien par un réparateur qualifié, uniquement avec des pièces de rechange identiques. Vous vous assurerez ainsi de maintenir la sécurité du produit.
35. Ne modifiez pas ou n'essayez pas de réparer l'appareil ou le bloc-batterie (le cas échéant), sauf de la manière indiquée dans les instructions d'utilisation et d'entretien.
36. Enlevez les cordons des autres appareils dans la zone à nettoyer.
37. N'utilisez pas l'aspirateur dans une pièce où il y a des chandelles allumées sur des meubles que l'aspirateur pourrait accidentellement heurter.

38. Ne laissez pas les enfants s'asseoir sur l'aspirateur.
39. Utilisez l'appareil seulement de la manière décrite dans ce manuel. Utilisez seulement les accessoires recommandés par le fabricant.
40. Ne rechargez l'appareil qu'avec le chargeur spécifié par le fabricant. Un chargeur qui est adapté pour un type de bloc-batterie peut créer un risque d'incendie s'il est utilisé avec un autre bloc-batterie.
41. Utilisez les appareils uniquement avec les blocs-batteries désignés à cette fin. L'utilisation de tout autre bloc-batterie peut créer un risque de blessure et d'incendie.
42. Le robot contient des batteries qui ne doivent être remplacées que par des personnes qualifiées. Pour faire remplacer la batterie du robot, veuillez communiquer avec le service à la clientèle.
43. Si le robot ne sera pas utilisé pendant une période prolongée, rechargez-le complètement, mettez-le HORS TENSION pour l'entreposer et débranchez la station d'accueil.
44. Pour réduire le risque de décharge électrique, n'utilisez pas cet appareil sur des surfaces mouillées. Ne l'exposez pas à la pluie. Entreposez-le à l'intérieur.
45. Pour réduire le risque de blessure lié aux pièces mobiles, débranchez l'appareil avant tout entretien.
46. Risque de blessure. La brosse peut démarrer de manière inattendue. Débranchez l'appareil avant de procéder à son nettoyage ou à son entretien.
47. Pour réduire le risque de blessure, l'utilisateur doit lire le manuel d'instructions.
48. Pour réduire le risque de décharge électrique, n'utilisez pas cet appareil à l'extérieur ou sur des surfaces mouillées.
49. Veuillez vous assurer que la tension d'alimentation de la prise correspond à la tension d'alimentation indiquée sur la station d'accueil.
50. N'utilisez pas la station d'accueil si elle est endommagée.
51. Retirez la fiche électrique de la prise avant d'effectuer le nettoyage ou l'entretien de la station d'accueil.
52. Interrupteur d'alimentation « I » = mise sous tension, « O » = mise hors tension.
53. Branchez l'appareil uniquement dans une prise correctement mise à la terre. Consultez les instructions de mise à la terre.

==	Courant continu
~	Courant alternatif

Cet appareil est conforme aux règlements sur les radiations du DHHS, 21CFR chapitre 1, sous-chapitre J.

Déclaration sur les interférences de la Federal Communications Commission (FCC)

REMARQUE : Cet équipement a été testé et jugé conforme aux limites pour appareils numériques de classe B, conformément à la section 15 des règlements de la FCC.

Ces limites sont destinées à assurer une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie radioélectrique et peut, en cas d'installation ou d'utilisation non conforme aux instructions, engendrer des interférences nuisibles aux communications radio.

Cependant, on ne peut pas garantir que des interférences ne se produiront pas dans certaines installations. Si cet appareil cause des interférences nuisibles à la réception des signaux de radio ou de télévision, qui peut être déterminé en allumant et en éteignant l'appareil, nous conseillons à l'utilisateur d'essayer de corriger ces interférences par un ou plusieurs des moyens suivants :

- Réorienter ou repositionner l'antenne de réception.
- Augmenter la distance séparant l'équipement du récepteur.
- Brancher l'appareil dans une prise d'un circuit différent de

celui du récepteur.

- Consulter le revendeur ou un technicien qualifié spécialisé en radio/télévision pour obtenir de l'aide.

Cet appareil est conforme à la section 15 des règlements de la FCC. L'utilisation est sous réserve des deux conditions suivantes :

(1) cet appareil ne doit pas engendrer des interférences nuisibles et (2), cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

Avertissement : Toutes les transformations ou modifications de cet appareil non expressément autorisées par la partie responsable de la conformité pourraient annuler le droit de l'utilisateur à utiliser l'équipement.

Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux normes RSS d'Innovation, Sciences et Développement économique Canada. L'utilisation est sous réserve des deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences pouvant provoquer un fonctionnement indésirable de l'appareil.

Avertissement relatif à l'exposition aux radiofréquences

Cet équipement est conforme aux limites d'exposition aux radiations définies par la FCC pour un environnement non contrôlé.

Cet équipement doit être installé et utilisé conformément

aux instructions fournies, et la ou les antennes utilisées pour cet émetteur doivent être installées de manière à fournir une distance de séparation d'au moins 20 cm de toute personne et ne doivent pas être colocalisées ni fonctionner en combinaison avec une autre antenne ou un autre émetteur.

Avertissement MPE (pour les appareils mobiles des sections 15.247)

Afin de satisfaire aux exigences de sécurité de la FCC et en matière d'exposition aux radiofréquences et aux circuits intégrés, une distance d'au moins 20 cm doit être maintenue entre cet appareil et toute personne durant l'utilisation de l'appareil.

Pour garantir la conformité, les opérations à une distance inférieure à cette distance ne sont pas recommandées.

Pour désactiver le module Wi-Fi sur le robot, suivez ces étapes : allumez le robot, puis placez-le sur la Station OMNI, en vous assurant que les contacts de charge sur le robot et la Station sont correctement connectés, puis appuyez et maintenez enfoncé le bouton  pendant 30 s jusqu'à ce que vous entendiez des bips.

Pour activer le module Wi-Fi sur robot, veuillez redémarrer le robot. En outre, débranchez et branchez le satellite.

CONSERVER CES INSTRUCTIONS


INSTRUCTIONS DE MISE À LA TERRE

Cet appareil doit être mis à la terre. En cas de mauvais fonctionnement ou de panne, la mise à la terre fournit un chemin de moindre résistance pour le courant électrique afin de réduire

le risque de décharge électrique. Cet appareil est équipé d'un cordon doté d'un conducteur de mise à la terre et d'une fiche de mise à la terre de l'équipement. La fiche doit être insérée dans une prise appropriée qui est correctement installée et mise à la terre conformément à toutes les ordonnances et à tous les codes locaux.

AVERTISSEMENT – Un branchement inapproprié du conducteur de mise à la terre de l'équipement peut entraîner un risque de décharge électrique. En cas de doute sur le caractère adéquat de la mise à la terre de la prise, consultez un électricien qualifié ou un technicien. Ne modifiez pas la fiche fournie avec l'appareil. Si elle ne convient pas à la prise, faites installer une prise appropriée par un électricien qualifié.

Cet appareil doit être utilisé sur un circuit d'une tension nominale de 120 V et est équipé d'une fiche de mise à la terre qui ressemble à la fiche illustrée sur la photo suivante. Assurez-vous que l'appareil est branché dans une prise ayant la même configuration que la fiche. Aucun adaptateur ne doit être utilisé avec cet appareil.



Pour utilisation résidentielle À L'INTÉRIEUR SEULEMENT. Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux normes RSS d'Innovation, Sciences et Développement économique Canada. L'utilisation est sous réserve des deux conditions suivantes :

(1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interférences pouvant provoquer un fonctionnement indésirable de l'appareil.

Afin de satisfaire aux exigences de sécurité de la FCC et en matière d'exposition aux radiofréquences et aux circuits intégrés, une distance d'au moins 20 cm doit être maintenue entre cet appareil et toute personne durant l'utilisation de l'appareil.

À des fins de conformité, l'utilisation à une distance moindre que celle-ci n'est pas recommandée.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Les antennes installées doivent être situées de façon à ce que la population ne puisse y être exposée à une distance de moins de 20 cm. Installer les antennes de façon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne.


Mise à jour de l'appareil

En général, certains appareils sont mis à jour deux fois par mois, mais ce n'est pas toujours le cas.


Certains appareils, surtout ceux qui ont été mis en vente il y a plus de trois ans, ne seront mis à jour que si une vulnérabilité critique est trouvée et corrigée.

CONTENU DU COLIS


① CONTENU DU COLIS




Robot




Station OMNI



Base



Cordon d'alimentation



Manuel d'utilisation

Remarque :

*Les chiffres et illustrations sont fournis à titre indicatif uniquement et peuvent différer de l'apparence réelle du produit. La conception et les spécifications du produit sont susceptibles d'être modifiées sans préavis.

② Diagramme de produit


1. Vue de face du robot

Bouton sur le robot

Appui bref : Démarrer/Pause

Pression longue pendant 3 s : retour à la charge

Appuyez deux fois : Libération/rétraction de la vadrouille à rouleau
(Le robot n'est pas dans la station)



2. Vue de dessous du robot

Capteurs anti-chute


Brosse latérale

Capteur de détection de tapis

Bouton de libération de la brosse

Bac d'égouttage


Vadrouille à rouleau remplaçable




3. Vue intérieure (sous le couvercle)

Bouton RÉINITIALISER


Configuration du réseau : Appuyez sur le bouton RÉINITIALISER et suivez l'invite vocale pour configurer le réseau. **Restaurer les paramètres par défaut :** Appuyez longuement sur le bouton RÉINITIALISER et maintenez-le enfoncé pendant 5 secondes. Après avoir entendu l'invite vocale, la musique de démarrage joue et le robot est réinitialisé aux paramètres par défaut.



4. Bac à poussière



5. Vue de face de la station OMNI




Remarque :


- Si le témoin lumineux clignote en rouge, consultez l'application YEEDI pour plus de détails sur le dysfonctionnement.
- Si le robot ne peut pas se charger, essayez les contacts de charge correspondants sur la station OMNI avec un chiffon sec.

6. Sac à poussière

Poignée du sac à poussière



7. Vue arrière de la station OMNI



8. Capteurs

Diagramme de produit	Description fonctionnelle
Module de navigation	La télémétrie laser est utilisée pour mesurer la distance entre le robot et les objets environnants en fonction de la différence de temps de réflexion, permettant au module de cartographier les objets environnants pendant que le robot se déplace. La portée de détection est de 10 m.
Module d'évitement d'obstacles	Grâce à la détection infrarouge et au concept de triangles semblables, le capteur émet des rayons infrarouges et capte la lumière des objets situés devant pour calculer la distance entre l'objet et le robot. Lorsque le capteur détecte un objet à proximité, le robot fait automatiquement demi-tour pour éviter de heurter l'objet. La portée de détection est de 0,3 m.
Capteurs anti-chute	La télémétrie infrarouge est appliquée par le capteur situé au bas du robot pour mesurer la hauteur entre le bas du robot et le sol. Lorsqu'il y a une différence de hauteur, par exemple une hauteur supérieure à 55 mm sur un sol de couleur blanche ou une hauteur supérieure à 30 mm sur un sol de couleur noire, le robot arrêtera d'avancer, remplissant ainsi la fonction Anti-chute.
Capteur de détection de tapis	La sonde à ultrasons peut émettre des ondes ultrasonores avec une fréquence de 300 kHz. L'énergie des ondes ultrasonores peut être absorbée par les tapis. Si l'énergie réfléchie est en deçà du seuil, le robot reconnaît la présence d'un tapis. Selon les tests du laboratoire, il est actuellement possible d'identifier plus de 50 types de tapis disponibles sur le marché.
Capteur anti-collision	Lorsque le signal transmis est bloqué par un objet, le récepteur du signal ne peut pas recevoir le signal. Avec ce principe, le robot évite les obstacles en cas de collision avec eux.
Bord Capteur	Grâce à la mesure de distance focale, le robot peut détecter la distance qui le sépare des objets situés sur son côté droit. Lorsqu'il y a un mur ou obstacle sur le côté droit, le robot effectue un nettoyage des bords pour éviter les zones manquées ou les collisions.
Caméra AI/VI	Utilisez des caméras IA pour collecter des images de l'environnement. *Réaliser un enregistrement vidéo. Grâce à l'interaction avec le MIC, un appel vidéo à distance peut être réalisé (pour certains modèles).


REMARQUES AVANT LE NETTOYAGE

1 Avertissements




Préparez la zone

Rangez la zone à nettoyer en plaçant les meubles, comme les chaises, à leur place. Rangez les objets bas, comme les balances, avant d'utiliser le robot.



Mettez en place des barrières de protection

Il peut être nécessaire de placer une barrière physique sur un bord de marche pour empêcher le robot de tomber.



Gardez les portes ouvertes

Lors de la première utilisation, assurez-vous que la porte de chaque pièce est ouverte pour aider le robot à explorer complètement votre maison.



Rangez les objets comme les câbles, les chiffons, les pantoufles, etc. sur le sol pour améliorer l'efficacité du nettoyage.



Avant d'utiliser le produit sur un tapis ou une moquette avec des bords à pompons, veuillez plier le tapis et glisser les glands à franges sous le tapis.



Veuillez ne pas vous tenir dans des espaces restreints tels que des portes et des couloirs, et assurez-vous de ne pas bloquer le chemin du robot lorsqu'il identifie des zones.



Assurez la clarté de la vision du robot et évitez de rayer ou de salir l'objectif de la caméra IA avec des empreintes digitales ou des taches huileuses. Utilisez un chiffon propre et doux pour essuyer l'appareil photo, plutôt que des produits de nettoyage, des détergents ou des sprays.



Assurez un éclairage suffisant


Le robot peut éviter les chaussures, les prises, les cordons, etc., et s'assurer que toutes les zones à nettoyer sont bien éclairées, ce qui peut améliorer l'évitement des obstacles.

2 Démarrage rapide

Avant utilisation, veuillez retirer tous les matériaux de protection du robot et de la station OMNI.


1. Installation

Le son du clic indique une installation correcte.



2. Connexion du cordon d'alimentation et placement de la station

Placez la station contre un mur sur un sol plat et dur. Assurez-vous qu'il n'y a aucun objet à moins de 0,05 m de chaque côté et à 0,8 m devant.




Remarque :

- S'il y a des objets réfléchissants tels que des miroirs et des plinthes réfléchissantes à proximité de la station OMNI, les 14 cm inférieurs doivent être recouverts.
- Ne placez pas la station OMNI sous la lumière directe du soleil.
- Placez la station dans un endroit avec un signal Wi-Fi puissant.

3 Allumer et charger le robot

Allumez l'interrupteur d'alimentation sous le capot du robot (« I » indique la mise sous tension et « O » indique que l'alimentation est coupée). Placez le robot devant la Station, en vous assurant que la Station est connectée à une alimentation électrique. Utilisez l'application YEEDI pour rappeler le robot afin qu'il commence à se charger à la Station OMNI, ou appuyez longuement sur le bouton du robot  pendant 3 secondes, et il reviendra à la Station pour se recharger.




Remarque :

- Le robot ne peut pas être chargé lorsque l'alimentation est coupée.
- Une fois que le robot a terminé sa tâche de nettoyage, il est recommandé de ne pas l'éteindre, mais de le laisser en charge, afin de mieux préparer la prochaine session de nettoyage.
- Il est recommandé que le robot commence le nettoyage à partir de la station. Ne déplacez pas la station OMNI pendant le nettoyage.

4 Télécharger l'application YEEDI

Téléchargez l'application YEEDI pour profiter de plus de fonctionnalités.

Vous pouvez balayer le code QR sur le robot pour télécharger l'application.



Ou recherchez YEEDI dans votre boutique d'applications mobiles pour télécharger l'application.



Remarque : Suivez le guide de l'application pour vous inscrire, vous connecter et connecter le produit à l'application.

5 Connectez le robot avec l'application

Par Bluetooth : mettez en marche le robot et activez le Bluetooth du téléphone portable. Autorisez l'application à obtenir l'autorisation du Bluetooth du téléphone mobile. Appuyez pour balayer le code QR sur le robot ou appuyez sur  ou **Add** dans l'application pour trouver le robot à proximité.

Par Wi-Fi : vous pouvez également choisir de connecter le robot à l'application par d'autres méthodes selon les invites sur la page de l'application.

Remarque : Veuillez vous connecter via Bluetooth pour une meilleure expérience.

Configuration requise pour le réseau Wi-Fi :

- Vous utilisez un réseau 2,4 GHz ou 2,4/5 GHz mixte.
- Votre routeur prend en charge les protocoles 802.11b/g/n et IPv4.
- N'utilisez pas de VPN (réseau privé virtuel) ou de serveur proxy.
- N'utilisez pas de réseau caché.
- WPA et WPA2 utilisant le cryptage TKIP, PSK, AES/CCMP.
- WEP EAP (Enterprise Authentication Protocol) n'est pas pris en charge.
- Utilisez les canaux Wi-Fi 1 à 11 en Amérique du Nord et les canaux 1 à 13 en dehors de l'Amérique du Nord (consultez l'organisme de réglementation local).
- Si vous utilisez un prolongateur/répéteur de réseau, le nom du réseau (SSID) et le mot de passe sont les mêmes que ceux de votre réseau principal.
- Veuillez activer le WPA2 sur votre routeur.

Témoin lumineux Wi-Fi

	Clignotement blanc lent	Déconnecté du Wi-Fi
	Clignotement blanc rapide	Connexion
	Blanc fixe	Connecté au Wi-Fi

Vous devez noter que l'accès à des fonctions intelligentes telles que le démarrage à distance, l'interaction vocale, l'affichage de cartes en 2D/3D et les paramètres de contrôle, ainsi que le nettoyage personnalisé (en fonction des différents produits) nécessite que les utilisateurs téléchargent et utilisent l'application YEEDI, qui est constamment mise à jour. Vous devez accepter notre politique de confidentialité et notre accord d'utilisation avant que nous puissions traiter certaines de vos informations de base et nécessaires, et vous permettre d'utiliser le produit via l'application YEEDI. Sans votre accord, certaines des fonctionnalités intelligentes susmentionnées ne sont pas accessibles via l'application YEEDI. Néanmoins, vous pouvez toujours utiliser les fonctions de base du produit pour une utilisation manuelle.


Informations sur l'interface réseau

Nom	Description
Interface de chargement	Fournit de l'énergie à la station et l'unité principale peut se connecter aux contacts de charge de la station pour se charger. L'interface infrarouge est désactivée par défaut et est activée lorsque le robot est dans la station.
Bluetooth	Activez Bluetooth pour connecter le robot au réseau pendant le processus de configuration du réseau.
Wi-Fi*	Facilite le transfert de données entre l'application et le robot, permettant le contrôle du robot via l'application.
Application YEEDI	Les produits YEEDI offrent des fonctions intelligentes telles que la configuration du réseau, la cartographie et la sélection du mode de nettoyage (spécifique à chaque produit). Pour utiliser ces fonctionnalités, les utilisateurs doivent télécharger et utiliser l'application officielle YEEDI.


* Les aspirateurs robotisés de la série robot sont conçus pour les scénarios de nettoyage domestique. Un réseau Wi-Fi domestique est nécessaire pour le fonctionnement et la protection anti-DDOS doit être configurée au moyen des paramètres du routeur.

6 Ajoutez une solution de nettoyage (vendue séparément)

1. Retirez le couvercle du contenant à poussière, retirez l'unité de solution de nettoyage et placez-la sur une surface plane et dure.




2. Ouvrez le couvercle de l'unité de solution de nettoyage et remplissez-la de solution de nettoyage YEEDI. Remettez le couvercle et remettez l'appareil à la station.



Remarque : La solution de nettoyage est pompée automatiquement à partir de l'unité de solution de nettoyage. N'ajoutez pas de solution de nettoyage dans les réservoirs d'eau.

3. Insérez le loquet supérieur du couvercle du contenant à poussière dans la fente, puis appuyez vers le bas pour assurer une bonne étanchéité.



Remarque :

- Veuillez utiliser la solution de nettoyage YEEDI en cas de dysfonctionnement.
- Assurez-vous qu'aucun objet étranger ne tombe dans l'unité de solution de nettoyage.

7 Commencer le nettoyage

1. Commencer la cartographie

Démarrez la cartographie via l'application YEEDI.

Lorsque vous créez une carte pour la première fois, suivez le robot pour éliminer certains problèmes mineurs.

Par exemple, le robot peut rester coincé sous les meubles. Veuillez vous référer aux solutions suivantes :

1. Si possible, surélevez les meubles bas;
2. Couvrir le bas du meuble;
3. Configurez une limite virtuelle via l'application :

Lors de la cartographie, le robot explore automatiquement l'environnement de la maison. L'itinéraire d'exploration peut être différent de celui de nettoyage.


2. Commencer le nettoyage

- Le réservoir d'eau du robot est automatiquement rempli via la Station OMNI. Le remplissage manuel n'est pas nécessaire.
- Lors du nettoyage, le robot reconnaît les types de sol et est capable de soulever automatiquement les balais lorsqu'il rencontre des tapis. N'utilisez pas le robot sur des moquettes ou des tapis à poils dotés de fibres de plus de 10 mm de long. Il est recommandé de les replier les tapis à poils dotés de fibres de plus de 10 mm pendant le processus de nettoyage, ou d'ouvrir la Carte > Stratégie de nettoyage de tapis dans l'application YEEDI pour définir la surface tapissée comme zone d'interdiction.

Avant d'effectuer une première aspiration, assurez-vous que le robot est dans la Station OMNI et complètement chargé. Appuyez sur le bouton  pour démarrer le nettoyage par le robot. Vous pouvez également utiliser l'application YEEDI pour démarrer le nettoyage.


3. Mettre en pause

Appuyez  sur le robot pour le mettre en pause pendant qu'il fonctionne. Vous pouvez également utiliser l'application YEEDI pour mettre le robot en pause.




5. Retourner à la station OMNI

Utilisez l'application YEEDI ou appuyez longuement sur le bouton du robot  pendant 3 secondes pour faire revenir le robot à la Station pour le recharger.



6. Mode Veille profonde

Le robot entrera en mode veille profonde pour protéger la batterie s'il reste hors de la station OMNI pendant environ 10 heures. Veuillez éteindre et allumer pour réveiller le robot.



Entretien régulier

1 Fréquence d'entretien


Pour garantir des performances optimales, entretenez et remplacez les pièces aux fréquences suivantes :

Partie	Fréquence d'entretien	Fréquence de remplacement
Vadrouille à rouleau remplaçable	Chaque semaine	Tous les 1 à 2 mois
Bac d'égouttage	Chaque semaine	/
Boîte à eau sale	Chaque semaine	/
Sac à poussière	/	Tous les 2 à 3 mois
Brosse latérale	/	Tous les 3 à 6 mois
Brosse principale	Chaque semaine	Tous les 6 à 12 mois
Filtre	Chaque semaine	Tous les 3 à 6 mois
Capteur de bord Roue universelle Capteurs anti-chute Pare-chocs Contacts de charge sur le robot Contacts de charge sur la station OMNI Module de navigation Module d'évitement d'obstacles Caméra AIVI	Environ tous les mois	/
Réservoir d' eau propre	Tous les 3 mois	/
Réservoir d' eau sale	Chaque mois	/
Intérieur du bac à poussière	Chaque mois	/
Corps et fond de la station	Chaque mois	/
Bac de lavage pour vadrouille	Tous les 5 mois	/


Remarque : Découvrez plus d' accessoires sur l' application YEEDI ou sur <https://www.yeedi.com>.

2 Bac à poussière


1. Retirez le bac à poussière, puis soulevez son couvercle pour vider le bac.



2. Soulevez le couvercle du bac à poussière pour retirer le filtre et l'élément filtrant.




3. Vous pouvez rincer les composants. Ensuite, secouez-les vigoureusement pour éliminer les gouttelettes d'eau restantes.



Remarque :

- Veuillez rincer le filtre à l' eau.
- N' utilisez pas les doigts ou les brosses pour nettoyer le filtre.

4. Séchez le bac à poussière et le filtre à l' air libre.




Remarque : Séchez complètement le filtre avant utilisation.


③ Entretien de la brosse principale et de la brosse latérale

Nettoyez la brosse principale.

1. Retirez le couvercle de la brosse principale.



2. Retirez et nettoyez la brosse principale.



3. Retirez, nettoyez et séchez le peigne-brosse.

