billboard

Bluetooth speaker

Bluetooth

Instruction manual

Button Introduction



BB2731

1. DC 5V Charging
2. CHARGE LED
3. LED Switch
4. TF
5. POWER & VOLUME knob
6. AUX
7. USB
8. MIC IN
9. MODE/MUSIC
10. LED MODE
11. REPEAT/FM
12. PAIR/MIC
13. MODE/PLAY & TWS
14. PAUSE/PLAY & TWS

Function of Remote

A wireless remote is included to control your wireless RGB LED backpack speaker. Please note that 2 AAA batteries are needed to power the remote. The batteries are not included.

- ⏻ –Power button, supported models can be turned on and off by pressing this button
- Mute –Mute button, quickly turn off the volume with one click, press again to restore the original volume.
- 0 – 9 –0-9 numbered buttons, select songs when playing on a storage device such as a USB / TF / SD card.
- 📁 –Mode button, select between audio input, wireless connection, FM radio, USB, TF/SD card
- ⏯ –Play / Pause (previous channel / next channel button in FM radio function)
- ⏮ ⏭ –Previous / Next (switch to previous / next channel in FM radio function)
- VOL+ –Volume up
- VOL- –Volume down
- EQ –Preset EQ effect switch;
- 🔁 –Repeat ; STOP –Stop the music playing in USB/TF mode

Connecting your BLUETOOTH® Device

Your speaker can play stored .all Bluetooth devices by simply pairing the device to the speaker. Please follow these steps to properly pair your device to your speaker.

1. Press the Mode button to choose the input signal source as BT channel when starting the machine.
2. Navigate to the Bluetooth section on your device and select "Browse for devices".
3. Look for the speaker device name "BB-BT-SP" and press connect.
4. You should hear a connection sound on your speaker and your device should display "connected". When the connection is successful, the LED indicator light will stop flashing and turn to constant,steady mode. The speaker is the device and try again.
5. Play the music from your device and adjust the volume on your device.
6. Adjust the master volume level on the speaker to your desired volume level.

Thank you for selecting the Billboard LED Wireless Backpack Speakes.

This product supports a variety of audio inputs and other formats. Such as, USB, SD/TF cards, wireless connectivity via Bluetooth, FM radio, wireless microphone, Beware, AUX input, wired microphone / guitar inputs. Some models may only support some of the functions listed above, the specific functions must be subject to the actual product.For more safety and efficient to product, please read this manual carefully before using it. Please keep this manual for reference. In order to have the best experience with your Billboard LED Wireless Backpack Speaker, please keep the accessories of this product.

Safety Warning

1. Please use within the specified power range,refer to the back plate on the product), otherwise damage may occur.
2. Avoid lying, bending, dragging or damaging the power cable or any other of the products cables.
3. Beside the speaker contain high voltage parts, please do not disassemble the product without authorization to avoid the risk of an electrical shock.
4) Pay attention to the environment when using the LED Wireless Backpack Speaker outside. Do not play during high temperatures, rain, snow or other inclement weather.
5) Turn off the speaker during thunderstorms. Unplug the speaker from any power sockets and disconnect and devices that may be connected to the speaker.
6) Avoid hitting the speaker against any hard objects, dropping from heights or knocking the speaker over.
7) Do not touch the back plate or other heat dissipating parts when the product is working.
8) Using in a well ventilated area, do not cover or put other items on top of the product and keep a proper distance as the speaker will produce heat.
9) Do not apply any liquids on the speaker to avoid risk of an electrical shock.
10) This product is not suitable for children to operate, please keep the speaker out of reach of children.
11) This product has a built-in battery. Do not let the battery overcharge for a long period of time.
12) If the speaker is infrequently used, please charge the speaker regularly to maintain the built-in battery performance and working life.

Operating Instructions

1. TWS : Turn on the two speakers of the same model , and keep the two speakers in bluetooth mode . press and hold the TWS button of the speakers when the display shows T or , the two speakers are paired . then use your bluetooth device to pair the speaker .
2. MIC/PRI : Press and hold this button , when music is playing on , you can use your microphone to speak and the playing music will be mute .
3. REC: Press and hold this button , and you can use your wired microphone to record what you sing or speak , press and hold this button again to finish what you have recorded . The speaker will play what you have sang and spoke just now . when you record , please insert your TF card or USB .
4. FM frequency range : 87.5MZ-108.8MZ
FM channels auto scan : when in FM mode , short press the play/pause button to auto scan the FM channels.
5.When using wired microphone , press and hold MODE button to increase the microphone volume . or press and hold the REPEAT button to decrease the microphone volume .

Common issues and solutions:

Issue	Reason	Solution
No Power	Power switch is not turned on	Turn on the power switch
	Built-in battery runs out	Charge the product / or adapter or power cable
	The plug is not plugged in properly or the power cable is defective	Reinsert or replace the power cable
	Power outlet is not device hot	Replace the power outlet
	Other reason	Contact after-sales dept.
No Sounds	Volume is turned off or in mute mode	Adjust the volume or turn off mute mode
	Source signal / input connection is not correct	Select the correct audio mode / input connection
	Audio media / input connection selected audio file	Reinsert media with supported format
	Other reason	Contact after-sales dept.
Microphone has no sounds	Microphone volume is off or too low	Adjust microphone volume
	Poor contact	Reinsert or replace the Microphone jack
	Other reason	Contact after-sales dept.
Distortion of sounds	Poor audio signal or volume too large	Adjust audio / input signal or volume level
	Battery running low	Fully charge before using
Sound from Microphone	The microphone volume is too loud or too close to the speakers	Adjust microphone volume and keep properly distance from speakers

Tips:
To protect your hearing from damage and avoid affecting others,
recommends that do not use this product at high volume for a long time.
In order to bring a better using experience, please keep the accessories of this product.

Note:

- Depending on the mode that the lights are in, it is possible not all lights will activate.
- While wearing the speaker on your back it may be necessary to have the remote pointed at the top of the speaker in order for the remote to work correctly with the speaker.

Battery information

Your device is powered by a rechargeable battery. The full performance of new batteries is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Do not leave fully charged Speaker connected to a charger, overcharging may shorten their lifetime. If left unused, fully charged Speaker batteries will lose their charge over time. Never use any charger or cord that is damaged. Leaving the device in hot or cold places will reduce the capacity and lifetime of the batteries. Optimal temperature for the batteries is between 59°F and 77°F. A device with a hot or cold batteries may not work temporarily, even when the batteries are fully charged.Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

Device Safety

- Your Wireless Speaker have an internal rechargeable battery. Improper usage may result in the Speaker becoming hot, igniting or bursting and causing injury if exposed to conditions of abuse.
- Do not disassemble, throw away or damage the Wireless Speaker. Store the Wireless Speaker in a dry place, keeping them away from damp corrosive materials and environments such as salt air
- Keep the Wireless Speaker away from direct sunlight, fire and high voltage equipment. Do not store the Wireless Speaker inside a car during hot weather. Remember a closed car acts as a green house allowing the inside to reach high temperatures.
- The Wireless Speaker are not a toy. Please keep them out of the reach of young children.
- Please do not discard the Wireless Speaker.Consult your local waste collection agency for proper disposal or recycling methods, You may also contact " Call2Recycle' at 877- 273- 2925 or online at 'call2recycle.org' for a battery recycling drop off location near you.

Charging The Battery

1. Plug the charger cable into the charge port.
2. Connect the charger to a USB power source. The red indicator light will display during charging. If charging does not start, disconnect the charger plug it in again, and retry. Charging the battery fully may take hours.
3. When the battery is fully charged, the red indicator light will turn off. Disconnect the charger from the USB power source and the Speaker. The fully charged battery has power for hours of music time.
4. Important!To prevent a complete discharge of your Speaker' battery, charge them up at least every six months.

LIMITED WARRANTY

ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor at any product the exterior of which has been damaged or defaced which design or construction.

The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases & Accessories, Inc.

The warranties described herein shall be the sole and exclusive
Warranties granted by ESI Cases & Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser.corrections of defects, in the manner and for the period of time described herein. shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases & Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liabilities and responsibilities of ESI Cases & Accessories, Inc. be liable or in any way responsible, for any incidental of consequential damages, so the above exclusion may not apply to you.
THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS. WHICH VARY FROM STATE TO STATE.

Manufactured By:
ESI Cases & Accessories
One Gateway Center, Suite 2600
Newark, NJ 07 102
Tech Support: (212) 883-8838
TechSupport@ESICellular.com

Return Instructions

If your speaker malfunctions during the warranty period of our calendar year (90 days for battery), contact our customer service department at (212) 883-8838 to obtain troubleshooting information. If troubleshooting assistance fails to remedy the problem, you will receive a return authorization # and instructions for sending your unit to our Service Center. Your return authorization number must be clearly visible and placed on the outside of box when the unit is returned.

Enclose a copy of your original proof of purchase showing the original purchase date, along with detailed information describing the exact nature of your problem. Be sure to include your complete name, address, email address, daytime and evening contact numbers. In addition, please send a check or money order made payable to "ESI Cases & Accessories " for return freight amount (given to you by our service agents). All of the above must be included with your return, or your package will not be eligible for service under our warranty.

The customer is responsible for packing the speaker in it's original carton or equivalent, and for insuring, and shipping the unit to our service center. Please make sure to pack all accessories included with your speaker so that we can properly identify any issues. All freight cost to return the unit to ESI Cases & Accessories, are the responsibility of the customer. If your speaker is under warranty, then ESI Cases & Accessories, will at its sole discretion, exchange or repair the speaker without charge for parts and labor. The customer is responsible for return freight and should include a check or money order payable to "ESI Cases & Accessories" with your return for the return freight amount. Any shipments received without a Return Authorization number will be refused. For more details please contact our customer service department.

Send product:
ESI Cases & Accessories
One Gateway Center, Suite 2600
Newark, NJ 07 102
Tech Support: (212) 883-8838
TechSupport@ESICellular.com

FCC Information

FCC ID: 2AS67-BB2731

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV/technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard FOR HOME OR OFFICE USE.
Warning: This equipment complies with FCC RF radiation exposure limit set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or connection with any other antenna or transmitter.

Bluetooth® is a registered trademark of Bluetooth® SIG
All other trademarks are property of their respective companies.

BC

RECYCLE YOUR BATTERY

WARNING:
BATTERY MAY EXPLODE IF DISPOSED OF IN FIRE.

DO NOT SHORT CIRCUIT: Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water. Storing batteries in original retail packaging, away from conductive materials, until ready to recycle.

WARNING: Do not dispose of batteries in a fire. Batteries may explode or leak.

WARNING: This product can expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

WARNING: It may damage your hearing if you listen with high volume for a long time. It is recommended that you set the lowest volume possible for listening to music.