

## PROFESSIONAL USER INSTRUCTIONS

### TF-007

This hearing protector is designed to reduce exposure to harmful levels of noise. To get the best comfort, fit and function from this product, read this User Instruction Manual carefully before operating this unit. Save this Manual for future reference. Noise is reduced, but it is not cancelled completely. For details on noise reduction, refer to the attenuation table.

#### SPECIFICATIONS

Three "AAA" sized batteries (provided) Frequency Response 200-10kHz AM Frequency (640-1700 kHz) FM Frequency (87.5-108 MHz)

#### PACKING INSTRUCTIONS

1. Instruction Pamphlet

#### COMPONENTS

1. LCD Display
  - A. Bluetooth mode (bt)
  - B. Battery Charge status
  - C. Radio station frequency
2. Memory Button - "M"
3. Charging LED
4. Forward/Tune Adjustment
5. Switch Button - "S"
6. Backward/Tune Adjustment
7. Power On/Off and Volume Adjustment
8. 3.2 mm Auxiliary Jack
9. Microphone
10. Three (AAA) Alkaline Batteries-packaged separately
11. Ear Cup Cushion
12. Acoustic Foam Absorbent

#### ⚠ WARNING

To reduce the risk of fire or electric shock do not expose this apparatus to rain or moisture. Do not expose the batteries to excessive heat for a long period of time.

#### BATTERY INSTALLATION

1. Take the earmuff cup (side with no electronics/buttons) and gently pull the cushioned ear muff ring.
2. Remove foam cushioning
3. Place batteries in the 3 slots as indicated. Insert the 3 AAA Alkaline batteries ensuring the polarity is correct according to the diagram inside the battery compartment. Incorrectly installed batteries could damage the unit.
4. To close the battery compartment, replace foam cushioning and snap earmuff ring securely in place.

#### ADJUST THE FIT

1. Don the earmuffs with the controls over your right or left ear.
2. Brush hair from beneath the cushions with your hand as much as possible.
3. With the headband over the crown of your head, position the muffs to completely enclose your ears.
4. Slide the muffs up or down to adjust for a firm, comfortable fit.

CAUTION! Foreign objects (such as pencils) between the ear cup and your head reduce the efficiency of the earmuff. Make sure the cushions seal tightly against your head. Do not reform or reshape the headband.

#### FUNCTIONAL OPERATION - Bluetooth Operation

1. Turn On/Off power/volume knob. BT and BT symbol will be on LED display with voice indicator. Bluetooth mode is connected. If you are in radio mode, press the "S" button to have Bluetooth connected.

2. Turn on the Bluetooth function on your phone or other Bluetooth enabled device. (This function is often found in the phones settings area) TF-007 will be listed under the device options for Bluetooth. Select this to pair with your device. After the device is paired, "Connected" will usually appear in the settings and "bt" will appear on the earmuff's LCD display.
3. Quickly/Short Press to play previous/go back.
4. Quickly/Short Press to play next/forward.
5. Quickly/Short Press "M" to Play/Pause.

The factory has advised that without obstructions, the Bluetooth could reach 300 meters, which is close to 900 feet. This seems like an awfully strong claim. Not sure that we would to leave it at that.

#### ANSWERING A PHONE CALL WHEN USING THE BLUETOOTH FUNCTION

When there is a phone call with a paired phone, there will be a telephone ringing sound in the earmuff. To answer the call, press the "M" button on the earmuff or the answer button on your phone. Note: You may also need to select the Bluetooth function on your phone's audio button (often found on the answer screen during a phone call. After the phone is paired, the user can still hear a phone call while in the AM/FM or Auxiliary device modes. When you finish the call, it will automatically switch back to original mode.

#### FM RADIO FUNCTION

- To use FM radio, Press "S" button on the earmuff to bring FM Frequency.
- Manual Search - Press the 'in' quick/short press to increase by 0.1mhz until desired frequency is reached.
- Auto Search - Press and hold 'for approximately 3 seconds to automatically scan. It will stop when a clear signal is reached. Repeat until desired station is reached.
- To go backward from current position to previous station, hold the < for approximately 3 seconds.
- To go backward from current position to previous station, hold the <

#### AM RADIO FUNCTION

- To use AM radio, Press "S" button on the earmuff to bring AM Frequency.
- Manual Search - Press the 'in' quick/short press to increase by 10kHz until desired frequency is reached.
- Auto Search - Press and hold 'for approximately 3 seconds to automatically scan. It will stop when a clear signal is reached. Repeat until desired station is reached.
- To go backward from current position by 10kHz, quickly/short press the <
- To go backward from current position to previous station, hold the < for approximately 3 seconds.
- Once the desired station is found, the volume can be adjusted accordingly.

#### PRESET RADIO STATIONS

- This unit features the ability to keep 10 preset stations for FM and 10 preset stations for AM.
- To save an AM or FM station,
- Once your desired station is selected, hold the "M" to display save mode. Quickly/Short press "M" to save again and confirm.
- Quickly/Short press the "M" to remove a saved station.

#### ANSWERING A PHONE CALL WHEN USING THE RADIO FUNCTION

When there is a phone call with a paired phone, there will be a telephone ringing sound in the earmuff. To answer the call, press the "M" button on the earmuff or the answer button on your phone. When you finish the call, it will automatically switch back to original mode.

#### AUXILIARY JACK OPERATION

Connect external audio devices (such as an mp3 player) through the auxiliary jack using a 3.5mm auxiliary jack cord (not included.) Once an external audio device is connected, you can adjust the volume accordingly.

#### PLEASE NOTE:

- Speaker volume is limited to comply with OSHA regulations.
- Radio reception quality may be slightly distorted depending on surroundings. To prevent damage to the radio, do not use in a high-temperature or high-humidity environment for prolonged periods of time. To prevent damage to the hearing protector and radio within, do not subject it to rough handling.

#### PRECAUTIONS

- These headphones contain a noise-cancelling feature. Noise cancelling senses the outside noise with a built-in microphone and sends an equal but opposite cancelling signal to the headphones. The noise cancelling effect may not be as pronounced in a very quiet environment, or some noise may not be heard.
- Noise cancelling effect may vary depending on how the earmuffs are worn and works best for noise in a low frequency band primarily.

#### MAINTENANCE

- Inspect the hearing protector regularly for cracks and signs of leakage. Earmuffs, in particular, cushions may deteriorate with use and age. Clean the outside of the muffs and cushions with soap and a damp cloth. Do not use abrasives or solvents.

#### STORAGE

- Ensure that the muffs are clean and dry before storage. Store the muffs at room temperature, away from dust. Do not store in direct sunlight. Exposure to direct sunlight in places such as car interiors, which may reach temperatures of up to 140°F (60°C), may warp the product, affect the performance of the electronics, or lead to malfunctioning. Do not store where the temperature could drop below freezing. Do not extend the headband. To avoid uneven compression of the ear cup cushion, ensure that the cushion lies flat against each other and that there are no creases in them. To prevent damage, remove the batteries.

#### TROUBLESHOOTING

- If the radio stops working: check for correct battery installation. Make sure the battery plates are clean and contact the batteries. Ensure the hearing protector is dry. If necessary, install new batteries.

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

#### INSTRUCTIONS POUR LES UTILISATEURS

##### TF-007

Ce protecteur auditif est conçu pour réduire l'exposition à des niveaux de bruit nocifs. Pour obtenir le meilleur confort, ajustement et fonctionnalité de ce produit, lisez attentivement ce manuel d'utilisation avant d'utiliser cet appareil. Conservez ce manuel pour référence ultérieure. Le bruit est réduit, mais il n'est pas complètement supprimé. Pour de plus amples détails sur la réduction sonore, reportez-vous au tableau d'atténuation.

#### SPECIFICATIONS

Trois piles de type « AAA » (fournies)  
Gamme de fréquence 200 à 10 kHz  
Fréquence AM (640 à 1700 kHz)  
Fréquence FM (87,5 à 108 MHz)

#### INSTRUCTIONS D'EMBALLAGE

1. Dépliant d'instructions
2. Casque d'écoute à réduction sonore Bluetooth

#### COMPOSANTS

1. Affichage ACL
  - A. Mode Bluetooth (bt)
  - B. État de charge de la pile
  - C. Fréquence de la station radio
2. Bouton Mémoire - « M »
3. DEL de rechargement
4. Réglage vers l'avant ou de syntonisation
5. Commutateur - « S »
6. Réglage vers l'arrière ou de syntonisation
7. Mise sous et hors tension et réglage du volume
8. Prise auxiliaire de 3,5 mm
9. Microphone
10. Trois piles alcalines (AAA) Piles emballées séparément
11. Amortisseur d'oreillette
12. Absorbant en mousse acoustique

## ⚠ AVERTISSEMENT

Afin de réduire le risque d'incendie et de choc électrique, ne pas exposer cet appareil à la pluie ou à l'humidité. Ne pas exposer les piles à des températures excessives pendant une longue période.

#### INSTALLATION DES PILES

1. Prenez le casque antibruit (côté sans électronique ou boutons) et tirez doucement sur l'anneau renforcé du cache-oreilles.
2. Enlever l'amortisseur en mousse.
3. Placez les piles dans les 3 fentes comme indiqué. Insérez les trois piles alcalines AAA conformément au diagramme de la polarité à l'intérieur du compartiment des piles. Des piles incorrectement installées pourraient endommager l'appareil.
4. Pour fermer le couvercle du compartiment des piles, replacez le revêtement en mousse et enclenchez fermement l'anneau du cache-oreille dans son emplacement.

#### RÉGLAGE D'ADAPTATION

1. Entaillez les cache-oreilles avec les commandes sur votre oreille droite ou gauche.
2. Retirez les cheveux se trouvant sous les coussins avec votre main autant que possible.
3. Avec le serre-tête au-dessus de la couronne de votre tête, placez les cache-oreilles pour enfermer complètement vos oreilles.
4. Faites glisser les cache-oreilles vers le haut ou vers le bas pour les ajuster pour un positionnement ferme et confortable.

ATTENTION! Des corps étrangers (comme des crayons) entre la coquille de l'oreille et votre tête réduisent l'efficacité du cache-oreilles. Assurez-vous que les coussins se referment fermement contre votre tête. Vous ne devez pas reformer ou remodeler le serre-tête.

#### OPÉRATION FONCTIONNELLE - Fonctionnement du Bluetooth

1. Mettre sous hors tension le bouton d'alimentation ou de volume. BT et le symbole BT s'afficheront sur l'écran à DEL avec la voix indiquant que le mode Bluetooth est connecté. Si vous êtes en mode radio, appuyez sur le bouton « S » pour que Bluetooth soit connecté.
2. Activez la fonction Bluetooth sur votre téléphone ou tout autre appareil compatible Bluetooth. (Cette fonction se trouve souvent dans la zone des paramètres du téléphone). Le TF-007 sera répertorié sous les options de périphérique pour Bluetooth. Sélectionnez cette option pour le jumeler à votre appareil. Une fois que l'appareil est jumelé, l'option « Connected (Connecté) » apparaît habituellement dans les paramètres et l'option « BT » apparaît sur l'écran ACL de l'oreillette.
3. Appuyez brièvement et rapidement sur ' pour reproduire la précédente ou recommencer.
4. Appuyez brièvement et rapidement sur ' pour reproduire la précédente ou recommencer.
5. Appuyez brièvement et rapidement sur « M » pour reproduire ou faire une pause.

#### RÉPONDRE À UN APPEL TÉLÉPHONIQUE LORS DE L'UTILISATION DE LA FONCTION BLUETOOTH

Quand il y a un appel téléphonique avec un téléphone jumelé, il y aura un téléphone qui sonne dans le cache-oreilles. Pour répondre à l'appel, appuyez sur le bouton « M » du cache-oreilles ou sur le bouton de réponse de votre téléphone. Remarque: Vous pouvez également avoir besoin de sélectionner la fonction Bluetooth sur le bouton audio de votre téléphone (souvent trouvé sur l'écran de réponse pendant un appel téléphonique). Une fois le téléphone jumelé, l'utilisateur peut toujours entendre un appel téléphonique dans les modes AM/FM ou auxiliaire. Lorsque vous avez terminé l'appel, il passera automatiquement en mode d'origine.

#### FONCTION DE RADIO FM

- Pour utiliser la radio FM, appuyez sur le bouton « S » du cache-oreilles pour amener la fréquence FM.
- Recherche manuelle - Appuyez sur ' en mode rapide/bref pour augmenter de 0,1 mhz jusqu'à atteindre la fréquence souhaitée.
- Recherche automatique - Appuyez sur ' pendant environ 3 secondes pour effectuer une recherche automatique. Lorsqu'un signal clair est détecté, il s'arrête. Répéter l'opération jusqu'à ce que la station souhaitée soit atteinte.
- Pour reculer de 0,1 mhz par rapport à la position actuelle, appuyez rapidement et brièvement sur <.
- Pour reculer de la position actuelle à la station précédente, appuyez sur < pendant environ 3 secondes.
- Une fois la station désirée trouvée, le volume peut être ajusté en conséquence.



