

FRONT

85

85

85

85

95

95

95

STRAYKIDS  
LIGHT STICK V2

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Any changes or modifications (including the antenna) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

SPECIFICATION

MODEL NAME

SIC\_V2

MODEL NUMBER

PS-2019-SICV2

LIGHT STICK SIZE

97 X 37 X 243.5 mm

INPUT POWER

3A X 3EA (4.5V)

MAIN FEATURE

WIRELESS LED CONTROL LIGHT STICK

WIRELESS SPECIFICATIONS

Bluetooth 5.0 / RF 2.4GHz (Receive only)

사용방법

버튼 짧게 누르기

버튼을 누르면 ON - FLICKER - DIMMING - REVERSE - ROTATION - OFF 순으로 LED 모드가 변경됩니다.

버튼 길게 누르기

버튼을 3초간 길게 누르면 피안색으로 깜박이며, 블루투스 페어링 모드가 됩니다.

기타와 블루투스 연결 후 애플리케이션을 통하여 다양한 경험을 즐길 수 있습니다.

중앙 제어

공연장에서 중앙 제어가 시작되면 별도의 버튼 조작 없이 자동으로 음원별 조명이 제어됩니다.

중앙 제어가 시작되면 음원별 조명을 사용자 스스로 제어할 수 있습니다.

안전지 설정 및 교체

아래의 그림과 같이 손잡이 하단을 돌려서 분리 후 내부에 있는 안전지 소켓을 꺼내주세요.

AAA 안전지 3개를 소켓에 끼워주는 방향에 맞춰 삽입해 주세요. (소켓에 스프링이 있는 부분입니다.)

물류 보충서

- 본 제품은 영격한 공장관리 및 품질관리를 통해 만들어진 제품입니다.
- 제품 보증 기간은 6개월입니다. (구매처 일부처)
- A/S 처리 기준  
(무상 수리)
  - 구매한 날부터 보증기간 내에 정상적으로 사용된 경우
  - 제품 외관에 이물질, 스크래치 등이 있는 경우 (미사용물에 한함)
  - (유상 수리)
    - 보증기간이 경과한 경우
    - 고액 부주의에 의한 파손, 고장이 발생한 경우
    - 화재, 물수, 지진 등 천재지변에 의해 고장이 발생한 경우
    - 고액 일회성 손해, 수리 및 개조로 발생한 고장의 경우
    - 보증기간 이내라 하더라도 유상 A/S로 판단될 경우 유급에 발생합니다.
    - 공식 판매처에서 구매한 제품에 대해서는 환불, 교환, A/S 등 고객 서비스 및 지원을 받으실 수 있습니다.
    - 본 보증서는 대한민국 내에서만 유효합니다.

주의사항

- 강한 충격을 받으면 고장의 원인이 됩니다.
- 물에 담그거나 넣지 마세요.
- 제품이 열화되어 있을 때 방열된 부분을 바라보지 마십시오.
- 직사광선, 고온 및 습한 장소에 보관하지 마십시오.
- 임의로 분해하거나 개조하지 마십시오.
- 제품 손상 등 이상에 있는 경우 사용을 중지하시고 A/S 의뢰하십시오. 2차 불량이 발생할 수 있습니다.
- 영/유아의 손이 닿지 않는 곳에 보관하십시오.
- 건전지(-) 극부터 (+) 극 순으로 삽입해 주세요.
- 정품 AAA 알칼리성 건전지를 사용하십시오.
- 새 건전지와 사용된 건전지를 혼합하여 사용하지 마세요.
- 동일한 제조사의 건전지끼리 사용하십시오.
- 마치 공연 시 새로운 건전지를 사용하십시오.
- 사용하지 않거나 사용 시에는 건전지를 분리 보관하십시오.
- 건전지 전압이 낮을 경우 LED가 동작하지 않습니다.

애플리케이션

아래의 QR코드를 찍어 애플리케이션을 다운로드 받으세요.

애플리케이션을 통해 음원별 조명 제어, OLED 화면 설정, 공연 티켓 등록을 할 수 있습니다.

앱 관련 자세한 내용은 애플리케이션을 다운로드한 후 확인하십시오.

iPhone

Android

A/S 접수방법

미사용 제품 또는 정상적으로 사용 중 발생한 문제의 경우 전화/이메일을 통해 고객지원 후, 제품을 수리 및 교환 절차를 안내드립니다.

상호명

사운드컨텐츠

연락처

02-381-3758

주소

경기도 고양시 덕양구 상동로193번길 1-6 3층 일부(상동)

고객센터 / 구매정보

|    |     |
|----|-----|
| 이름 | 구매처 |
| 전화 | 구매처 |
| 주소 |     |

How to use

Press the button briefly

Once you press the button, the LED mode changes in the order of ON - FLICKER - DIMMING - REVERSE - ROTATION - OFF.

Press and hold the button

If you press and hold the button for 3 seconds, it will blink in blue, and the Bluetooth pairing mode will be activated. After connecting the device through Bluetooth, you can enjoy diverse experiences using the application.

Central control

When central control is activated in the concert hall, the lighting of the light stick will be automatically controlled without any additional button operation.

When central control is activated, users are unable to individually control the lighting of the light stick.

Inserting and replacing the battery

As shown in the figure below, rotate the bottom part of the handle to separate.

Insert 3 AAA batteries in the direction written on the socket.

(The part with the spring in the socket is the (-) pole.)

Certificate of quality

- This product has been manufactured by strict process control and quality testing.
- The product warranty period is 6 months. (From the date of purchase)
- Repair Service Criteria
  - (Free repair)
    - If product has been used normally within the warranty period from the date of purchase.
    - If there are foreign substances, scratches, etc. on the exterior of the product. (Limited to unused products only)
    - (Paid repair)
      - If the warranty period expired.
      - In the case that product has been damaged or is malfunctioning due to customer's carelessness.
      - In the case of malfunction due to natural disasters, such as fire, flood, earthquake, etc.
      - In the case of product malfunction caused by disassembly, repair, and modification by the customer.
      - Even if the warranty period has expired, a fee will be charged for the repair requires payment according to the terms above.
  - Customer service and support such as return, exchange, repair, etc. are available only for products purchased from official vendors.
  - This warranty is valid only in Korea.

Precautions

- Strong shock may cause breakdown.
- Do not let the product touch or soak in water.
- Do not look at the illuminated part when the product is on.
- Do not store in a place with direct sunlight, high temperature, and humidity.
- Do not disassemble or remodel.
- If there is an abnormality including (but not limited to) damage to the product, do not use the product and request customer support. Secondary defects may occur.
- Keep out of reach of infants & children.
- Insert in order of (-) pole to (+) pole of the battery.
- Use genuine AAA alkaline batteries.
- Do not mix new and used batteries.
- Use batteries from the same manufacturer.
- Please use new batteries for each show.
- When product is not used or discharged, store batteries separately.
- If the battery level is low, the LED will not work.

Application

Download the application by scanning the QR code below. Through the application, you can control the lighting of the light stick, set the OLED screen, and register the performance ticket.

Please download the application for more details.

iPhone

Android

How to receive customer service

In the case that issues occur from unused or normally used products, contact us through phone/email for customer consultation and we will guide you through the product repair and exchange procedure.

Customer Service Center

SOUNDCONTENTS

Tel

02-381-3758

Customer Service Address

(Samsong-dong) The 3rd floor, 1-6, Samsong-ro 193 Beon-gil, Deogyang-gu, Gyeonggi-do, Republic of Korea

Customers / Purchasing Details

|         |          |
|---------|----------|
| Name    | Location |
| Mobile  | Date     |
| Address |          |

BACK

85

85

85

85

95

95

95

STRAYKIDS  
LIGHT STICK V2

使用法

短接按钮

按钮短接的话, 会按照ON - FLICKER - DIMMING - REVERSE - ROTATION - OFF 的顺序变更为LED模式。

长按按钮

长按3秒青色灯亮起后, 进入蓝牙配对模式。

与蓝牙耳机后, 可通过APP程序感受多样性质体验。

中央控制

在演出会场, 将中央控制打开的话, 无需另行其他操作, 应援棒可自动形成应援模式。

中央控制启动后, 用户将无法自行调控应援棒的照明。

电池的插入与更换

如下图所示, 转动把手的下端, 分离后, 把内部的电池插盒拿出。

请按照插盒上写着的方向插入3个AAA电池。 (插盒上有弹簧的部分是(-)极)

品質保証書

- 本製品は厳格な工程管理と品質検査を経て生産された製品です。
- 製品保証期間は6ヶ月です。(購入した日から)
- アフターサービス処理基準  
(無償修理)
  - 購入日から保証期間内に正常に使用した場合
  - 製品の外観に異物、スクラッチなどがある場合(未使用品に限ります)
  - (有償修理)
    - 保証期間が経過した場合
    - お客様の不注意による破損、故障が発生した場合
    - 火災、洪水、地震など天災災害による故障が発生した場合
    - お客様より任意に分解、修理、改造し発生した故障
    - 保証期間内でも有償アフターサービスと判断された場合、料金が発生します。
    - 公式販売先でご購入された製品に限り、返品、交換、アフターサービスのカスタマーサービス及びサポートをお受けいただけます。
    - 本保証書は、大韓民国内でのみ有効となります。

注意事項

- 強い衝撃を受けると故障の原因となります。
- 水に浸かると故障の原因となります。
- 製品が点灯している際、発光された部分を目で見ないでください。
- 直射日光、高温や湿った場所での保管は避けてください。
- 任意に分解したり改造しないでください。
- 製品に異常があるなど異常がある場合は、使用を中止しアフターサービスにご依頼ください。
- さらなる不具合が発生する可能性があります。
- 乳幼児の手の届かない場所に保管してください。
- 乾電池を小瓶から小瓶の両面に挿入してください。
- 純正乾電池をご使用ください。
- 新しい乾電池と使用済みの乾電池を混用しないでください。
- 同メーカーの電池だけをご使用ください。
- 毎回の公演の前、新しい乾電池に替えてご使用ください。
- 使用しない場合や放電の際は、電池を取り外して保管してください。
- 電池残量が低い場合、LEDが動作しません。

应用程序

请扫描下方二维码下载APP程序。

通过APP程序可以控制应援棒的照明、OLED画面的设置、登陆演出门票。

有关APP的详细内容, 请下载APP后确认。

iPhone

Android

A/S申请方法

未使用的产品或正常使用中出现故障, 可通过电话/电子邮件进行客诉咨询后, 为您介绍产品维修及更换程序。

商号名

SOUNDCONTENTS

連絡先

02-381-3758

住所

京畿道 高阳市 德阳区 三松路193号路 1-6 3楼 部分(三松洞)

顧客名 / 购买情報

|    |      |
|----|------|
| 姓名 | 购买链接 |
| 电话 | 购买日期 |
| 地址 |      |

使用法

ボタンを短く押す。

ボタンを押すと ON - FLICKER - DIMMING - REVERSE - ROTATION - OFF の順にLEDモードが変更されます。

ボタンを長く押す。

ボタンを3秒間長く押すと青色に点滅し、Bluetoothペアリングモードになります。

デバイスとBluetoothが接続された後、アプリケーションを通して様々な経験を楽しむことができます。

中央制御

会場で中央制御が始まると、別途のボタン操作なしに自動的にペンライトの照明が制御されます。

中央制御が開始すると、ペンライトの照明をユーザーが自ら制御することはできません。

乾電池の挿入と交換

下記の通り、握り手の下端を回して取り外した後、内部にある乾電池ボックスを取り出してください。

乾電池ボックスをボックスに書かれている方向に合わせて挿入してください。

(リッパットにアタリが合致する部分に(-)極です。)

品質保証書

- 本製品は厳格な工程管理および品質検査を通して制作された製品です。
- 製品保証期間は6ヶ月です。(購入した日から)
- アフターサービス処理基準  
(無償修理)
  - 購入日から保証期間内に正常に使用した場合
  - 製品の外観に異物、スクラッチなどがある場合(未使用品に限ります)
  - (有償修理)
    - 保証期間が経過した場合
    - お客様の不注意による破損、故障が発生した場合
    - 火災、洪水、地震など天災災害による故障が発生した場合
    - お客様より任意に分解、修理、改造し発生した故障
    - 保証期間内でも有償アフターサービスと判断された場合、料金が発生します。
    - 公式販売先でご購入された製品に限り、返品、交換、アフターサービスのカスタマーサービス及びサポートをお受けいただけます。
    - 本保証書は大韓民国内でのみ有効となります。

注意事項

- 強い衝撃を受けると故障の原因となります。
- 水に浸かると故障の原因となります。
- 製品が点灯している際、発光された部分を目で見ないでください。
- 直射日光、高温や湿った場所での保管は避けてください。
- 任意に分解したり改造しないでください。
- 製品に異常があるなど異常がある場合は、使用を中止しアフターサービスにご依頼ください。
- さらなる不具合が発生する可能性があります。
- 乳幼児の手の届かない場所に保管してください。
- 乾電池を小瓶から小瓶の両面に挿入してください。
- 純正乾電池をご使用ください。
- 新しい乾電池と使用済みの乾電池を混用しないでください。
- 同メーカーの電池だけをご使用ください。
- 毎回の公演の前、新しい乾電池に替えてご使用ください。
- 使用しない場合や放電の際は、電池を取り外して保管してください。
- 電池残量が低い場合、LEDが動作しません。

アプリケーション

以下のQRコードをクリックしてアプリケーションをダウンロードしてください。アプリケーションを通じてペンライトの照明コントロール、OLED画面設定、公演チケット登録を行うことができます。

アプリケーションについては、アプリケーションをダウンロードしてご確認ください。

iPhone

Android

アフターサービスの受付方法

未使用品または正常に使用した際に発生した問題に関しては、電話またはメールでお客と相談の後、製品の修理及び交換手続きをご案内いたします。

A/S Center

サウンドコンテンツ

Tel

02-381-3758

A/S Address

京畿道高阳市徳陽区三松路193番地1-6 3階一部(三松洞)

お客様 / 購入情報

|     |     |
|-----|-----|
| ご氏名 | 購入先 |
| 電話  | 購入日 |
| ご住所 |     |