尺寸:72*120mm
材质:128g双面铜版纸

Cyboris **S20**

# Metal Magnetic Split Bluetooth Speaker



# Manual

## QUICK START GUIDE

### 1. Power On & Bluetooth Pairing

◎ Press and hold the ⏻ button on both speakers for 3 seconds
☀ The indicator light flashes blue rapidly

After both speakers power on, wait 3–5 seconds until you hear a "beep" .The two speakers have successfully connected automatically

Turn on your phone' s Bluetooth, search for the device Cyboris S20, and tap to connect

Tips
If only one speaker plays audio and the other remains silent:
① Turn off your phone' s Bluetooth
② Restart both speakers and wait 3–5 seconds for them to automatically connect
③ Turn on your phone' s Bluetooth again, search for, and connect to Cyboris S20

### 2. USB Drive / Micro SD Card / AUX Input

Insert a USB flash drive, microSD card, or AUX audio cable
The speaker will automatically recognize and play the content (supports MP3 and FLAC formats)

⚠ If playback does not start automatically:

· Press the ⏻ button to switch playback modes
· Or check if the music format is correct

Important Note
In USB, Micro SD card, and AUX playback modes, two devices cannot be connected; playback must be done independently

### 3. Charging

Please use a standard 5V charger
Both speakers must be charged separately


### 4.How to turn off the RGB lights

※ Quick double-click the ⏻ key

## PARAMETER

| Model | Cyboris S20 | Input | Type-C 5V/1A |
|---|---|---|---|
| BT version | V5.4 | F.R | 60Hz~18KHz |
| BT range | ≤18M (Open field) | Distortion | ≤5% |
| Speaker | 2*15W | Speaker size | 57mm*2 |
| Battery | 3.7V/2000mAh*2 | Full charge | ≤3H |

## BUTTON FUNCTION




## ACCESSORIES



Type-C cable*2

## CONNECTION AND PLAY

●BT wireless playback

a.The Blue light flashes after power on, and the speaker enters the Bluetooth waiting state;

b.Turn on the Bluetooth of the mobile phone, search for the Bluetooth name "Cyboris S20" and click connect;

c.With a beep, and the Bluetooth connection is successful.

● TWS connection and playback

a. When two new "Cyboris S20" units are powered on at the same time, they will automatically connect (an audible tone will sound);

b. Open your phone's Bluetooth settings, search for "Cyboris S20" and tap to connect; once connected, an audible tone will sound, and you can enjoy wireless stereo sound by playing music;

c. Press and hold the "◁" button to disconnect or reconnect the TWS pairing; (To reconnect, you must first disconnect the Bluetooth connection)

d. TWS is only supported in Bluetooth mode.In USB, Micro SD card, and AUX playback modes, two devices cannot be connected; playback must be done independently.

PS: When the two speakers are not connected and turned on at the same time, two Bluetooth names will be displayed, and two devices can be connected separately and used as independent speakers.

● AUX cable playback
Connect the AUX cable to the device and the speaker to play.

● Micro SD card playback(up to 64G)
After inserting the SD card into the speaker, with a beep, the speaker will automatically read the card and play.(Supports MP3 formats)

● USB flash drive playback(up to 64G)
After inserting the USB flash drive into the speaker, with a prompt sound, the speaker automatically reads the card and plays.
(Supports MP3 formats)

| Button | Operating | Function Description |
|---|---|---|
| — | Short press | Volume down |
| | Long press | Previous song |
| ◁ | Short press | a. When the music is playing: short press the play/pause function;<br>b. When the call is in the status of the call: short press to connect the call;<br>c. When a call has been answered: short press to hang up the call; |
| | Long press | Disconnect/Reconnect TWS |
| + | Short press | Volume up |
| | Long press | Next song |
| | Short press | Switch Playback Mode |
| | Long press | Press and hold for 3 seconds to turn on/off |
| | Double-click | Turn the lights on/off |

## GUARANTEES SERVICE

### After-sales service content:

1. Within 7 days from the day after you sign for the product, if there is a performance failure listed in the "Speaker Performance Failure Table", the product can be returned or exchanged for free if it is determined by testing;
2. Within 8-15 days from the day after you sign the receipt, if this product has a performance failure as listed in the "Speaker Performance Failure Table", it will be determined by the after-sales service center, and you can enjoy free replacement or repair services;
3. Within 12 months from the day after you sign for the product, if there is a performance failure listed in the《Speaker Performance Failure Table》, it will be determined by the after-sales service center and you can enjoy free maintenance services.

### 《Speaker Performance Failure Table》

1. The device cannot be charged, or cannot be turned on normally after charging;
2. Device keys cannot be used normally;
3. The device can't make a sound;
4. The device function cannot be used normally due to other hardware failures.

### No Three Guarantees Service:

1. Unauthorized maintenance, misuse, collision, negligence, abuse, liquid ingress, accident, alteration;
2. Improper use of accessories other than this product, or tearing up or altering the label;
3. The validity period of the three guarantees service has expired;
4. Damage caused by force majeure such as fire, flood, lightning strike, etc;
5. Does not meet the performance failures listed in the《Speaker Performance Failure Table》;
6. Due to human reasons, this product and its accessories have performance failures listed in the《Speaker Performance Failure Table》.

## SAFETY PRECAUTIONS

1. The equipment complies with the standard GB 4943.1-2022;
2. This product cannot be taken, please keep it out of the reach of children to prevent accidents;
3. Do not place the machine in a high temperature environment, including direct sunlight;
4. Do not place the machine near fire sources or other overheated environments;
5. Do not place the machine in a humid or humid place;
6. In addition to the provided charging cable, please do not try to use other methods to charge the machine;
7. Do not disassemble the machine, and prohibit any attempt to repair or modify the machine;
8. Please pay attention to drops, impacts, scratches or other behaviors that affect the function of the machine. If there is any damage, such as hot, high temperature deformation or corrosion, please stop using the product and equipment immediately and contact the merchant;
9. If the machine produces abnormal odors, higher than normal temperature, and abnormal changes in color or shape, please stop using the machine immediately and contact the merchant;
10. If the battery is incorrectly replaced, there is a risk of burning, and only the same type or equivalent type of battery can be used for replacement;
11. Using the machine at high volume for a long time may cause damage to your hearing.

## KIND REMINDER

1. When the machine has not been used for more than 3 months, the machine needs to be charged before use;
2. When not in use for a long time, it is recommended to charge the machine once every 3 months, which can more effectively protect the battery;
3. It is recommended to use the machine after it is fully charged.

## POWER DESCRIPTION

a. Please use the charger that supports 5V/1A and the original Type-C cable for charging;

b. The red light is always on when charging, will turn off when fully charged;

c. When the voltage is too low, there will be a "beep" tone.

## PRODUCTION INFORMATION

Product name: Metal Magnetic Split Bluetooth Speaker
Model: Cyboris S20
Service telephone: 0755-2373-9380
Email: sales@cyboristech.com
Producer: Shenzhen Haisaite Technology Co., Ltd.
Manufacturer Address: 2nd Floor, 3rd Factory Building, Area A, Xiangli Industrial Park, No. 1 Xiangli Road, Longhua District, Shenzhen

www.cyborisaux.com

Cyboris
Create Your Better Life

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:**
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

**Note:**
The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.
The device can be used in portable exposure conditions without restriction.

# Warranty Card

Dear customer, thank you for purchasing our products. In order to better serve you, after purchasing the product, please read carefully and keep this warranty card carefully

### Warranty description

1. Please keep this warranty card properly for maintenance certificate
2. This product is warranted for one year from the date of purchase
3. Warranty equipment during the warranty period, in the state of normal use and maintenance, there are problems and failures in machine materials and processes. Upon verification, we will provide repair services free of charge
4. During the warranty period, if the following events occur, the company has the right to refuse service or collect materials and service fees according to the situation
   (1) Cannot provide this warranty card and valid proof of purchase
   (2) Product failure and damage caused by improper use by users
   (3) Man-made abnormal external force damage
   (4) Damage caused by disassembly by maintenance service personnel not authorized by our company
   (5) Failure or damage caused by natural disasters or other force majeure factors
   (6) Others intentionally damaged
5. Our company reserves the right to modify and explain all content

### Product information

| Maintenance Records | Date | Fault description |
|---|---|---|
| | | |
| Product Model | | |
| Customer Name | | |
| Customer Phone | | |
| Purchase Date | | |
| Shipping Address | | |