RETEVIS

USER'S MANUAL

TRANSCEIVER

RT27

• Scan function

• Busy Channel Lock Out

HENAN EISHON ELECTRONIC COMMERCE CO.,LTD

Web www.retevis.com E-mail:support@retevis.com

Facebook:Retevis Ailunce

EAS1 01/08

FM Transceiver

Dear user:

Welcome to use our handheld transceiver. We believe you will be pleased to use it in our daily life and work.

This transceiver adopts advanced technology, we hope you will be satisfied with its quality and functions. This transceiver will bring you convenient, fast, reliable two-way communication.

Please read this manual carefully before using this transceiver.

- Please do not communicate or charge this transceiver in flammable,explosive and area which transceiver communication is prohibited(such as oil station,gas station, airport etc.)
- Please do not operate this transceiver without license in countries where license is required.
- Please make sure this transceiver avoids the sunshine, and avoids to put it near heating device.
- Please make sure this transceiver avoids any dusty,humid and water splashed place,and also avoids to put it on unstable platform.
- If transceiver smells or smokes, please remove the battery pack from transceiver at once, and then contact our maintenance center for help.
- The repair job of this transceiver is in the charge of professionals & technicals, self-disassembly is prohibited.

CONTENTS

UNPACKING AND CHECKING EQUIPMENT 1

PREPARATION 2

GETTING STARTED 5

BASIC OPERATION 6

SCAN FUNCTION 8

CTCSS/DCS 8

AUXILIARY FUNCTIONS 8

CTCSS FREQUENCY(38 CTCSS FREQUENCY) 10

DCS FREQUENCY (105 DCS FREQUENCY) 10

UNPACKING AND CHECKING EQUIPMENT

We recommend that you open the packing box before use and check carefully the main transceiver in the packing box and the supplied accessories. If any item missed or damaged during shipping, please contact your dealer shipper or local dealer.

1. Supplied Accessories

Item	Quantity
Hand Strap	1
Belt Clip	1
Battery	1
USB Charger	1
User's Manual	1
Adapter	1

1

PREPARATION

Notice:

· Do not charge the battery for a long time!

If battery is not fully charged within schedule time, stop charging. Otherwise the battery may be overheated and damaged, even explode.

· Do not throw the battery into micro-wave oven and high-pressure container!

The battery may be overheat and smoke and burst into fire.

· Prevent the trash as well as liquid spilling battery from fire!

Do not put battery near heating device, fire or high temperature, and away from inflammable area. The electricity spilling from the battery is easy to catch fire, and it will cause battery damage and even fire accidently.

· Do not use unusual battery!

If battery smells smelly, different colors, out of shape or any unusual display, please remove the battery from charger or operating device and do not use it.

1.Battery Charging Warning

The charger supplied is specialized designed for this transceiver only, it will charge the battery more scientific reasonable, and safety.

2. Use Li-ion Battery

Li-ion battery has long service use

· To prevent battery pack from discharging, please remove the battery from transceiver or device when it is not in use for a long time, and put it in cool dry place.

· For battery pack storage

1. Remove the battery from device

2. If possible,discharge battery.

3. Store it in a cool(below 25℃) and dry place.

2.Battery Characteristic

• The capacity of battery will reduce step by step after being charged and discharged again and again.

• Battery will be damaged if it is left in low voltage.

• It will cost longer time to charge the battery in cool and dry place.

• Battery working life will be reduced if being charged in high temperature area, such as under direct sunlight or in car.

Please do not leave battery in car and put it near any heating device.

• If battery working life becomes shorter, please replace it even it is fully charged. If go on being charged and discharged, it may explode.

3.Charge Li-ion Battery

If battery smells smelly, different colors, out of shape or any unusual display, please remove the battery from charger or operating device and do not use it.

4.Install/Remove Battery Pack

Note:

· Do not short circuit battery pack terminals or throw battery into fire.

· Do not open or damage the battery pack shell.

· Do not install battery pack under dangerous conditions.

Install battery pack as following:

· Insert the bottom of battery pack into the top 2 slots of the transceiver and then press the battery pack down until a "click" sound is heard. (Pic1)

To remove the battery pack, make sure the transceiver has been turned off, and then press the battery released latch in the bottom of transceiver, and pull the battery pack out. (Pic2)

(Pic1) (Pic2)

5.Install Hanmee Belt Clip

If necessary, install the supplied screws into the belt clip at the back of the transceiver with a screwdriver.

To remove the belt clip, directly remove the two screws only.

6.Install Hand Strap

Install the hand strap at the middle circle of the transceiver.(Pic3)

(Pic3) (Pic4)

2 3 4

GETTING STARTED

① Power/Volume Knob

Rotate the knob clockwise to turn on the transceiver, keep rotating to adjust the volume. To turn it off, rotate the knob counterclockwise.

② LED Indicator

When transmitting, LED indicator turns green, and when receiving a signal, LED indicator red. LED indicator will flash red when battery in low voltage.

③ Channel Selection Knob

Rotate this knob to select different channels.

④ PTT(Push-To-Talk) Switch

Press this button to transmit. PTT button and face towards microphone to talk.

⑤ Scan Key

Press this open and again to close this function.

5 6 7

⑥ MONI Key

Press it to monitor the selected channel.

⑦ MIC-SP Jack

It is to connect the optional microphone-speaker.

BASIC OPERATION

1.Turn On/Turn Off

Rotate the Power/Volume knob clockwise to turn on the transceiver

Rotate the Power/Volume knob anticlockwise to turn on the transceiver.

2.Adjust Volume

Rotate the Power/Volume knob to adjust the volume. Clockwise increase volume,and counter-clockwise decrease volume to reduce the volume.

· More accurate adjustment is needed while communication. Note: You can press MONI key to monitor the background noise while adjusting volume.

3.Channel Select

Rotate Channel Selection Knob to select needed channel. Clockwise rotation will rise the channel number and anticlockwise rotation will reduce the channel number.

Voice Prompt: The radio will be voice prompt recent channel number,and then the channel will be announced.

Note: If you want to change to English and Chinese, you can select the language by software.

8 9 10

4.Adjust Squelch Level

Squelch function is used to let speaker quiet when no any signal. When squelch is on, you can hear background noise from speaker. When squelch is off, no any noise can be heard.

The selected squelch level will decide where to turn on or off the squelch. The higher squelch level is, the high the signal strength needed can not be heard, but if the squelch level is too low, then signal will appear with the background noise. (RC programmable)

5.Transmit(Call)

(1) Keep the different settings of monitor function, press (MONI) key to monitor loudspeaker. Make sure no any transceiver is transmitting on the selected channel.

2. Press (PTT) key, and speak to microphone.

(1) Keep microphone away from your mouth about 3~4 cm, press (PTT) key and speak in usual tone, so that the receiver can get best tone quality.

(2) Press (PTT) key, LED indicator displays red.

3. Release (PTT) key and start to receive.

6.Receive

When receiving a selected channel is being called, LED indicator displays green, you can receive the call.

· If the transmitting signal is weaker, and also higher squelch level is set, then maybe you can not receive the call.

· Maybe your local dealer has set CTCSS/DCS signaling to your radio, when receiving a signal without matching tone has been selected, only transceiver with same signaling can be received. Other transmitting can not be received.

11 12 13

SCAN FUNCTION

Press Scan key to start auto scan. When receiving signal, it will stop at current channel, and it will auto scan again after signal disappears in 5s. Press (PTT) key, if scan is working, then transmitting will according to the frequency from the scan start channel. If scan stops, transmitting will according to current channel.(PC programmable)

CTCSS and DCS

Maybe your local dealer has set CTCSS/DCS signaling on your radio, when receiving a signal without matching tone has been selected, only transceiver with same signaling can be received. Other transmitting can not be received.

This function can help you to receive unnecessary call. It seems the transceiver maybe have its own channel after CTCSS/DCS has been input, but if other transceivers have not input the CTCSS/DCS codes, your transmitting can be also heard.

AUXILIARY FUNCTION

1. Busy Channel Lockout

Start the function to prevent interfering other transceiver using same channel frequency.

The default setting of this function is off. if the selected channel is programmed on by software or local dealer, when receiving a signal, you can't transmit by pressing (PTT) key, then can not transmit, and transceiver will sound "beep", "beep". To stop beep sound, release PTT key.

14 15 16

When this channel is free, press PTT key again to transmit.

2. Battery Voltage

When transceiver power is on, battery voltage will be auto detected, if battery voltage is low, LED indicator will flash red.

The transceiver can be used for a while, but necessary transmitting will run out of battery quickly. When battery voltage is very low, an alarm will be heard, transmitting is prohibited. Please charge the battery pack or replace the battery.

3. Monitor

You can press (MONI) key to monitor weaker signal which is too weak to open squelch. Press (MONI) key again to adjust the selected channel volume if signal disappears.

4. CTCSS Select

Open the software , input the necessary frequency,click "CTCSS" which is under "CTCSS/DCS decode" and "CTCSS/DCS encode", and select the necessary CTCSS, then write it into transceiver by software.

5. DCS Select

Open the software , input the necessary frequency,click "DCS" which is under "CTCSS/DCS decode" and "CTCSS/DCS encode", and select the necessary CTCSS, then write it into transceiver by software.

6.Time-out Timer(TOT)

TOT function is used to prevent a channel have been used for a long time.

If the transmitting time exceeds the programmable time, transceiver will stop transmitting, and send alarm sound. Release (PTT) key, transceiver will back to receiving mode automatically.

17 18 19

1.Product safety and RF Exposure for transceiver:

Before using this transceiver, please read the manual which contains important operating instructions for safe usage, RF Energy Awareness control information and operating instructions to satisfy compliance to RF Energy Exposure limits in applicable national and international standards, and also read the operational instructions for safe use.

CAUTION!

This transceiver is compliance to FCC RF Exposure requirements and refers to FCC website https://apps. fcc.gov/oet/ea/ reports Generic Search,vide search for FCC ID: 2A3ARRETEVISRT27 to gain further information include SAR value.

WARNING!

SAFETY INFORMATION

Your wireless hand-held portable transceiver contains a low power transmitter. This product sends out radio frequency (RF) signals when the Push-to-Talk (PTT) button is pressed. The power output is considered low and is rated at less than 50%. In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for transceiver. These guidelines

To control your exposure and ensure compliance with the general population or uncontrolled environment exposure limits, transmit no more than 50% of the time. The radio generates measurable RF energy exposure only when transmitting.

CAUTION!

Don't Tamper or Modifications

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment and should not be made. To comply with FCC requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified in the commercial radio transmitter and receiver in the private land mobile and Fixed services as certified by an organization representative of the user of these services. Unauthorized modifications of certified transmitters, semiconductors, etc) not authorized by the FCC equipment authorization for this radio could violate FCC rules.

Note: Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be illegal.

CAUTION!

Body-Worn Operation

To maintain compliance with FCC's RF exposure guidelines, for body-worn operation, keep transceiver and its antenna at least 2.5cm from your body. FCC RF exposure guidelines when used with Retevis Radio Corp. accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

If you do not use any accessories supplied or approved by Retevis, ensure the radio and its antenna are at least 1 inch (2.5 cm) from your body when transmitting.

CAUTION!

Safeness

1). The antenna in the packing is unique, please do not optional change.

2). For safe operation, the antenna for the product shall be least 1 inch (2.5 cm) away from the body of the user.

3). Switching to other antennas is prohibited and will affect the radio performance.

4). DO NOT use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with your skin, a burn can result.

CAUTION!

Batteries

All batteries can cause property damage and or bodily injury such as burning or explosion if conductive touches expose terminals. The conductive material may be complete an electrical circuit (short circuit) and become very hot.

• Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove these batteries.

• Do not store batteries in any manner that allows them to carelessly when placing it inside a pocket, purse or other container with metal objects.

• Do not discard your battery in a fire.

• Do not replace the battery in any area labelled "Hazardous atmosphere" or "Explosive atmosphere", such as potentially in atmosphere can cause explosion or fire.

• Do not disassemble, crush, puncture, shred or otherwise modify or mutilate the battery in any way.

• Do not use a hot battery or damp battery with any appliance or heat source, such as a hair dryer or microwave oven.

• Do not leave the battery unattended when submerged in water, dry and clean the battery contacts before attaching the battery to the radio.

CAUTION!

Battery Charger Safety Instructions:

1. Turn the radio off when charging the battery.

2. Charge the battery in a well ventilated environment. Chargers should only be used indoors.

3. Do not operate or disassemble the charger. Do not use a damaged charger. Do not attempt to repair the charger.

4. Never alter the AC cord or plug provided with the unit. If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician. An improper condition can result in a risk of electric shock.

5. To reduce the risk of damage to the cord or plug, pull the plug rather than the cord when disconnecting the charger from the AC receptacle.

6. To reduce the risk of electric shock, unplug the charger from the outlet before attempting any maintenance or cleaning.

7. Use of an attachment not recommended or sold by Retevis Solutions may result in a risk of fire, electric shock or personal injury.

8. Make sure the cord is located so it will not be stepped on, tripped over or subjected to damage or stress.

9. Do not operate the charger with a damaged cord or plug. If necessary, Use of an improper extension cord could result in a risk of a fire and or electric shock. If an extension cord must be used, make sure that:

The pins on the plug of the extension cord are the same number, size and shape as those on the plug of the charger.

The extension cord is properly wired and in good condition. 10. The supply cord of the AC adaptor cannot be replaced. If the cord is damaged, sell customer service.

CAUTION!

The information listed below provides the user with the information needed to make him or her aware of RF exposure, and how he or she can ensure that the radio operates with the FCC RF exposure limits of this radio.

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed or otherwise configured for electromagnetic compatibility.

During transmissions, RETEVIS, INC. radio generates RF energy that can possibly cause interference with other devices or systems.

Facilities

radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy. To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio.

When instructed to do so, turn off your radio when onboard an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

Medical Devices - Pacemakers, Defibrillators or other Implanted Medical Devices

Persons with pacemakers, Implantable cardioverter defibrillators (ICDs) or other active implantable medical devices should:

• Consult with their physicians regarding the potential risk of interference from radio frequency transmitters, such a portable two-way radio. Implanted medical devices may be more susceptible to interference.

• Turn the radio OFF immediately if there is any reason to suspect that interference is occurring.

• Do not carry the radio in a chest pocket or near the implantation site, and carry or use the radio on the opposite side of their body from the implantable device to minimize the potential for interference.

Hearing Aids

Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

Note: The areas with potentially explosive atmosphere referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles (such as grain, dust or metal powders) and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmosphere are often – but not always – posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn off your radio when you are near electrical blasting caps, in a blasting area or in areas posted "Turn off two-way radios". Obey all signs and instructions.

⚠ Warning: CHOKING HAZARD- Small Parts. Not for children under 3 years.

⚠ Attention! RISQUE D'ETOUFFEMENT - Contient de petites pièces. Ne convient pas aux enfants de moins de 3 ans.

⚠ Advertencia: PELIGRO DE ASFIXIA - Contiene piezas pequeñas. No conveniente para niños menores de 3 años.

⚠ Achtung: ERSTICKUNGSGEFAHR - Kleinteile. Nicht für Kinder unter 3 Jahren geeignet.

⚠ Waarschuwing: VERSTIKKINGSGEVAAR - Bevat kleine onderdelen. Niet geschikt voor kinderen jonger dan 3 jaar.

⚠ Avviso: RISCHIO DI SOFFOCAMENTO - Piccole parti. Non adatto a bambini di età inferiore a 3 anni.

⚠ Aviso: RISCO DE ASFIXIA - Peças pequenas. Produto não recomendado para crianças com menos de 3 anos.

5.Specifications

• Operating frequency: 462.5500MHz~467.7125MHz

• Channels: 22 FRS

• Antenna: Fixed antenna

• Power:2 out or 1.0 out Battery 3.7V DC/1100mAh

CH/NO.	CH/Freq.	DMP	CH/NO.	CH/Freq.	DMP	CTCSS/DCS
1	462.5625	23H	12	1668	12	462.6875	23H	D026N
2	462.5875	23H	13	1669	13	462.7375	23H	D026N
3	462.6125	23H	14	1668	14	462.7875	23H	D026N
4	462.6375	23H	15	1668	15	462.8375	23H	1668
5	462.6625	23H	16	1668	16	462.8750	23H	1668
6	462.6875	23H	17	1668	17	462.9000	23H	1668
7	462.7125	23H	18	1668	18	462.9375	23H	1668
8	462.7375	23H	19	1668	19	462.9625	23H	1668
9	462.7625	23H	20	1668	20	462.9750	23H	1668
10	462.7875	23H	21	1668	21	462.9875	23H	1668
11	462.8125	23H	22	1668	22	463.0000	23H	1668

Note: Above channels are FRS license free channels.

CTCSS FREQUENCY(50 groups)

01	67.0	11	94.8	21	141.3	31	179.9	41	225.7
02	71.9	12	100.0	22	146.2	32	183.5	42	229.1
03	74.4	13	103.5	23	151.4	33	186.2	43	233.6
04	77.0	14	107.2	24	156.7	34	189.9	44	241.8
05	79.7	15	110.9	25	159.8	35	192.8	45	250.3
06	82.5	16	114.8	26	162.2	36	196.6	46	254.1
07	85.4	17	118.8	27	165.5	37	199.5		
08	88.5	18	123.0	28	167.9	38	203.5		
09	91.5	19	127.3	29	171.3	39	206.5		
10	97.4	20	131.8	30	173.8	40	210.7		

DCS FREQUENCY(105 groups)

01	023	18	125	35	261	52	364	69	464	86	627	103	774	120	953
02	025	19	131	36	263	53	365	70	465	87	631	104	805	121	954
03	026	20	132	37	265	54	371	71	466	88	632	105	818	122	965
04	031	21	134	38	271	55	411	72	503	89	645	106	820	123	971
05	032	22	143	39	274	56	412	73	506	90	646	107	832	124	972
06	036	23	145	40	306	57	413	74	516	91	652	108	843	125	973
07	043	24	152	41	311	58	423	75	523	92	662	109	846	126	988
08	047	25	155	42	315	59	431	76	526	93	664	110	852	127	031
09	051	26	156	43	325	60	432	77	532	94	703	111	855	128	032
10	054	27	162	44	331	61	445	78	546	95	712	112	864	129	043
11	065	28	165	45	332	62	446	79	565	96	723	113	866	130	047
12	071	29	172	46	343	63	452	80	606	97	731	114	874	131	051
13	072	30	174	47	346	64	454	81	612	98	732	115	877	132	054
14	073	31	205	48	351	65	455	82	624	99	734	116	884	133	065
15	074	32	212	49	356	66	462	83	627	100	743	117	906	134	071
16	114	33	223	50	360	67	464	84	627	101	754	118	912	135	072
17	115	34	225	51	361	68	464	85	627	102	758	119	923	136	073

17

GUARANTEE CARD

Model Number: .....

Serial Number: .....

Purchasing Date: .....

Dealer: ..... Telephone: .....

User's Name: ..... Telephone: .....

Address: ..... Post Code: .....

REMARKS:

1. This guarantee card to be kept by the user,on repair environment if lost.
2. This guarantee card to be filled & chopped by the dealer or it is invalid.
3. Please keep the guarantee card, please confirm the serial number on the guarantee card is same as that on the machine.
4. One-year guarantee,charger,battery,earphone,antenna and can cable are not under guarantee.
5. The user can get repairing service from the following ways: 1.Return to the shop where you buy the machine 2.Go local repairing agent

18 19