BV370

Bluetooth Boombox speaker

USER MANUAL ▶

Preface

Dear Users:

Thanks for purchasing SeaMetaver's product, please read this user manual carefully before using it.

Thanks, Let's enjoy music together!

FCC Certification Requirements

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

1

Beginnning

Warnings

*Please use and store this product at room temperature

Do not expose this product to rain or wet conditions

Please avoid throwing and dropping the speaker

Do not self-dismantling, repair and transform the product

Do not use chemical solvent cleaning the product

Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion

2

Packing Content

1 Bluetooth speaker 1Pcs

2 USB cable 1Pcs

3 Music 1Pcs

4 3.5mm Audio cable 1Pcs

5 User manual 1Pcs

3

Features

- Take pictures by one button via Bluetooth
- Hands-free and support MP3/WMA normal format
- Support APE/FLAC/WAV lossless music format
- Built-in 1100 mAh Li-ion rechargeable battery
- Support voice prompt
- Built-in radiators to enhance the bass
- Output power: 3.5Wx2, stereo sound

Technique Parameters

Appearance parameters	
Interface	Micro USB port
Product Size	4*4.2*3.5inch (W*H*D)
Product weight	0.7kg (Bulk machine)

4



5

Technical	
Output power	6Wx 2ohm
Frequency response	60Hz-20KHz
S/N	85dB (A-weighted to 1dB) 1
Charging time	DC 5V/1000mA around 2-3.5 hours
Playback time	around 3-5 hours when middle volume

TF card music play

Music format	MP3, WMA, APE, FLAC, WAV
Bit Rates	MP3 : 8KBps - 320KBps
	WMA : 32Kbps - 384Kbps
	APE : 400Kbps - 1411Kbps
	FLAC : 400Kbps - 1411Kbps
	WAV : 705Kbps - 1411Kbps

6

Get Started

Key Function

Hotkey the keyfs function on BV370



7

1 **Power/Mode Key:** Long press: power on or power off

Short press: Mode shift

When in call mode or BT/ TF card press this mode key will shift the mode from BT > TF > AUX orderly

When in AUX mode, long press mode key mode shift, just stay on BT mode

2 **Bluetooth** disconnect/connect/ handsfree answer/hanging

1)When a call coming in, short press to answer the call short press to hang up the call

2)During the BT, enter into Bluetooth mode or disconnect Bluetooth short press to reconnect

3)Long press to reconnect the last paired device

3 **Previous** short press, go to the previous song

long press, volume down

4 **Play/pause** short press to play/pause music

5 **Next** short press, go to the next song; long press, volume up

8

1 **TF card slot:** Insert TF card and play the stored music

2 **Reset:** Press it when speaker crashes

3 **Line in:** Connect 3.5MM Audio cable connect the computer to receive the TF

4 **Micro USB port** charging

5 Built-in Microphone

6 **Power indicator light:** battery capacity

9

Battery indicator

- 100% Power
- 75% Power
- 50% Power
- 25% Power (Battery need to be recharged)
- Turn off Power

Charging indicator

- Charge to 100%
- Charge to 75%
- Charge to 50%
- Charge to 25%
- Charging
- Fault battery

Note:

When turning low Power, red LED quick flash, when turn on, and BV370 will turn off in 15S.

10

Mode indicator

1 **Turn on:** white LED quick flash, waiting to be connected, white LED stay when connected

2 **Pause under Bluetooth mode:** white LED slow flash

3 **Play under Micro SD card:** white LED stay

4 **Pause under Micro SD card:** white LED flash

5 **Play under Aux in:** white LED stay

6 **Mute under Aux in:** white LED flash

7 **Max volume:** white LED quick flash

11

Built in snapshooting function

1 Snapshooting

When BV370 connected with Apple devices (iPhone, iPad, etc), Operate camera app, then short press [+] to take pictures.

2 Compatible list

iPhone 4/4S/5/5S/5C/6/ iPad etc.

12

Operation & Bluetooth connection

1 In long press turn on/ turn off

Power on, "Ding Dong" tone, voice prompt "Bluetooth mode" white LED turn on and flash

2 Bluetooth connection

Turn on Bluetooth function on smart phone, tablet or other Bluetooth devices, search the speaker "BV370" and connect it

13

3 Connected and play

There is "Ding dong ding" sound and colorful LED flash when the speaker is successfully connected to BV370 from your smart phone or tablet etc.

1、If need to pair new device or other device to connect and position to connect	2、BV370 will reconnect to the last paired device automatically

14

Connect other Bluetooth devices

1 Bluetooth disconnect

Long press [+] can disconnect current Bluetooth device, then the speaker enter into pairing mode, white LED flash and the voice prompt is "ding"

Turn on the Bluetooth function on smartphone or other devices, search the Bluetooth "BV370" to connect.

2 short press

[+] to reconnect the last paired device

15

Micro SD card mode and play

1 Insert TF card and turn on

Insert the TF card, turn on the speaker

2 short press

[+] and shift to "TF card mode", the speaker will play the stored music

Note: If the speaker is on stand by mode, insert the tf card,it will shift to TF card mode automatically.

16

Handsfree

1 BV370 connected with smart phone or tablet

When a call coming in, the ringing will be pressed, then ring long, short press [+] to answer the call, short press again to hang up. Long press to reject the call

Connect to BV370

connect to play device

Audio cable

Line in mode poly

Long press to turn on the speaker, press [+] to shift the "Line in mode", then use the audio cable to play music.

17

Charging: Use DC 5V-500mA adapter or computer USB port

Note: Please charging the speaker if long time no using.

18

FAQ

Symptoms	Solutions
No sound when connect	1. Restart the speaker
	2.1) make sure your volume is not LOW
Music wire break	2. Please insert the Bluetooth connection again and reconnect it successfully to control the device
Sound turned wrong	3.1) Check the TF format (make sure it is FAT32 format)
	2) the music format can only WMA, MP3, APE, FLAC or WAV
No sound	4.1) Increase the volume adjustment on the speaker
	2) Check if the speaker is in Mute (paused)
Line-in no sound	5.1) Check if the audio cable connected is right and
Not Turn on	1) Check if the power is low
Speaker Noise	1) Please keep away the noise source to avoid interference