
17cm
16.7cm
17cm
16.7cm
16.7cm
31.9cm
16.7cm
RADIO CONTROLLED ACTION VEHICLE
FLIPSYNC 360
BLUE HAT
TOY COMPANY
AGES 6+
DUAL-SIDED FLIP DESIGN
FOR JUMPS AND STUNTS
RC Stunt Vehicle with 360-Degree Flip Action
Full Function Wireless Remote Control
High-Performance Rubber Grip Tires
Bright LED Lights for Night Driving
FULL FUNCTION REMOTE CONTROL
FlipSync vehicle requires six "AA" 1.5V batteries (not included). RC controller requires one 9V battery (not included). See bottom panel for additional information. Colors and styles may vary.
BATTERY OPERATED PLAY VEHICLE
AGES 6 AND UP
⚠ WARNING!
CHOKING HAZARD-
Small parts. Not suitable for children under 3 years.
WIRELESS RC ACTION!
INTERMEDIATE SKILL LEVEL
EXTRA-BRIGHT LED LIGHTS FOR RACING AT NIGHT
CRASH-RESISTANT DESIGN
FLIPS OVER FOR 2-SIDED DRIVING!
EXCITING FLIP ACTION!
RC Stunt Vehicle with 360-Degree Flip Action
Full Function Wireless Remote Control
High-Performance Rubber Grip Tires
Bright LED Lights for Night Driving
BATTERY INSTALLATION
Operation requires 6 AA 1.5V batteries (not included) for vehicle, and one 9V battery (not included) for radio controller.
After removing your vehicle from the box, you must remove the paper tray. Unscrew the fasteners underneath the vehicle to remove from the tray (and repeat for RC controller).
Locate the battery compartment(s) on the wide wheel cover and controller.
Remove the battery compartment door of vehicle using a standard screwdriver (Fig. 1).
Locate the battery contacts (Fig. 2). Insert 6 AA batteries. Replace screws and battery compartment door.
Unlatch the battery compartment door of the radio controller.
Insert one 9V battery according to the polarity diagram located on the battery tray (Fig. 3).
Replace the battery compartment and battery cover.
BASIC OPERATION
NOTE: YOUR STUNT VEHICLE MOVES BEST IN A HARD, OPEN AREAS.
Switch the vehicle and controller power switches to their "ON" positions.
Operate the stunt vehicle according to the controls diagram below.
For best operation, use on a hard and flat surface.
Fig.1
Fig.2
Fig.3
LEFT JOYSTICK
FORWARD & REVERSE
RIGHT JOYSTICK
LEFT & RIGHT
ON
OFF
OFF/ON SWITCH
RADIO CONTROLLER USES ONE 9V BATTERY (NOT INCLUDED)
SAFETY WARNINGS - PLEASE READ BEFORE USING PRODUCT
•Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
•It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.
BATTERY WARNING:
• Do not mix old and new batteries.
• Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
• Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
• Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire - they may leak or explode.
• Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.
• Always use, replace, and recharge (if applicable) batteries under adult supervision.
KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio TV technician for help.
WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment
Made in China
©2016 MerchSource, LLC. Blue Hat Toy Company, Blue Hat Toy Company logos are trademarks of MerchSource, LLC. All rights reserved.
Distributed by MerchSource, LLC, Irvine, CA 92618.
PATENT PENDING
The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.
FULL FUNCTION REMOTE CONTROL