IP-COM

Quick Installation Guide

802.11 AC Indoor/Outdoor Wi-Fi Access Point

IUAP-AC-M

The Quick Installation Guide tells you through how to store and how to perform first-time configurations. For product in-hand item details, please operate screws, IP-COM is a platform.

Package contents



Get to know your device

LED indicator



LED Indicator	Status	Description
LED	Light on	The system is starting up or is abnormal.
	Blinking	The system is normal.
	Off	The device is not powered on or the LED indicator is turned off.

Port/button



Port/Button	Description
GND	GND terminal Used for ESD and lightning protection. Use a grounding cord and the nearest grounding screw to connect this GND terminal to the earth.
Reset	Reset button When the IUAP-AC-M is powered on, press and hold down this button for about 8 seconds, and then release it. When the SYS LED indicator flashes, it indicates that the device restores to factory settings.
PoE/LAN	It is a gigabit PoE port used to supply power to network devices. Use the included PoE adapter or a PoE switch to supply power to the device. To establish a connection to the device, connect an Ethernet cable to the PoE/LAN port. The PoE/LAN port supports 10/100/1000 Mbps self-adaptive Ethernet connection and MDI/MDIX auto-negotiation.

Attach antennas

Tips
The ■ indicates the connector on an antenna ■ means ■ indicates the male ■ means the female ■ indicates the connector. The ■ and ■ must correspond.

1. Remove and discard the two rubber waterproof gaskets from the rubber gaskets remain in place.
2. Connect the antennas to the SMA connectors.

Tips
Make sure the antennas are connected firmly to the corresponding SMA connectors. Otherwise, poor connection will affect the performance of the AP.



Install the device

Option 1 Wall mounting

Tips
Ensure that the wall is strong enough to withstand at least four times the weight of the device and the mounting bracket.

1. Mark the drill ■ mounted bracket at the target location on the wall with a ■ pencil, as shown in the following figure.
2. Ensure that the bracket is ■ about 90 degrees vertical to the ground and mark four holes.
3. Drill out the holes to a depth of 25 to 30 mm with a ■ drill bit.
4. Use a rubber hammer to knock the four plastic anchors (Length: 26.6 mm; Diameter: 6.6 mm) into the holes one by one.
5. Secure the wall ■ mounted bracket on the wall by using the four screws (Length: 12 mm; Diameter: 3 mm).
6. Attach the AP to the ■ mounted bracket by aligning the mounting tabs to the buckles of the latter.
7. Fix the ■ screw (Length: 12 mm; Diameter: 3 mm) and ■ washer (Diameter: 13 mm) to the ■ bracket.



Option 2 Pole mounting

Tips
Make sure the pole is ■ secure and the ■ bracket is installed ■ and vertical.

1. Slide the wall ■ mounted bracket down onto the pole, as shown in the following figure. Put the bracket away and keep it ■. You may need it should you change to the wall ■ mounting option.
2. Use the plastic strap to secure the AP onto the pole.



Lightning and ESD protection

Connect the GND terminal of the AP to a grounding terminal, connected the earth or building to protect the AP from over voltage and environment caused by lightning and ESD.

1. Connect one side of a grounding cord to the ■ plated grounding screw on the GND terminal of the AP.
2. Connect the grounding screw to the GND terminal of the AP, and tighten it.
3. Remove the cable grommet and then replace the port cover.
4. Connect the other side of the grounding cord to the grounding terminal connected to the earth or building.



Power the AP

Option 1 Connect to a PoE adapter

1. Connect the AP to the **PoE** port of the PoE adapter with an Ethernet cable.
2. Connect the **LAN** port of the power/ethernet Connect an Ethernet cable from your LAN to the **LAN** port of the PoE adapter.
3. Connect the power cord to the adapter and then plug the power cord to a power source.



Option 2 Connect to a PoE switch

Connect an Ethernet cable directly from the AP to a PoE port on a PoE switch compliant with IEEE 802.3af/at. The switch automatically supply power to the AP.



Configure your APs

You can configure the AP through the web UI of the AP, Ruijie Cloud, or the IP-COM Utility. This chapter mainly describes the configuration methods of using the web UI and the IP-COM Utility. For details about the IP-COM platform configuration method, refer to the user guides of target products.

Scenario 1: Through the iUniFi Controller

The network topology diagram for configuration through the IP-COM Controller is shown as follows. For details about how to configure APs through the IP-COM Controller, refer to its user guide.



Scenario 2: Through the Web UI of the AP

Tips
Connect and turn figure your APs over by one. That is to say, connect one AP to your switch and configure it. When you finish, connect the second AP, and repeat steps 4 and 5.

Connect devices

Connect the management computer to the switch to which the AP has connected. For details about how to connect other devices, see the following figure.



Configure the IP address of the management computer (Example: Win10)

On the computer desktop, click **Start** > **Settings** > **Change adapter options**. Right-click **Ethernet**, click **Properties**, and double-click **Internet Protocol Version 4 (TCP/IPv4)**. Choose **Use the following IP address**, and enter an IP address (for example, **192.168.0.254**) that is from the same network segment as the AP's default IP address (**192.168.0.254**) and is not occupied by other devices) and **Subnet mask** (**255.255.255.0**), and save the configurations.

Log in to the web UI of the AP

Start a web browser on the management computer, and access **192.168.0.254**. Follow the on-screen instructions to login.

Then select **5GHz** from the **Radio Band** drop-down list and repeat the above operations.

Tips
It is recommended to log in to each AP in the web UI of the AP, refer to FAQ Q4.

Modify the SSID and password

Choose **Quick Setup**, configure the **SSID** (WiFi name), **Security Mode** (**WPA2-PSK** is recommended), **Key**, and click **Save**.

Modify the IP address of the AP

Choose **Internet Settings** > **LAN Setup**. Modify the IP address of the AP to 192.168.0.X (X: 2 to 253), and ensure that the new IP address has not been occupied in this network, then click **Save**.

Example:

You can set the new IP address of the first AP to 192.168.0.201, and the new IP address of the second AP to 192.168.0.202.

Done.

Wifi name: The **SSID** you set in step 4 Modify the SSID and password.

Wifi password: The **Key** you set in step 4 Modify the SSID and password.

(Optional) AP wireless bridge

Tips
If you need to connect an AP to a network in a wireless manner, please refer to this chapter. The AP supports wireless bridge under only one wireless band at a time. Those who 2.4 GHz or 5 GHz is required. This chapter uses 2.4 GHz as an example for illustration.

Connect devices

Connect the management computer to AP2. For details about how to connect other devices, see the following figure.

Configure the IP address of the management computer & Log in to the web UI of AP2

Refer to steps 2 to 3 in **Scenario 2: Through the Web UI of the AP** in **Configure your APs**.

Configure AP2

Set the **Working Mode** of AP2 to **Client+AP**, and click **Scan**.

Select the wireless network of AP1 and its **SSID**, **Security Mode**, and **Encryption Algorithm** are the same as those of AP1, which are **PSK/TKIP**, **PSK/AES**, **WPA2-PSK**, and **AES** in this example. Enter the **Key** for the wireless network of AP1, and click **Save**.

Check the bridge status

Choose **Tools**, click **Diagnostic Tool**, and ping the IP address of AP1. If the IP address can be pinged, the bridge is successful. Otherwise, refer to Q8 in **FAQ**.

FAQ

Q1. What should I do if I cannot access the web UI of the AP after entering 192.168.0.254?

A1. Try the following options:

- Check if your Ethernet cables are connected properly. If yes, the SYS LED indicator lights up.
- Ensure that the IP address of your computer has been set to 192.168.0.X (X: 2 to 253), and the IP address is not occupied by any other devices in the network.
- Clear the cache of your web browser, or replace the web browser.
- Disable the firewall of your computer, or replace the computer.
- If you use more APs are connected to the network without IP-COM Controller for AP platform, you should leave only one AP in the network first and configure the AP's IP address. Then repeat this procedure to change the IP addresses of the other APs. Meanwhile, ensure that the APs' new IP addresses are in the same network segment with the IP address of the management computer. Then log in to the AP's web UI using their new IP addresses.
- The AP may be managed by IP-COM Controller or AP platform and therefore its IP address is no longer **192.168.0.254**. In this case, go to the web UI of the IP-COM Controller or AP platform to view the new IP address of the AP, and then log in to the AP's web UI using the new IP address.
- If the problem persists, reset the AP.

Q2. How to reset my AP?

A2.

Option 1: Reset using the Reset button

When the **SYS** LED indicator of the AP blinks, hold down the **Reset** button for about 8 seconds. The AP is reset successfully when the SYS LED indicator flashes fast and on.

Option 2: Reset using the web UI

Log in to the web UI of the AP, choose **Tools** > **Maintenance**, and navigate to the **Reset** section, then follow the on-screen instructions to reset it.

Note: Resetting clears all configurations of your AP.

Q3. What should I do if AP wireless bridge failed?

A3. Try the following options:

- Verify that the **Key** for the wireless network of the uplink device (AP1 in this guide) is correct.
- Check whether the signal of the wireless network of the uplink device (AP1 in this guide) is too weak. If so, move the AP (AP2 in this guide) closer to the uplink device AP1 in the guide.

Q4. How to log in to the web UI of the AP if I forget the IP address of the AP?

**A4