English

Getting to know your device

LED Indicator

LED Indicator	Description
Off	Not powered on
Solid green	The system is working properly or is connecting (booting).
Blinking green	The system is connecting.
Off	Wi-Fi function is powered off, or the LED indicator is turned off.
Solid white	The system is working properly.
Blinking white	Data is being transferred over the Internet.
Blinking red	The device is in the process of resetting.
Solid red	The device is booting up or the system is abnormal.
Solid white (2 min)	The device is in WPS connection mode.
Blinking red (2 min)	The device is in WPS connection timeout mode.

Jack/Port/Button

Jack/Port/Button	Description
Power	Connects to a power source.
Reset	It is used to connect to the included external adapter to supply power to the device.
WAN/LAN	Connects to a computer, modem or network device.
Reset	Press and hold the button for about 5 seconds when the device is powered on and running. Release the button when all LEDs become light and green. When the LED indicator blinks again, the device is successfully restored to factory settings.
Wi-Fi	Wi-Fi function is powered on by default. Press and hold the button for about 3 seconds to turn off the Wi-Fi function. Press and hold the button again for about 3 seconds to turn on the Wi-Fi function.
WPS	Press and hold the button for about 3 seconds, then release it. The WPS LED flashes. Activate your client device's WPS function within two minutes.

Bracket

The bracket is used to install the device onto a ceiling, wall, or pole. See **Install the device** for details.
- Screw holes for ceiling installation
- Screw wings/nuts for pole installation
- Screw and washer/nuts

Set up the device

Tips
Connect a power source (not supplied) through the wall (5 V/2.5 A) and an Ethernet cable. This port turns on to how to manage the device through the web UI. For more management types, please refer to relevant documents.

Power on the device. **Scenario 1** or **Scenario 2** to perform your configuration depending on your networking requirements. PoE power supply is used for illustration.

Scenario 1: Serve as a router

If you have a modem provided by your ISP, select **Router Mode** and set the Wi-Fi to the **PnP** (out-of-the-box) mode.
1. Connect Ethernet cable to connect the **LAN** port of the ISP device to the device.
2. Use the included power adapter to connect the PoE injector to a power source.
3. Connect Ethernet cables to connect the **PoE** port of the PoE injector to the device.
4. Connect computer to the device.

Use an Ethernet cable to connect the computer to the **LAN** port of the AC.

Connect the power adapter to the AC.

5. Open a web browser on the computer or on the smart phone, and visit **192.168.0.1** or **www.ipcom8.com**.
6. Click **Start** then follow the on-screen instructions to configure the internet settings.

Scenario 2: Serve as an AP

When serving as an AP, the device can be added into an existing Mesh network established by the model EW72 of other devices or creates a new one for other devices to join.

- Place the device nearby, added will be near the node serving as a router (hereafter referred to as the router), and power on the newly added node.
- Wait for the LED indicator blinks green and the ZIN LED indicator blinks blue, the system completes startup.

2. Refer to step 4 and 5 in **Scenario 1: Serve as a router** to login to the web UI of the existing router node.
3. Click **Add a Node** on the top right corner of the web UI, then follow the on-screen instructions to add the node.
4. Relocate the newly added node, and connect it to Ethernet.

Tips
If the LED LED indicator does not blink green slowly, reset the newly added node to factory settings and try again.

5. Repeat the above steps to add more nodes.

When the EW72 LED indicator of the newly added node blinks green, mark the status of the ZIN LED indicator. Adjust the position of the newly added node according to the descriptions in the following table until the ZIN LED indicator turns to orange when blinking.

Status	Description
Slow green blinking	Excellent connection
Fast green blinking	Fair connection. Be sure to connect the node to the nearby, added router closer to the upstream node. Under mesh or another router is also recommended.
Solid orange	Poor connection. Be sure to connect the node to the nearby, added router closer to the upstream node.
Fast blinking	Poor connection. Be sure to connect the node to the nearby, added router closer to the upstream node.

Once the nodes are added to the nearby, added router to the optimized position.

When the LED indicator turns off, the newly added node and the same with the existing mesh nodes, providing you with the better WiFi signal when you are moving around.

Install the device

Tips
- The mounting materials, provided hammer, screwdriver and a drill bit, or a screwdriver are only suitable for the installation. Please prepare them yourself.
- Please choose the appropriate wall plugs and screws. The guidelines are based on masonry. The guidelines are based on masonry. The guidelines are based on masonry