



Label placement(5056N)

 CAUTION

NON-REMOVABLE BATTERY.
ATTEMPTING TO REMOVE THE BATTERY OR THIS STICKER COULD
RESULT IN INJURY AND WILL VOID YOUR WARRANTY.
DO NOT ATTEMPT TO DISASSEMBLE, DAMAGE, ALTER OR REMOVE
BATTERY FROM DEVICE.
PRESS AND HOLD THE POWER KEY FOR MORE THAN 10 SECONDS
TO RESTART.

ESTE ES UN DISPOSITIVO DE UNA SOLA PIEZA, LA BATERÍA NO ES
EXTRAÍBLE.
EXTRAER LA BATERÍA O DESARMAR LA CUBIERTA PODRÍA
CAUSARLE DAÑOS Y PERDERÍA LA GARANTÍA.
NO INTENTE DESARMAR, ROMPER, DAÑAR O EXTRAER LA BATERÍA
DEL DISPOSITIVO.
MANTENGA PULSADO EL BOTÓN DE ENCENDIDO DURANTE MÁS
DE 10 SEGUNDOS PARA REINICIAR EL DISPOSITIVO.

ALCATEL
onetouch



USE ONLY POWER
SUPPLIES LISTED IN USER GUIDE
UTILICE SOLAMENTE
LAS FUENTES DE ALIMENTACIÓN QUE
FIGURAN EN INSTRUCTIVO DE USO
WWW.ALCATELONETOUCH.COM

Model: 5056N HW 02 HAC:M4/T4
Made in China

Date: 07/2016 FCC ID: 2ACCJB062

IMEI: 014650000000014

Label(5056N)



NON-REMOVABLE BATTERY.
ATTEMPTING TO REMOVE THE BATTERY OR THIS STICKER COULD
RESULT IN INJURY AND WILL VOID YOUR WARRANTY.
DO NOT ATTEMPT TO DISASSEMBLE, DAMAGE, ALTER OR REMOVE
BATTERY FROM DEVICE.
PRESS AND HOLD THE POWER KEY FOR MORE THAN 10 SECONDS
TO RESTART.

ESTE ES UN DISPOSITIVO DE UNA SOLA PIEZA, LA BATERÍA NO ES
EXTRAÍBLE.

EXTRAER LA BATERÍA O DESARMAR LA CUBIERTA PODRÍA
CAUSARLE DAÑOS Y PERDERÍA LA GARANTÍA.

NO INTENTE DESARMAR, ROMPER, DAÑAR O EXTRAER LA BATERÍA
DEL DISPOSITIVO.

MANTENGA PULSADO EL BOTÓN DE ENCENDIDO DURANTE MÁS
DE 10 SEGUNDOS PARA REINICIAR EL DISPOSITIVO.

ALCATEL
onetouch



USE ONLY POWER
SUPPLIES LISTED IN USER GUIDE
UTILICE SOLAMENTE
LAS FUENTES DE ALIMENTACIÓN QUE
FIGURAN EN INSTRUCTIVO DE USO
WWW.ALCATELONETOUCH.COM

Model: 5056W HW 02 HAC: M4/T4
Made in China

Date: 07/2016 FCC ID: 2ACCJB062

IMEI: 014665000000012

Label(5056W)