SITS ON YOUR SHOULDER
肩に乗る
SQUEEZE TO INTERACT WITH OTHERS
握ると他のチコと交流する
SOUND ACTIVATED
音に反応する
SQUEEZE TO LIGHT UP
握ると光る
THE SUPER MARIO GALAXY MOVIE
BLUE LUMA
3+
BATTERIES
Please keep this information for future reference as they contain important information.
BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.
• Requires 3 1.5V AAA batteries. Included.
• Use only fresh batteries of the same type.
• Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
• Do not mix old and new batteries, different brands or types of batteries, such as alkaline, standard (carbon-zinc) or rechargeable.
• Call a local poison control center for treatment information.
• Do not recharge batteries that are not rechargeable.
• Do not force discharge, recharge, disassemble, heat above 158°F (70°C) or incinerate. Doing so may cause batteries to leak corrosive or explode, with injuries resulting in chemical burns.
• The supply terminals are not to be short-circuited.
電池
電池取扱い上の警告
●本製品には単4形アルカリ乾電池3本が必要です。●新品の電池3本を使用してください。●使用済みの電池は、地域の条例に従って処分してください。●電池を家庭用ゴミと一緒に捨てたり、焼却したりしないでください。●電池を廃棄する際は、電池の端子をテープなどで絶縁してください。●異なる種類の電池を混ぜて使用しないでください。●充電できない電池を充電しないでください。●電池を分解したり、加熱したり、焼却したりしないでください。●電池の液漏れや破裂により、化学やけどを負う恐れがあります。●電池の端子をショートさせないでください。
Nintendo
ILLUMINATION
UNIVERSAL
© Nintendo and Universal City Studios LLC. All Rights Reserved
TM & © Universal Studios. • www.universalstudios.com
Universal Destinations & Experiences
1000 Universal Studios Plaza
Orlando, FL 32819 USA
Made in China
THE SUPER MARIO GALAXY MOVIE
NINTENDO WORLD
3 x 1.5V AAA batteries ● 単4形電池3本使用
Always turn the power OFF (O) when not in use.
●使用しないときは必ず電源をOFF（O）にしてください。
●電池残量しるべは、点灯に関係なく電池を交換してください。
BATTERY INSTALLATION
• Battery Use: Product is designed for adult only.
• Do not mix old and new batteries, different brands or types of batteries, such as alkaline, standard (carbon-zinc) or rechargeable.
• To install or replace batteries, unscrew, and lift cover and tray.
• Remove batteries when product is not in use for a long time. Equipment not used for an extended period of time, according to local regulations.
• Insert batteries as indicated inside the battery compartment.
• Ensure the batteries are installed correctly according to polarity (+ and +).
• Replace cover and secure with screw provided.
• Do not operate product if battery cover is not secured. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.
電池の取扱について
●電池の正極と負極を逆さまに入れないでください。●電池をショートさせたり、充電、分解、加熱、火の中に入れたりしないでください。●電池を使用済みとする前に、電池の端子をテープなどで絶縁してください。●異なる種類の電池を混ぜて使用しないでください。●充電できない電池を充電しないでください。●電池を分解したり、加熱したり、焼却したりしないでください。●電池の液漏れや破裂により、化学やけどを負う恐れがあります。●電池の端子をショートさせないでください。
WARNING: ADULT SUPERVISION REQUIRED - May release small parts.
CAUTION – Contains strong magnet
May affect pacemakers and other implanted medical devices.
FCC ID: 2ACUBWT133
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential use. This device generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the device and receiver.
—Consult the dealer or an experienced radio/TV technician for help.

PROJECTOR SOUND IN ENGLISH ONLY ● 音声は英語のみです
OFF