ART DEPARTMENT			
Job # / Filename 2017-02-07_SITOYRCMonsterSpinningCar_BlackBlueRed_BlackRed_v2		**Product Line** Sharper Image	**Revision #** 2
Designer Elena McMillin	**Brand Manager** Lisa Nagamoto	**Finished Size** 9.35" L x 7.36" D x 7.68" H / 23.75cm L x 18.7cm D x 19.5cm H	**Today's Date** 02-07-2017
File Format Adobe Illustrator CC (live)/CS2 (OL)	**Fonts** Helvetica, September, Eurostyle, Future Bugler, Trade Gothic, Univers	**Color (Spot or 4C)** 4 Color Process	**# of Colors** 4
Printing Process / Finishing Matte PP Coating		**Comments**	

MerchSource
All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC, or any third-party licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.

SHARPER IMAGE®

RC 360° RALLY CAR THUNDER TUMBLER®

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING!
Cchoking Hazard -
Small parts. Not suitable for children under 3 years.

Car requires 4 "AA" 1.5V alkaline batteries (not included).
Remote requires 1 9v battery (not included).
See bottom panel for additional battery information.
Colors and styles may vary.

TWO FREQUENCIES
COMPETITIVE RACING

360 DEGREE SPINS
SPINS AND FLIPS

AGES 6+

SHARPER IMAGE®

RC 360° RALLY CAR
THUNDER TUMBLER®

SHARPER IMAGE®
www.sharperimage.com

RC 360° RALLY CAR
THUNDER TUMBLER®

OPERATING INSTRUCTIONS

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Turn the battery pack switch on the back of the car to the "ON" position.
3. Swivel latches on bottom of car to release battery pack and insert batteries.
4. Switch on power on remote control to the "ON" position.
5. For best results use the car on hard surfaces such as wood or tile.

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

POWER SWITCH

BATTERY DIAGRAM

POWER SWITCH

BATTERY PACK (USES 4 "AA" BATTERIES NOT INCLUDED)

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

ACTION BUTTON

Reverse: Press both control sticks backward.

Forward: Press both control sticks forward.

Spinning Action: Press and hold the control sticks in opposite directions to make the car spin.

Action Button: Press and hold this action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow while operating car.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car on surfaces or load surfaces, as this will cause damage to your car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is operating.
- Do not store car or transmitter near sources of heat or under direct sunlight for extended periods of time.
- Do not store car or transmitter outside overnight. Dampness is harmful to interior components.
- Always turn the power switch to the "OFF" position and remove batteries when not in use to avoid battery leakage.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:

- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old batteries with new batteries. Always purchase batteries by the battery type number listed in the battery compartment. Always purchase batteries with the same battery type number.
- Do not mix batteries from different manufacturers.
- Do not dispose of batteries in fire. Batteries may explode or leak.
- Do not short circuit the battery terminals.
- Do not charge batteries.
- Do not attempt to recharge batteries that are not intended to be recharged.
- Do not use batteries that have been damaged or have leaked.
- Do not use batteries that are not listed.
- Do not use batteries that are not the correct size for the battery compartment.
- Do not use batteries that are not inserted correctly with regard to polarity (+ and -).
- Do not use batteries that are not inserted correctly with regard to polarity (+ and -).
- Do not use batteries that are not inserted correctly with regard to polarity (+ and -).

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Colors and styles may vary.
Product specifications, features or colors may not represent exactly as pictured. Sharper Image is not responsible for third party components.
For product support, please visit www.sharperimage.com or call 1.800.344.3744.
Please keep this package for reference as it contains important information.
Specifications are subject to change without notice. Sharper Image reserves the right to change this in the future.

FC

©2017 Sharper Image. Sharper Image® name and logo are registered trademarks. All rights reserved.
©2016 MerchSource, LLC. Thunder Tumbler and the fifth wheel design are both protected by MerchSource, LLC. All rights reserved.

SHARPER IMAGE

Distributed by MerchSource, LLC, Irvine, CA 92618.

Design Patent No. 2,201,250,028,060.1

1002392 (234x007)

0 84202 32588 9

Made in China

Try RC Monster Spinning Car