





X360, X1, Xbox Elite 1, Xbox Elite 2 → PS4



Each Wingman XE can only connect to a single Xbox 360 / Xbox One device. Wingman XE supports most of the accessories that are compatible with original factory specifications. To expand the number of supported accessories, firmware will be updated irregularly.



LED Display	
Lighting	Status
Blue LED Permanently on	The connector and the device are currently connected.
Blue LED Slow blinking (Once every two seconds)	Wired device is not connected Wireless device is searching for connection...
Blue LED Fast blinking	Wireless connection mode is ON. Searching for pairing device...
Red LED Blinking	Turbo-Remap button is being pressed
Red LED Permanently on	Entering Turbo-Remap Settings

Connecting to the Device

step.1

Insert Wingman XE into the PS4 console USB port. Slow blinking of the **Blue LED** indicates that the connection to the console is successful.

step.2

Wired Connection:

Connect the X360/X1 wired controller or game pad to Wingman XE through the USB port.

Using a X360 wireless controller:

Simply connect the X360 wireless receiver to the Wingman XE through the USB port.

Wireless Connection:

Connect the Xbox One wireless controller (Bluetooth model) or the Xbox One Elite Series 2 to the Wingman XE and the controller will be ready for use. When connecting, hold the LED buttons at the two sides of the Wingman XE for 1 second to enter wireless connection mode. Then press the **Pair button** on the wireless controller to begin pairing. Fast blinking of **Blue LED** indicates that pairing is in progress.

step.3

Check whether the two **Blue LEDs** at the sides of the Wingman XE are permanently on. This indicates that the connection is completed.

Connection Pairing Supplementary Instructions

step.1

Holding the LED buttons on the two sides of the Wingman XE for 1 second will activate wireless connection pairing mode. The Wingman XE will engage in pairing with surrounding Bluetooth devices. The pairing mode will end if:

A. The connection pairing with the wireless controller is successful.

B. The connection pairing is unsuccessful after 1 minute.

C. The LED buttons are held for 1 second.

step.2

Wireless connection records between an Xbox One wireless controller (with Bluetooth function)/Xbox One Series 2 and the Wingman XE will be erased if a wired connection is used. Wireless connection re-pairing will be required if wireless connection is used.

step.3

If Xbox One Elite Series 2 controller is used, please turn off controller profile settings to prevent interference with Wingman XE's Turbo or Remap settings. As Xbox One Elite Series 1 controller is incapable of turning off profile settings, using Xbox One Elite Series 1 controller might result in Remap function overlapping.

Corresponding Buttons		
List for PS4, Xbox360 and XboxOne Game Pads		
PS4 Game Pad	Xbox360 Game pad	XboxOne Game pad
D-Pad (U/D/L/R)		
Lx / Ly		
Rx / Ry		
×	A	A
○	B	B
□	X	X
△	Y	Y
L1	LB	LB
R1	RB	RB
L2	LT	LT
R2	RT	RT
L3	LSB	LSB
R3	RSB	RSB
OPTIONS	START	MENU
SHARE	BACK+ START	VIEW+ MENU
PS Key	Xbox Guide Key	Xbox Guide Key
TouchPad Key	BACK	VIEW

Touch Pad Simulation Function

Using the Xbox 360 controller:

BACK + R Stick can simulate the PS4's Touchpad button.

BACK + START can simulate the PS4's SHARE button.

Hold the R Stick to the left, then press BACK.

Hold the R Stick to the right, then press BACK.

Press BACK.

Hold the BACK, then press START.

Touch Pad Simulation Function

Using the Xbox One controller:

VIEW + R Stick can simulate the PS4's Touchpad button.

VIEW + MENU can simulate the PS4's SHARE button.

Hold the R Stick to the left, then press VIEW.

Hold the R Stick to the right, then press VIEW.

Press VIEW.

Hold the VIEW, then press MENU.

Turbo Function Settings

The following instructions are based on the Xbox One controller. For those using an Xbox 360 controller, please refer to the **Corresponding Buttons List for PS4, Xbox360 and XboxOne Game Pads**.

Turbo Function Settings

Buttons that can be set as Turbo function buttons include: A, B, X, Y, LB, RB, LT, RT, LSB, RSB 10 (hereinafter referred to as FK)

Step 1. Enter setting mode:

Press VIEW + Xbox Guide, the **RED LED** of the Wingman XE will be permanently on.

Step 2. Choosing a FK button: (e.g. Setting A as turbo function)

Hold VIEW, then press A

Step 3. Completing Setting Mode:

Release all buttons, then press MENU to save settings.

Step 4. Exit setting mode:

Press Xbox Guide, the **BLUE LED** of the Wingman XE will be permanently on.

Cancelling Turbo Function

Step 1. Enter setting mode:

Press VIEW + Xbox Guide, the **RED LED** of the Wingman XE will be permanently on.

Step 2. Erasing all Turbo function buttons

Press VIEW + MENU

Step 3. Exit setting mode:

Press Xbox Guide, the **BLUE LED** of the Wingman XE will be permanently on.

Button Remap Settings

The following instructions are based on the Xbox One controller. For those using an Xbox 360 controller, please refer to the **Corresponding Buttons List for PS4, Xbox360 and Xbox One Game Pads**.

Button Remap Settings

Buttons that can be Remap include: A, B, X, Y, LB, RB, LT, RT, LSB, RSB 10 (hereinafter referred to as FK)

Step 1. Enter setting mode:

Press MENU + Xbox Guide, the **RED LED** of the Wingman XE will be permanently on.

Step 2. Choosing a FK button: (e.g. Setting X as A+B) Press X

Step 3. Choosing button to be set:

Hold VIEW, then press A + B.

Step 4. Completing setting mode:

Release all buttons, then press MENU to save settings.

Step 5. Exit setting mode:

Press Xbox Guide, the **BLUE LED** of the Wingman XE will be permanently on.

Cancelling Button Remap Settings

Step 1. Enter setting mode:

Press MENU + Xbox Guide, the **RED LED** of the Wingman XE will be permanently on.

Step 2. Erasing all settings for Button Remap Settings.

Press VIEW + MENU.

Step 3. Exit setting mode:

Press Xbox Guide, the **BLUE LED** of the Wingman XE will be permanently on.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Ambient Operating Temperature0°C to +50°C

FCC ID: 2ADKM005A

P/N: Wingman XE
M/N: ZPP005A, ZPP005C, ZPP005D, ZPP005F

For more details please visit our official website at www.brookaccessory.com

202006V2

WINGMAN
CONVERTER

XE

X360, X1, Xbox Elite 1, Xbox Elite 2

→

PS4


透過 USB 介面連接 PS4 或 PC 主機。

LED按鍵

LED按鍵

連接 Xbox 360 / Xbox One 有線手把即可使用，同時也支援 Xbox 360 / Xbox One 相關週邊裝置。

每個 Wingman XE 一次僅能對應一支 Xbox 360 / Xbox One 裝置。Wingman XE 支援大多數符合原廠規格之相容配件，並不定時藉由韌體更新擴充支援清單。



LED	
燈 號	狀 態
藍色 LED 恆亮	轉接器與裝置連線工作中
藍色 LED 慢速閃爍 (兩秒閃一次)	有線裝置未接續、無線裝置連線搜尋中
藍色 LED 快速閃爍	無線註冊模式啟動、搜尋配对裝置中
紅色 LED 閃爍	Turbo-Remap 功能鍵被按下
紅色 LED 恆亮	進入Turbo-Remap 設定模式

連線使用

step.1

將 Wingman XE 連接到 PS4 主機的 USB 連接埠，當 藍色 LED 慢速閃爍即代表與主機連線成功。

step.2

有線連接：
將 X360/X1 有線手把或大搖台以 USB 線連接至 Wingman XE 即可使用。

無線連接：
將 Xbox One 無線遊戲接收器與 Wingman XE 透過 USB 介面連接即可使用。

無線連接：
將 Xbox One 無線控制器（藍芽規格）或 Xbox One 菁英手把二代與 Wingman XE 進行無線配对連線後即可使用。配对時需按壓 Wingman XE 兩側的 LED 按鍵1秒鐘以進入無線配对狀態，並按下無線控制器上的無線註冊鍵以進行配对。此時呈現藍色 LED 快速閃爍狀態。

無線註冊鍵

step.3

確認 Wingman XE 兩側顯示為 藍色 LED 恆亮，即表示遊戲控制器連線完成。

配对補充說明

step.1

按壓 WingmanXE 兩側的 LED 按鍵1秒鐘後會進入無線配对模式，並會對周遭的藍芽裝置進行配对，當發生以下任一狀況時會退出配对模式：
A. 與無線手把配对成功
B. 配对超過一分鐘仍未成功
C. 再次按壓 LED 按鍵 1 秒鐘

step.2

若使用 Xbox One 無線控制器（藍芽規格）或 Xbox One 菁英手把二代與 Wingman XE 進行無線配对後，若改為有線連接，將導致控制器本身的無線配对紀錄被清除。再次以無線連線方式使用時，需重新進行無線配对。

step.3

若使用 Xbox One 菁英手把二代，請關閉手把的 Profile 設置，以避免與 Wingman XE 本身的Turbo或 Remap 設置互相干涉。Xbox One 菁英手把一代因沒有關閉 Profile 功能，可能造成 Remap 功能的重疊。

按鍵配置對應表		
PS4, Xbox360, XboxOne 手把		
PS4 手把	Xbox360 手把	XboxOne 手把
D-Pad (U/D/L/R)		
Lx / Ly		
Rx / Ry		
×	A	A
○	B	B
□	X	X
△	Y	Y
L1	LB	LB
R1	RB	RB
L2	LT	LT
R2	RT	RT
L3	LSB	LSB
R3	RSB	RSB
OPTIONS	START	MENU
SHARE	BACK+ START	VIEW+ MENU
PS 鍵	Xbox 鍵	Xbox 鍵
觸控板鍵	BACK	VIEW

觸控板模擬功能

使用 Xbox 360 控制器：

Back 按鍵加上右搖桿可模擬 PS4 的觸控板按鍵。

Back 按鍵加上 START 按鍵可模擬 PS4 SHARE 按鍵。

2

1

Xbox 360

=

PS4

Hold the R Stick to the left, then press BACK.

2

1

Xbox 360

=

PS4

Hold the R Stick to the right, then press BACK.

1

2

Xbox 360

=

PS4

Press BACK.

1

2

Xbox 360

=

PS4

Hold the BACK, then press START.

觸控板模擬功能

使用 Xbox One 控制器：

VIEW按鍵加上右搖桿可模擬PS4的觸控板按鍵。

VIEW按鍵加上MENU按鈕可模擬PS4 SHARE按鍵。

2

1

Xbox One

=

PS4

Hold the R Stick to the left, then press VIEW.

2

1

Xbox One

=

PS4

Hold the R Stick to the right, then press VIEW.

1

2

Xbox One

=

PS4

Press VIEW.

1

2

Xbox One

=

PS4

Hold the VIEW, then press MENU

連射功能設定

以下說明使用 Xbox One 控制器為範例，使用 Xbox 360 控制器請參照按鍵配置對應表。

連射功能設定

允許設定連射功能的按鍵包括：A、B、X、Y、LB、RB、LT、RT、LSB、RSB 10個按鍵（以下稱為FK）。

Step 1. 進入設置模式：

按 VIEW + Xbox Guide 鍵，Wingman XE 將顯示 紅色 LED 恆亮。

Step 2. 選擇 FK 按鍵: (例如，A 設置 Turbo 功能)

按住 VIEW，然後按 A。

Step 3. 完成設置模式：

釋放所有按鍵，然後按 MENU 儲存設定。

Step 4. 退出設置模式：

按 Xbox Guide 鍵，Wingman XE 將顯示 藍色 LED 恆亮。

取消連射功能

Step 1. 進入設置模式：

按 VIEW + Xbox Guide 鍵，Wingman XE 將顯示 紅色 LED 恆亮。

Step 2. 清除所有 Turbo 功能按鍵：

按 VIEW + MENU 鍵。

Step 3. 退出設置模式：

按 Xbox Guide 鍵，Wingman XE 將顯示 藍色 LED 恆亮。

重新分配設定

以下說明使用 Xbox One 控制器為範例，使用 Xbox 360 控制器請參照按鍵配置對應表。

重新分配設置

允許重新分配設置的按鍵包括：A、B、X、Y、LB、RB、LT、RT、LSB、RSB 10個按鍵（以下稱為FK）。

Step 1. 進入設置模式：

按 MENU + Xbox Guide 鍵，Wingman XE 將顯示 紅色 LED 恆亮。

Step 2. 選擇 FK 按鍵: (例如，X 做 A + B 功能)

按 X 鍵。

Step 3. 選擇重新分配按鍵：

按住 VIEW，然後按 A + B 鍵。

Step 4. 完成設置模式：

釋放所有按鍵，然後按 MENU 儲存設定。

Step 5. 退出設置模式：

按 Xbox Guide 鍵，Wingman XE 將顯示 藍色 LED 恆亮。

取消重新分配

Step 1. 進入設置模式：

按 MENU + Xbox Guide 鍵，Wingman XE 將顯示 紅色 LED 恆亮。

Step 2. 清除所有重新分配按鍵的設定：

按 VIEW + MENU 鍵。

Step 3. 退出設置模式：

按 Xbox Guide 鍵，Wingman XE 將顯示 藍色 LED 恆亮。

低功率電波輻射性電機管理辦法

第十二條

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

P/N: Wingman XE

M/N: ZPP005A, ZPP005C, ZPP005D, ZPP005F

更多詳細操作請上 Brook 官網查詢

www.brookaccessory.com

202006V2

7

8

9

10

11

12

WINGMAN
CONVERTER

PS4

X360, X1, Xbox Elite 1, Xbox Elite 2

PS4

透过 USB 介面连接
PS4 或 PC 主机。

LED 按键

连接 Xbox 360 / Xbox One 有线手柄即可
使用，同时也支援 Xbox 360 / Xbox One
相关周边装置。

· 每个Wingman XE 一次仅能对应一支 Xbox 360 / Xbox One
装置。Wingman XE 支援大多数符合原厂规格之兼容配件，
并不定时藉由韧体更新扩充支援清单。

LED	
灯 号	状 态
蓝色 LED 恒亮	转接器与装置 联机工作中
蓝色 LED 慢速闪烁 (两秒闪一次)	有线装置未接续、 无线装置联机搜寻中
蓝色 LED 快速闪烁	无线注册模式启动、 搜寻配对装置中。
红色 LED 闪烁	Turbo-Remap 功能键被按下
红色 LED 恒亮	进入Turbo-Remap 设定模式

联机使用

step.1

将 Wingman XE 连接到 PS4 主机 的 USB 端口，当 蓝色 LED 慢速闪烁即代表与主机联机成功。

step.2

有线连接：
将 X360/X1 有线手柄或大摇台以 USB 线连接至 Wingman XE 即可使用。

使用X360无线手柄：
将X360无线游戏接收器与 Wingman XE 透过 USB 接口连接即可使用。

无线连接：
将 Xbox One 无线控制器（蓝芽规格）或 Xbox One 菁英手柄二代与 Wingman XE 进行无线配对联机後即可使用。配对时需按压 Wingman XE 两侧的 LED 按键1秒钟以进入无线配对状态，并按下无线控制器上的无线注册键以进行配对。此时呈现蓝色 LED 快速闪烁状态。

step.3

确认 Wingman XE 两侧显示为 蓝色 LED 恒亮，即表示游戏控制器联机完成。

配对补充说明

step.1

按压 WingmanXE 两侧的 LED 按键1秒钟後会进入无线配对模式，并会对周遭的蓝芽装置进行配对，当发生以下任一状况时会退出配对模式：
A. 与无线手柄配对成功
B. 配对超过一分钟仍未成功
C. 再次按压 LED 按键 1 秒钟

step.2

使用 Xbox One 无线控制器（蓝芽规格）或 Xbox One 菁英手柄二代与 Wingman XE 进行无线配对后，若改为有线连接，将导致控制器本身的无线配对纪录被清除。再次以无线联机方式使用时，需重新进行无线配对。

step.3

若使用 Xbox One 菁英手柄二代，请关闭手柄的 Profile 设置，以避免与 Wingman XE 本身的Turbo或 Remap 设置互相干涉。Xbox One 菁英手柄一代因没有关闭 Profile 功能，可能造成 Remap 功能的重迭。

按键配置对应表		
PS4, Xbox360, XboxOne 手柄		
PS4 手柄	Xbox360 手柄	XboxOne 手柄
D-Pad (U/D/L/R)		
Lx / Ly		
Rx / Ry		
×	A	A
○	B	B
□	X	X
△	Y	Y
L1	LB	LB
R1	RB	RB
L2	LT	LT
R2	RT	RT
L3	LSB	LSB
R3	RSB	RSB
OPTIONS	START	MENU
SHARE	BACK+ START	VIEW+ MENU
PS 键	Xbox 键	Xbox 键
触控板键	BACK	VIEW

触控板模拟功能

使用Xbox 360 控制器：

Back 按键加上右摇杆可模拟 PS4 的触控板按键。

Back 按键加上 START 按键可模拟 PS4 SHARE 按键。

2

1

Xbox 360

=

PS4

Hold the R Stick to the left, then press BACK.

2

1

Xbox 360

=

PS4

Hold the R Stick to the right, then press BACK.

PS4

Press BACK.

1

2

Xbox 360

=

PS4

Hold the BACK, then press START.

触控板模拟功能

使用Xbox One 控制器：

VIEW按键加上右摇杆可模拟PS4的触控板按键。

VIEW按键加上MENU按钮可模拟PS4 SHARE按键。

2

1

Xbox One

=

PS4

Hold the R Stick to the left, then press VIEW.

2

1

Xbox One

=

PS4

Hold the R Stick to the right, then press VIEW.

PS4

Press VIEW.

1

2

Xbox One

=

PS4

Hold the VIEW, then press MENU

连射功能设定

以下说明使用 Xbox One 控制器为范例，使用 Xbox 360 控制器请参照按键配置对应表。

连射功能设定

允许设定连射功能的按键包括：A、B、X、Y、LB、RB、LT、RT、LSB、RSB 10个按键（以下称为FK）。

Step 1.

进入设置模式：
按 VIEW + Xbox Guide 键，Wingman XE 将显示 红色 LED 恒亮。

Step 2.

选择 FK 按键:(例如，A 设置 Turbo 功能)
按住 VIEW，然後按 A。

Step 3.

完成设置模式：
释放所有按键，然後按 MENU 储存设定。

Step 4.

退出设置模式：
按 Xbox Guide 键，Wingman XE 将显示 蓝色 LED 恒亮。

取消连射功能

Step 1.

进入设置模式：
按 VIEW + Xbox Guide 键，Wingman XE 将显示 红色 LED 恒亮。

Step 2.

清除所有 Turbo 功能按键：
按 VIEW + MENU 键。

Step 3.

退出设置模式：
按 Xbox Guide 键，Wingman XE 将显示 蓝色 LED 恒亮。

重新分配设定

以下说明使用 Xbox One 控制器为范例，使用 Xbox 360 控制器请参照按键配置对应表。

重新分配设置

允许重新分配设置的按键包括：A、B、X、Y、LB、RB、LT、RT、LSB、RSB 10个按键（以下称为FK）。

Step 1.

进入设置模式：
按 MENU + Xbox Guide 键，Wingman XE 将显示 红色 LED 恒亮。

Step 2.

选择 FK 按键:(例如，X 做 A + B 功能)
按 X 键。

Step 3.

选择重新分配按键：
按住 VIEW，然後按 A + B 键。

Step 4.

完成设置模式：
释放所有按键，然後按 MENU 储存设定。

Step 5.

退出设置模式：
按 Xbox Guide 键，Wingman XE 将显示 蓝色LED 恒亮。

取消重新分配

Step 1.

进入设置模式：
按 MENU + Xbox Guide 键，Wingman XE 将显示 红色 LED 恒亮。

Step 2.

清除所有重新分配按键的设定：
按 VIEW + MENU 键。

Step 3.

退出设置模式：
按 Xbox Guide 键，Wingman XE 将显示 蓝色 LED 恒亮。

P/N: Wingman XE
M/N: ZPP005A, ZPP005C, ZPP005D, ZPP005F

更多详细操作请上 Brook 官网查询
www.brookaccessory.com

202006V2