**Precisión**
Tarjeta SIM: Tarjeta SIM estándar (2FF)
Pantalla: 2.4" QVGA, 240 x 320 píxeles, 262K colores
Cámara: Cámara trasera de 0.3MP
Memoria: Ranura para tarjeta microSD (TransFlash), admite tarjetas de hasta 32GB
Batería: Batería de litio recargable de 1000mAh
Conectividad: Bluetooth 3.0
Radio FM: Radio FM estéreo con antena integrada
Idiomas: Admite varios idiomas, incluido el español
Características adicionales: Linterna, alarma, calculadora, calendario, grabadora de voz, altavoz manos libres
Compatibilidad: Compatible con redes GSM 2G en la banda de 900/1800MHz
Dimensiones: Aproximadamente 115 x 50 x 15 mm
Peso: Aproximadamente 100 gramos
Contenido del paquete: Teléfono móvil, batería, cargador, manual de usuario, auriculares (según el modelo)
Garantía: Consulte los términos de garantía específicos proporcionados por el fabricante o el vendedor
Compatibilidad de accesorios: Compatible con una variedad de accesorios estándar, como cargadores, auriculares y fundas
Actualizaciones de software: Posibilidad de actualizaciones de software para mejorar el rendimiento y agregar nuevas funciones
Soporte técnico: Disponible a través del fabricante o del vendedor
Disponibilidad: Disponible en tiendas minoristas y en línea
Precio: Precio competitivo en el momento del lanzamiento
Opciones de color: Varias opciones de color disponibles
Fecha de lanzamiento: Lanzado en el mercado en [fecha de lanzamiento]

1. **Introducción**
**-Contenido**
Gracias por comprar nuestro teléfono, puede convertir esa vieja pantalla en algo nuevo y brillante con un mínimo de esfuerzo. Lo convertiremos original en 100%.
**-Instrucciones para SIM y batería**
Presione la ranura de la tarjeta SIM y desconecte el cargador antes de retirarse la batería.
**-Encender y apagar**
Presione la tecla de "encendido" para encender o apagar el dispositivo. Luego se le indica que ingrese su PIN y PUK. Por favor ingrese la contraseña requerida (dentro) y verifíquela tal como está.
**-Antena**
Antena integrada: evite interferencias con antena interna o separada. El ajuste con otros dispositivos transmisores, no toque la antena de ocupar recursos, ya que esto podría afectar la calidad de la comunicación y resultar en consumo de energía mayores a los requeridos, reduciendo así el tiempo de llamada.
2. **Método de ingreso**
Ingresa los de teléfono y el método de ingreso de texto disponible.
3. **Llamada**
Puede ajustar la vía manos de las conexiones mejorando nombres y números de teléfono en la libreta. La cantidad almacenada de entradas en la tarjeta SIM depende del tipo de tarjeta.
4. **Mensajes**
**-SMS**
El teléfono puede enviar y recibir mensajes SMS. Puede recibir la cantidad de mensajes almacenados en la tarjeta SIM según su configuración.
**-Enviar mensaje** Puede seleccionar enviar el mensaje ingresando desde SIM 1 o SIM 2. Puede elegir cómo ingresar los cuando desea enviar mensajes a más de 1 persona.
**-Recibir mensaje** Puede seleccionar este opción para recibir el SMS de la tarjeta SIM 1 o 2. Aquí puede editar el número de buzón de la tarjeta SIM cuando se visualiza con el proveedor de servicios.
5. **Cámara**
**-Aspecto de Seguridad**
Puede establecer funciones de relación con la seguridad de su teléfono. (Clave: 1234)
**-Restaurar configuración de fábrica**
Ingrese el código correcto en el teléfono para restablecer la configuración original del teléfono. Esta debe ser realizada correctamente. (Clave original: 1234)
6. **Juegos**
**-Opción de notas**
Esta opción está relacionada al procedimiento de notas. Favor contactar al mismo para realizar esta tarea de ajustes.



**-Modo avión** No están permitidas las comunicaciones en este modo.
**-Modo dormir**
Puede elegir cuando no quiere sonidos o de para selectivo, SMS o no SMS y en modo avión.
7. **SIM**
**-Configuración de Llamada**
Puede navegar en Menú de Llamada en Mi Cuenta para ajustes que puede navegar en cualquier momento. Para más información, comuníquese con el proveedor de servicios de red.
8. **Grabadora de Video**
Con esta opción, puede elegir la composición de la cámara, entre cuadrado, tableta o de pantalla.
9. **Cámara**
En las opciones de la cámara, puede establecer el modo de fotografía entre otros. Puede agregar efectos para mejorar las formas que utiliza el teléfono.
10. **Reproductor de Video**
El reproductor de medios reproduce archivos reconocibles como mostrarlo en la lista actual.
11. **Reproductor de Video/ Modo de imágenes**
Puede ajustar el modo de imagen para mejorar los ingresos reconocibles por el equipo.
12. **Administrador de Archivos**
Para la tarjeta de memoria, puede seleccionar una para copiar para o entrar la tarjeta.
13. **Administrador de Tareas**
El historial de llamadas conecta un mensaje a la llamada realizada, recibida, perdida y enviada. También puede establecer para alternativa por separado según su ubicación.
14. **Calculadora**
Ingresar la contraseña del. Puede intentar un actual manualmente.
15. **Grabadora**
Puede ajustar el modo para grabar o escuchar sonidos grabados.
16. **Conexión**
Utilice y establezca el punto de acceso GPRS.
17. **Bluetooth**
Puede establecer el nombre predeterminado por el proveedor de red.
18. **Alarma**
Establezca el tiempo de la alarma. En el momento indicado por alerta para que suenar, se puede establecer diferentes según sus configuraciones.
19. **Bluetooth**
Puede establecer las conexiones inalámbricas con otros dispositivos compatibles con esta función.
20. **Conectar a PC**
**-Almacenamiento masivo**
Modo USB Flash: Insertamos en el teléfono como disco de almacenamiento.
21. **Linterna**
Puede encender la linterna.
22. **Configuración**
Contraste de pantalla para verificar fecha.
23. **Calculadora**
Aplicación de calculadora para realizar operaciones matemáticas simples.



24. **SOS**
Activación para SOS.
25. **Escritorio original**
Reflexiona el distribuidor de accesorios cool. Aquí se incluyen algunas precauciones para el uso de los accesorios.
Mantenga el cargador lejos del alcance de los niños.
Mantenga presente en el corredor cuando desconectar de la fuente de poder, en vez de de solo tirar el cable.
Revise con regularidad los equipos móviles con este cable para verificar que estén funcionando correctamente. Si no lo hacen, llévelos a un centro de servicio calificado.
Solo un técnico, suspenden y asumen no operación por el fabricante. Uso en otro tipo de accesorios puede invalidar una anulación de la garantía y el fabricante debido.
26. **Cuidado y mantenimiento de la batería**
La batería y cargador son partes clave del funcionamiento de un teléfono al garantizar su funcionamiento regular so cuenta su seguridad. Se facilitan así con nuestra investigación de cuidado y mantenimiento de la batería y cargador para ayudarle a prolongar la vida útil de la batería.
Utilizar a accesorios de otras marcas definitivamente que producen fallas en el equipo, un material letal y cargador.
27. **Información importante sobre de seguridad y la batería inalámbrica**
Evite la pila de la batería a extremo más cerca a su tiempo de duración de carga de la batería. Durante la vida del teléfono inalámbrico. El cargar inmediato ahora la operación normal de las baterías inalámbricas.
El mantenimiento y confiabilidad del equipo a pueden ser comprometidos todos dentro la calidad de sonido y vida útil más susceptible.
Las baterías deben ser almacenadas a medianos y por cerca para un peligro de seguridad por el consumidor.
28. **Acerca de la batería**
**-Carga y descarga**
La batería recargable se usa para el equipo. La batería puede ser cargada y descargada como cualquier otra batería. Cuando la batería se agota, se puede cargar y descargar cientos de veces. Sumadas acumulada. Inadvertencia, hasta reemplazar la batería. Si la batería es reemplazada y utilizada por primera vez, la batería ha sido maximizada por muchas horas en ahorro, puede ser necesario cargar y descargar la batería durante varios ciclos para lograr su máximo rendimiento. Cuando el cargador no está en uso, favor desconecta esta corriente eléctrica. Si la batería no queda sin electricidad, puede tener que esperar unos cuantos minutos a que el símbolo de carga en pantalla en la pantalla y luego puede contestar cualquier llamada.
No use la batería para otros propósitos. No use baterías o cargadores dañerizados.



**-Uso y vida de la batería**
Evite el sobrecalentamiento de la batería, de otra manera, la batería puede sufrir daños y generar calor a peligro de incendio.
No coloque la batería en altas temperatura o en lugar, de la cocina, puede explotar.
No intente desarmar la batería.
Entregue el uso de vida útil la detención de la batería a cargador.
Reemplace siempre cuidar y desechelas de la manera y lugar de recuperación apropiados. No deben desecharse como basura doméstica.
29. **Mantenimiento a servicio**
Su equipo es un producto de diseño y proceso esquisito, favor usar con cuidado. A continuación, recomendar una serie de sugerencias para su ayuda mantenimiento óptimo:
1. Mantenga seco. El lluvia del lluvia, humedad y otros líquidos pueden contener materias minerales, los que pueden provocar oxidación eléctrica. Si el equipo se humedece, favor retirar la batería inmediatamente y secarlo.
2. No use o almacene en lugares sucios o sucios, de lo contrario, las partes removibles del equipo y elementos y [illegible] pueden sufrir daños.
3. No lo coloque en lugares calurosos.
4. No mantenga el equipo en lugares frías, de otra manera, cuando la temperatura se normaliza, se genera humedad la cual daña los circuitos.
5. No deje caer, golpee o sacuda el equipo bruscamente [illegible].
6. No limpie a usando solventes químicos fuertes, detergentes concentrados.
7. No pinte el equipo. La pintura puede bloquear substancias extrañas en partes removibles, y afectar la operación normal.
8. Utilice el teléfono con un paño limpio y suave (por ejemplo, [illegible] limpia lentes) en vez de cepa o [illegible].
9. Solo use una antena aprobada para su uso. Una defiada. Antenas no aprobadas pueden resultar en daños permanentes a los circuitos.
10. Favor, use el equipo con una toma corriente.
11. Los elementos de respaldo debe ser almacenada.
12. Se recomienda que el usuario respalde los datos para restaurar el equipo a su funcionamiento normal [illegible] en caso de fallas.
13. Los siguientes artículos aplican para el cargador y la batería, los casos de funcionamiento ninguna favor diseñe técnica sobre [illegible] estándares.



Model: GO

RAYO
MOVIL

WWW.RAYOMOVIL.COM

## FCC Caution

**Labelling requirements.**
This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.
Model: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.
**Specific Absorption Rate (SAR) information:**
This model phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.
FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Portable Equipment (FCC ID:2ACJA9VCOGO) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the head is 0.66 W/kg and when properly worn on the body is 0.03 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that does not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

**Body-worn Operation**
This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

**Declaration**
Please read the user's manual to keep your mobile phone in the best condition. The manual has been carefully reviewed and tested. The information in the manual is based on the model specifications at the time of publication. However, mobile phones also feature software, and the contents of their manuals are subject to modifications without further notification. Our company reserves the right to revise in the manual.

1. **Introduction**
**Contents**
**Phone password**
With the phone powered, you can insert others from using your mobile phone without your permission. The default password is 1234.
- **Insert the sim card and the battery**
Ensure to turn off the equipment and disconnect with the charger before taking out the batteries.
2. **Input methods**
Press the required power supply to dial up or shut down the mobile phone.
If it is necessary to input PIN or PIN2, please input the required password (shown as **** ) as the screen.
3. **Menu**
- **Antenna**
The mobile phone may be provided with built-in and exposed antenna, but like using any other radio and transmitting devices, don't touch the antenna more than necessary because it may affect the quality of telecommunication and result in equipment operating in an energy level higher than required, thus shortening the service life of the battery.
4. **Input methods**
Select to be sure to change one of Input Methods.
5. **Call**
You may save the information of contacts to My names & telephone numbers in the phone book. The storable entries of sim card depend on the type of the card.
6. **Messages**
- **SMS**
The cell phone supports sending of and receiving of SMS. You may check the quantities of sort messages stored in the SIM card according to your subscription.
- **Write a message** You may select multiple receivers to send the message to more than 1 person with setting. You may select to edit the SMS setting either of SIM card 1 or 2, whom, you can edit the number of the service center (which is obtained from the service provider).
7. **Settings**
- **General**
**Restore factory setting**
[illegible]
8. **Video recorder**
You may set functions in situations to set phone security. (phone lock:1234)
**Restore the factory setting**
Enter the correct password of the phone will time to change your phone settings back to factory default state value, the use of the function be used with caution. (Default password: 1234)



- **Phone**
**Network setting**
The option is related to your network provider. Please get in contact with the network provider for details.
**Digital mode** No communication function is available in flight mode).
**Light mode**
You may select modes of dual standby and single pass, SIM 1 or/SIM 2 in and flight mode.
- **WAP**
You may surf mobile with WAP Browser, which means that you may surf on it at any time and in any place. For details, please get in contact with the network service provider.
- **Video recorder**
In the options of the video camera, you may set the exposure compensation, wireless of white balance, color effects, banding, special effects, and the etc.
- **Camera**
In the options of camera, you may set the photometry mode etc. You may enter the album to check the photos taken from the cell phone camera.
- **Audio Player**
The music player is used to play music files in supported by Voice in the current player's list.
- **Video player/ Image viewer**
Check the video or pictures files supported by the cell phone.
11. **File manager**
Via the file management card, you may establish a data file folder etc.
12. **Call history**
The call list lists all types of calls, including received ones, dialed ones and unanswered ones, so you can easily [illegible] the respond ★ to of missed calls, dial [illegible] and answer to call by check or operation.
13. **File Radio**
The radio can be broadcast, and you may manually tune the channel.
14. **Recorder**
Use this function you can record or listen to your own record.
15. **Calculator**
Add and set the GPRS access point
Note: The "account data" is to be provided by the network operator.
16. **Alarm**
Set the time of alarm clock, At the time of alarm clock, an alarm ring will be given as the the calling.
17. **Bluetooth**
You may establish wireless connection with other compatible devices with the Bluetooth technology.
18. **Connect to PC**
- **Mass storage**
Use the T-Flash inserted in the mobile phone as U-Disk.



19. **Lamp**
Set the flashlight lamp function.
20. **Calendar**
Support Calendar function.
21. **Calculator**
Support Calculator functions.
22. **SOS**
Support SOS function.
23. **Original Accessories**
Please use the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories.
1). Please keep the accessories be out of children's reach.
2). When you disconnect the power cord from the power overtaken out off the power supply.
3). Regularly check the mobile equipment in the accessible to see whether they are correctly installed and without wear to control.
4). Please use only the battery and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in voidance of the certification or warranties terms or even lead to danger.
5). Do not short-circuit the battery. (Metal objects)
Battery and charger are key parts of a mobile part because they play important roles in guaranteeing the normal operation of the mobile phone as well as your safety. It is chosen in our investigation to maintain the battery and charger to help you prolong the service life of the battery.
Non-usage of non-eligible accessories, especially ineligible battery and charger
Caused resulting from usage of ineligible battery and charger
The maintenance and reliability of the equipment [illegible] may more or fewer than that.
Batteries should be stored in a place with the safe limits of battery. Inexperienced users must not carry out the disassembly of the battery.
6). Recover the service life of the mobile phone: Longer, Unneeded will not affect the normal operation of the mobile phone and standby time.
7). Affect the performance and reliability of the mobile phone, reducing the voice quality and being accessible to human capital.
8). Avoid the battery from explosion and thus endanger the personal safety of the customers.
24. **About the battery**
- **Charging and discharging**
The rechargeable battery is used for the equipment. The battery may be charged and discharged for several hundreds of times and finally will be obsolete. In case the standby time and call duration shorten obviously, please replace the battery. If the battery is replaced and used for the first time, or if it has been stored for a long time, it may be necessary to charge and discharge it with the charger, disconnect and then reconnect in order to charge the battery. When the charger is not used, please disconnect with the equipment and plug it out from the power socket.
If the battery runs out of electricity, you may have to wait for a few minutes till the symbol of charging is shown on the screen, and then you can make and answer any call.
Don't use the battery for any other purpose. Don't use any damaged charger or battery.



- **Usage and treatment of battery**
Avoid short circuit of battery otherwise, the battery may be damaged, and generate heat to cause fire hazard.
Don't charge the battery under high temperature or in fire otherwise, it may explode.
Don't attempt to take apart the battery.
Stop usage in case of damage or obvious aging of battery and charger.
Don't use the battery for purposes except or specified manufacturers also.
Don't store it where in domestic garbage.
25. **Maintenance and service**
Your equipment is a product with exquisite design and process. Please use carefully.
Following are some suggestions for you to effectively use the maintenance service:
1). Keep the equipment dry. Rain, moisture and all types of liquids or water may contain mineral matters, which may erode the electronic series. If the equipment is wetted, please take out of the battery till the equipment is totally dried and interrupt in the battery.
2). Don't use or store the equipment in dusty or filthy places, otherwise, the detachable parts and electronic antenna may be damaged.
3). Don't store the equipment in overheated places.
4). Don't keep the equipment in under cooled places, otherwise, when the temperature rises to warmed, moisture may be generated within the equipment, resulting in damage of the circuit boards.
5). Please open the equipment as per the descriptions in the manual. Don't try any other means.
6). Don't throw, knock or shake the equipment. Any rough treatment of the equipment may result in damage of the inner circuit board and its exquisite mechanics.
7). Don't clean the equipment with ardent chemicals detergent or strong wash.
8). Don't paint the equipment. Paining may block foreign substances in detached parts and thus affect the normal operations.
9). Close the lens with clean, dry soft cloth (such as the camera lens, range sensor and light sensor).
10). Only use marketed or approved antenna for substation of the damaged one. Unapproved antenna, alteration or accessories may result in damage of the equipment and violence of regulations concerning radio equipment.
11). Please use the charger in indoor area.
12). Backup data that should be kept (such as the address-list and calendar memorandum).
13). Please turn off the equipment and take out the battery to isolate the equipment setting in regular to maintain the optimal performance.
14). In case of any problem with your equipment, batteries, charger and other accessories. In case any device doesn't work, please take it to the nearest authorized maintenance agency for repair.