SMART WATCH

Operation Manual
HY-CAMW

Thank you for purchasing the Hope Smart Watch. Please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS
- Smart Watch with Built-in Camera
- USB Charging Cable
- Operation Manual

KEY FEATURES
- 0.66inch Built-in Camera
- Pho music wireless
- Hands-free call
- Rechargeable lithium-ion battery
- Built-in microphone and speaker

SAFETY INSTRUCTIONS
Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, dirt, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.

This product is not a toy. Keep out of reach of children.

Do not expose batteries, battery pack, or batteries to be installed to excessive heat, such as direct sunlight, or open flame.

SMART WATCH FEATURES

PRODUCT FEATURES
1. Touch Screen
2. Power / End Call
3. Adjustable Silicone Wrist Strap
4. Speaker
5. Micro USB Charging Port
6. Microphone
7. Return / Home Button

COMPATIBILITY

Please note, some features of your smart watch are only available for specific devices.

At the top of each section of the manuals compatibility is shown using the two icons below.

Only available for Android devices.

Available for Android and Apple devices.

Only available for Apple devices.

BLUETOOTH PAIRING

Make sure your smart watch is turned on and is fully charged.
Make sure Bluetooth is enabled on your smart phone or tablet and your device is discoverable.

NOTE: Android users should download and use "Camera Hands Camera" App prior to pairing with Bluetooth. See "Settings / QR Code" for installation details before pairing.

Press the Bluetooth Icon on your home screen to enter Bluetooth settings screen.

Press and hold the screen of your watch when the pairing clock is showing to unlock your Smart Watch and return to your Home Screen.

In the Bluetooth settings for your smart phone or tablet, search for nearby devices and find your watch.

If should appear as "HY-CAMW"
Select it to begin pairing.

On your smart watch, press "My device", "Search new devices..." and select your device in the next screen.

Your smart watch will send a pairing code to your phone. Make sure the codes match on your smart watch and on your device screen.

Press "Yes" on your smart watch to complete pairing.

Press "Pair" from your smart phone or tablet.

Press "Yes" on the bottom left to complete pairing.

NOTE: For Android users, after pairing with Bluetooth, your smart watch will ask you to sync date and time.

Press "Yes" on your screen on the lower left to synchronize date and time.

Your watch should confirm with "Success".

Pairing is now complete. If you are unsuccessful, press the "Return" key on the home of your smart watch to repeat the pairing process.

To restart the pairing process, you will first need to turn off "Visibility" and turn off Bluetooth "Power" first. Then turn Bluetooth off on your device and begin from the first step of this section.

To switch to another smart phone or tablet, return to the "My device" page and select your tablet or smart phone from that page. You may need to disconnect and delete paired devices before attempting to switch between paired devices.

BT NOTICE

Press the BT notification on your home screen to enter and customize your notifications.

This App can only be used on smart watches paired with Android devices.

Before using, please download the "Funda Companion" App. See "Settings / QR Code" for installation details.

Push notifications set on your phone will appear as a short preview on your smart watch. An incoming message is shown as an example below.

Scroll down on your touch screen to see time and date of notification. Press the "Scroll" button on your watch frame to view additional messages or to view more than one notification.

1. Notification At Front of Notifications
2. Messaging App Icon
3. Contact Name
4. Message Preview
5. Notification Date
6. Notification Time

BT Notice will send push notifications to your smart watch from your Android phone from all compatible Apps on your Android that are set for push notifications.

Some compatible BT notice Apps are listed below:

- SMS Messaging
- What's App
- Message +
- Gmail

NOTE: Open source App compatibility with "BT notice" may vary based on software design and are subject to change without notice.

Hope™ is not responsible for software updates and software compatibility made by third party software developers on the Android platforms or on the App Store.

When you are reading your Notifications, press the "Return" button on your watch frame to return to your App menu screen.

MESSAGES

Press the Messages Icon on your home screen to enter Messages and received messages.

The App can only be used on smart watches paired with Android devices.

Before using, please download the "Funda Companion" App. See "Settings / QR Code" for installation details.

Your smart watch will sync with SMS Messages on your phone to show your Inbox and Sent Messages.

Select the Inbox you would like to access. Scroll down to access the Inbox. Select an entry on the list to see message details and message body.

The date and time of the message will appear at the top of the message body.

Scroll down to read the full message.

When you're done reading your messages, press the "Return" button on your watch frame to return to your Inbox.

Press the "Return" button again to return to your messaging folder.

When you are reading your messages, press the "Return" button on your watch frame to return to your App menu screen.

VOLUME

Press the Volume Icon on your home screen to adjust alarm and music volume.

On the next screen, use the "+" or "-" buttons on your touch screen to adjust volume.

These buttons will control the volume of your music if you are connected to your smart watch.
See "Bluetooth music" section for more information.

BT Music

If you are not connected to "Bluetooth Music," these buttons will adjust the volume of your notification and alarm volume.

If you do not press the "+" or "-" button on this screen for 3 seconds, the smart watch will automatically return to your home screen.

MENU LIST

Press the Menu Icon on your home screen to see your available smart watch Apps.

Your smart watch will begin displaying available Apps.

If you are looking for a specific App but do not see it on your screen, swipe left or right on your touch screen to see additional Apps.

At any time while using Apps, press the "Return" key to return to the previous screen.

Eventually, you will be taken back to the home page.

SETTINGS

Press the Settings Icon on your home screen to adjust settings on your smart watch.

SETTINGS QR code

"Quick Response Code" will display the Setup QR code.

Please note, this QR code is to be used for quick setup and pairing of your smart watch with your smart phone or tablet.

This feature is only available on Android devices.

Using your Android smart phone, scan the QR code from your smart watch screen. Follow the on screen instructions to download the quick sync messages, push notifications, and date and time.

Install the downloaded App and have it ready and running on your Android device before Bluetooth pairing.

SETTINGS Time/Date

"Time and date" will allow you to set the time and date.

Press the "Return" key on your watch frame to return to the previous page.

Select "Set home city" to view the list of cities.

Scroll through the list by swiping your finger upwards on your watch touch screen or press the number buttons to name on the touch screen of your watch.

Select "Date settings" to put in the current date.

A dial will appear to let you indicate the current date. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the numbers.

Press the "OK" to confirm the date, press "Back" to exit without saving the date.

A dial will appear to let you indicate your alarm time. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.

Press "OK" to confirm the time, press "Back" to exit without saving the time.

Select "Set format" to set your digital clock to show time in the standard 12-hour format, or the 24-hour military format.

Press the left or right arrows to cycle through "12" or "24." Press the "Save" button on the bottom left to confirm your selection.

If you select the 24-hour time format, make sure your time is input in your watch as such in order for Set Time/Date" section.

Select "Update with time zone" to turn the automatic update during Daylight Saving Time on or off.

When Update options are set and shown correctly, press the "OK" key on your watch to confirm the information.

Keep pressing the "Return" key until you return to your "Settings" main screen.

SETTINGS Language

Select "Language" to choose the language shown on your watch from the default settings in English.

Scroll through the list by swiping your finger upwards on your watch touch screen. Find your desired language, and press its name on the touch screen of your watch.

In the example below, "English" is chosen.

When your selection is confirmed, your watch will show you "Done" and take you back to "Settings" main screen.

SETTINGS Display

Select "Display" to adjust your preferences for wallpaper and automatic standby mode.

Select "Wallpaper" to view the background of the home screen. Please note, depending on Smart Watch model, the number of wallpapers available on Smart Watch models will vary. Only one wallpaper device will be available on a preset. It will be a basic clock wallpaper.

Press the "OK" key on your smart watch to confirm the selection, press the back key on your smart watch to go back to the display menu.

Select "Timer standby" to set the timer for standby mode. Choices are between Off, 15 secs, 30 secs, and 1 min. You may need to scroll on your touch screen to see all options.

Keep pressing the "Return" key until you return to your App menu screen.

SETTINGS Common Settings

"Common settings" will allow you to choose your unlock screen, clock type, and automatic standby mode. It will also allow you to adjust backlight settings.

"Unlocking type selection" will allow you to select the type of clock you want your watch to display when your smart watch is in standby mode.

The default setting is "Digital Clock 1". When selecting the other clocks you will have to scroll down on your touch screen for "Digital Clock 1" has.

After you have made your selection, your smart watch will show you that your selection is "Done" and take you back to your Common Settings screen.

"Motion sensor" will allow you to enable different motions to mute the watch when ringing.

When Motion sensor is off, the other options will not display.

Use the left and right arrow keys to turn the motion sensor on or off. More options will display below.

Use the left and right arrow keys to turn the Mute Home feature on or off. This function requires you to flip the watch upside down in order to mute your watch.

Scroll down on the touch screen of the watch to access the next option.

Use the left and right arrow keys to turn "Flip to mute alarm" on or off. This function requires you to flip the watch upside down in order to mute your watch alarm.

When you have finished setting all desired motion sensors, press the "Save" key on your smart watch to return to the "Common settings" menu screen.

SETTINGS Restore Settings

"Restore settings" will allow you to reset all settings on your phone and delete all Bluetooth devices and personal information.
It is best to use this feature if you no longer want your smart watch.

Press the "Yes" button on your watch to begin the restore process.

Your watch should confirm with "Restore processing."

The smart watch will restart and the settings will be restored to the default settings. It will leave you at the home screen.

POWER SAVE

Press the Power Save Icon on your home screen to set or turn off Power Save mode.

Power Save mode will attempt to put your watch on standby as much as possible to conserve battery life.

If Power Save is turned on, the watch will automatically attempt to conserve battery life.

It will override any settings you have entered in the "Settings" menu of your Settings.

Once Power Save is selected, your watch will show you "Entering Power Save."

Press "Back" on the watch screen to return to your App menu screen.

RINGTONE

Press the Ringtone Icon on your home screen to set your ring, or alarm notifications.

Select a ringtone preset to customize how your watch should act when alerting you of notifications.
Select a feature to set the selected preset.

Select the ringtone you want to use. If you want to adjust each ringtone alert sound and tone, ensure it is selected from the list.

Select "Options" to adjust preferences of the chosen Ringtone.

Select "Alert type" to choose how your watch should act when alerting you of notifications.

Select "Ring type" to choose how your watch should ring.

Scroll down on the touch screen of your watch to select your preferred "Ringtone volume."

The smart watch comes preprogrammed with 5 ringtones to choose from. Scroll down to see all 5 options.

Once you select a ringtone, it will appear under "Ringtone."

To preview the other ringtones, click back into the "Ringtone" list and select another ringtone. Wait 2 seconds, and your watch will play a preview of the ringtone.

Scroll down on the touch screen of your watch to select your preferred "Ringtone volume."

On the next screen, use the "+" or "-" buttons on your touch screen to adjust volume.

These buttons will control the volume of your ringtone under the preset you have set. "Active" is the preset in order for it to take effect.

When your Ringtone settings are all to your preferences, press the "Option" on your watch frame. A pop up menu will appear.

Select change ringtone to go back and change these settings. Select save if you wish to save these settings and return to the ringtone menu.

To change or set other presets, repeat the aforementioned steps for desired preset.

ALARM



Press the Alarm Icon on your home screen to set an alarm. Your smart watch can set up to 5 customizable alarms.

Select any alarm time without a check mark next to it to customize alarm settings.

Scroll down on the touch screen of the watch to access the 5th alarm.

Use the left and right arrow keys to turn the alarm on or off.

Press into the time display to set the time of your alarm.

A dial will appear to let you indicate the current date. Press the field you wish to edit and then press the plus or minus symbols to increase or decrease the number.

Press "OK" to confirm your alarm time or press "back" to exit without saving the time.

Scroll down on the touch screen of the watch to continue customizing alarm settings.

Select the box under "Repeat" to choose the days you want your alarm to ring.

"Once" will have your alarm ring only once your watch clock reaches the set alarm time.

"Everyday" will have your alarm ring each time your watch clock reaches the set alarm time.

"Custom" allows you to choose which days of the week you want your alarm to ring.

Select the day of the week you would like your alarm to ring.

A pop-up window will appear to allow you to select "On" or "Off."

Once you have made your selection, press "Done."

CALENDAR

Press the Calendar Icon on your home screen to access your calendar.

The Calendar will immediately bring you to today's date, highlighted in light blue.

Use the left and right arrows on the top of the calendar to scroll to the previous or the following months.

When you are done using your Calendar, press the "Return" button on your watch frame to return to your App menu screen.

PEDOMETER

Press the Pedometer Icon on your home screen to access your pedometer.

Your Pedometer has a built-in timer stop watch.

Press "Start" to start the timer and the step counter.

You can press "Back" if you have not started the timer, and you want to return to your App menu screen.

You can also "Pause" and "Resume" the timer.

If you want to reset the timer and step counter, press the "Reset" button.

The built-in sensor on your smart watch will track your movements and count your steps.

Swipe right on your screen to check your summary page on the second screen. The red dot on the bottom of your Pedometer App indicates which screen you are on.

Your summary pages will show the below information:

Total Number of steps
Total Calories burned
Total Distance (KM)
Heart Rate value (times/ PC)
Total Exercise Time
Mileage Total travelled distance

STOPWATCH

Press the Stopwatch Icon on your home screen to access your stopwatch.

Press the left button to start your stopwatch.

Press it again to pause your stopwatch. The stopwatch will keep going, but the time will freeze for you to read it.

Press the right button to reset your stopwatch.

When you are finished using your Stopwatch, press the "Return" key on the watch frame to return to your App menu screen.

CALLS

Your smart watch will sync with your mobile device to show you a list of Missed Calls, Outbound Calls, Received Calls, or all Call Logs.

Select the list you would like to access. Scroll down to access a list of corresponding calls.

Select an entry on the list to see call details and contact information for the call.

Scroll down to read call details. Press the "Return" button to return to your Call History menu.

When you are finished checking your Call History, press the "Return" key on the watch frame to return to your App menu screen.

BT MUSIC

Press the BT music Icon on your home screen to play music from your smart watch.

Your smart watch will connect to your smart phone or tablet that is playing music. Once it is connected, you can control media from the screen below.

1. Track Name
2. Elapsed Time
3. Remaining Time
4. Screen Volume
5. Increase Volume
6. Previous Track
7. Play/Pause
8. Next Track

When you are finished using your BT Music, press the "Return" key on the watch frame to return to your App menu screen.

CALCULATOR

Press the Calculator Icon on your home screen to access your calculator.

A numeric keypad will appear.
Enter in your desired calculation and press the "=" button to calculate the result.

Press "Clear" to clear your entry.

You can press "Back" to return to your App menu screen.

When you are done using your calculator, you can also press the "Back" button on your watch or the "Return" key on your watch frame to return to your App menu screen.

SLEEP MONITOR

Press the Sleep Monitor Icon on your home screen to monitor your sleep.

A timer will appear. Press "Start" when you are ready to sleep.

You can press "Back" if you have not started the timer, and you want to return to your App menu screen.

You can also "Pause" and "Resume" the timer.

If you want to reset the sleep timer, press the "Reset" button.

Each time you wake, the "Results" section will mark if your sleep habits were good and uninterrupted or bad and constantly interrupted.

If you have reset your Sleep Monitor timer, you can press "Back" to return to your App menu screen.

When you are finished using your Sleep Monitor, press the "Return" button on the watch frame to return to your App menu screen.

PHONE BOOK

Press the Phonebook Icon on your home screen to access your contacts list.

Please note, you will need to disconnect from "BT music" before your smart watch can access your contacts list. If your smart watch is not disconnected, press the Confirm button on the watch frame before proceeding.

Your Phonebook will connect to your phone and show you your contacts list.

The first number is your number. Press it to view details.

Your contact will show be your number. My number is listed below.

Press the "Return" key on your watch frame to go back to your contacts list.

Contacts will be listed in alphabetical order based on first name.

Select any name on the list whose contact you want to view or who you want to call.

In this example, Dawn is selected.

An example of a full contact is shown to the left.

To call your selected contact, select the mobile number.

A pop-up window will appear. Select "OK".

To cancel, press the "Return" key on your watch frame to go back to the contact page.

CAMERA

Press the Camera Icon on your home screen to access the camera feature.

Press "Options" to view and set your photo options.

Select "Photos" to view photos you have taken with your camera. Press "Back" to return to your camera screen.

Select "Camera Settings" to set your camera settings.
Use the left or right arrows to switch between the available options.

Press "Save" on the bottom left corner of the screen to save your settings and return to the Camera screen. Press "Back" on the Options menu to set other options.

Select "Image Settings" to set your preferences.

Choose the White Balance setting that best matches your photo conditions. Choices are between the following:

- Auto: your camera will automatically balance color.
- Daylight: Natural Outdoor lighting.
- Cloudy: Natural Outdoor lighting.
- Fluorescent: Indoor Business lighting.
- Incandescent: Indoor Home lighting.

Scroll through to set a delayed time to take photos. Choices are the following options:

- Off
- 3 seconds
- 10 seconds
- 15 seconds

The camera is located at the top of your watch frame. Frame your photo by pointing your watch in the direction you want to take a photo.

Press the purple shutter button located on the right side of your screen to take a photo.

The watch will make a shutter sound to indicate when the photo was taken. The file name of the photo will appear at the top of the image.

After a few seconds of inactivity, your phone will return to the Camera screen for you to take another photo.

Return to your Image Viewer by pressing "Options" and "Photos" to review photos taken by your camera.

Select "Delete" if you want to delete a photo from your smart watch. The watch will prompt you. Select "Yes" to delete. The action is non-reversible.

Scroll down to access additional options.

Select "Sort by" to sort your photos by file name, type, time taken, or size (from largest to smallest).

DIALER

Press the Dialer Icon on your home screen to dial numbers from a phone book.

A numeric dialpad will appear.

Enter the number you wish to dial including 1 + area code.

Press the "Delete" button on the bottom right of your watch to delete any incorrect numbers.

Press the "Call" button on the bottom left of your watch to call the number entered.

Please refer to the "Phonebook" section for details about accessing your contacts list.

When you are done using the Dialer, press the "Return" button on your watch frame to return to your App menu screen.

BT CAMERA

Press the BT camera Icon on your home screen to access the remote shutter button.

This App can only be used on smart watches paired with Android devices.

Before using, please download the "Funda Companion" App. See "Settings / QR Code" for installation details.

The BT camera will connect to your Android device's built-in camera and work as a remote shutter button.

You can see a low-resolution preview of your phone's camera.

When switching from portrait to landscape, give your smart watch a couple seconds to sync the image preview before taking a photo.

Press the screen on your watch to take a photo.
Wait for your smart watch to finish taking the photo.

The photo preview will freeze on your watch screen. The photo will also save to your Android's camera roll.

Press the "Return" button on your watch frame to return to your camera preview to take another photo.

NOTE: BT camera only accesses the outward facing camera of your Android device. It will not allow you to flip your camera to face yourself to take selfies.

When you are done using the BT Camera shutter button, press the "Return" button on your watch frame to return to your App menu screen.

SEDENTARY REMINDER

Press the Sedentary Reminder Icon on your home screen to set a reminder for moving, seated for too long.

Use the left and right arrow keys to turn the reminder on or off.

Press into the time display to set the time of your reminder.

A dial will appear to let you indicate the current time. Press the field you want to edit and then press the plus or minus symbols to increase or decrease the numbers.

Press "OK" to confirm the time, press "Back" to exit without saving the time.

Press the "Options" key on the smart watch to set your reminders.

Press "Clear" to delete all your settings for your Sedentary Reminder.

When you are done setting your reminder, press the "Return" button on your watch frame to return to your App menu screen.

DRINK WATER REMINDER

Press the Drink Water Reminder Icon on your home screen to customize a time water consistently throughout the day.

Use the left and right arrow keys to turn the reminder on or off.

Select any reminder time to customize reminder settings. If the icon shows a white border around the water drop, this indicates an alarm is already set.

Scroll down on the touch screen to access 5th reminder.

Use the right and left arrows to turn the reminder on or off. Press into the time to set the reminder time by using military or 24-hour format to differentiate between AM and PM.

Scroll down on the touch screen of the watch to continue customizing alarm settings.

Select the box under "Repeat" to choose the days you want your alarm to ring.

"Once" will have your alarm ring only once your watch clock reaches the set reminder time.

"Everyday" will have your alarm ring each time your watch clock reaches the set reminder time.

"Custom" allows you to choose which days of the week you want your reminder to ring.

Select the day of the week you would like your reminder to ring.

A pop-up window will appear to allow you to select "On" or "Off."

Once you have made your selection, press "Done."

A water drop icon with a white border will appear next to the days of the week you have set your reminder to ring.

Scroll down on this screen to access and customize all 7 days of the week.

Press the "Return" key on the watch frame to return to your Drink menu.

Press "Save" on the bottom left screen, or "Back" to cancel your reminder.

When you are done setting your reminder, press the "Return" button on your watch frame to return to your App menu screen.

BATTERY CARE

The lithium-ion battery is built into the device. Do not disassemble the device or remove the battery or attempt to replace the battery in the device.

- When charging the device, please use the endorsed USB charging cable or otherwise ensure that the battery charging conditions are met.
- Do not connect or attach the device or the battery to a power supply plug or directly to a car's cigarette lighter.
- Do not place the device or batteries near a fire, or into direct sunlight. Heating the device and/or the battery can cause additional heating, breaking, or ignition of the battery inside the device.
- Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, ruptures, or ignites.

To preserve natural resources, please recycle or dispose of batteries properly. Do not dispose of batteries in household waste or in fire. Federal laws may prohibit disposal of lithium-ion batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.

- Do not attempt to modify, change, or replace your battery.
- Do not use your device if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials or breathe fumes emitted.
- Do not allow children and animals to touch an exposed battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into an exposed battery.

- Please only use the charger provided by Hopelt.
- Do not attempt to charge the device if the battery has discharge or emits any substances. In that case, immediately distance yourself from the battery in case of fire or explosion.
- Lithium-ion batteries are considered to be hazardous materials. Please follow all local, state and federal laws in regards to recycling, handling and disposing of lithium-ion batteries.

SPECIFICATIONS

Bluetooth:	Version 3.0
Display:	1.44 inch LCD touch screen (3.65 cm)
Resolution:	128 x 128pixels
Charge Time:	Up to 3.5 hour
Battery:	Built-in 180 mAh Lithium-ion Battery
Music Time:	Up to 3 hours
Standby Time:	Up to 120 hours
Charging Interface:	Micro USB
Weight:	0.081 lbs. / 0.037 kg.

FCC ID: 2ADYMHTCAMW
IFTBD: 20220611

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

WARRANTY INFORMATION

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser.

* You must be able to prove the date of original purchase of the unit with a dated receipt.
* This warranty is only applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
* The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
* This warranty does not cover any damage due to accident, misuse, abuse, or any unauthorized repair or modification of the unit.
* Modification or repair of the unit should be done by authorized and duly certified service personnel. Carrier or returned to the manufacturer.
* This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.
* The following conditions complete the requirements and scope of this warranty. Supplier shall not be held liable for any legal and contractual obligations.
* Supplier is not responsible for any damages or loss caused by the use of this product, provided there is no obligatory liability/duty. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to wage restrictions, data loss, and loss of working and business hours.

Asserting a warranty claim:

1) To make use of the warranty service for hardware issues, you must contact the DGL™ Service Center by email at support@dgl.com.

2) DGL™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to DGL™.

IMPORTANT: DGL™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

1) Send the product suitably packaged with carriage and insurance prepaid. Please use the original packaging or similar (cardbo, charges, manuals, etc.) unless the DGL Service Center specifies otherwise.

2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.

3) You must enclose a copy of the sales slip as proof of purchase.

4) Once DGL™ has received the product, it will meet its warranty obligations by, at its discretion, either repairing the product or will return the product to the service with carriage and insurance paid.

SERVICE OUTSIDE OF WARRANTY

DGL™ can refuse any service claim made that is not covered by the warranty.

If DGL™ agrees to provide a service outside the warranty, the customer will be invoiced for labour and transport costs. DGL™ will not accept any packages that have not first been approved by DGL™ by means of an RMA (Return Material Authorization).

DGL Group guarantees the quality of its product.

For questions or comments, please feel free to contact us via email at support@dgl.com.

To download a digital copy of this manual, please visit us at www.dglux.com/smartwatch