62mm

100mm

BIO-key™
Powered by Touch

TouchLock™ XL PLUS
User Manual
Model Number : BF1409

To check more information about the product, view instructions in other languages, or watch the instructional video, please see the lic below:
www.bio-key.com/download.html

Download the App using QR Code or simple by Searching 'TouchLock or TouchLock BT' in the App Store and Google Play:

iOS 8.0 or above

Android 4.3 or above

TouchLock™ XL PLUS



FINGERPRINT ACCESS :

To Power On:
Press the hook once to turn the power on.
Note:

- If the LED does not light up, you may need to re-charge via the micro-USB charging port.
- If no action is done within 15 seconds after the activation of the lock, the door will turn off automatically.

Fingerprint Enrollment

PLEASE ERASE ALL THE ENROLLED FINGERPRINTS BEFORE THE INITIAL ENROLLMENT

Press hook once until you see a blinking green and red light.	Touch the sensor for 3 times,you will see a green light for 2 seconds after each successful scan). *If a red light flashes, please try again.	A green light will be lighted for 4 seconds and that indicates the fingerprint is successfully enrolled. *Please make sure to put the finger flat on the sensor to get an accurate scan.

To Unlock using Fingerprint

Press hook once until you see a green light	Touch and hold the sensor with the enrolled finger until you see the green light flashes for 2 seconds. *If red light flashes, please try again.

Erase Fingerprint Records



Press the hook for 6 seconds until the green light flashes rapidly.	Touch & hold the sensor with a previously enrolled finger until you see a solid green light activates and stays for 2 seconds. *If a red light flashes, please try again.	When the red and green light flashes, press the hook for 6 seconds again until the red light flashes rapidly and then release the hook.
Touch the sensor with a previously enrolled finger when you see the rapidly flashing red light.	Hold the finger until you see the green light activates for 2 seconds and that indicates all the enrolled fingerprints are erased successfully.	

TouchLock™ XL PLUS

指纹登録
在初次進行指紋登記前請刪除所有已注冊指紋

1.按壓鎖扣一次，紅燈和綠燈交叉閃爍。
2.觸摸傳感器3次（每次傾斜成功後，綠燈持續2秒）。
"如果紅燈亮，請再試一次。
3.成功注冊後，綠燈長時間保持4秒。
*請務必將手指平放在傳感器上以獲得準確的掃描。

使用指紋開鎖
1.按壓鎖扣一次知道看到綠燈閃爍。
2.用已注冊的手指觸摸和按壓傳感器直到綠燈閃爍2秒。
* 如果紅燈亮，請再試一次。

登記更多的指紋
1.按住鎖扣6秒，直到你看到綠燈快速閃爍。
2.用之前已注冊的手指觸摸和按壓傳感器直到綠燈亮且持續2秒。
"如果紅燈亮，請再試一次。
3.等到紅綠燈交叉閃爍後就可以開始注冊新的指紋。
4.觸摸傳感器3次，成功將錄1次。
*每次掃描成功後，它會看到綠燈持續2秒.
"如果紅燈亮，請再試一次。

TouchLock™ XL PLUS

指紋录入：

前提：
- 初期調節→次回前電源
- 如LED 燈沒反應，請以micro-USB線充電
- 充電前數秒15 秒沒有指紋，則無法錄指上

5.當掃描持續亮4秒表示著指紋已經注冊成功。
*你可以用這個流程增加更多的指紋或者通過輸入你已經注冊的手指的不同區域或角度來提高解鎖的成功率。

清除指紋記錄
1. 按鎖扣6 秒直到藍灯快閃.
2. 以之前已登錄之指紋按感測器直至看灯亮.
* 如以打開, 請再按你的手指按感應器 2 直正.
3. 連灯藍灯閃, 按鎖鈕6 秒, 直到看到紅灯閃特你開鎖狀.
4. 以之前已登錄的指紋按感測器直至綠灯閃2秒.
5. 所有指紋記錄清空成功.

利用电脑重置
如你不能用鎖開鎖上面的鎖作點,請閱讀以下指示:
1. 在以下鏈接下載及安裝TOUCHLOCK TOOL：
http://www.bio-key.com/download.html or
http://www.bio-key.com.hk/download.html
2. 跟以micro-USB 線, 透過USB 充電口連接電腦
開鎖:
1. 點擊"UNLOCK BY PASSWORD",輸入開鎖密碼：
* 註：預設密碼為"0000".
為了保安理由, 請重設你的個人密碼

清除已登記之指紋記錄:
點擊"DELETE FINGERPRINTS"
點擊"YES"及輸入你的密碼
然後點擊"CONFIRM"

更改密碼:
1. 點擊 "CHANGE PASSWORD"
2. 輸入預設的密碼.
3. 輸入及確認新的密碼.

TouchLock™ XL PLUS

はじめに:

前提
フックを押して長く点灯する：
LEDが点灯しない場合、充電が必要な場合があります。
15秒以内にロックを操作しない場合、ドアは自動的にオフになります。

最初の指紋の登録
工場出荷時の状態（指紋データの登録されていない状態）であれば最初の指紋が登録できます。

1. フックを一回押すと、赤と緑のライトが点滅します。
2. 指でセンサーをタッチして、スキャンします（スキャンできたときは、緑のライトが2秒間点灯します）。同じ指で3回スキャンを繰り返します。
* 赤色のライトが点滅したときは、もう一度、センサーに指を置いてください。
3. 登録が成功したときは、緑色のライトが4秒間点灯します。
* 指をセンサーに十分に置くと、より正確にスキャンできます。

開錠
1. フックを一回押すと、緑色のライトが点滅します。
2. 登録されている指を指をセンサーに置いて、緑色のライトが点灯した後に、指で開錠します。
* 赤色のライトが点滅したときは、もう一度、センサーに指を置いてください。

指紋の追加登録
1. フックを5秒間押し続けると、緑色のライトが2回点滅します。
2. 登録されている指で指紋センサーにタッチすると、緑色のライトが点灯します。
* 赤色のライトが点滅したときは、もう一度、センサーに指を置いてください。
3. 緑と赤のライトが点滅したら、新しい指紋が登録できます。
4. 指でセンサーをタッチすると、スキャンします。同じ指で3回タッチを繰り返します
* スキャンできたときは、緑色のライトが2秒間点灯します。
* 赤色のライトが点滅したときは、もう一度、センサーに指を置いてください。
5. 緑色のライトが2秒間点灯したら、指紋の登録が完了です。
* 指をセンサーに十分に置くと、より正確にスキャンできます。

登録されている指紋の消去
1. フックを5秒間押し続けると、緑色のライトが2回点滅しますので、フックを離します。
2. 登録されている指で指紋センサーにタッチすると、緑色のライトが点灯します。
3. 登録されているすべての指紋が消去されます。

PCのツールで鍵をリセット
これまでの操作説明の通りに扉が操作できないときは、次の操作を参照してください。
1. 次のリンクからTouchLockツールをPC（Windows OS 7以上）にダウンロードしてインストールします：
http://www.bio-key.com/download.html または
http://www.bio-key.com.hk/download.html
2. 提供されているmicro-USBケーブルを使用して、PCとロックを接続します。
3. 「Unlock by Password」パスワードで開錠（デフォルトパスワードは「0000」）を入力します。
*注：パスワードは変更することをお勧めします。
セキュリティ上の理由から、毎回のパスワードに変更してください。

登録されている指紋の消去
1. "Delete Fingerprints（指紋の消去）"をクリックします。
2. "yes（はい）"をクリックし"Enter（入力）"パスワードを入力します。
3. "Confirm（確認）"をクリックします。

パスワードの変更
1. "change password（パスワードの変更）"をクリックします。
2. 初期のパスワードを入力します。
3. 4桁の新しいパスワードと確認用のパスワードを入力します。
4. 指でセンサーをタッチすると、スキャンします。同じ指で3回タッチを繰り返します
* スキャンできたときは、緑色のライトが2秒間点灯します。
* 赤色のライトが点滅したときは、もう一度、センサーに指を置いてください。
5. 緑色のライトが2秒間点灯したら、指紋の登録が完了です。
* 指をセンサーに十分に置くと、より正確にスキャンできます。

Fast-Click Unlock Mode

Caution: Please set up your personalized Fast-Click Code after admin fingerprint registration IMMEDIATELY.

Code Registration :

Fast-Click allows you to create a custom access code of short and long taps to unlock the door lock without computer for backup unlock.
Set-up Guide:
The Fast-Click code is a 4-digit code made up of a string of 4 long and short taps.
Example: = long = short
1. Press hook once to activate mode:
* Tap and hold the hook for 5 seconds and wait for a flashing blue light, continue holding until the red and blue light flashes.
2.1 Input your first Fast-Click digit:
- A long tap is longer than 1 second red and blue light turns on and that indicates a successful enrollment of a long tap.
- A short tap is less than 1 second, LED change to a rapid flashing blue light, indicates a successful enrollment of a short tap.
2.2 The first digit is successfully registered, a blue light will be activated and enjoy on for 4 seconds.
2.3 Repeat 2.1 until all 4 digits are successfully enrolled. After a code has been successfully registered, a blue light will be activated and stay on for 4 seconds.
* Please write down your code after registration: _ _ _ _

Unlock Using Fast-Click Code or Change Your Code:

To Unlock:
2.1 Tap and hold the hook for 5 seconds and wait for a flashing blue light, continue holding until the red and blue light flashes down.
2.2 Enter your registered code and wait until the blue light activates, that indicates the code is entered correctly. The lock will be unlocked after 4 seconds.
2.3 If the code is entered incorrectly, a red light will be activated and turns into a slow flashing red and blue light right after, then you can re-enter your registered Fast-Click code.
* The lock will exit the Fast-Click Unlock Mode after 4 attempts of entering the wrong code.

Change Your Code:
3.1 Repeat the previous step 2.1,2.2 and tap the hook within 3 seconds after the blue light is activated, then a rapid red blue light will flash, indicates the Fast-Click Code is enrolled. (The previous registered code will be erased automatically)
3.2 Repeat step 1,2,3,3 and 1.4 in Code Registration section to input your new Fast-Click Code.

Erase the Fast-Click code

-Where clear all fingerprint record, Fast-click coder record would also be erased, method please refer to erase fingerprint record section in this manual.

FAQ :

- In the unlikely event the battery dies while locked, TouchLock should be charged using an external battery to provide quick access to unlock.
- For other questions or more instructions, please visit us@ http://www.bio-key.com/download.html OR http://www.bio-key.com.hk/download.html

FC Tr ID:2AJwJ-BF1409

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

正面

BLUETOOTH SECTION :

This part is to tell how to operate lock with Smartphone via Bluetooth.

1. To Power on : Press the hook once and wait for the flashing blue light.	2. Open the App and the activated lock will appear on the screen.

*The lock will be powered off automatically after 3 minutes with operation is performed.

1.REGISTER ADMIN USER

1. Open the App and the activated lock in range will appear on the screen.	2. Click on the lock icon and the "Register" screen will appear.	3. The yellow tab on the top will disappear when it is successfully activated and you can start the registration process.



4. You will be able to change the Admin password or Unlock password after the lock is registered successfully.	5. "Register Admin Success" message will appear.

2. SETTINGS

Select the lock and tap 'Setting' to see the details.
*Only the admin user can change the admin password and reset the lock to factory settings.

3. UNLOCK



1. Click on "Open".	2. Use either fingerprint or unlock password to unlock.	3.The lock is opened successfully.

4. ADD ADDITIONAL USER

1. The additional user needs to be authorized by the admin to add the lock to it when they Open the App on the user's smartphone and click on the icon.	2. Follow the instructions to enter the User ID and the Admin password.	3. Type in the 4 digit admin password.	4. "Register User Success" message will appear.

SAFETY WARNING & INSTRUCTION

Read before using your Lock

The following sections provide critical safety and regulatory information for TouchLock and instructions on how to access more detailed electronic version of the publications developed for your Lock.

To watch the video instructions or download the electronic version of this manual instruction, please visit:
http://www.bio-key.com/products/touchlock/

⚠ DANGER

Failure to follow the safety precautions described below may result in severe injury to people, damage to the product or property.

***Do not attempt to disassemble or modify the product.**
Attempting to do so can cause personal injury, burning, electric shock or fire.
***Keep the product away from fire.**

⚠ WARNING

Failure to follow the safety precautions described below may result in severe injury to people, damage to the product or property.

***Please use the proper voltage when charging.**
The use improper power usage supply may result in product being damaged. To avoid possible injury,
***Stop using the product immediately if you sense abnormal smell, smoke, discoloration or if there is any allergic reaction.**
***Avoid heavy impacts such as throwing or slamming.**
***Avoid placing a conductive substance in terminal. or do not short-circuit it.**
***Avoid touching the terminal.**

⚠ CAUTION

Failure to follow the safety precautions described below may result in severe injury to people, damage to the product or property.

***Discontinue use if the product is damaged.**
***Discontinue use if the terminal or micro-USB cable is damaged.**
***Disconnect micro-USB cable from the product when it is not in use or being charged.**
***Parental supervision is recommended for age 12 or under.**
***Recharge the battery if the product is left long and not being used.**
***Do not put the product in trash that is disposed of in landfills. When disposing of the product, comply with local ordinances or regulations.**

蓝牙部分:

這部分是講述手機如何通過藍牙(Bluetooth)門鎖操技術操作智能型鎖具。

1. 開機 按壓鎖扣一次，藍燈亮。
2. 打開藍牙App，連接已經在鎖具的藍牙。
* 若3分鐘無任何操作，智能鎖自動關機。

1. 注冊管理員賬戶

1. 打開鎖具的藍牙，並掃描已經在鎖具的藍牙。
2. 點擊鎖具標誌進入"注冊"頁面，然後點擊屏幕底部注冊
3. 黃色標誌注冊成功後，綠色表明智能鎖已經激活
成功，這標誌就可以開始注冊。
4. 在智能鎖成功注冊後，您可以更改管理密碼或同鎖密碼。
5. "管理員注冊成功" 的信息會顯示在屏幕上。

2. 設置

這部分是講述如何更改智能鎖的管理員密碼或增加用戶。

3. 開鎖

1. 點擊"OPen"按鈕。
2. 使用指紋或者輸錄密碼開鎖。
3. 智能鎖成功開鎖。

4.增加其他用戶

1. 其他用戶需要得到智能鎖的管理員授權才能注冊:
打開用戶智能手機上的應用程序並點擊搜尋。
2. 按照說明提供短信息管理密碼。
3. 輸入管理密碼。
4. "用戶注冊成功" 信息會顯示在屏幕上。

安全警告及指引

*使用此產品前, 請先閱讀安全警告及指引及正確使用此產品. 閱讀後包請保存好此指引.
*此指引提供了用家正確使用, 避免不當使用導致及自身或其它人, 以及防止不當使用導致此產品, 請嚴遵指引中所提供
各標示的說明.
*以下標示說明如不相遵以下各項指引使用的可能導致的損害及嚴重程度, 以及不當使用此產品

⚠ DANGER
如不按安全指南使用, 有極高可能造成嚴重傷害甚或死亡.

⚠ WARNING
如不按安全指南使用, 有可能造成嚴重傷害甚至死亡

⚠ CAUTION
如不按安全指南使用, 或會造成受傷或損壞財位的風險

⚠ DANGER

* 不要試圖打開鎖板, 拆開, 改裝或打開產品
* 以避免造成個人受傷, 損壞,觸電或燒傷
* 不要放在火場上, 不要放入或放在會有高, 熱場, 接近爐, 壁力裝或其它有熱力加熱. 不要放在大氣壓下的壓的汽車內.
* 以避免造成個人受傷, 損壞,觸電或燒傷

⚠ WARNING

* 請使用正確的電源及電壓充電.
* 如果用不當使用或電壓或, 或者造成電池損壞.
* 智慧鎖產品存在極小的危險即成在電中出現異味, 出煙,過熱, 變色, 或變形,請停止使用
* 如不停止使用會導致或受傷或損壞.
* 不要使用激大物度扭曲, 拋, 搖動, 跳壓.
* 以避免造成損壞
* 不要放導電物會充電口的端子(例如, 金屬件或鉛筆), 或不要造成充電端子短路, 也不要放波體或液體進入產品.
* 以避免造成損壞
* 在插充電器及接充電線時,不要用手觸碰充電端子, 及不要用手指或金屬件接內的電池.
* 以避免造成產品損壞.
* 如發現損壞請勿使用或充電.
* 以避免造成產品損壞.

⚠ CAUTION

* 當電品損壞了, 不要使用產品.
* 如充電端子或充電線損壞請不要使用.
* 當產品不在使用及不在充電, 請拔掉充電線.
* 長時間使用此產品, 要保護無線正確使用方法及健康正常使用.
* 請保存此產品在花坛不能接觸到的地方.
* 以避免在花不小心導入赶或造成受傷.
* 如產品放入了湿用, 電壓或會降低因電池慢慢自然放電, 再使用前請充電.

Bluetoothロック
Bluetoothでスマートフォンと接続して使用するとき

1. 扉の電源をオンにする（扉のフックを短く（0.5秒未満）押して、上記の電源、青色の点灯ライトが点滅するまで待ちます。Bluetoothが有効になります。
2. スマートフォンのアプリケーションを開くと、起動中の扉が画面に表示されます。
* 30分以上操作しないと、扉は自動的にシャットダウンします。

1. 管理者登録

1. スマートフォンのアプリケーションを開くと、Bluetoothが有効になっている扉が画面に表示されます。
2. 扉を選択して他の画面を表示します。"Connect"が緑色でタップします。
3. 扉とスマートフォンが正しく接続されると、画面下部の"Register"（登録）ボタンが青色に表示されます。登録ボタンをタップして、登録登録します。
4. 指が正しく登録されると、管理者パスワードと開錠パスコードが変更できるようになります。
5. "Register Admin Success"（管理者を登録しました）が表示されます。

2. 設定変更

Setting（設定）画面では、管理者パスコードと開錠パスコードが変更できます。また、扉の名称や写真のカスタマイズも可能です。
パスコードの初期値
*初期 ： 33333333 *管理者：00000000
管理者パスでSetting（設定）をタップすると今の扉の詳細設定が表示されます：
* "Change Admin Password（管理者パスコードの変更）」と
* "Reset to Factory（工場出荷時の設定に戻す）」は、管理者のみが使用できます。

3. 開錠

1. 青色い"Open"（開錠）ボタンをタップします。
2. 画面下部に開錠ビーチの選択が表示されます。
3. 指紋による開錠、または4つのユーザーの4桁パスワードを使用できます。

4.ユーザーの追加

1. ユーザーの追加には管理者の承認が必要です。
2. 管理者がアプリケーションを開くと、扉は、指示に従って新規ユーザーに管理者パスコードを与えるように促します。
2. 新規ユーザーのスマートフォンでアプリケーションを開きます。管理者登録と開錠にご設定ください。ドアを開錠し、登録ボタンをタップします。
3. 管理者パスコードを入力します。
4. "Register User Successful.(ユーザーを登録しました)"が表示されます。

安全上のご注意

ご使用の前に、この「安全上のご注意」をよくお読みの上、正しくお使いください。また、お読みになった後は大切に保管してください。
・ここで記述された注意事項は、お使いになる人や、他の人への危険、財産への損害を未然に防ぐための内容を記載していますので、必ずお守りください。
禁止の説明
・次の表示の区別は、表示内容を守らず、誤った使用をした場合に生じる危害や損害の程度を説明しています。

身分ビデオの視聴や最多マニュアルのダウンロードは、
http://www.bio-key.com/products/touchlock/
または http://www.bio-key.com.hk/download.html
をお使いください。

⚠ 危険	この表示は、取扱い状況から見て、「死亡または重傷を負う危険が切迫して生じることが想定される」内容です。
⚠ 警告	この表示は、取扱い状況から見て、「死亡または重傷を負う可能性が想定される」内容です。
⚠ 注意	この表示は、取扱い状況から見て、「軽傷を負う可能性または物的損害のみが発生が想定される」内容です。

⚠ 危険

・分解、改造をしないでください。
・火の中に投入したり、電子レンジ、IH調理器などの調理器具で熱を加えたり、圧力容器などの高圧力容器に入れたり、決して激しくたたいたりしないでください。また次ページの取り扱いについて。
・火災、やけど、けが、感電などの原因となります。

⚠ 警告

・指定の電源、電圧で使用してください。
・誤った電源、電圧で使用すると発熱や故障の原因となります。
・異臭、異音、発煙など、異常、イオン、物質、電熱、変色、変形などの異常が発生したときは、使用を中止してください。
・そのまま使用すると火災、感電の原因となります。
・落下させる、踏みつける、投げつけるなど激しい衝撃、振動を与えないでください。
・本体の故障の原因となります。
・本機の端子に異物を挿入しないでください。
・ショートや発火、感電、けがなどの原因となります。
・次のような場所では使用しないでください。
・火気の近くや油煙、湯気、湿気、水滴がかかる場所
・直射日光、暖房などの熱源の近くや温度が高くなる場所
・水槽の近くや水に濡れる場所（屋外での使用を含む）
・本機の故障の原因となります。
・本機にmicroUSBケーブル以外を接続しないでください。
・誤った接続をすると、火災や感電の原因となります。
・本機の故障の原因となります。
・お使いケーブルを他の製品に流用しないでください。
・本機の故障の原因となります。
・充電ケーブルを無理に曲げたり、ねじったり、引っ張ったりしないでください。
・火災や感電の原因となります。
・充電ケーブルを熱器具に近づけないでください。
・被覆が溶けて火災や感電の原因となります。
・濡れた手でケーブルを抜き差ししないでください。
・感電の原因となります。
・本機を分解しないでください。
・感電やけがの原因となります。
・内部の点検や修理は、販売店または当社の修理窓口にご依頼ください。
・本機を廃棄するときは、地方自治体の条例または規則に従って処分してください。
・詳しくは、地方自治体にお問い合わせください。

⚠ 注意

・本機が破損した場合使用しないでください。
・ケガや火災の原因となります。
・扉が正しく閉まらないときやロックがかからないときは、ロックしないでください。
・不用心で盗難の原因となります。
・長時間ご使用になるときは、扉を開けた状態でお使いください。
・高温になり、やけどなどの原因になります。
・使って頂かないように、ロックなどの施錠にならないで下さい。
・ロックしないと、ドアを閉めてしまうと自動的に施錠してしまいますので、ご使用の前に充電を行ってください。
・不意に閉じられた場合、扉の内部から施錠ボタンを押して開けることができます。

BIO-key International, Inc.
www.bio-key.com
Made in China
Warranty registration : http://support.bio-key.com/warranty

FC CE IP54

背面

Fast-Click 解锁模式

注意：确定初始设置后，请立即设置指纹后密码。

密码注册：

Fast-Click 允许您创建一个自定义访问代码，由短按和长按组成，以在没有计算机的情况下解锁门锁进行备份解锁。

设置指南：

Fast-Click 代码是一个4位数代码，由4个长按和短按的字符串组成。

例： = 长按 = 短按

1. 按一下按钮以激活模式：
* 按住按钮5秒钟，等待蓝色指示灯闪烁，继续按住，直到红色和蓝色指示灯闪烁。
2.1 输入您的第一个Fast-Click数字：
- 长按时间超过1秒，红灯和蓝灯亮起，表示长按已成功注册。
- 短按时间少于1秒，LED灯变为快速闪烁的蓝灯，表示短按已成功注册。
2.2 第一个数字已成功注册，蓝灯将亮起并保持4秒钟。
2.3 重复2.1，直到成功注册所有4个数字。密码成功注册后，蓝灯将亮起并保持4秒钟。

* 注册后请记下您的密码：_ _ _ _

使用Fast-Click密码解锁或更改密码：

解锁：
2.1 长按按钮5秒钟，等待蓝灯闪烁，继续按住，直到红灯和蓝灯闪烁。
2.2 输入已注册的密码，等待蓝灯亮起，表示密码输入正确。4秒后门锁将解锁。
2.3 如果密码输入错误，红灯将亮起，然后变为缓慢闪烁的红灯和蓝灯，然后您可以重新输入已注册的Fast-Click密码。
* 输入错误密码4次后，门锁将退出Fast-Click解锁模式。

更改您的密码：

3.1 重复上一步骤2.1,2.2，并在蓝灯亮起后的3秒内轻触按钮，然后快速红蓝灯将闪烁，表示Fast-Click密码已注册。（之前注册的密码将自动删除）
3.2 重复步骤1,2,3,3和1.4，在密码注册部分输入新的Fast-Click密码。

删除Fast-Click密码

-要清除所有指纹记录，Fast-Click密码记录也将被删除，方法请参阅本手册中的删除指纹记录部分。

常见问题：

- 在不太可能的情况下，如果电池在锁定时耗尽，应使用外部电池对门锁进行充电，以便快速访问解锁。
- 如需其他问题或更多说明，请访问我们的网站@ http://www.bio-key.com/download.html 或 http://www.bio-key.com.hk/download.html

FC ID:2AJwJ-BF1409

对设备未经合规负责方明确批准的更改或修改可能会使用户操作该设备的权限无效。
本设备符合FCC规则的第15部分。操作须遵守以下两个条件：
(1)此设备不得造成有害干扰，以及
(2)此设备必须接受任何接收到的干扰，包括可能导致意外操作的干扰。

注意：本设备已经过测试，并符合B类数字设备的限制，根据FCC规则的第15部分。这些限制旨在提供合理的保护，防止在住宅安装中有害干扰。本设备会产生，使用并可能辐射射频能量，如果不按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果本设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定，鼓励用户尝试通过以下一种或多种措施来纠正干扰：
- 重新定向或重新放置接收天线。
- 增加设备与接收器之间的距离。
- 将设备连接到与接收器所连接的电路不同的电路上的插座。
- 咨询经销商或有经验的无线电/电视技术人员寻求帮助。

本设备符合FCC针对不受控环境规定的辐射暴露限制。本设备应安装并操作，发射器与您的身体之间的最小距离为20厘米。本发射器不得与任何其他天线或发射器共同放置或操作。

正面

フック クリック コードを利用した補助開錠モード

注：最初に指紋を登録した後は、他の人が解錠できないようにするためにフック クリック コードを登録してください。

フック クリック コードの登録

1. 最初に登録するは、フック クリック コードが登録できます。
2. はじめに、フックを長押しします。3秒間ほどの間ライトが点滅するまで、それぼタップを数回すことから2秒間、点灯すると、赤と青のライトが同時に点灯しない。長押しの登録が成功です。
3. 指のフックを長押しします。3秒間ほどの間ライトが点滅するまで、それぼタップを数回すことから2秒間、点灯すると、赤と青のライトが同時に点灯しない。長押しの登録が成功です。
4. 4まだ3.5の操作を繰り返します。4個のフックを入力し終えると、緑ライトが4秒間点灯し、フック クリック コードの設定は完了です。

フック クリック コードで開錠、または フック クリック コードの変更

1. はじめに、フックを長押しします。3秒間ほどの間ライトが点滅するまで、それぼフックを数回すことから2秒間、点灯すると、赤と青のライトが同時に点灯しない。登録が成功です。
2. コードが正常に入力されると、緑色のライトが2秒間点灯します。この2秒間にフックを再度押しないかぎり、自動的に開錠します。この3秒間にフックを再度押すと、ロックが施錠されます。（以前に登録されたフック クリック コードは、すべて消去されます。）
3. フック クリック コードの入力に失敗した場合、赤いライトが点灯し、次に緑色のライトが点滅します。その後、フック クリック コードを再入力してください。
4. フック クリック コードの入力に4回失敗すると、フック クリック コードの入力が完了するまで、30秒のロックが行われます。

フック クリック コードの消去

-指紋の登録方法すると、フック クリック コードも削除されます。詳細は、本マニュアルの「指紋の登録」を参照してください。

よくある質問

-低電圧端子部が開錠できないときは、充電端末部のUSBポートと接続してください。
-その他のQ&Aは、
http://www.bio-key.com/download.html または
http://www.bio-key.com.hk/download.html のページを参照してください。

背面