

80mm

560mm

140mm

Quick Start Guide



Gold Wireless Headset



For assistance with this product, visit playstation.com/helpme.
"PS" and "PlayStation" are registered trademarks of Sony Interactive Entertainment Inc.
© 2016 Sony Interactive Entertainment America LLC. Printed in China

Let's get started

IMPORTANT: Before using this product, read the safety precautions in the Safety and Support Guide.

You can also use your headset with a PC, Mac or portable media player.
For details, visit us.playstation.com/support/wirelessstereoheadset.

1. Turn on your PS4™ system or PS3™ system



Press the power button.

2. Charge the headset



Connect your headset to a USB port using the supplied USB cable.
Your headset might need up to 3.5 hours to charge fully.

3. Insert the wireless adaptor



Use one of the USB ports on your system.

4. Turn on your headset



Slide the power/audio mode switch to position "1" or "2".

Headset Companion app

The free Headset Companion app allows you to download a new audio mode to your headset. The app is available from PlayStation®Store.*

You can create your own audio mode with the Headset Companion app, or select from preset modes that have been specially designed to deliver an optimal audio experience.



* Sony Entertainment Network account and Internet service required.

Headset anatomy

Front



SOUND/CHAT buttons

Adjust the chat voice volume in relation to the game sound.

Microphone (integrated)

Faceplates

Faceplates are removable and customizable.

Power/audio mode switch

Sets the audio mode or turns off the headset.
OFF - turns off the headset.

1 - Standard Mode

2 - Bass Boost Mode (default)

This mode can be replaced with audio modes from the Headset Companion app.

Rear



VSS (Virtual Surround Sound) button

The Virtual Surround Sound effect is on by default.

VOL (Volume) + / - buttons

MUTE button

- Press to switch microphone MUTE on and off.
- To engage the sidetone feature, hold down the MUTE button until a beep is heard. Then choose the sidetone volume (high, medium, off) by pressing the MUTE button.

Bottom



USB port

Connect to a supported USB device to charge the headset. (A micro USB cable is included.)

Audio input jack

Use the supplied audio cable to connect your headset to mobile devices.

Status indicator

For more instructions about the use of this product (including the Headset Companion app), visit us.playstation.com/support/wirelessstereoheadset.

80mm

560mm

140mm

Guide de démarrage rapide



Casque-micro sans fil or



Pour de plus amples renseignements, visitez playstation.com/helpme.
"PS" et "PlayStation" sont des marques déposées de Sony Interactive Entertainment Inc.
© 2016 Sony Interactive Entertainment America LLC. Imprimé en Chine.

Pour commencer

IMPORTANT : Avant d'utiliser ce produit, veuillez lire les consignes de sécurité du guide de sécurité et de support technique.

Vous pouvez également utiliser votre casque-micro avec un PC, un Mac ou un lecteur multimédia portatif. Pour plus de détails, visitez us.playstation.com/support/wirelessstereohdset.

1. Mettez le système PS4™ ou PS3™ sous tension



Appuyez sur l'interrupteur d'alimentation.

2. Rechargez le casque-micro



Connectez votre casque-micro à l'aide du câble USB à un port USB. Votre casque-micro peut nécessiter jusqu'à 3,5 heures pour une recharge complète.

3. Insérez l'adaptateur sans fil



Utilisez un des ports USB de votre système.

4. Mettez votre casque-micro sous tension



Positionnez l'interrupteur d'alimentation/Mode audio sur 1 ou 2.

Application compagnon du casque-micro

L'application compagnon gratuite du casque-micro vous permet de télécharger un nouveau mode audio sur votre casque-micro. L'appli est disponible dans PlayStation®Store.*

Vous pouvez créer votre propre mode audio à l'aide de l'outil de personnalisation, ou sélectionner parmi les modes pré-réglés spécialement conçus pour offrir une expérience audio optimale.



* Avec un compte Sony Entertainment Network et une connexion Internet.

Anatomie du casque-micro

Avant



Touches SOUND/CHAT

Réglez le volume du clavier vocal par rapport au volume sonore du jeu.

Microphone (intégré)

Plaques de protection

Les plaques avant sont amovibles et peuvent être personnalisées.

POWER - Interrupteur d'alimentation / Mode audio

Active le mode audio ou éteint le casque-micro.

OFF - éteint le casque-micro.

1 - mode standard

2 - mode accentuation des basses (par défaut)

Vous pouvez remplacer ce mode à l'aide des modes audio fournis par l'appli compagnon du casque-micro.

Arrière



Touche VSS (ambiophonie virtuelle)

L'effet du son virtuel ambiophonique est activé par défaut.

Touche VOL (Volume) + / -

Touche MUTE

- Appuyez sur la touche MUTE (micro en sourdine) pour l'activer et la désactiver.
- Pour activer et désactiver l'effet local, maintenez la touche MUTE enfoncée jusqu'à ce que vous entendiez un signal sonore. Puis, sélectionnez le volume d'effet local voulu (haut, moyen, éteint) en appuyant sur la touche MUTE.

Dessous



Port USB

Pour recharger le casque-micro, connectez-le à un périphérique compatible USB. (Un câble micro-USB est inclus.)

Prise d'entrée audio

Utilisez le câble audio inclus pour connecter le casque-micro aux appareils mobiles.

Indicateur de statut

Pour de plus amples renseignements, consultez la documentation en ligne à l'adresse us.playstation.com/support/wirelessstereohdset