Licensed Interactive Watch Instruction Booklet - English REV 240321

24/03/2021

3” H x 18” W when printed - 3” H x 3” W when folded.
6 folded sections - double sided print - *for printing, page 12 is on the back of page 1

COLOR : 4C + 4C

FRONT

3 inches | 3 inches | 3 inches | 3 inches | 3 inches | 3 inches

www.itimewatches.com
INTERACTIVE WATCH
- USER GUIDE -

Charge 30-60 minutes before first use.
Notice screen may be blank while charging for 30 minutes.
Warning: Do not leave your watch charging unattended for more than 3 hours.
It may weaken the life of your battery.

ρ1

TABLE OF CONTENTS

1.1) POWER ON/OFF
1.2) CLOCK FACES
1.3) STATUS BAR ICONS
1.4) BATTERY RECHARGING
1.5) SPLASH PROOF
2) GAMES
3) CAMERA
4) VIDEO
5) MUSIC PLAYER
6) PEDOMETER
7) VIEWER
8) TIME TOOLS
8.1) ALARM
8.2) STOPWATCH
8.3) TIMER
9) RECORDER
10.) CALCULATOR
11.) SETTINGS
11.1) WALLPAPER
11.2) DATE
11.3) TIME
11.4) STORAGE
11.5) BRIGHTNESS
11.6) VOLUME
11.7) DEVICE RESET
12) BLUETOOTH CONNECT

ρ2

1.1) Power On and Power Off:
- Power on: Press and hold the power button to turn on the watch.
- Power off: Press and hold the power button to turn off the watch.
- Home menu: Press the power button once to display the clock.

1.2) Clock Face:
- Press and hold the center of the clock to change the clock face.

*Swipe left or right to scroll through the clock face options and touch to select. Swipe right to exit to the main menu.

1.3) Status Bar Icons:



ρ3

1.4) Battery Recharging:
*Note: Adult operation is suggested.

- Gently pull out the cover of the Micro-USB port on the right side of the watch.
- Insert the included Micro-USB cable (small end) into the Micro-USB port on the watch.
- Insert the large end of the Micro-USB cable on your computer or to a standard USB power outlet adapter.
- Once the connection is successful, you will see a battery-charging symbol appear on the watch screen.
- When the battery is fully charged, the charging icon will stop animating and the battery symbol on the screen will show full.
- When the battery is fully charged, disconnect the charger from the power outlet first, then disconnect the watch from the charger cable.
- The battery strength icon on the status bar will scroll until the device is fully charged.

Note: Please charge your watch before you use it. It takes approximately 1 hour to fully charge the battery.

Battery Notice:
Misuse of batteries can lead to them bursting, causing a fire or chemical burns. Please read the following precautions:

ρ4

- Do not disassemble the battery.
- Do not crush and do not expose the battery to any shock or force such as hammering, dropping, or stepping on it.
- Do not expose to high temperatures or place near a heat source.
- Do not leave in direct sunlight.
- Do not dispose of in a fire.
- Do not handle damaged or leaking batteries.
- Keep the battery out of the reach children.
- Keep the battery dry.

1.5) Splash Proof for Everyday Play:
- Do not put the watch under running water.
- Do not submerge under water. Not suitable for showering, bathing, or swimming.
- Keep the cover of the Micro-USB port closed tightly while it is not in use in order to prevent any water getting in the watch.

2) Games:

- BASKETBALL SHARP SHOOTER
- SPEED RACING
- MEMORY GAME
- GAME TIME
- FIND THE DIFFERENCE
- FIGHTER PILOT

ρ5

3) Camera:
- Tap the camera icon in the main menu to enter camera mode.
- Tap the shutter icon to take a photo.
- Tap the save or trash bin icon to save or delete your last photo.

4) Video:
- Tap the video icon in the main menu to enter video mode.
- Tap the record icon to begin recording video.
- When you are finished, tap the same icon.
- Tap the save icon to save your last video.

ρ6

5) Music Player:
Power off the watch
Use the USB cable to connect watch to computer.
Once connected you will see two storage paths displayed on your desktop. Double click on (Music) storage path to open and load mp3 music file. After saving unplug USB. Power up watch. Go to Music and select a song and it will play automatically.

6) Pedometer:
* This is a basic pedometer to count your movements. The watch should be worn on the wrist for greatest accuracy.

- Tap the start icon to start the pedometer and you can tap the stop icon to stop it from counting any further.
- Tap the reset icon to reset the counter back to zero.
- On the pedometer screen you can check the distance walked and calories burned.

* This pedometer is just for fun and is not 100% accurate. The pedometer only counts movement when the pedometer feature is open and activated. The pedometer will only count movement if it is worn on the arm that is moving. Swipe right to exit to the main menu.

ρ7

7) Viewer:
- Tap the viewer icon on the main menu to browse or delete your photos and videos.

8) Time Tools:

8.1) Alarm: *Swipe right to exit to the main menu.
- Select the hour and minute by tapping up or down on the hours, minutes and AM/PM.
- Tap the tone icon to display the alarm tone selection menu. There are 3 build-in alarm sounds, tap left or right to preview and select one of the three different tones.

ρ8

3 inches

BACK

3 inches | 3 inches | 3 inches | 3 inches | 3 inches | 3 inches

- Once you choose an alarm, tap the green check icon to confirm and start your alarm.

8.2) Stopwatch: *Swipe right to exit to the main menu.
- Tap the play icon to start your stopwatch
- While the stopwatch is running, tap the pause icon to pause the stopwatch. Tap it again to resume.
- Tap the reset icon to stop the stopwatch and reset the time back to zero.

8.3) Timer: *Swipe right to exit to the main menu.

ρ9

- Tap the timer to enter timer settings.
- Tap the play icon to start the timer immediately. Tap up or down on the minutes and seconds to change the time. Once set, tap the green check to confirm.
- While the time is running, tap the pause icon to pause the countdown and tap it again to resume. Tap the reset icon to stop the countdown and reset the timer.

9) Recorder: *Swipe right to exit to the main menu.
- Tap the record icon to start recording, when you finish recording, tap it again to stop.
- Tap left or right to review the previous or next recording.
- Tap the play icon to display and play back your last recording
- To delete a recording, tap the trash bin icon to delete.

ρ10

10) Calculator: *Swipe right to exit to the main menu.
- Tap the calculator icon to enter the calculator function.
- Tap the "C" button to clear the calculator.
- Tap the button to delete the last number typed.

11) Settings:
*Tap left or right to scroll through the setting options.

11.1) Wallpaper: Tap the "set" button to choose one of three wallpapers to select.

11.2) Date: Tap up or down on the month, day and year to set the date. Tap the green check icon to save.

ρ11

11.3) Time: Tap up or down on the hours, minutes and AM/PM to set the time. Tap the green check icon to save.

11.4) Storage:
* As such is recommended for adding micro SD storage to this device in a dry and safe environment. To remove screws on the case back, use a micro or eyeglass screw driver. Expandable up to 32GB.
- Tap the "set" button to enter the storage menu.
- Tap "watch" to save photo, video, and voice recordings to the watch.
- Tap "card" to save photo, video, and voice recordings to the memory card if one has been added.
- Tap "space" to view the space remaining in both the watch storage and micro SD storage.

Note: Always save your music files to the music drive.

ρ12

- To download Pics & Video Power off the watch. Use the USB cable to connect watch to computer. Once connected you will see two storage paths displayed on your desktop. Double click on (File)storage. You will find all your video and image files in this drive.

11.5) Brightness: Tap the + or - icons to set the screen brightness.

11.6) Volume: Tap the + or - icons to set the system volume.

11.7) Device Reset: Tap the "set" button to reset the watch to its factory settings. Once prompted, type password "1122" and the watch will restart and reset.

Battery: Li-ion Battery
Do not Mix Alkaline, Standard (Carbon Zinc) or Rechargeable (Nickel-Cadmium)

ρ13

12)Bluetooth Connect
(Bluetooth name:MTS005F)

Enter the Bluetooth application, turn on the Bluetooth, enter the search list and select the available Bluetooth audio device connection.



The User can change the Bluetooth name of the connected device reconnect and delete the device etc. function on My device interface.

ρ14

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ρ15

Hard Reset Instructions:

Trouble Shooting:

If your watch is not able to be fully charged or makes a sound that cannot be turned off, you require a hard reset.

Simply reset your watch by pushing a pin in the hole beside the USB port. You should feel a slight click which will reset your watch and restart it. This should resolve your issue.

FCC ID:2ALPLMTS005F

ACCUTIME WATCH CORPORATION

1001 Avenue of the Americas, 6th FL, New York, NY 10018

Questions or comments, please email: info@accutimewatch.com

Made in China

ρ16

3 inches