billboard

Bluetooth®

TRUE WIRELESS EARBUDS



Thank you for purchasing the billboard true wireless earbuds. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.

BC

Package contains:
1. Wireless earbuds
2. Charging Case
3. USB charging cable
4. User manual







RECONNECT TO YOUR DEVICE

• You only need to pair your Bluetooth® device with these earbuds once.
• With your device's Bluetooth® feature turned on and in range, remove the left & right earbuds from the charging case.
• They will automatically connect to each other and to your Bluetooth® enabled device.
• If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device and select " **BB-BT-EB** " from the list of paired Bluetooth® devices and press **"forget this device"** and then proceed to follow the instructions on how to pair the earbuds to a Bluetooth® enabled device.

1. Multi-Function Touch Control Button
2. LED Indicator Light
3. LED Battery Meter display
4. Strap



WARNING

Read the following warning thoroughly before you start using your earbuds. Store this manual with product packaging for future reference. The safety precaution warning helps reduce the risk of fire or injury when strictly adhered to.

TO REDUCE THE RISK OF INJURY
• Keep batteries out of reach of children.
• Do not heat, open, or dispose of product in fire.
• Do not allow metal objects to touch the battery contacts on the earbuds and inside charging case.
• Do not expose battery pack to excessive heat.

TROUBLESHOOTING

No power	Recharge your earbuds using the included USB charging cable. Try using a different USB cable.
Music is not playing over Bluetooth®	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the earbuds to reconnect your Bluetooth® device.
Bluetooth® device will not reconnect with the earbuds	Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap " **BB-BT-EB** " and select **"Forget."** Now follow the steps to pair your device again.

It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for listening to music.

AUTO PAIRING

• Open the charging case and take earbuds out, the earbuds will automatically turn on. To pair the earbuds with your Bluetooth® enabled device, open the Bluetooth® setting on your device and select " **BB-BT-EB** " After the initial pairing, the earbuds should pair to the device automatically every time they are taken out of the case.

OPERATION

POWER ON/OFF
• Remove the earbuds from the charging case. The earbuds will automatically turn on.
• Place earbuds into charging case to automatically turn off.

PLAY/PAUSE MUSIC
When listening to music:
• Tap the left or right earbud once to play or pause the music.

PREVIOUS/NEXT SONG
When listening to music:
• Tap the left earbud two times to go to Previous Song.
• Tap the right earbud two times to go to Next Song.

VOLUME -/+
• Tap the right earbud three times to increase Volume.
• Tap the left earbud three times to decrease Volume.

ANSWER/HANG UP CALL
When there is an incoming call:
• Tap left or right earbud once to answer the call.
• Tap left or right earbud again to end the call.

REJECT INCOMING CALL
When there is an incoming call:
• Press and hold left or right earbud for 2 seconds to reject the call.

VOICE ASSISTANT
• Press and hold left or right earbud for 3 seconds to activate Siri voice assistant.
PLEASE NOTE: The Voice Assistant Feature is only available when the earbuds are paired with your iOS Smartphone or Tablet device. This feature will not work with any other Bluetooth® enabled devices connected to your earbuds.

CHARGING FUNCTION

RECHARGING THE BATTERY IN THE CHARGING CASE
• There is a USB-C cable included in the box.
• Connect it to the USB type-C charging port on the charging case and the other end into a USB power source to charge your case. While charging, the LED lights on the charging case will flash.
• The number on the outside of the case indicates how much battery life the case currently has on a scale of 0-100%.
• When the battery of the charging case is fully charged , the number displays "100" on the charging case.

EARBUDS CHARGING
• Earbuds light will turn solid red, and LED display of case will flash white. After fully charged, the LED indicator light on the earbuds will go out.
LED display of case will solid white for several seconds and then go out.
• Place the earbuds back into the charging case to recharge.
• While charging, the LED indicator lights on the earbuds will turn solid Red. When the earbuds have been completed charged, the LED indicator light on the earbuds will go out.

FCC Information **FCC ID: 2AML6KR419A**
This device complies with Part 15 of the FCC rules.
Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.
Federal Communications Commission (FCC) Statement
This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard. FOR HOME OR OFFICE USE.

Warning :
This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

RECYCLE RBRC Li-ion 1-800-822-8837

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle battery according to local, state and national regulations.

Battery information
Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.

Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.
Never use any charger that is damaged.
Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 15℃ and 25℃ (59°F and 77°F).
A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

LIMITED WARRANTY

ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor at any product the exterior of which has been damaged or defaced which design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases & Accessories, Inc.

The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases & Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases & Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liabilities and responsibilities of ESI Cases & Accessories, Inc. be liable or in any way responsible, for any incidental of consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

This warranty does not cover cables that have become frayed, cracked, or broken from use. The user should immediately replace this, or any, charge cable that has become frayed, cracked, or broken, as it may constitute a serious safety risk, including electrocution, if it is continued to be used.

Send product with $11.95 shipping & handling fee to:
ESI Cases & Accessories
One Gateway Center, Suite 2600 Newark, NJ 07102
TechSupport@ESICellular.com

EARBUDS PAIR AS BB-BT-EB **VENDOR ADD FCC ID #**