



Wireless Remote Control Puck Lights

BATTERY INSTALLATION: To open, turn back cover of puck light counterclockwise and remove. Insert 3 AA batteries (noting polarity). To close, replace cover and turn clockwise

REMOTE: To replace exhausted battery, open the battery compartment on the back of the remote. Insert 1 A23 battery. Replace cover.

IMPORTANT: Different types of batteries or new and used batteries should not be mixed. Exhausted batteries should be removed from the fixture and disposed of properly.

OPERATION: To turn ON or OFF, push lens or use remote. "I"= ON "0"=OFF

MOUNTING INSTRUCTIONS:

- Use included screws or double-sided tape to mount battery door where you want it.
- When installing using screws, screw through holes in battery door. Do not over tighten.

NOTE: Battery door may remain mounted when changing batteries.

FCC STATEMENT: This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC STATEMENT : This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. To comply with FCC's RF radiation exposure limits for general population/uncontrolled exposure, this device must be installed to provide a separation distance of at least 20cm from all persons. **WARNING:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MADE IN CHINA/HECHO EN CHINA

©2017 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jasco Products Company, LLC. All other brand names are trademarks of their respective owners. Neither Jasco Products Company, LLC nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

Questions? Contact us at 1-800-654-8483 between 7:00AM-8:00PM CST. 90-day warranty. Visit www.byjasco.com for warranty details.

⚠ WARNING

- BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY AND PRODUCT DAMAGE
- DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES
- REPLACE ALL BATTERIES AT THE SAME TIME
- REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIODS OF TIME



Luces táctiles con control remoto inalámbrico

INSTALACIÓN DE LAS PILAS: Para abrir, gire hacia la izquierda la tapa posterior de la luz táctil y sáquela. Coloque 3 pilas AAA (según la polaridad). Para cerrar, vuelva a colocar la tapa y gire hacia la derecha.

CONTROL REMOTO: Para cambiar la pila, abra el compartimento de estas ubicado en la parte posterior del control. Coloque la pila A23. Vuelva a colocar la tapa.

IMPORTANTE: No se deben mezclar distintos tipos de pilas ni tampoco las nuevas con las usadas. Las pilas agotadas se deben sacar del aparato y deben desecharse de manera adecuada.

FUNCIONAMIENTO: Para encender la luz, presione la lente o use el control remoto.

"I" = ENCENDIDO "0" = APAGADO

PARA UNA INSTALACIÓN:

- Utilice tornillos incluidos o cinta de doble cara para montar la puerta de la batería donde dese.
- Al instalar con tornillos, tornillo agujeros en la puerta de la batería. No apretar en exceso.

NOTA: Puerta de la batería puede permanecer montado al cambiar las pilas.

FCC Declaración Este dispositivo cumple con la Parte 15 de las Normas de la FCC. La operación está sujeta a las siguientes dos condiciones: (1) este dispositivo no puede causar interferencias perjudiciales y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan provocar una operación indeseable.

FCC NOTA: Los cambios o modificaciones a esta unidad que no hayan sido expresamente aprobados por la parte responsable del cumplimiento de las reglas, pueden anular la autoridad del usuario para poder operar el equipo.

NOTA: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la Parte 15 de las Normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias en una instalación residencial.

Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencia dañina a la comunicación por radio. Sin embargo, no hay ninguna garantía que no ocurra interferencia en una instalación en particular. Si este equipo causa interferencias perjudiciales a la recepción de radio o televisión, esto se puede comprobar apagando y encendiendo el equipo repetidamente, se le sugiere al usuario tratar de remediar la interferencia tomando una o más de las siguientes medidas.

- Reorientar o reubicar la antena de recepción
- Aumentar la separación entre el equipo y el receptor
- Conectar el equipo a un tomacorriente en un circuito distinto de aquel al que está conectado el receptor
- Consultar al distribuidor o a un técnico de radio / TV para obtener ayuda.

⚠ ADVERTENCIA

- LAS PILAS PUEDEN PERDER LÍQUIDOS PERJUDICIALES O MATERIALES INFLAMABLES, O EXPLOTAR Y CAUSAR LESIONES Y DAÑOS EN LOS PRODUCTOS
- NO COMBINE PILAS VIEJAS Y NUEVAS, NI TIPOS DE PILAS DISTINTAS
- REEMPLACE TODAS LAS PILAS AL MISMO TIEMPO.
- QUITE LAS PILAS SI NO USARÁ EL PRODUCTO DURANTE PERIODOS PROLONGADOS

©2017 Energizer. Energizer y algunos diseños gráficos son marcas comerciales de Energizer Brands, LLC y subsidiarias relacionadas, que se utilizan bajo la licencia de Jasco Products Company, LLC. Todos los demás nombres de marca que aparecen son marcas comerciales pertenecientes a sus respectivos propietarios. Ni Jasco Products Company, LLC ni Energizer Brands, LLC están relacionados con los propietarios respectivos de sus marcas comerciales. ¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7:00 a.m. y las 8:00 p.m. CST (hora central estándar) Garantía de 90 días. Visite www.byjasco.com para conocer los detalles de la garantía.