| ART DEPARTMENT | | | |
|---|---|---|---|
| Job # // Filename<br>2018-05-22_SI_ToyRCBoxingRobots_BikTeaDry | | Product Line<br>Sharper Image | |
| Designer<br>Jack Ma / Luna Qin/Nick Xue | Brand Manager<br>Lisa Nagamoto | Finished Size<br>12.8" L x 13.625" H x 8.66" W / 32.51cm L x 26.96cm H x 22cm W | |
| File Formed<br>Adobe Illustrator CC (live)/CS4 (OL) | Fonts<br>DIN Next, Gotham, Helvetica Neue | Color (Spot or 4C)<br>4 Color Process | # of Colors<br>4 |
| Printing Process / Finishing<br>Matte PP Coating | | Comments | |

All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by INTERCHANGE LLC, or any third party licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both locally and internationally.
















REMOTE CONTROL BOXING BATTLE ROBOTS

REMOTE CONTROL BOXING
# BATTLE ROBOTS

**SAFETY PRECAUTIONS:**
- Do not use the product near small children or animals, the detachable head can pose a choking hazard.
- Adult supervision is recommended at all times.
- Avoid water, sand and snow when operating your vehicle. Never submerge any portion of your product in water.
- Keep product away from direct rays/sources of heat, under direct sunlight or outside overnight as this is harmful to internal components.

**BATTERY WARNING:**
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Batteries must be removed or disposed of when dead. Dispose of batteries according to federal, state, and local laws. Do not dispose of batteries in a fire, as they may leak or explode.
- Only use manufacturer-specified batteries/jacks, chargers and/or adapters. If applicable, ensure that they are compatible.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

**SAFETY WARNINGS: PLEASE READ BEFORE USING PRODUCT**
- RECOMMENDED: Do not mix batteries (old and new or carbon and alkaline), or another charger's AC adaptor/battery, as it can cause the batteries to leak chemicals and damage the unit. Handling and use to reduce the risk of electrical shock.
- Use only as described in this manual.
- Use only recommended accessories from or authorized by the manufacturer.
- Do not lay this item into animals, pouch, or hazardous objects.
- Do not attempt to recharge batteries with another charger's AC adaptor/battery, as it can cause the batteries to leak chemicals and damage the unit.
- Always use caution when using this item.
- Always supervise children when using this item.
- Always use caution when using this item around high wire.
- Do not use this item if damaged.
- Do not attempt to repair this item.
- Do not use this item in wet/damp conditions.
- Do not use this item near heat sources.
- Do not use this item in rain.

0000000 (00000)

Made in China

©2018 Sharper Image. Sharper Image® name and logo are registered trademarks of SI, LLC, New York, NY.
Distributed by NeoVentures, LLC, Irvine, CA 92618.

For customer support, please call 1-800-374-2744.

China Patent No. ZL201130191154.7, ZL201330004279.4
US Design Patent No. D712,983

**OPERATING INSTRUCTIONS**

Each robot requires 3 "AAA" 1.5V batteries (not included). Each remote control requires 1 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for best performance.

1. Carefully remove items from the package.
2. Locate the battery compartment on the back of each robot, as well as remote control.
3. On robots, loosen the screws and remove battery doors. Slide doors open on to units.
4. Insert "AAA" batteries inside robots while observing the correct polarity in each compartment (see diagram). Insert one 9V battery into each remote control.
5. Replace battery doors and tighten screws.
6. Switch robot and remote control power switches to the "ON" position.
The power switch is located on the side of the robot(s).

**NOTE: Before use, adjust the robots to make sure both feet have good contact with the ground before use. Use on a hard, flat surface for best results.**




**OPERATING CONTROLS**
- Push both levers on to move forward.
- Pull both levers back to move backwards.
- Push left lever to turn left.
- Push right lever to turn right.
- Push left lever on to spin left and right lever back to spin clockwise.
- Push the left lever down and the right lever up to spin counter-clockwise

**HOW TO PLAY**

There are sensors located beneath each robot's chest plate. The object of the game is to punch the opponent's chest plate to cause the head to eject. Once the robot thrus opening the robot's head). To restore the head, place it face forward onto the neck and gently press down until it clicks into place.

**WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.**

REMOTE CONTROL BOXING BATTLE ROBOTS