

MINISO

USER MANUAL

使用説明書

Outdoor Portable Speaker with Strap

Enceinte avec Sangle Portable pour Extérieur

ساعات محمولة مع حزام

Atavoz Portátil com Correa para Exteriores

戶外携提扬声器

MODEL: A168

MINISO A168 户外携提扬声器

Dear customer

Thank you for using Miniso Wireless Speaker. Please read this manual carefully before use. Using it properly for best product performance. MINISO Wireless Speaker has stylish appearance, true-to-life sound and multiple functions. The whole series have the patent of appearance design. The system adopting the industry-leading technology enables you to enjoy the excellent sound effects anytime at home, outdoors, during a trip or music on your laptops, digital music players and other audio-visual players, leading you to a better life with beautiful music!

Specifications

BT Version: V5.4
Pairing Name: MINISO-A168
Charging Input: 5V === 500mA
Battery Capacity: 500mAh
Charging Port: USB-C
Transmission Distance: Around 10m
Music Playback Time: 4h (70% volume)
Charging Time: Around 2h

Contents

Speakers1, Charging Cablex1, User Manualx1

Product Diagram

①Power Button
②USB-C Charging Port

Functions

Function	Instructions
Power ON/Off	Long press power button
Play/Pause	Press power button
Previous	Short press three times to move to previous track
Next	Short press twice to move to next track
Charging Indicator Light	When charging, red light is on, and turns off when fully charged

Cautions

- Please use and store the equipment and accessories within the temperature range of +10°C~45°C. When the temperature is too high or too low, it may cause malfunctions.
- Please place the device and its accessories in a ventilated, cool place away from direct sunlight.
- Do not disassemble, hit, crush the product or throw the device into fire to avoid explosion. If the battery bulges or leaks, stop using it.
- When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, etc.).
- Due to the features of BT technology, the strength of the signal is related to the specific environment. If there are more overlapping wireless signals nearby or there is strong electromagnetic interference, the signal received by the BT speaker may become weaker or even disconnected.
- If not used for a long time, please charge the product once every three months to avoid battery over-discharge damage.
- Stop using the equipment before cleaning or maintaining.

Troubleshooting

- The wireless speaker is unable to be paired with the cell phone.
Solution: Confirm if the wireless speaker is in pairing mode, and if the Bluetooth on your phone is turned on. Then delete the product in the list, pair it with your phone again according to the User Manual.
- The wireless speaker is unable to be turned on.
Solution: Confirm the battery level. Charge the speaker if it is needed.
- Can the battery of the wireless speaker be replaced?
Solution: No, this is lithium polymer battery which is irreplaceable.
- Can I use the wireless speaker at a high volume for a long time?
Solution: To extend the lifespan of the wireless speaker, it is not recommended to play it at a high volume for a long time.
- The link between the wireless speaker and the cell phone has been disconnected within 10 meters.
Solution: Bluetooth is wireless so that it is very sensitive to objects between the speaker and the connected device. Check if there are any metal or other objects that may affect connection within the effective distance.
- Cannot hear audio playing when the speaker is connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.
- Can I operate the Apps of my phone through the speaker after pairing the wireless speaker with the phone?
Answer: Some apps may not support being operated through the speaker due to their settings.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

IC Warning

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS-102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

WEEE Warning

Do not dispose of electrical appliances as unsorted municipal waste. Use a separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfill or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

The charging device is not included.

The power delivered by the charger must be between min (2.5) Watts required by the product, and max (2.5) Watts. In order to achieve the maximum charging speed.

Cher client

Merci d'avoir choisi l'enceinte sans fil MINISO. Veuillez lire attentivement ce manuel avant utilisation. Utilisez-la correctement afin de profiter pleinement des performances du produit. L'enceinte sans fil MINISO se distingue par son design élégant, une qualité sonore réaliste et de multiples fonctions. Toute la série bénéficie d'un brevet de design. Grâce à une technologie de pointe dans le secteur, vous pouvez profiter d'effets sonores remarquables à tout moment, que ce soit à la maison, en plein air, en voyage ou au travail. Elle vous offre une expérience parfaite lorsque vous écoutez de la musique sur vos ordinateurs portables, lecteurs de musique numérique et autres lecteurs audiovisuels, vous permettant de profiter d'une vie meilleure grâce à une belle musique !

Spécifications

Version BT: V5.4
Nom d'appariement: MINISO-A168
Entrée de Charge: 5V === 500mA
Capacité de la Batterie: 500mAh
Charging Port: USB-C
Distance de Transmission: Environ 10m
Temps de Lecture Musicale: Environ 4h (70% volume)
Temps de Charge: Environ 2h

Contenu

Enceinte x1, Câble de Recharge x1, Manuel d'Utilisation x1

Schéma du Produit

①Bouton d'Alimentation
②Port de Chargement USB-C

عربي المستخدم

شكرًا لاختيارك السماعات اللاسلكية من مينيسو. يرجى قراءة دليل المستخدم بعناية قبل الاستخدام. يوتي السماعات اللاسلكية مينيسو مظهرًا أنيقًا وخصائص تصميم رائعة. بفضل التكنولوجيا المتقدمة، يمكنك الاستمتاع بجودة الصوت المتميزة في أي وقت وفي أي مكان. سواء كنت تستمع إلى الموسيقى على هاتفك المحمول أو تلعب الألعاب، فإن السماعات توفر لك تجربة صوتية رائعة. يرجى قراءة دليل المستخدم بعناية قبل الاستخدام.

المواصفات

إصدار البلوتوث: 5.4
اسم الاقتران: MINISO-A168
إدخال الشحن: 5 فولت === 500 مللي أمبير
سعة البطارية: 500 مللي أمبير الساعة
USB-C
مسافة النقل: حوالي 10 أمتار
مدة التشغيل: حوالي 4 ساعات عند مستوى صوت 70%
مدة الشحن: حوالي ساعتين

وصف المنتج

① زر تشغيل/إيقاف
② منفذ شحن USB-C

الوظائف

الوظيفة	طريقة التشغيل
تشغيل/إيقاف التشغيل	اضغط مطولاً على زر التشغيل/الإيقاف
تشغيل/إيقاف مؤقت	في وضع التشغيل، اضغط زر التشغيل/الإيقاف
المنقلع السابق	اضغط 3 مرات للمسار السابق
المنقلع التالي	اضغط 2 مرات للمسار التالي
المؤثر	اضغط مرة واحدة على زر المؤثر

تحذير

- يستخدم وتحت درجة حرارة سالبة إلى 10 درجة مئوية.
- يجب تجنب التعرض المباشر للشمس أو الحرارة المفرطة. تجنب تعريض المنتج لأي شكل من أشكال التلف.
- لا تفك أو تدمر أو تحرق المنتج أو أي من أجزائه. تجنب التعرض للماء.
- لا تضع المنتج في الماء أو في مكان قريب من الماء.
- لا تضع المنتج في مكان قريب من النار أو في مكان قريب من النار.
- لا تضع المنتج في مكان قريب من النار أو في مكان قريب من النار.

اكتشاف الأعطال وإصلاحها

- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.
- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.
- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.
- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.
- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.
- إذا لم يكن المنتج يعمل، تحقق من أن البطارية ممتلئة.

Estimado/a cliente

Gracias por elegir el altavoz inalámbrico MINISO. Lea atentamente este manual antes de utilizar el producto para garantizar un uso correcto y obtener el mejor rendimiento. El altavoz inalámbrico MINISO presenta un diseño elegante, tamaño compacto, sonido nítido y múltiples funciones. Toda la serie cuenta con patente de diseño. Su sistema adopta tecnología avanzada, lo que le permite disfrutar de un sonido de alta calidad en cualquier lugar, en casa, al aire libre, de viaje o en el trabajo. Ofrece una experiencia excelente al reproducir música en computadoras portátiles, reproductores de música digital y otros dispositivos audiovisuales, para que disfrute de una vida mejor llena de música maravillosa.

Especificaciones

Versión BT: V5.4
Nombre de Emparejamiento: MINISO-A168
Entrada de carga: 5V === 500mA
Capacidad de la batería: 500mAh
Puerto de carga: USB-C
Distancia de transmisión: Aproximadamente 10m
Tiempo de reproducción de música: Aproximadamente 4h (70% de volumen)
Tiempo de carga: Aproximadamente 2 h

Diagrama del Producto

①Botón de encendido/apagado
②Puerto de carga USB-C

Funciones

Función	Instrucciones
Encender/Apagar	Mantener presionado el botón de encendido/apagado
Reproducir/Pausar	Presionar el botón de encendido/apagado
Anterior	Pulsar brevemente tres veces para la pista anterior
Siguiente	Pulsar brevemente dos veces para la pista siguiente
Luz	Durante la carga, la luz roja está encendida y se apaga cuando la batería está completamente cargada

Precauciones

- Use and store the equipment and its accessories within the temperature range of +10°C~45°C. When the temperature is too high or too low, it may cause malfunctions.
- Do not disassemble, hit, crush the product or throw the device into fire to avoid explosion. If the battery bulges or leaks, stop using it.
- When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, etc.).
- Due to the features of BT technology, the strength of the signal is related to the specific environment. If there are more overlapping wireless signals nearby or there is strong electromagnetic interference, the signal received by the BT speaker may become weaker or even disconnected.
- If not used for a long time, please charge the product once every three months to avoid battery over-discharge damage.
- Stop using the equipment before cleaning or maintaining.

Solución de problemas

- The wireless speaker is unable to be paired with the cell phone.
Solution: Confirm if the wireless speaker is in pairing mode, and if the Bluetooth on your phone is turned on. Then delete the product in the list, pair it with your phone again according to the User Manual.
- The wireless speaker is unable to be turned on.
Solution: Confirm the battery level. Charge the speaker if it is needed.
- Can the battery of the wireless speaker be replaced?
Solution: No, this is lithium polymer battery which is irreplaceable.
- Can I use the wireless speaker at a high volume for a long time?
Solution: To extend the lifespan of the wireless speaker, it is not recommended to play it at a high volume for a long time.
- The link between the wireless speaker and the cell phone has been disconnected within 10 meters.
Solution: Bluetooth is wireless so that it is very sensitive to objects between the speaker and the connected device. Check if there are any metal or other objects that may affect connection within the effective distance.
- Cannot hear audio playing when the speaker is connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.
- Can I operate the Apps of my phone through the speaker after pairing the wireless speaker with the phone?
Answer: Some apps may not support being operated through the speaker due to their settings.

尊敬的客戶

感謝您選擇MINISO無線音響產品。請在使用前仔細閱讀此說明書。MINISO無線音響產品具有時尚外觀、真實還原音質、多種功能。整個系列均擁有外觀設計專利。該系統採用行業領先技術，使您無論在室內、戶外、旅行或工作時，都能享受優質音響效果。請在每次長時間不使用後，為電池充電一次，以確保電池健康。請在每次長時間不使用後，為電池充電一次，以確保電池健康。

產品參數

無線版本: V5.4
無線名稱: MINISO-A168
充電輸入: 5V === 500mA
電池容量: 500mAh
充電接口: USB-C
傳輸距離: 約10m
音樂時間: 約4h (70%音量)
充電時間: 約2h

包裝清單

1. 無線音響 x1
2. 充電線 x1
3. 說明書 x1

功能操作介紹

功能	操作
開機/關機	長按開機鍵
暫停/播放音樂	長按開機鍵
上一曲	短按下一開關鍵
下一曲	短按下一開關鍵
充電指示燈狀態	充電時亮紅燈，充滿後熄滅

注意事項

- 避免將產品存放在溫度低於-10°C或高於45°C的環境中。溫度過高或過低可能會導致產品故障。
- 請勿拆解、敲打、擠壓產品，或將產品投入火中，以免發生爆炸。如果電池膨脹或漏液，請立即停止使用。
- 使用時，請將產品與植入式醫療設備（如心臟起搏器等）保持至少15厘米的距離。
- 由於藍牙技術的特性，信號強度與環境有關。如果附近存在較多無線信號或強電磁干擾，可能會導致信號接收不穩定。
- 如果長時間不使用，請每三個月為產品充電一次，以確保電池健康。
- 請勿將產品投入火中，以免發生爆炸。
- 請勿將產品投入火中，以免發生爆炸。

故障排除

- 無線音響無法與手機配對。
解決方法: 確認無線音響是否處於配對模式，並檢查手機上的藍牙功能是否已打開。然後刪除產品，重新配對。
- 無線音響無法打開。
解決方法: 檢查電池電量。如果電池電量不足，請為電池充電。
- 電池電量不足。
解決方法: 為電池充電。
- 藍牙音響無法與手機配對。
解決方法: 檢查手機上的藍牙功能是否已打開。然後刪除產品，重新配對。
- 藍牙音響無法與手機配對。
解決方法: 檢查手機上的藍牙功能是否已打開。然後刪除產品，重新配對。
- 藍牙音響無法與手機配對。
解決方法: 檢查手機上的藍牙功能是否已打開。然後刪除產品，重新配對。

尺寸:52*52mm(单页)
材质:105g铜版纸
双面印刷