Damai

Product specification

Product name:	8MxRB8MS Cloud Meeting
Model number:	DB3148US
CPU:	Quad core Cortex-A53
OS:	Android 9x0
RAM:	2GB
Flash:	8GB
POE:	12V ⎓ 1A
Work Environment:	work temperature: 0°C ~+40°C humidity: <90% RH storage temperature: -40°C ~+60°C humidity: <95% RH

Friendly reminder:

- The mobile HDD connected USB port and the requirements of external mobile HDD output current should not be more than 5V 500mA, otherwise the protection circuit will be activated, HDD cannot be used.
- Device needs a minimum of 10cm surrounding gap, do not cover with newspaper and other objects.
- Device is not waterproof, Objects such as vase ⚠ with liquid should not be placed on top of the device.
- Please keep the product away from moisture, sun exposure, high temperature and objects with magnetic fields.
- Please avoid scratches and damages on the casing and interface, avoid dropping or throwing the product, otherwise it may cause damage to the product.
- Please use the original power adapter, to prevent excessive current and other reasons, such as damage to the motherboard and important components.
- Please do not disassemble or repair the product, the maintenance work is limited to the company's authorized staff only.

Packing list



Connecting Interface



Installation instructions



Device connection

1.Connect the HDMI OUT ⎍ of the box with the TV HDMI input.

2.If the box uses wired connection, please connect the wired connection output to wireless router or ADSL Modem, as ☐. When connected to network, the system will configure the network automatically.

3.The box has embedded DHCP, You may start the DHCP function in the box, search for WiFi, and connect.

4.Connect power cord ⎓ of the box.

5.Connect the MIC to the box with the MIC input.

Network configuration

Switch on the box and check the indicator to verify if the box boots properly, then begin to configure the network(Choose wireless or wired connection):

Wired connection configuration:

System setup→Network setup→Choose 'wired connection'

If you choose wired connection, system will configure the network automatically and obtain IP address.

PPPOE configuration

System setup→Network setup→Choose 'broadband dial-up' copy to dial-up interface, Input broadband account(username)/Broadband Operation ADSL account and password, click dial, Begin dial automatically, if this option is checked, system will dial up automatically.

Wireless network configuration

System setup→Network setup→Choose 'Wireless network', the system will search for WiFi signals and the device list automatically.

Type in the right password, click 'network connection', and start network connection.

Camera Operation

1. Push the top to expose or hide the camera.
2. Turn the ring to adjust vertical angle of the camera.

Remote control



FCC Caution

§ 15.21 Modifying requirements.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environments. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Feature warranty

Service Hotline: 1-888-481-4588