

ATEEZ OFFICIAL LIGHT STICK USER MANUAL

배터리 삽입 및 교체 방법

- 제품 손잡이 하단의 캡을 돌려 내부에 있는 배터리 하우징을 꺼주세요.
- 그림과 같이 AAA배터리 3개를 하우징에 결합해주세요.
(배터리 결합 시 +, -극을 잘 확인하여 주세요, 하우징에 스프링이 있는 부분이 배터리로 -극, 스프링이 없는 부분이 +극입니다.)
- 배터리 결합된 배터리 하우징을 제품의 손잡이에 표시된 화살표 방향으로 넣고 한 번 캡을 닫아주세요.
(배터리 하우징을 거꾸로 넣으면 제품이 작동하지 않습니다.)

제품 기능 및 사용 방법

- ATEEZ 공식 응원봉은 무선 컨트롤 기능을 가지고 있는 제품 입니다.
- 전원 설정
응원봉 손잡이에 있는 버튼을 눌러 작동 시킬 수 있습니다.
- LED 모드 설정
화이트 ON → 화이트 Blink → 화이트 Flicker → 레드 오토로 모드 → 그린 오토로 모드 → OFF

제품 사양서

- 제품명 : ATEEZ OFFICIAL LIGHT STICK
- 모델명 : ATEEZ-light01
- 크기 : 100 * 113 * 256 (mm)
- 무게 : 약 180g
- 재질 : PC, ABS, Rubber
- 구성품 : 응원봉, 스트랩, 사용 설명서
- 배터리 : 미포함 (임카리온 AAA 배터리(3개) 사용)
- 사용전압 : 4.5V
- 무선 주파수 : 2.4 GHz
- 작동시간 : 5시간
- 인증번호(KC) : R-R-cdi-ATEEZ-light01
FCC ID : 2AP7NATEEZ-LIGHT01
- 기획 및 판매 : KQ ENTERTAINMENT / PLAY COMPANYY
- 제조사 : COMPACT.D
- 제출일자 : 2020. 01
- 제조국가 : Made in China

취급 시 주의사항

- 고온 다습한 곳을 피하고 보관 시에는 상온에서 유지하여 주세요.
- LED 빛을 가까이 곳에서 직접 보는 것을 피해 주세요.
- 임의 분해 및 조립, 강한 충격이나 물 또는 화기 근처에서 사용하는 경우 제품 고장의 원인이 됩니다.
- 정품 임카리온 AAA 배터리를 사용해 주세요, 정품 배터리를 사용하지 않으면 제품에 손상을 줄 수 있습니다.
- 배터리 교체 시 모든 배터리(3개)를 교체하십시오.
- 제품을 보관할 시에는 배터리역으로 인한 제품 손상을 막기 위하여 배터리를 분리하여 보관하십시오.
- 배터리는 열/우야의 손이 닿지 않는 곳에 보관하여 주시고, 수명이 다 된 배터리는 지정된 폐기장소에 폐기하십시오.
- 반드시 배터리 +/- 극성을 잘 확인한 후 올바른 극성 방향으로 배터리를 장착해 주세요.
잘못된 장착은 제품 고장의 원인이 되며 화재 및 화상의 위험이 있습니다.
- 배터리 부위가 갑자기 뜨거워지는 경우 바로 제거해 주시고 A/S 문의 바랍니다.
- 매회 교환 권장 전 새 배터리로 교체바랍니다.
- 강연 중 갑자기 컨트롤이 되지 않거나 빨간불이 들어오면 새 배터리로 교체바랍니다.
- 본 제품은 무산용량 중 전파 혼신 가능성이 있습니다.

A/S 규정

- 보증기간(구매일로부터 3개월) 이내에 정상적으로 사용한 제품에 대해서는 제품 수리 및 교환 서비스를 무상으로 받을 수 있습니다.
- 수리를 의뢰하실 때에는 반드시 이 보증서를 제시하시기 바랍니다.
- 보증서는 대한민국 내에서만 유효합니다.
- 보증기간은 구매일로부터 3개월 이내 입니다.
- 다음의 경우는 보증기간 이내라도 무상수리를 받을 수 없습니다.
 - 보증기간(구매일로부터 3개월)이 경과한 경우
 - 사용상의 과실, 부주의로 인해 고장, 파손이 발생한 경우
 - 홍수, 화재, 지진 등 천재지변으로 인해 고장이 발생한 경우
 - 사용 중 발생한 흠집 등으로 케이스 교체를 원하는 경우
 - 정식 A/S 센터 외 다른 A/S센터를 이용하거나 제품을 임의의 분해, 수리 또는 개조한 경우

A/S 신청 접수처

PLAY COMPANYY Corp. (TEL: 02-323-0882)
품질보증기간 : 구매일로부터 3개월 (영수증 보관 및 인증 필요)

ATEEZ OFFICIAL LIGHT STICK USER MANUAL

How to Insert Battery and Replace it

- Rotate the battery cap on the bottom of the product to remove the battery housing inside.
- Insert 3 alkaline AAA batteries to the housing as shown below.
(Please check the + and - polarity when inserting the battery.
The part of the battery housing with the spring is the negative pole of the battery, and the part without the spring is the positive pole.)
- Insert the battery housing with the battery in the direction of the arrow on the light stick and close the battery cap.
(The product will not work if the battery housing is turned upside down.)

Product Features and Usage Instructions

- ATEEZ OFFICIAL LIGHT STICK is a product with wireless control function.
- Power Setting
Press the push button in the middle of the light stick.
- LED Mode Setting
When you press the push button, LED mode will change sequentially as below.
White ON → White Blink → White Flicker → Red Aurora mode → Green Aurora mode → OFF

Product Specification

- Product Name : ATEEZ OFFICIAL LIGHT STICK
- Model : ATEEZ-light01
- Size : 100 * 113 * 256 (mm)
- Weight : Approximately 180g
- Materials : PC, ABS, Rubber
- Components : Light Stick, Strap, User Manual
- Battery : Not Included (Use 3 Alkaline AAA batteries)
- Rated Voltage : 4.5V
- Radio Frequency : 2.4 GHz
- Operating Time : 5 Hours
- Certification(KC) : R-R-cdi-ATEEZ-light01
FCC ID : 2AP7NATEEZ-LIGHT01
- Planning and Sales : KQ ENTERTAINMENT / PLAY COMPANYY
- Manufacturer : COMPACT.D (Tel. +82 (0)2 6053 0244 / Address, 2F, 703, Eonju-ro, Gangnam-gu, Seoul, 06041, Republic of Korea)
- Date of Manufacture : Jan 2020
- Country of Origin : Made in China

Precautions

- Avoid high temperature or humidity, and store at room temperature.
- Do not allow the LED light to shine directly in the eyes.
- Arbitrary disassembly and assembly, strong shock or use near water or fire may cause product malfunction.
- Please use genuine alkaline AAA batteries. Failure to use genuine batteries may damage the product.
- Replace all batteries (See) when replacing batteries.
- When storing the product, remove the batteries to prevent damaging the product due to the battery fluid.
- Keep the batteries out of the reach of children/infants. Dispose of used batteries at the designated disposal site.
- Be sure to check the polarity of the batteries before inserting the batteries in the correct polarity direction.
Incorrect inserting may cause product malfunction, and may cause fire and burns.
- If the battery suddenly becomes hot, remove the battery immediately and contact the customer service center.
- Please replace with new batteries before each show.
- If the light stick suddenly does not work at the show or red lights come in, please replace with new batteries.
- This product may be interrupted during wireless operation.

Customer Service Rule

- You can get product repair and exchange service free of charge for normally used products within the warranty period (3 months from date of purchase).
- Be sure to present this warranty the requesting repair.
- Warranty is valid only in Korea.
- The warranty period is three months from the date of purchases.
- In any of the following cases, you cannot get free repair even within the warranty period.
 - If the warranty period (3 months from date of purchase) has expired
 - Failure or damage caused by negligence or negligence in use
 - Failure due to natural disasters such as flood, fire or earthquake
 - If you want to replace the case due to scratches during use
 - Any use of customer center other than the official customer center, or any disassembly, repair or modification of the product

Application for Customer Service

PLAY COMPANYY Corp. (TEL: 02-323-0882)
Warranty period : 3 months from date of purchase (Receipt verify required)

