Milestone


Thermal Printe r
热敏打印机

MHT-P8008



Reading manual to use it better
阅读使用手册，以便更好地使用

1, Accessory instruction 部件说明





1. Power light
电源灯
2. Error light
错误灯
3. Charging light
充电灯
4. Bluetooth light
蓝牙灯
5. Type-C/Data transmission
充电口/数据传输
6. Turn on/off button
开关键
7. Open paper depot button
开仓键
8. Go out paper button
出纸键

Instruction light/button situation introduction 指示灯/按键状态说明	Situation 表示状态
Power light 电源灯	Green light is on all time when turn on 开机时常亮蓝灯
Charging light 充电灯	Red light is on when charging 充电时显示蓝灯
Error light 错误灯	Red light is on when cover is not close rightly 翻盖无闭合显示蓝灯
Go out paper button 出纸键	Paper will be going out when pressing it 轻按走纸

2. Install paper function 纸卷安装

■ Install paper function 安装纸卷

A4打印机采用是装置机构，装纸非常方便，纸张安装方法如下

① Pressing button to open cover（figure one）
按压顶盖开启按钮，打开顶盖（如图一所示）

② Installing paper（figure two）
安装纸卷（如图二所示）

③ Pull out part paper,close the cover,to make sure sides of cover both close rightly, As shown in figure three（figure three）
拉出部分纸卷，闭合顶盖，请确保顶盖两侧都闭合（如图三所示）

④ Rip off left paper,As shown in figure four
撕掉纸刀方向箭去多余的纸张（如图四所示）



（figure one）
（图一）



（figure two）
（图二）



（figure three）
（图三）



（figure four）
（图四）

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

售后服务请扫码关注

美恒通智能电子（广州）股份有限公司
Milestone Intelligent Electronics(Guangzhou)Co.,Ltd.
地址：广州市增城区新塘镇太平洋工业区140号
全国售后服务热线:4009-658-020

3. Software Download 软件下载

Search TattooPrinter Google store
扫一扫二维码下载软件并安装

网站下载地址：
https://www.mhtclouding.com
/tattooprint/download.html

4. Driver download 驱动下载

扫描下方二维码，下载驱动

网站下载地址：
https://www.mhtclouding.com/mht/service.html#driver

5. Device date 设备参数

Effective printing width 有效打印	210mm
Resolution 分辨率	203dpi
Weight 产品重量	1350g
Size 产品规格	267mm*95mm*51mm
Battery capacity 电池容量	1500mAh
Connecting way 连接方式	Bluetoth+USB 蓝牙+USB
Input 输入	5V⎓2A
paper size 耗材规格	paper size:A4 官方A4热敏纸

6. Common problem 常见问题

Problem 故障现象	Reason 故障原因	Method 解决方法
Don't have date when printing 打印时没打印数据	The paper is loaded backwards 打印纸装反	Correct the paper orientation 修正放纸方向
Blurred printing 打印模糊	The printer is not open for a long time, and the consumables are bad 打印机长期不清洁/耗材不良	Close the printer and replace standard consumables 清洁打印机/更换标准耗材
The printer keeps making sounds 打印机一直发出滴滴声	The cover is not tight or the paper is not installed correctly 纸仓没盖紧/耗材安装不正确	Close the lid or put the paper correctly 盖好纸仓/正确安装耗材
The printer automatically turns off / prints intermittently 打印机自动关闭/打印间歇	Battery exhausted 电池电量将耗尽	Charging soon 请立即充电

7. Notes on charging and printing head 打印头、充电注意事项

● Notes on charging and printing head
打印头注意事项

1.It is recommended not to print in high humidity and dusty areas.
建议不要在高湿度和多灰尘地带打印。

2.The print head is too hot after printing, please do not touch it directly.
打印后，打印头过热，请勿直接触摸。

3.When changing the printing paper, do not touch the print head.
更换打印纸时，请勿触摸打印头。

4.To prevent static electricity from damaging the print head, please do not touch the print head.
为防止静电对热敏打印头造成损坏，请勿触摸打印头。

● Note when charging
充电注意事项

1. Do not vigorously plug in or unplug the charging cable.
请勿猛力插入或拔掉充电线。

2. Please disconnect the plug in time after charging.
充电完成后，请及时断开充电器插头。

3. Please use the original power cord for charging, otherwise the printer may overheat, catch fire and burn.
请使用原装电源线进行充电，若使用其他电源线充电，可能导致打印机出现过热、起火或燃烧等危险情况。

4. Do not charge in high temperature environment.
请勿在火源旁，户外烈日下或其他出热电方进行充电。

尺寸	90mm*200mm	颜色	四色印刷
工艺	上光油	注意事项	装订方式：风琴折
材质	128G双铜纸		