

maxwest

NEO flip PLUS

User Manual

Basic Knowledge

Introduction

- Thank you for choosing our digital color screen mobile phone. By reading these guidelines before using your mobile phone you will have an overall knowledge of this phone set and understand its simple but outstanding functions.

- This phone set is designed for GSM networks. On top of basic functions, it enables you to use name card style contacts, clock/ alarm, calendar, calculator, games, audio player, camera , video recorder , image/FM radio and other functions. It serves your work and leisure time. Having unique interface and perfect feature designing this phone set meets all your expectation.

- Our phone set meets the GSM standard and has the qualification from related organizations worldwide.
- Our company reserves the rights modifying the content in this instruction without pre-notice.

Safety information

- Under the circumstance of stealing and lost, contact the telecom branch or sales outlet immediately.
- When you contact with telecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the back of the phone set, remove the battery to discover it). Please record the IMEI number and keep it safe for future use.
- To prevent miss usage of your phone set please take precautions such as:
 - Set the PIN number of the SIM card, and update it timely
 - When get off the car. Please do not leave the phone set unattended, keep it with you or in the suitcase.
 - Set call barring.

Safety and health precautions

- Read the guidelines before using your phone. Failure to comply with them may be dangerous.

Description of Keys

Name of key	Letters or functions
Key	Off/On/ : / : /
Key	ABCDEF
Key	DEFdef
Key	GHIghi
Key	JKLjkl
Key	MNOMno

- 1 -

3. Call logs

3.1.Missed calls

In Call logs menu, choose Missed calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.

3.2.Dialed number

In Call logs menu, choose Dialed number and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.

3.3.Received calls

In Call logs menu, choose Received calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.

3.4.Rejected calls

In Call logs menu, choose Rejected calls and press "OK key" to view the records.

3.5.Delete call

Your phone allows you to delete all of call logs.

3.6.Call timers

Your phone allows you to view the timers for calls made and received.
In Call logs menu, choose Call timers, press "OK key" to view the content.
* Last Call: List out the last call time of your conversation
* Received calls: Sum of total call time you have received.
* Dialed calls:Sum of total call time you have dialed.
* Reset All: Reset the time counter to zero.

4. Settings

4.1.Call Settings

Your phone provides the following selections for your option: Sing/SIM:Standby mode/Reply by original SIM/Set SIM name
Call divert/call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel all divers
Call waiting: Activate/Deactivate/Query Status.

- 6 -

Key	PORSpspt7
Key	TUVuvx8
Key	WXYZzyz9
Key	0
Key	1.After inputting telephone number, if you want to input extension number, please press twice asterisk key, after the display screen shows "+", please input your extension number. 2.*-?@: / # \$ % & * 3.
Key	1. In text editing interface, press "H" key to switch text the input method. 2. On the standby interface Press and hold "H" key to transfer the profile of General/Silent/Vibrate.
Scrolling Up	Move cursor up
Scrolling down	Move cursor down
Scrolling left	Move cursor left
Scrolling right	Move cursor right
Left soft key	In the standby mode, press Left Soft key to access Main menu, Right Soft key to access Contacts.
Right soft key	
OK key	determining options
Dial key	dial telephone numbers and receive incoming calls
End	1.Return to idle screen 2.End calls or reject incoming calls

Description of functions

Key	The SIM card's signal strength of the cellular network at your current location.
Key	The battery charge level.
Contacts	

- 2 -

Store	You can review pictures you have taken by pressing OK.
DV mode	Switch to DV mode
Effect	Set photo color
Settings	Size/Set photo size Quality/Set photo quality Banding/to avoid flashing Shutter sound/activate/off Auto save/activate/off Storage/phone/memory card

5.2.DV
You can record the video clip through built-in camera.The status of your video recorder setting will be displayed on the top of preview mode.To start using Video recorder in Multimedia menu, select Video recorder and press "OK key"
Press Options to personalize your camera setting.

5.3.Video
Key video play function
Press play or pause video
Short press choose the previous or next music
Note: You can adjust this volume +/- through scrolling right/left key.Press Sky to adjust brightness.
Play: Allows you to play the video saved in the My stuff.
Local play list:List the video files of phone and memory card.
Shuffle/whether to shuffle play
Repeat:to set the play mode/offrepeat all/repeat one
Settings:Local video play mode/settings reset/help
Details:to view the details of a video file

5.4.Image

View the images

5.5.Recorder

6. File manager

To view the file memory.

- 8 -

Message
Call logs
Settings
Multimedia
File manager
Application
Profiles
FM Radio
Audio
Calendar

In the main display, you may see several icons shown on your status bar.

1. Contacts

You can use the Contacts features business card information will be stored to mobile phones.

1.1 Quick search

Enter the name of the first letter in the contacts to find qualified records.

1.2.New

In the options, add a telephone number to phone or SIM card.

1.3.Delete multiple
choose to delete phone numbers from SIM or Phone, you can mark all of the phone numbers then choose "OK" to delete - you can also choose to delete them one by one.

- 3 -

7. Application

7.1. Calculator

This function enables you to add, subtract, multiply and divide.
The screen will initially display the number "0". Enter the first number to be calculated.

7.2.Alarm

To set a new alarm, alarm clock icon will be displayed when an alarm is active.
At the same time, three groups can be set up alarm clock.

7.3.Bluetooth

Your phone provides the following selections for your option: Bluetooth/Bluetooth visibility/Paird device/Transferring files/device name/Bluetooth file storage/help
According to the menu, will enter the corresponding function setting.

8. Profiles

Normal: Suitable for normal use.
Silent: Suitable for silent use.
Meeting: During the meeting, suitable for use.
Outdoor: Suitable for outdoor use
Indoor: Suitable for indoor use.

9. FM radio

You can listen to Fm radio freely with plug in the earphone.
Enter the radio interface, search the frequency. (87-106.)
Auto search and save/Channel list/save/Manual search/dese/open speaker/background play
+Auto search and save/Search frequency available automatically.

- 9 -

1.4.Import/Export

Copy

Copy contacts from phone/SIM card to SIM card/phone.

Import contacts

Import contacts file from phone or memory card to Contacts.

Expert contacts

Choose some phone numbers in contacts then export them to phone or memory card.

1.5.Others

Own number

To edit the name and the number of your SIM card.

Service number

Support the steps for reaching actual people to solve your problem.

Memory status

To view the capacity of SIM card and phone.

1.6.groups

You can view and edit the details of the group and members of the group to remove or add operation.
Your phone provides the following selections for your option key:
Family/Friends/Business/Classmates

New group

Add a new group

Mass texting

Send SMS to many phone numbers that you select from Contacts.

2. Message

2.1.Write message

You could write new message by using this function. When you input the message to be sent, press left soft key to send, to insert the templates, to add contact person information, to add phiz and to save, etc. Within the write message menu you can write and edit text message up to 160 characters.

2.2.New

In the options, add a telephone number to phone or SIM card.

2.3.Delete multiple

choose to delete phone numbers from SIM or Phone, you can mark all of the phone numbers then choose "OK" to delete - you can also choose to delete them one by one.

- 4 -

— Channel list: You can view all the broadcasting stations you saved.
—save:Save a channel to channel list.

—Manual search: Search the broadcasting station by input frequency manually.
—desopen speaker:You can start up loudspeaker to make the sound louder.
—background play:you can do other operations while listening to the radio.
—Record:to record a channel.
—Timing:record to set the time of recording and the channel.
—Record list:List the record file you have recorded.

10. Audio

Key Audio Play Function

Press play or pause music
Short press can choose the previous and next
Music long press can fast back or fast forward.
Note: You can adjust this volume +/- through scrolling up/down key.
Music list:List the musics of your phone and memory card.
Add to saved play list/no play list
Set as ringtone/set as incoming call ringtone/set as alarm ringtone
Shuffle/whether to shuffle play
Repeat:to set the play mode/offrepeat all/repeat one
Settings:Equalizer/BT stereo output/BT stereo headset
Open review to review Music

11. Calendar

To view the calendar.

- 5 -

2.4.Sentbox

When you send a message successfully,The phone stores the message in the sentbox folder.

2.5.Drafts

When you save a message you have written,The phone stores the message in the drafts folder.

2.6.Security index

you can move a message from inbox ,outbox,drafts,sentbox to security inbox.
To enter the security inbox,you should input the security inbox password.

2.7.Templates

Your phone offers you a list of templates that you can use in replying to messages. You can also use templates when writing messages.

2.8.Broadcast message

Send or receive message to same area subscribers in Broadcast Message mode. You also can turn this function on/off here.

Receive mode: ON/OFF broadcasting function.
Language: Turn On/Off all languages.

Channel Setting: Set Broadcasting Message parameter.

2.9.Voice mail server
Line 1 number /Fax number/Data number

2.10.SMS Settings
SIM message center : to show your text message center.

Message validity period:6 hours/24 hours/72 hours/1 week/maximum
Status report:You can request the network to send status reports on your text message(network service).A status report is indicated by in front of the message header.
Save sent message:prompt user/save/don't save
Preferred storage:phone/SIM

2.11.Message capacity
to view the SMS memory of SIM card and phone.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Consult the dealer or an experienced radio/TV technician for help.

■ SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output.

■ Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

■ For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designed for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 0.5 cm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

- 6 -

Warning

■ Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Consult the dealer or an experienced radio/TV technician for help.

■ SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output.

■ Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

■ For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designed for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 0.5 cm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

- 11 -

 NEO flip PLUS Manual Del Usuario	1. Información básica 1.1 Instrucción Gracias por elegir el nuestro teléfono móvil Maxwest . Las instrucciones sobre cómo hacer funcionar el teléfono se detallan en este manual del usuario. El teléfono MAXWEST es compatible con GSM El MAXWEST incluye todas las funciones básicas que se esperan de un teléfono con muchas más características, como Bluetooth, cambiador de voz, cámara, reproductor de música, reproductor de video, radio y muchos más. Estas funciones están diseñadas para la comodidad y mejorar la experiencia del usuario. 1.2 Para su seguridad Por favor revise estas sencillas instrucciones para su propia seguridad. No seguir estas instrucciones puede ser peligroso o ilegal. Lea la guía del usuario para obtener más información. Nota: La calidad de la llamada y la conexión depende de su proveedor de servicio local y de la señal. No nos hacemos responsables de cualquier daño físico o daños materiales debido a un uso inadecuado. 2. Apariencia 2.1 Descripción del teclado 2.1.1 Izquierda / Derecha tecla de navegación Mover el cursor a la izquierda o derecha durante la edición. Mientras que en reposo, optimiza la tecla izquierda de navegación al menú [Bandeja de entrada], pulse la tecla de navegación hacia la derecha al menú [perfiles]. Durante el uso de la aplicación de la cámara, pulse la tecla izquierda / pulse la tecla izquierda de navegación puede abrir el menú de opciones, pulse la tecla de retorno de navegación derecha al menú anterior.	2.1.2 Tecla arriba / abajo de navegación Ver el nombre, número de llamada, mensaje y todas las opciones del submenú. Mover el cursor a arriba o hacia abajo cuando edición. En estado de reposo, presione la tecla de navegación al menú [alarma]. 2.1.3 Tecla suave izquierda Para realizar la función del indicador que aparece en la esquina inferior izquierda de la pantalla. 2.1.4 Tecla suave derecha Para realizar la función del indicador que aparece en la esquina inferior derecha de la pantalla. 2.1.5 Tecla de marcación Para marcar o extracto de un número de llamada entrante. En el modo de espera, presione la tecla de marcación para mostrar la llamada SIM archivos. 2.1.6 Tecla colgar Para finalizar una llamada o rechazar llamadas entrantes. Mantenga pulsado este botón para el encendido / apagado. Bajo la mayoría de circunstancias al pulsar esta tecla pondrá el teléfono móvil en modo de espera. 2.1.7 Número clave 0 ~ 9 tecla número número de entrada de Can y palabra, la velocidad para seleccionar el menú de opciones, llamada velocidad (la llamada debe ser almacenado en el directorio telefónico). 2.1.8 Tecla * Tiene función diferente en diferentes menús. 2.1.9 Tecla # Tiene función diferente en diferentes menús. 2.1.10 Medio clave En el modo de espera, presione la tecla para entrar en el menú principal. En otros submenús, que funciona igual	que la izquierda tecla de función. 2.1.11 EX1 En el modo de espera, llave EX1 presione para entrar en el modo de llamadas SIM. 2.1.12 EX2 En el modo de espera, presione la tecla de cámara o EX2 FM u otro menú principal. Consejo: En este manual, la frase "pulse la tecla" se refiere a pulsar y soltar un tiempo corto "Mantenga pulsado una tecla" se refiere a pulsar una tecla y mantener pulsado durante 2 segundos o más. 2.2 Icono Descripción Cuántas más barras aparezcan, mayor será la intensidad de la señal Alloqueo de teclado Vibrar Anillo y vibran Anillo Vibrar y después melodía Auricular de entrada Indicador de itinerancia Indicador SMS Mensaje de voz Configuración y alarma abierta SIM abierta Desvío La llamada de SIM Estado de la batería Bluetooth abierto crónometro de usos múltiples abierto	2.3 De la batería Para un uso óptimo por favor asegúrese de que el celular se carga a plena capacidad antes de usar. 2.4 Conectar Red 2.4.1 Tarjeta SIM Asegúrese de que se inserta una tarjeta SIM antes de utilizar su teléfono. La tarjeta SIM debe ser proporcionada a usted por su proveedor de servicios. Toda esta información es almacenada en la tarjeta SIM, tales como información de contacto, agenda, La música, etc se almacena en la tarjeta SIM. Para un uso óptimo de no tocar la parte metálica de la tarjeta SIM y mantenerlo alejado de los imanes y la electricidad. Si la tarjeta SIM se ha roto el teléfono el teléfono podría no ser capaz de completar todas sus funciones. Advertencia: Antes de insertar o extraer la tarjeta SIM, asegúrese de que el teléfono está apagado. Asegure que el teléfono no está conectado a una fuente de alimentación externa, ya que esto podría dañar potencialmente la tarjeta SIM. 2.5 Funciones características En estado de reposo, pulse la tecla de número a número de llamada de entrada, pulse la tecla de función derecha para borrar la entrada error, mucho tiempo pulsar la tecla de función derecha para borrar todas las entradas. Pulse la tecla programable izquierda para guardar el número de llamada de teléfono o tarjeta SIM. Pulse la tecla de marcación para realizar una llamada. En estado de la llamada, puede dirigir tecla numérica de prensa para el número de entrada si es necesario. Para realizar llamadas internacionales se debe pulsar la tecla "0" hasta que aparezca el prefijo telefónico internacional "+" en la pantalla ("+" en lugar de 00). 2.7 Las llamadas de emergencia	2.8 Responder a una llamada 2.9 Finalizar una llamada 2.10 Historial de llamadas 2.11 opción de llamada 3. Función 3.1 Teléfono libro Puede guardar campos de información ya sea a su tarjeta SIM o el teléfono, esta información incluye el nombre linkman, número de teléfono, número de casa, nombre de la empresa, correo electrónico, teléfono de la empresa, número de fax, cumpleaños, tono de llamada selecto, grupo de llamada. Mientras la prensa de inactividad la tecla derecha para "libreta de teléfonos", ver el registro de llamadas. NOTA: El auricular almacenar max 500 pcs registros telefónicos, base de la memoria de la tarjeta SIM en la misma capacidad. 3.2 Mensajes Mientras la tecla de navegación para seleccionar "Mensajes" para entrar en el submenú, incluyen SMS, Chat y mensajes de voz del servidor de difusión.
3.2.1 Chat Esta función se basa en SMS. 3.2.2 servidor de correo de voz Esto redireccionará automáticamente las llamadas entrantes al centro de correo de voz cuando no se puede aceptar una llamada para que la persona que llama puede dejar un mensaje en el sistema de correo de voz de la red de servicios. Marque la casilla de correo de voz número para acceder a su correo de voz. 3.2.3 Mensaje de difusión 3.3 El jugador Audio Entrar en el menú del reproductor de audio, presione hacia arriba de navegación / abajo - 8 - clave para controlar la música para reproducción / pausa y parada. Pulse la tecla izquierda de navegación / derecha para cambiar la música, presione "+" y la tecla "-" para ajustar el volumen. Oprima hacia la izquierda tecla de entrar en la lista de reproducción, pulse submenú "opción" pop-up como siguen 3.4 Marcación 3.5 Multimedia En el estado de menú principal, pulse la tecla de navegación para encontrar menú multimedia, pulse la tecla programable izquierda para entrar, o pulse icono de multimedia para acceder a este menú. 3.5.1 Cámara Utilizar esta función, tomar una foto o un video por sí mismo ama y guardar en el archivo de video de la tarjeta de memoria o tienda en su teléfono. 3.5.2 Imagen espectador	Pulse la tecla programable izquierda para operar su foto seleccionada, se puede ver, buscar Estilo, Enviar, Renombrar, Eliminar. Eliminar todos los archivos de su foto, también se les puede cambiar la posición de almacenamiento. Ha separado imagen. Presione la tecla de navegación hacia arriba / abajo para navegar. 3.5.3 Video El auricular es compatible con función de grabación de video. 3.5.4 Grabador de sonido Esta función muestra la lista actual de la grabadora que se almacenan en el teléfono, el apoyo grabadora de AMR y WAV. WAV. Si su teléfono no tiene la grabadora, la pantalla le pedirá - 9 - (Vaciar carpeta). 3.5.5 Lista FMrecord Esta función de grabación del horario FM teléfono de soporte (también se puede utilizar en el estado de energía apagado). Pueden configurar FMrecord horario múltiples. 3.5.6 Espectáculo de diapositivas Puede seleccionar una carpeta, que se almacena en la tarjeta de memoria o el teléfono, y reproducir imágenes de esta carpeta. 3.6 Gestor de archivos En este menú puede ver la lista de archivos de video y optimiza la tecla izquierda para jugar, enviar, renombrar, borrar, eliminar todos los archivos de video, también se les puede cambiar la posición de almacenamiento. Ordena, establece Bluetooth. 3.8 FM Radio El teléfono ha construido en función de radio, basta con insertar un auricular para abrir esta función. En el menú de	radio, pulse arriba / abajo de navegación para activar o desactivar la función de los canales de búsqueda, pulse la tecla de navegación izquierda / derecha para buscar canales automático hasta que busco un canal. Cierre la función de búsqueda automática, puede buscar un canal por lo que quiere a mano. Pulse una vez la izquierda o la tecla de navegación para añadir o 0,1 Mhz minis. 3.9 Alarm 3.10 Calendario Pulse las flechas arriba / abajo y derecha / izquierda de la tecla de navegación - 10 - interruptor para editar la fecha, la hora. 3.11 Organizador 3.12 Centro de llamadas Pulse la tecla de navegación para esta función, a continuación, pulse submenú tecla izquierda de entrar en él. historial de llamadas 3.12.1 Las llamadas perdidas En esta función, se mostrará la lista de llamadas perdidas. Seleccione un registro de llamadas perdidas, presione la tecla programable izquierda para visualizarla detalle información, 3.12.2 Configuración general de llamada 3.13 Servicios 3.13.1 Cuenta de Datos 3.13.1 Configuración En opción, puede configurar el teléfono como su preferencia.	3.14.1 calibración de la pantalla Tocar Introduzca la calibración de tocar la pantalla para calibrar el lápiz para tocar más exacta. 3.14.2 Configuración del teléfono 1) El tiempo y la fecha 2) Ajuste Ciudad Ajustar la hora local de la ciudad como su tiempo de teléfono. 3) Ajuste de hora Puede establecer una fecha y hora 2000-2030 4) Formato Establecer hora Puede establecer 12 horas o formato de 24 horas. 5) Energía del horario El teléfono tiene cuatro potencias On / Offtiempo para editar. Nota: la función no se puede utilizar si el encendido / apagado de tiempo se estableció el mismo. 3.14.3 Configuración de la red Establecer la información de seguridad para proteger su tarjeta de teléfono y la tarjeta SIM contra el uso no autorizado. 3.14.5 Restaurar fábrica Introduzca la contraseña de inicio de teléfono (número predeterminado es: 12 - 0000. Esta característica se restablecerá el teléfono a la misma 3.13 Servicios 3.15 Los perfiles de usuario Puede establecer perfiles de teléfono de acuerdo a su necesidad. Los perfiles de usuario incluyen en general, reunión, al aire libre, de interior, auriculares y Bluetooth. 3.16 botón de la luz de la antorcha Puede abrir la luz de la antorcha pulsando el botón OK durante mucho tiempo. Si la luz de la antorcha ha sido	se abre al pulsar el botón lateral, no hará ninguna diferencia pulsando el botón OK. 4. El modo de introducción de texto 4.1 Recapitulación definición 4.2 Teclado Tecla de función izquierda: confirman Tecla de función derecha: el retorno o clara Tecla de navegación: mover el cursor o seleccionar esperar carácter de entrada. 0 ~ 9: número de entrada o carta. Tecla #: cambiar el modo de entrada * Clave: En el estado de entrada, presionelo cuadro de entrada de símbolos para abrir. EX1: pulse esta tecla para ver los registros de llamadas SIM. EX2: pulse esta tecla para menú de la cámara. reemplazo de la batería tipo incorrecto causará una explosión peligrosa. Asegúrese de seguir las instrucciones para hacer frente a la batería terminada. Gracias por elegir nuestro teléfono Maxwest - Si necesita cualquier información adicional, por favor, póngase en contacto con nosotros en: www.maxwesttelecom.com	Calentamiento ■ Cualquier cambio o modificación no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para utilizar los equipamiento. Este dispositivo cumple con la parte 15 de las normas de la FCC. La operación está sujeta a las siguientes dos condiciones: (1) Este dispositivo no puede causar interferencias perjudiciales y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo interferencias que puedan causar un funcionamiento no deseado. Note: Este equipo ha sido probado y cumple con las limitas para un dispositivo digital de Clase B, de acuerdo con la parte 15 de las normas FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales a la radio de comunicaciones. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación particular. Si este equipo causa interferencias perjudiciales en la radio o la televisión, que puede ser determinada grande el equipo apagado y, se recomienda al usuario que intenta corregir la interferencia mediante una o más de las siguientes acciones: -Reorientar o reubicar la antena receptora. -Aumentar la separación entre el equipo y el receptor. -Conectar El equipo a una toma de un circuito distinto de aquel al que está conectado el receptor. -Consultar A su distribuidor o a un técnico de radio / televisión para obtener ayuda. ■ Las pruebas de SAR se realizan en posiciones de funcionamiento estándar aceptadas por la FCC con el teléfono transmitiendo a su nivel más alto de potencia certificado en todas las bandas de frecuencia probadas, aunque el índice SAR se determina al máximo nivel de potencia certificado, el nivel SAR real del teléfono en funcionamiento puede estar muy por debajo del valor máximo. En general, cuanto más cerca se encuentre de una antena de estación base inalámbrica, menor será la potencia de salida. ■ Antes de que un nuevo modelo de teléfono es disponible para la venta al público, debe ser probado y certificado ante la FCC que no excede el límite de exposición establecido por la FCC, pruebas para cada teléfono se realizan en posiciones y ubicaciones (por ejemplo, en el oído y llevándolo en el cuerpo) requeridas por la FCC. ■ Para usarlo en el cuerpo, este modelo de teléfono ha sido probado y cumple con las pautas de exposición a RF de la FCC cuando se utiliza con un accesorio designada para este producto o cuando se utiliza con un accesorio que no contiene metal y que posiciona el dispositivo a una distancia mínima de 15 cm del cuerpo. El incumplimiento de estas restricciones puede resultar en violación de las normas de exposición RF.