

55mm
75mm

PROSCAN

BLUETOOTH SPEAKER

MODEL NO. PPS1067

INSTRUCTION MANUAL



This picture is only provided for reference. Please refer to the actual unit. PROSCAN and the PROSCAN logo are trademarks and are the property of CURTIS INTERNATIONAL LTD. - www.proscan-brand.com.


Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not put objects into any of the openings. Keep the unit free from dust, etc.
- Do not use this unit for anything other than its intended use.
- This product is not a toy.
- Do not use abrasive cleaning solvents to clean the unit.
- To remove the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity.
- Do not operate around water (e.g. bathroom, swimming pool etc.).
- Do not expose to excessive heat such as sunlight, fire etc.
- Never immerse the unit in water or any other liquid for cleaning purposes.

Content:

Bluetooth Speaker
USB TYPE-C Charging Cable
AUX in Audio Cable
Instruction Manual

Illustration:



1. On/Off button & Pause / Play button
2. Short press: To Play Previous Song
Long press: To Decreasing Volume
3. Short press: To Play Next Song
Long press: To Increase Volume
4. Mode Button
(Bluetooth/FM Radio Mode/TF Card/LED charging mode)
5. AUX IN Port
6. TF card slot
7. USB Charging Port

Instructions (How to use the wireless mode)

- Turn on the speaker by pressing and hold the on/off button (1). The Bluetooth mode will be on automatically.
- Press and hold the "M" button (4) to browse through the mode options.
- Stop pressing the "M" button when hearing the command "Bluetooth mode".
- Turn on the Bluetooth menu on your wireless device (phone, tablet, laptop, etc.) and select "Pro PPS1067".
- Pair the device.
- Play music.

Instructions (How to change the LED mode)

- Turn on the speaker by pressing and hold the on/off button (1).
- Short press the M button to change any LED mode you want.

Instructions (How to use the FM Radio mode)

- Turn on the speaker by pressing the on/off button (1).
- Insert the 3.5mm Aux cable into the 3.5mm Aux in slot (5) to work as an antenna.
- Press and hold the "M" button (4) to browse through the mode options.
- Stop pressing the "M" button when hearing the command "FM Mode".
- Press the Play/Pause button (1) to scan the FM channels. The speaker will now search for channels, this might take few minutes. When the search is finished the speaker will stay on a channel. Short press the button (3) and button (2) to change the channel.

Instructions (How to use the TWS Pairing)

- Make sure both speakers are "ON" and not paired with any Bluetooth device.
- Simultaneously press the button (3) on any one speaker, an indication tone would be heard. After few seconds, the other speaker will join the pairing.

Specifications:

Speaker version	S.3
Bluetooth version	5.3 (wireless)
Wireless range	15 meters(max)
File format	MP3
Frequency response	20Hz-20KHz
Driver size	Pro-Designed 1.5W Driver
Power capacity	40W RMS
Charging time	About 2.5 hours
Working time	About 2.5 hours

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rule. These limits are designed to provide reasonable protection against harmful interference that may cause undesired operation.

This equipment does not emit radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

05 day Warranty

This product is warranted to be free from defects in material and workmanship for a period of ninety (90) days from the date of original purchase. During this period, your exclusive remedy is repair or replacement at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be returned inoperable or returned to us.

To make a warranty claim, please email support@curtis.com or call 1-800-968-9853.

This product is warranted to be free from defects in material and workmanship for a period of ninety (90) days from the date of original purchase. During this period, your exclusive remedy is repair or replacement at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be returned inoperable or returned to us.

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. Every implied warranty, including any statutory warranty or condition of merchantability, is hereby excluded to the extent prohibited by law, in which case such warranty or condition is limited to the duration of the written warranty. This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties of fitness, merchantability or consequential damage, so the foregoing limitations may not apply to you.

For service assistance and product information

please call 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15,
MISSISSAUGA, ON, L5B 2A3
www.curtis.com

PROSCAN

EXCITERE BLUETOOTH

MODEL NO. PPS1067

MANUEL D'INSTRUCTIONS



Ces images ne sont fournies qu'à titre de référence. Veuillez vous référer à l'unité réelle. PROSCAN et le logo PROSCAN sont des marques de CURTIS INTERNATIONAL LTD. - www.proscan-brand.com.


Consignes de sécurité

- Gardez l'appareil à l'écart des sources de chaleur, de la lumière directe du soleil, de l'humidité, de l'eau et de tout autre liquide.
- N'utilisez pas l'appareil s'il est tombé ou a été endommagé de quelque façon que ce soit.
- Les réparations de l'équipement électrique ne doivent être effectuées que par un technicien qualifié. Des réparations incorrectes peuvent mettre l'utilisateur en danger.
- Ne placez aucun objet dans les ouvertures. Gardez l'appareil à l'écart de la poussière, des peluches, etc.
- N'utilisez pas cet appareil pour autre chose que l'usage auquel il est destiné.
- Gardez l'appareil hors de portée des enfants.
- Ce produit n'est pas un jouet.
- N'utilisez pas de solvants abrasifs pour nettoyer.
- Pour minimiser le risque d'incendie ou de choc électrique, évitez d'utiliser dans des conditions humides telles que la pluie ou l'humidité.
- Ne pas utiliser près de feu (par exemple, salle de bain, piscine, etc.).
- Ne pas exposer à une chaleur excessive comme le soleil, le feu, etc.
- Ne plongez jamais l'appareil dans l'eau ou tout autre liquide à des fins de nettoyage.

Contenu:

Haut-parleur Bluetooth
Câble de charge USB Type-C
AUX dans le câble audio
Manuel d'instructions

Illustration:



1. Bouton marche/arrêt et bouton Pause/Lecture
2. Appui court : pour lire la chanson précédente
Appui long : pour diminuer le volume
3. Appui court : pour lire la chanson suivante
Appui long : pour augmenter le volume
4. Bouton Mode (Mode Bluetooth/Radio/TF Card/Mode de chargement de LED)
5. Port d'entrée AUX
6. Emplacement pour carte TF
7. Port de chargement USB

Instructions (Comment utiliser le mode sans fil)

- Allumez l'enceinte en appuyant longuement sur le bouton marche/arrêt (1).
- Appuyez brièvement sur le bouton M pour changer le mode LED de votre choix.

Instructions (Comment changer le mode LED)

- Allumez l'enceinte en appuyant longuement sur le bouton marche/arrêt (1).
- Appuyez brièvement sur le bouton M pour changer le mode LED de votre choix.

Instructions (comment utiliser le couplage TWS)

- Assurez-vous que les deux haut-parleurs sont « ON » et ne sont associés à aucun appareil Bluetooth.
- Appuyez deux fois sur le bouton (3) d'importer quel haut-parleur, une tonalité d'indication se fera entendre.
- Après quelques secondes, une autre tonalité d'indication se fera entendre s'ils s'associent automatiquement.
- Activez le menu Bluetooth sur votre appareil sans fil (téléphone, tablette, ordinateur portable, par exemple) et sélectionnez « Pro PPS1067 ».
- Jouez de la musique.

Instructions (Comment utiliser le mode Radio FM)

- Allumez l'enceinte en appuyant sur le bouton marche/arrêt (1).
- Insérez le câble AUX de 3,5 mm dans la fente d'entrée AUX de 3,5 mm (5) pour fonctionner comme une antenne.
- Appuyez et maintenez enfoncé le bouton "M" (4) pour parcourir le mode.
- Options, arrêtez l'appareil sur le bouton « M » lorsque vous entendrez la commande « Mode FM ».
- Appuyez sur le bouton Lecture/Pause (1) pour rechercher les chaînes FM. L'enceinte va maintenant rechercher les chaînes, cela peut prendre quelques minutes. Une fois la recherche terminée, l'enceinte restera sur une chaîne. Appuyez brièvement sur le bouton (3) et le bouton (2) pour changer de chaîne.

Specifications:

Version	S.3
Bluetooth version	5.3 (sans fil)
Portée sans fil	15 m (max)
Format de fichiers	MP3
Largeur de bande	20Hz-20KHz
Capacité de puissance	40W RMS
Temps de charge	Env. 2.5 heures
Temps de travail	Env. 2.5 heures

Attention ! Danger

Ne placez pas l'équipement à proximité de la source d'énergie ou d'une source intense de chaleur, ne l'exposez pas à la pluie ou à l'humidité, ne l'exposez pas à la poussière, ne l'exposez pas à la chaleur excessive,