SolaceRise

L02 User Manual

Vibrating Alarm Clock

Thank you for purchasing SolaceRise Wireless Vibrating Alarm Clock. To ensure the best product performance, please read this user manual in detail and retain it for future reference.

Questions? Contact Customer Service Center at

solaceriseshop@outlook.com

Version 1.0

PRODUCT SPECIFICATIONS

Dimensions: 4.3(L)*2.5(W)*4.3(H)inches

N Weight: 0.45lb

Clock accuracy: ±13 seconds/month (in normal temperature)

Material: Plastic + Silicone + Fabric

Power Input: DC 5V/1A

Power: AC, 100-240V (50/60Hz)

ITEMS INCLUDED IN THE BOX

1. Wireless Vibrating Alarm Clock ×1
2. Magnetic Charging Base ×1
3. Power Adapter ×1
4. User Manual ×1
5. Reminder Card ×1



FEATURES

- Portable Digital Alarm Clock
- 5 Vibration Levels
- 3 Wake-Up Modes
- Rechargeable Battery
- Wireless Bed Shaker
- 15 Volume Levels
- Auto/Manual Dimming
- 9-Minute Snooze Function

QUICK GETTING STARTED

1. How to charge?

There are two charging methods:

(1) Charging with Base (Magnetic Charging)

• Plug the charging base into a standard outlet.



• Place the device on the charging base so that the two magnetic contacts on the bottom align with the two pins on the base.



• During daily use, after waking up, place the device back on the charging cradle. This keeps it powered and ensures the time is always visible.



• If charging does not work or if the connection is poor, clean the charging contacts with cotton swabs.

Maintenance tip: Regularly clean charging ports with cotton swabs to ensure optimal contact.

(2) Charging with Cable (USB-C Port)

Open the silicone cover on the Type-C charging port (on the right side of the device). Insert the USB-C cable into the port and connect it to a power source.

The silicone cover protects the port from dust when not in use.

2. Usable for 29 hours when fully charged and at maximum brightness.

Charging Port	USB-C (5V 1A)
Battery	Built-in rechargeable lithium battery
Battery Life	≈29 hours
Battery Icon Indicator	**Charging**  **Fully charged**

Important

1. When the battery is low, the battery icon flashes slowly and a warning tone sounds every 20 seconds.
2. When the battery is almost empty, the icon flashes quickly for 10 seconds and a continuous tone plays before the device shuts down.
3. During charging (with either the Type-C cable or the charging base), the battery icon stays on. Once fully charged, the icon will disappear.

3. Slide the Power switch to ON to turn on the device.



FRONT VIEW



NOTICE: Please check "AM" & "PM" indicator when you set time and alarm.

OVERVIEW OF BUTTON FUNCTIONS

OFF ON POWER	1. Slide to Power ON/OFF
VIB SOUND BOTH	2. Slide to select Wake-up Mode
SOUND	3. Press to enter Alarm Sound Setting
AL VOL	4. Press to enter Alarm Volume Setting
AL SET	5. Press to enter Alarm Setting
	6. Press to select Vibration Intensity
DIMMER SNOOZE	7. Press to enter Snooze Mode Press to Manually Adjust Brightness Press and hold 5 seconds to enter Lock Mode
SET+	8. Press to enter Forward
SET-	9. Press to enter Backward
TIME SET	10. Press to enter Time Setting & Switch the Regular Time and Military Time
ON/OFF	11. Press to turn Alarm ON/OFF
AUTO DIMMER OFF ON	12. Slide to turn Auto Dimmer ON/OFF

TIME SETTING



1. Press " TIME SET " button once to enter HOUR setting, the HOUR digits will flash on the display. Press " SET- " or " SET+ " buttons to advance to the correct hour.



HOUR Flashes

2. Press " TIME SET " button again to confirm and enter MINUTE setting, the MINUTE digits will flash. Press " SET- " or " SET+ " buttons to advance to the correct minute (hold for rapid setting).



MINUTE Flashes

3. Press " TIME SET " button a third time to confirm and enter TIME FORMAT setting. "12H" will flash. Press " SET- " or " SET+ " buttons to toggle between 12H and 24H formats.

"12H" flashes and Indicates 12-hour Mode

4. Press " TIME SET " button a fourth time to confirm and exit the time setting mode.

NOTICE:

1. The clock will automatically exit the time setting mode if no action is taken within 10 seconds.
2. When using the 12-hour time format, the AM icon will appear from 12:00 midnight to 11:59 am, and the PM icon will appear from 12:00 noon to 11:59 pm.
3. In regular time, AM or PM will be displayed. Otherwise, the clock is in 24-hour (military) time.

ALARM SETTING



1. Press " AL SET " button once to enter ALARM HOUR setting, the HOUR digits will flash on the display. Press " SET- " or " SET+ " buttons to advance to the desired hour.

HOUR Flashes

2. Press " AL SET " button again to confirm and enter ALARM MINUTE setting, the MINUTE digits will flash. Press " SET- " or " SET+ " buttons to advance to the desired minute (hold for rapid setting).



MINUTE Flashes

3. Press " AL SET " button a third time to confirm and exit the alarm setting mode.

ALARM ON/OFF

Press " ON/OFF " button to turn the alarm on or off. The alarm icon will appear when the alarm is on.



ALARM ON

ALARM OFF (meaning no alarm)

WAKE-UP MODE SETTING

To select the wake-up mode, slide " VIB SOUND BOTH " to your desired position:
a) "SOUND" for sound only
b) "VIBRATION" for bed shaker only
c) "BOTH" for sound and bed shaker.

Attention:

1. When the clock is charging, it will automatically switch to SOUND mode.
2. When it is not charging, it will automatically return to the previous wake-up mode.

ALARM SOUND

Press " SOUND " button to select the alarm sound.

There will be an eight-second trial listen for alarm sound.

S01	S02	S03	S04	S05
Beep	Siren	Music	Birds Chirping	Jackhammer

ALARM VOLUME

Press " AL VOL " button to adjust the alarm volume.

There will be an eight-second trial listen for alarm volume.



VIBRATION SETTING

Press " " button to adjust the vibration level.

There will be an five-second trial listen/intensity for vibration setting.

PAUSE ALARM AND RESET FOR NEXT DAY

When alarm goes off, press " ON/OFF " button to pause it, or let the alarm stops on its own. This will re-set the alarm for the next day.

NOTICE: If not stop the alarm, it will last 10 mins before going silent.

SNOOZE FUNCTION

When alarm goes off, press the top " DIMMER SNOOZE " button to temporarily suspend the alarm for 9 minutes. Snooze can be repeated once again and again.
Press " ON/OFF " button to end the Snooze Function.



LOCK FUNCTION

The Lock Function is designed to prevent accidental changes to your settings if the device is shaken strongly or falls due to vibration.

1. Press and hold the " DIMMER SNOOZE " button for 5 seconds to activate Lock mode. The lock icon will appear.



2. In Lock mode, all buttons will be disabled. However, you can still press " DIMMER SNOOZE " to activate the snooze mode, and press " ON/OFF " to stop the alarm or disable the snooze function.



3. Press and hold the " DIMMER SNOOZE " button again for 5 seconds to exit Lock mode. The lock icon will disappear.

DIMMER

There are two dimmer modes: auto and manual.

AUTO DIMMER

In non-setting mode, slide " AUTO DIMMER OFF ON " can turn on or turn off the auto dimmer.

NOTICE:

1. The default auto dimmer is OFF.
2. When the auto dimmer is on, the auto dimming sensor, on the front of the clock, will automatically adjust the brightness based on the ambient light.

AUTO DIMMING SENSOR

MANUAL DIMMER

The brightness of the screen can be freely adjusted by pressing the " DIMMER SNOOZE " button.

NOTICE: When the auto dimmer is ON, the manual dimmer will be disabled.

TIPS

1. How to Extend Battery Life?

(1) Slide " OFF ON POWER " to turn off the machine when placing it in a suitcase.
(2) Set to the darkest level in manual dimming mode.

2. How to Improve Wake-Up Effectiveness?

(1) Sound-Only Wake-Up Mode
Place the clock on the charging base (P1), or place it with the screen side facing down (P2) on a flat surface without covering.



(P1) (P2)

(2) Vibration / Vibration + Sound Wake-Up Mode
Place the clock with the screen side facing down in the center under the pillow.



SAFETY INSTRUCTIONS

- Keep the clock away from rain and moisture to prevent fire or electric shock.
- Do not place the clock near radiators, heating vents, direct sunlight, or water.
- Always unplug by holding the plug—do not pull on the cord.
- Do not handle the plug with wet hands to avoid electric shock or fire.
- Do not open or attempt to disassemble the clock casing.
- Avoid bending, twisting, or pinching the power cord. Use only manufacturer-approved parts for any replacements.

TROUBLESHOOTING

Q 1. Display does not light up?

A -Check if the battery still has power.
-Press the **[AUTO DIMMER ON/OFF]** to turn off auto dimmer.
-Press the **[MANUAL DIMMER]** button to set the display brightness to bright level.
-Get customer support for help.

Q 2. Press the [DIMMER] button can't adjust the display brightness manually

A -Slide the **[AUTO DIMMER ON/OFF]** to turn off auto dimmer.
-If the lock icon appears on the display, press and hold the **[SNOOZE]** button for 5 seconds to exit Lock mode.
-Get customer support for help.

Q 3. Alarm doesn't go off at the set time?

A - Check if the alarm is set to AM or PM time.
-Check if the alarm is turned on (alarm icon display on the screen).
-Press **[AL VOL]** button to set alarm volume at "U15"
-Get customer support for help.

Q 4. How to turn off alarm daily?

A - When the alarm goes off, pressing the " ON/OFF " will turn the alarm off until the next scheduled time.
-Get customer support for help.

Q 5. Bed shaker doesn't vibrate in "BOTH" or "VIBRATION" mode?

A -Make sure the wake-up mode switch is set to "VIBRATION" or "BOTH", not "SOUND".
-Check that the clock is not charging — vibration is disabled while charging.
-If vibration still does not work, try resetting the clock by unplugging and reinserting the power cable.
-Get customer support for help.

Q 6. Some buttons do not respond when pressed?

A -Check if the lock icon appears on the display.
-If yes, press and hold the **[SNOOZE]** button for 5 seconds until the lock icon disappears.
-Get customer support for help.

Q 7. I received a product that is damaged, missing parts, scratched, or dirty. What should I do?

A - We're sorry to hear about the issue with your product. We are committed to providing 18-month warranty on this product. Please contact us via Email at

solaceriseshop@outlook.com

for a brand new replacement.

WARRANTY & SUPPORT

✓ 45-Day Money Back | 18-month Warranty
✓ For assistance, please keep the model number and order ID number of this product，then contact us by sending email:

solaceriseshop@outlook.com

Any changes or modifications not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

折页尺寸95X110mm

风琴页折页　彩色印刷