



MANUAL EARBUDS

Audífonos inalámbricos



HYUNDAI
TECHNOLOGY,
INC.



Warning

Special Note: Before using the earphone for the first time, please put the earphone into the ordinary charging case once and then remove it. Only then can touch be effective.

Please read the warnings below carefully. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

- Keep batteries out of reach of children.
- Do not heat, open, or dispose of battery pack in fire.
- Do not allow metal objects to touch the battery on the device.
- Do not expose battery pack to excessive heat.
- Do not use a high current charger, or the charging line will burn out.

Product Specification

- Chipset solutions: AB5636
- Bluetooth version: V6.0
- Bluetooth working frequency: 2.402GHz-2.480GHz
- Frequency response: 20Hz-20KHz
- Speaker size: 10mm
- Sensitivity(speaker unit): 108.0±3dB at 1KHz
- Speaker impedance(speaker unit): 32Ω±15% at 1mW / 1000Hz
- Effective distance: 15m (in an ideal environment without any large obstacles)
- Earphones battery capacity: 40mAh,
- Charging case battery capacity: 400mAh,
- Playing time: 5-6 hours (70% volume)
- Charging times for the headset: about 2.5 times

Pairing

1. Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

2. **Syncing your earphones**

When earphones do not sync together .

1. In the absence of any connection.
2. Put both headphones back in the charging case, then open the charging case again, take out the headphones, and wait 5-8 seconds to search for TWS pairing
3. Open up Bluetooth setting on your smart device and scan for **"Miraculous-EB"**

Operation

1. **Power on/off**

1. Take the earphones out of the charging case, automatically turn on; Put the earphones back to the charging case, automatically turn off.
2. Long press 3 seconds to turn on
Long press 5 seconds to turn off.

2. **Play/Pause music**

When listening to music.

Tap left/right earphones once to play or pause the music.

3. **ANC Mode**

When taking the earphones out of the charging case, it is regular Bluetooth mode.

Transparent mode Long press right earphones for 2 seconds to enter

Noise reduction mode Long press right earphones for 2 seconds again to enter

Regular Bluetooth mode Long press right earphones for 2 seconds again to enter

4. **Volume +/-**

When listening to music.

Quick double tap left earphones to decrease the volume.

Quick double tap right earphones to increase the volume.

5. Previous /Next Song

When listening to music.

Quickly tap left earphone 3 times to go to the previous song.

Quickly tap right earphone 3 times to go to the next song.

6. Answer/Hang up

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

7. Reject

When there is an incoming call.

Long press left or right earphones for 2 seconds to reject the call.

8. Voice assistant

Long press left earphones for 2 seconds to activate voice assistant.

Charging Function

Fully charge the case and earphones before using for the first time.

1. Charging the case

When the charging case is being charged, the indicator light will flash. Once it is fully charged, the light will remain steady.

2. Charging the earphones

a. Place the earphones into the charging case.

b. The lights on the earphones will remain steady to indicate that charging has started. The lights will turn off once charging is complete.

Charging Status

1. Charging case charging - Indicator light flashes

2. Charging case fully charged - Indicator light stays on

3. Earbuds charging - Indicator light stays on

4. Earbuds fully charged - Indicator light turns off



Advertencia

Nota importante: Antes de usar los audífonos por primera vez, colóquelos en el estuche de carga normal una vez y luego retírelos. Solo así la función táctil será efectiva.

Lea cuidadosamente las siguientes advertencias. Conserve este manual junto con el empaque del producto. Las precauciones de seguridad reducen el riesgo de incendio o lesiones si se siguen correctamente.

Para reducir el riesgo de lesiones:

- Mantenga las baterías fuera del alcance de los niños.
- No caliente, abra ni arroje la batería al fuego.
- No permita que objetos metálicos entren en contacto con la batería del dispositivo.
- No exponga la batería a calor excesivo.
- No use un cargador de alta corriente, ya que el cable de carga puede dañarse.

Especificaciones del producto

- Chipset: AB5636
- Versión Bluetooth: V6.0
- Frecuencia de operación Bluetooth: 2.402 GHz – 2.480 GHz
- Respuesta de frecuencia: 20 Hz – 20 kHz
- Tamaño del altavoz: 10 mm
- Sensibilidad (unidad de altavoz): 108.0 $\pm$ 3 dB a 1 kHz
- Impedancia del altavoz: 32 Ω $\pm$ 5% a 1 mW / 1000 Hz
- Distancia efectiva: 15 m (en un entorno ideal sin obstáculos grandes)
- Capacidad de batería de los audífonos: 40 mAh
- Capacidad de batería del estuche de carga: 400 mAh
- Tiempo de reproducción: 5–6 horas (al 70% del volumen)
- Número de cargas para los audífonos mediante el estuche: aproximadamente 2.5 veces.

Emparejamiento

1. Emparejamiento automático

Al sacar los audífonos del estuche de carga, se encenderán automáticamente,

se sincronizarán entre sí y entrarán en modo de emparejamiento.

2. Sincronización de los audífonos

Cuando los audífonos no se sincronizan entre sí:

1. Asegúrese de que no haya ninguna conexión activa.

2. Coloque ambos audífonos en el estuche de carga, luego ábralo nuevamente, sáquelos y espere de 5 a 8 segundos para que busquen el emparejamiento TWS. Abra la configuración Bluetooth en su dispositivo y busque “Miraculous-EB”

Operación

1. Encendido/apagado

- Al sacar los audífonos del estuche de carga, se encienden automáticamente; al colocarlos de nuevo en el estuche, se apagan automáticamente.
- Mantenga presionado 3 segundos para encender.
Mantenga presionado 5 segundos para apagar.

2. Reproducir/pausar música

Mientras escucha música, toque una vez el audífono izquierdo o derecho para reproducir o pausar.

3. Modo ANC

Al sacar los audífonos del estuche, se encuentran en modo Bluetooth normal.

Modo transparente: mantenga presionado el audífono derecho durante 2 segundos para entrar.

Modo reducción de ruido: mantenga presionado el audífono derecho durante 2 segundos nuevamente para cambiar.

Modo Bluetooth normal: mantenga presionado el audífono derecho durante 2 segundos otra vez para regresar.

4. Volumen +/-

Mientras escucha música, toque dos veces rápidamente el audífono izquierdo para disminuir el volumen.

Toque dos veces rápidamente el audífono derecho para aumentar el volumen.

5. Anterior / Siguiente canción

Mientras escucha música:

Toque rápidamente 3 veces el audífono izquierdo para ir a la canción anterior.
Toque rápidamente 3 veces el audífono derecho para ir a la siguiente canción.

6. Responder / Colgar

Cuando hay una llamada entrante:

Toque una vez el audífono izquierdo o derecho para contestar.

Toque nuevamente para finalizar la llamada.

7. Rechazar llamada

Cuando hay una llamada entrante:

Mantenga presionado el audífono izquierdo o derecho durante 2 segundos para rechazar la llamada.

8. Asistente de voz

Mantenga presionado el audífono izquierdo durante 2 segundos para activar el asistente de voz.

Función de carga

Cargue completamente el estuche y los audífonos antes del primer uso.

1. Carga del estuche

Cuando el estuche de carga se está cargando, la luz indicadora parpadeará.

Una vez que esté completamente cargado, la luz permanecerá encendida de forma fija.

2. Carga de los audífonos

a. Coloque los audífonos dentro del estuche de carga.

b. Las luces de los audífonos permanecerán encendidas de forma fija para indicar que la carga ha comenzado. Las luces se apagarán una vez que la carga esté completa

Estado de carga

1. Estuche de carga cargándose – La luz indicadora parpadea.

2. Estuche de carga completamente cargado – La luz indicadora permanece encendida.

3. Audífonos cargándose – La luz indicadora permanece encendida.

4. Audífonos completamente cargados – La luz indicadora se apaga.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AVTH-EB



HYUNDAI
TECHNOLOGY,
INC.