deli

USER MANUAL

Scanner Scanner No.14653W

CERTIFICATE

Inspector:

Date of manufacture:

DELI GROUP CO., LTD.
Add: Cixi Economic
Ningbo 315301 China Made in China
Tel: 0574-63788888 Fax: 0574-63788999

ASIA ONE
CUTTING ME
Version: A
Date: 2022.01

Dear customers, thank you for your purchase of our products. We are committed to providing our customers with high quality products. To ensure best performance, please read the manual carefully before use!

How to use a barcode scanner correctly

1. Please fill the scanner in an appropriate angle to achieve optimal decoding.
2. Don't scan the barcode in a 90-degree angle, because the reflected light may affect the decoding.
3. To scan a barcode, aim correctly and ensure the scan line crosses every bar and space of the symbol, otherwise, there might be an error.



Overview of scanner parts



Technical parameters

Battery capacity	3.7V/2000mAh/Rechar. Battery
Working current	100mA
Max current	300mA
Charge voltage	DC5V/1A
Light source	Laser Wavelength
Print contrast	≥25%
Roll angle	360°
Resolution	4mil
Applicable barcode	UPC/EAN, Code 39, Code 128, Code 93, Codabar, ISBT 128, UPC/EAN with 2 or 5 digits supplemental, Code 32, Code 39 Full ASCII, Interleaved 2 of 5, Discrete 2 of 5, Chinese 2 of 5, Matrix 2 of 5, UCC Coupon Code, IATA, Code 11, Code 39 Trioptic, Bookland EAN, Coupon Code, MSI, GS1 DataBar (RSS), Composite Codes, PDF417, QR Code, Data Matrix, Micro PDF417, Micro QR Code, Aztec, Han Xin Code
Operating temperature	0°C ~ 50°C
Storage temperature	-20°C ~ 60°C
Operating humidity	5% -95% (no condensation water)
Drop height	1.5m
Protection	Waterproof Level
Interface	USB
Scanning mode	Manual induction
Scanning angle	Pitch angle 65°, Deflection angle 60°
Anti-shock capability	Drop the 1m free fall test
Scope	Warp, Tilt, Pull&Dip

Packing list

Barcode Scanner×1, USB Cable×1, Actual Manual(s), Quick Manual×1

Instructions

Please note that our retail users will use the product correctly in a standard way, but not settings are listed in this manual. Some tedious operations are deleted in this manual to avoid confusion. Please do not operate by users' unpredictability needs, thus greatly improving the user's work efficiency. For any questions or if you need more information, please refer to the Configuration and User Manual , which can be downloaded from the Download Center under Customer Service section of our company website.

Product features

1. With built-in memory and inventory mode, the scanner is capable of storing up to 4,000 EAN-13 barcodes and counting the numbers of barcodes. Settings of all parameters can be configured by scanning the programming barcode, and will be stored in the internal memory. However, information and parameters will be kept after the power is off.
2. Supports one-click pairing with simple and fast transmission. Pairing/re-The pairing of this product has been finished when it was produced.
3. Built-in high-capacity battery, up to 100 meters in open air. 100m-300 transmission indoor with different obstacles and environment.
4. Fast battery charging function, long standby time, built-in 2000mAh lithium battery.
5. Wireless receiver is compatible with Windows/Android/Mac/Linux and other operating systems.

Installing the receiver

1. Plug the wireless USB receiver to the USB port of the computer.
2.Once the wireless receiver is connected to the computer, the operation system should automatically detect the new hardware and install the driver. Wait until the driver installation is finished.

Basic Settings



Function Settings



Pairing Settings

1. Pairing barcode



2. Pairing Method

One-click pairing method: Firstly use the scanner to scan the pairing barcode, then plug the receiver into the USB port of the computer when the buzzer beeps twice. The buzzer will stop beeping after paring is done successfully within 30 seconds.



3. Barcode Scanner ID Setting



Setting Method: use wireless barcode scanner to scan the "Setting Method" barcode first, then scan the "Setting Method" barcode. Finally scan the barcode on the scanner ID as "0" as below. Enter ID Settings > Parameter Value Scan "0" barcode first and then scan "1" barcode.

The method to set Display/Hide ID as below: use wireless barcode scanner to scan the "Setting ID" barcode to display/hide ID of the barcode scanner.


Scanning modes



Troubleshooting

NO.	Problem	Possible Causes	Solution
1	Barcode is damaged or blurred and cannot be read	Poor barcode quality	Improve poor barcode quality by using a new barcode
2	Barcode data is not output	The scanner is not powered on	Check the cable connection between the scanner and the computer
		Barcode is not in the scan area	Aim the scanner at the barcode
		Barcode is not in the scan area	Aim the setup symbol to enable the scanner
3	Laser comes on, but cannot decode	Barcode is too close or too far from the scanner	Move the scanner closer to or farther from the barcode
		Barcode is not in the scan area	Make sure the scan line aim at the barcode
		Barcode is damaged	Change the scan method to Manual Induction
4	Scanned data is incorrect	Wrong scanning mode	Restore the scanner to factory default settings
5	Failed to connect to computer	Wireless receiver is not connected	Connect the wireless receiver
		Out of wireless signal, too far	Move the scanner closer to the wireless receiver
6	Failed to connect to computer	Out of wireless signal, too far	Select the shortest signal of connection
		Wireless receiver is not connected	Reconnect the wireless receiver
		Wireless receiver is damaged	Replace the wireless receiver

Beeper On/Off Settings(Default=On)



Beeper Volume Settings



List of Storage of Wireless Barcode Scanner:

Keeping	Hearing
Power on	Long working (Power on)
Low power beep	Normal working, Voice prompt: Low battery, please charge in time
Power off	Shutdown (Power off)
Pairing success	Pairing success, Voice prompt: Pairing success

Battery Indicator



Simple maintenance methods

1. Stains and dusts on the scanning window can sometimes affect the scanner's performance. Please use soft-purity cloth to gently wipe the scanning window.
2. Please do not touch the lens with fingers. Fingerprints or smears can affect the scanning. Please use a soft cloth to gently wipe the lens.
3. Please do not use corrosive liquid for a long period of time will damage the surface smoothness and affect the appearance.
4. The shell of the scanner may be cleaned with a soft cloth if needed, clean the exterior using a soft cloth with a mild detergent-water solution.

Maintenance

Warranty

1. Our product follows occur under normal operating circumstances, free of charge repair service shall be provided within the warranty, within one year from the date of purchase.
2. The period of warranty shall start from the date of purchase as per the invoice.
3. Customer is requested to present the warranty card and the invoice upon request for repairing service.
4. Our Repair Service Center will be glad to provide services to customers for out-of-warranty products.

Under any of the following circumstances, no free of charge repair service will be provided:

1. The warranty period has expired.
2. The user cannot present the invoice or dated proof of purchase.
3. The user requires a replacement of the product with the excuse that the product appearance looks old after long time use.
4. Machine failure is caused by user in violation of instructions.
5. Machine failure is caused by falling or collision.
6. Machine failure is caused by self-assembling, self-disassembling and self-repair.

7 Commercial samples and goods sold at reduced prices or as-is products that have undergone poor performance overhaul tests.

Note: The information in this document is subject to change without notice.

Special Statement

Many information of this manual has been carefully checked for accuracy, no guarantee is given for the completeness and correctness of the contents. Such information is subject to change without notice. Specifications and contents without further notice. The intellectual property of this manual belongs to our company and no organization or individual is allowed to change the contents.

Precautions

1. Avoid eye or skin exposure to direct laser beams!
2. Do not look into the laser directly or with any optical instruments (e.g. telescopes)!
3. The device must not be modified by yourself, otherwise, laser will emit radiation. Avoid direct eye exposure to the laser beam.
4. Please ask a professional for disassembling, adjusting or repairing!
5. Please keep the product out of reach of children!
6. Please do not throw the battery into fire, cause the product into fire. Stop using if it seems swelling occurs. Do not place it in an area of high temperature.



Warning

—Do not expose the separation between the equipment and the battery to water.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Kein Ersatz der Batterie, Cam die sog/ staubt ft das was sich prüfen sisa cching by chang bit. Chang Sti ist phus au Kraft? Kang ich sen Ausfall Ihrer Batterie, Cam die sog/ staubt ft das was sich prüfen sisa, holte Ihr ist dung sog Kraft? Kang ich sen Ausfall Ihrer Batterie, Cam die sog/ staubt ft das was sich prüfen sisa cching by chang bit. Chang Sti ist phus au